## s112\_nrf52 migration document

## Introduction to the s112\_nrf52 migration document

#### **About the document**

This document describes how to migrate to new versions of the s112\_nrf52 SoftDevices. The s112\_nrf52 release notes should be read in conjunction with this document.

For each version, we have the following sections:

- "Required changes" describes the changes that need to be done in the application when migrating from an older version of the SoftDevice.
- "New functionality" describes how to use new features and functionality offered by this version of the SoftDevice. **Note:** Not all new functionality may be covered; the release notes will contain a full list of new features and functionality.

Each section describes how to migrate to a given version from the previous version. If you are migrating to the current version from the previous version, follow the instructions in that section. To migrate between versions that are more than one version apart, follow the migration steps for all intermediate versions in order.

Example: To migrate from version 5.0.0 to version 5.2.0, first follow the instructions to migrate to version 5.1.0 from version 5.0.0, then follow the instructions to migrate to version 5.2.0 from version 5.1.0.

Copyright (c) Nordic Semiconductor ASA. All rights reserved.

Nordic Semiconductor Page 1 of 10

## s112 nrf52 7.0.1

This section describes how to use the new features of s112\_nrf52\_7.0.1 when migrating from s112\_nrf52\_6.1.1. The s112\_nrf52\_7.0.1 has changed the (Application Programming Interface) API compared to s112\_nrf52\_6.1.1 which requires applications to be recompiled.

#### Required changes

The application can no longer use the option BLE\_COMMON\_OPT\_ADV\_SCHED\_CFG. The advertiser will always use improved scheduling. This was previously defined as ADV\_SCHED\_CFG\_IMPROVED.

The macros NRF\_SOC\_APP\_PPI\_CHANNELS\_SD\_DISABLED\_MSK, NRF\_SOC\_APP\_PPI\_CHANNELS\_SD\_ENABLED\_MSK, NRF\_SOC\_APP\_PPI\_GROUPS\_SD\_DISABLED\_MSK, and NRF\_SOC\_APP\_PPI\_GROUPS\_SD\_ENABLED\_MSK are removed. The application can use the macros NRF\_SOC\_SD\_PPI\_CHANNELS\_SD\_ENABLED\_MSK and NRF\_SOC\_SD\_PPI\_GROUPS\_SD\_ENABLED\_MSK to deduce the PPI channels and groups available to the application.

#### **New functionality**

# Configurable inclusion of Central Address Resolution (CAR) characteristic and Peripheral Preferred Connection Parameters (PPCP)

#### **API Updates**

- BLE\_GAP\_CFG\_CAR\_INCL\_CONFIG. This allows the application to include or exclude the CAR characteristic from the GAP Service.
- BLE GAP CFG PPCP INCL CONFIG. This allows the application to include or exclude the PPCP characteristic from the GAP Service.

For the above inclusion configuration APIs, the application can use:

- BLE GAP CHAR INCL CONFIG INCLUDE: The characteristic is included.
- BLE\_GAP\_CHAR\_INCL\_CONFIG\_EXCLUDE\_WITH\_SPACE: The characteristic is excluded, but the SoftDevice will reserve the attribute handles which are otherwise used for this characteristic.
- BLE GAP CHAR INCL CONFIG EXCLUDE WITHOUT SPACE: The characteristic is excluded.

#### Usage

The code snippet below illustrates how to configure the SoftDevice to exclude both CAR and PPCP from the GAP Service.

Nordic Semiconductor Page 2 of 10

```
int main(void)
{
  ble_cfg_t cfg;

/* Exclude CAR from GAP service, but reserve the ATT Handles that will otherwise be used up by CAR. */
  cfg.gap_cfg.car_include_cfg = BLE_GAP_CHAR_INCL_CONFIG_EXCLUDE_WITH_SPACE;
  sd_ble_cfg_set(BLE_GAP_CFG_CAR_INCL_CONFIG, &cfg, ...);

/* Exclude PPCP from GAP service, but reserve the ATT Handles that will otherwise be used up by PPCP. */
  cfg.gap_cfg.ppcp_include_cfg= BLE_GAP_CHAR_INCL_CONFIG_EXCLUDE_WITH_SPACE;
  sd_ble_cfg_set(BLE_GAP_CFG_PPCP_INCL_CONFIG, &cfg, ...);

/* Enable the BLE Stack. */
  sd_ble_enable(...);

[...]
}
```

### Other additions to the API

• sd\_ble\_gap\_next\_conn\_evt\_counter\_get(). This API can be used to retrieve the next connection event counter.

Nordic Semiconductor Page 3 of 10

## s112\_nrf52\_6.1.0

This section describes how to use the new features of s112\_nrf52\_6.1.0 when migrating from s112\_nrf52\_6.0.0. As with all minor releases, the s112\_nrf52\_6.1.0 is binary compatible with s112\_nrf52\_6.0.0. Hence existing applications running on s112\_nrf52\_6.0.0 need not be recompiled unless the new features are needed.

## **New functionality**

#### API for removing a Vendor Specific base UUID

Using sd\_ble\_uuid\_vs\_remove(), the application can now remove a Vendor Specific base UUID that has been added with sd\_ble\_uuid\_vs\_add(). This allows the application to reuse memory allocated for Vendor Specific base UUIDs. The application must provide a pointer to the UUID type to be removed as an input parameter to sd\_ble\_uuid\_vs\_remove(). The UUID type must not be in use by the ATT Server. A limitation with the current implementation is that the input parameter can only point to BLE\_UUID\_TYPE\_UNKNOWN or the last added UUID type.

#### API to enable or disable extended RC calibration

Extended RC calibration is a new SoftDevice feature that performs additional RC oscillator drift detection and calibration when the SoftDevice is acting as a peripheral and the RC oscillator is used as the SoftDevice clock source. The extended RC calibration is performed in addition to the periodic calibration which is configured when calling sd\_softdevice\_enable(). If using only peripheral connections, the periodic calibration can then be configured with a much longer interval because the peripheral can detect and adjust automatically to clock drift and calibrate when required.

The extended RC calibration is enabled by default. The option BLE\_COMMON\_OPT\_EXTENDED\_RC\_CAL is added to the BLE option API, allowing the application to enable or disable this feature. When using this API, set ble common opt t::extended rc cal::enable to '1' to enable, or to '0' to disable.

## API to get the advertiser Bluetooth device address

A new API sd\_ble\_gap\_adv\_addr\_get() enables the application to get the local Bluetooth device address that is used by the advertiser. The application must provide the advertising handle of the advertiser for the adv\_handle input parameter, and a pointer to an address structure p\_addr to be used as the output parameter. The function may only be called when advertising is enabled.

Note: If privacy is enabled, the SoftDevice will generate a new private address every ble\_gap\_privacy\_params\_t::private\_addr\_cycle\_s, which is configured when calling sd\_ble\_gap\_privacy\_se t(). Depending on when sd\_ble\_gap\_adv\_addr\_get() is called, the returned address may not be the address that is currently used by the advertiser.

#### Hardware resource usage API

Nordic Semiconductor Page 4 of 10

The API now contains new macros to inform the application about the hardware resources used by the SoftDevice.

- The macro NRF NVIC SD IRO PRIOS indicates the interrupt priority levels used by the SoftDevice.
- The macro \_\_NRF\_NVIC\_APP\_IRQ\_PRIOS indicates the interrupt priority levels available to the application.
- The macros NRF\_SOC\_SD\_PPI\_CHANNELS\_SD\_ENABLED\_MSK and NRF\_SOC\_SD\_PPI\_CHANNELS\_SD\_DISABLED\_MSK can be used to identify the PPI channels reserved by the SoftDevice when the SoftDevice is enabled or disabled respectively.
- The macros NRF\_SOC\_APP\_PPI\_CHANNELS\_SD\_ENABLED\_MSK and NRF\_SOC\_APP\_PPI\_CHANNELS\_SD\_DISABLED\_MSK can be used to identify the PPI channels available to the application when the SoftDevice is enabled or disabled respectively.
- The macros NRF\_SOC\_SD\_PPI\_GROUPS\_SD\_ENABLED\_MSK and NRF\_SOC\_SD\_PPI\_GROUPS\_SD\_DISABLED\_MSK can be used to identify the PPI groups reserved by the SoftDevice when the SoftDevice is enabled or disabled respectively.
- The macros NRF\_SOC\_APP\_PPI\_GROUPS\_SD\_ENABLED\_MSK and NRF\_SOC\_APP\_PPI\_GROUPS\_SD\_DISABLED\_MSK can be used to identify the PPI groups available to the application when the SoftDevice is enabled or disabled respectively.

#### Other additions to the API

- The macro SD VARIANT ID indicates the SoftDevice variant.
- The macro SD\_FLASH\_SIZE indicates the amount of flash memory used by the SoftDevice.

#### s112 nrf52 6.0.0

This section describes how to migrate to s112 nrf52 6.0.0 from s132 nrf52 5.1.0 (which is API compatible with s112 nrf52810 5.1.0).

#### Notes:

- s112\_nrf52\_6.0.0 has changed the API compared to s132\_nrf52\_5.1.0 which requires applications to be recompiled.
- s112 nrf52 6.0.0 includes some features that are not Bluetooth qualified. For more information, see the release notes.

#### **New functionality**

#### Write to SoftDevice protected registers

A new API, sd\_protected\_register\_write(), has been added to give the application the possibility to write to a register that is write-protected by the SoftDevice. A write-protected peripheral shall only be accessed through the SoftDevice API when the SoftDevice is enabled.

The new API supports writing to the Block Protection (BPROT) peripheral. The application can use sd\_protected\_register\_write() instead of sd\_flash\_protect() to set the flash protection configuration registers.

Nordic Semiconductor Page 5 of 10

#### Usage

```
/* Old API: */
errcode = sd_flash_protect(value0, value1, value2, value3)

/* New API: */
errcode = sd_protected_register_write(&(NRF_BPROT->CONFIG0), value0)
errcode = sd_protected_register_write(&(NRF_BPROT->CONFIG1), value1)
errcode = sd_protected_register_write(&(NRF_BPROT->CONFIG2), value2)
errcode = sd_protected_register_write(&(NRF_BPROT->CONFIG3), value3)
```

## **Required changes**

#### **Updated advertiser API**

sd\_ble\_gap\_adv\_data\_set() has been removed.

A new API, sd\_ble\_gap\_adv\_set\_configure(), has been added with the following functionalities:

- Configuring and updating the advertising parameters of an advertising set.
- Setting, clearing, or updating advertising and scan response data.

Note: The advertising data must be kept alive in memory until advertising is terminated. Not doing so will lead to undefined behavior. Note: Updating advertising data while advertising can only be done by providing new advertising data buffers.

#### Configuring and updating an advertising set

Advertising Set is a term introduced in Bluetooth Core Specification v5.0.

Each advertising set is identified by an advertising handle. To configure a new advertising set and obtain a new advertising handle, sd\_ble\_gap\_adv\_set\_configure() should be called with a pointer p\_adv \_handle pointing to an advertising handle set to BLE\_GAP\_ADV\_SET\_HANDLE\_NOT\_SET.

To update an existing advertising set, sd\_ble\_gap\_adv\_set\_configure() should be called with a previously configured advertising handle.

Note: Currently only one advertising set can be configured in the SoftDevice.

Nordic Semiconductor Page 6 of 10

#### Configuring advertising parameters for an advertising set

Setting advertising parameters has been moved from sd ble gap adv start() to sd ble gap adv set configure().

The content of ble\_gap\_adv\_params\_t has changed:

- ble\_gap\_adv\_params\_t::type has been removed.
- A new parameter, properties, of the new type ble\_gap\_adv\_properties\_t has been added.
  - The advertising type must now be set through ble\_gap\_adv\_properties\_t::type.
  - The advertising type definitions (BLE\_GAP\_ADV\_TYPES) have changed, and new types have been added.

The mapping from old to new advertising types is shown below. These advertising types are referred to as *legacy* advertising types:

- type = BLE\_GAP\_ADV\_TYPE\_ADV\_IND -> properties.type = BLE\_GAP\_ADV\_TYPE\_CONNECTABLE\_SCANNABLE\_UNDIRECTED
   type = BLE\_GAP\_ADV\_TYPE\_ADV\_DIRECT\_IND -> properties.type = BLE\_GAP\_ADV\_TYPE\_CONNECTABLE\_NONSCANNABLE\_DIRECTED\_HIGH\_DUTY\_CYCLE or BLE\_GAP\_ADV\_TYPE\_DIRECTED\_HIGH\_DUTY\_CYCLE or BLE\_GAP\_ADV\_TYPE\_DIRECTED\_HIGH\_DUTY\_CYCLE or BLE\_GAP\_DIRECTED\_HIGH\_DUTY\_CYCLE or BLE\_GAP\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_DIRECTED\_HIGH\_DUTY\_CYCLE OR BLE\_DIRECTED\_HIGH\_DUTY\_DIRECTED\_HIGH\_DUTY\_DIRE
- type = BLE\_GAP\_ADV\_TYPE\_ADV\_SCAN\_IND -> properties.type = BLE\_GAP\_ADV\_TYPE\_NONCONNECTABLE\_SCANNABLE\_UNDIRECTED
- type = BLE\_GAP\_ADV\_TYPE\_ADV\_NONCONN\_IND -> properties.type = BLE\_GAP\_ADV\_TYPE\_NONCONNECTABLE\_NONSCANNABLE\_UNDIRECTED
- ble\_gap\_adv\_params\_t::fp has been renamed ble\_gap\_adv\_params\_t::filter\_policy.
- ble\_gap\_adv\_params\_t::timeout has been renamed ble\_gap\_adv\_params\_t::duration and is now measured in 10 ms units.
- ble\_gap\_adv\_params\_t::channel\_mask type has been changed from ble\_gap\_adv\_ch\_mask\_t to the new type ble\_gap\_ch\_mask\_t.
  - Note: At least one of the primary channels that is channel index 37-39 must be set to 0.
  - Note: Masking away secondary channels is currently not supported.
  - The mapping from old type ble gap adv ch mask t to the new type ble gap ch mask t is shown below:

    - channel\_mask.ch\_38\_off = 1 -> channel\_mask = 0x4000000000
    - channel\_mask.ch\_39\_off = 1 -> channel\_mask = 0x8000000000
- ble gap adv params t has several new parameters:
  - max adv evts has been added to allow the application to advertise for a given number of advertising events.
  - scan\_req\_notification flag has been added to give the application the possibility to receive events of type ble\_gap\_evt\_scan\_req\_report\_t. This replaces BLE\_GAP\_OPT\_SCAN\_REQ\_REPORT.
  - primary\_phy and secondary\_phy allow the application to select PHYs for primary and secondary advertising channels.
    - primary\_phy should be set to BLE\_GAP\_PHY\_AUTO or BLE\_GAP\_PHY\_1MBPS for legacy advertising types. For extended advertising types, it should be set to BLE\_GAP\_PHY\_1MBPS or BLE\_GAP\_PHY\_CODED if supported by the SoftDevice.
    - secondary\_phy can be ignored for legacy advertising. For extended advertising types, it should be set to BLE\_GAP\_PHY\_1MBPS, BLE\_GAP\_PHY\_2MBPS, or BLE\_GAP\_PHY\_CODED if supported by the SoftDevice.
  - set id has been added to allow the application to choose the set ID of an extended advertiser.

#### Other Advertising API changes

- BLE GAP TIMEOUT SRC ADVERTISING has been removed.
  - A new event, BLE\_GAP\_EVT\_ADVERTISING\_SET\_TERMINATED with structure ble\_gap\_evt\_adv\_set\_terminated\_t, has been introduced to let the application know when and why an advertising set has terminated.
- A new configuration parameter, ble\_gap\_cfg\_role\_count\_t::adv\_set\_count, has been introduced to set the maximum number of advertising sets.

  Note: The maximum number of supported advertising sets is BLE\_GAP\_ADV\_SET\_COUNT\_MAX.
- BLE GAP ADV MAX SIZE has been replaced with BLE GAP ADV SET DATA SIZE MAX.

Nordic Semiconductor Page 7 of 10

- ble\_gap\_evt\_connected\_t now includes adv\_handle and adv\_data of the new type ble\_gap\_adv\_data\_t. These are set when the device connects as a peripheral.
- ble\_gap\_evt\_scan\_req\_report\_t now includes adv\_handle.
- BLE GAP OPT SCAN REO REPORT has been removed.
- BLE\_GAP\_ADV\_TIMEOUT\_LIMITED\_MAX has been changed from 180 to 18000 as sd\_ble\_gap\_adv\_params\_t::duration is now measured in 10 ms units.

#### Usage

```
static uint8 t raw adv data buffer1[BLE GAP ADV SET DATA SIZE MAX];
static uint8 t raw scan rsp data buffer1[BLE GAP ADV SET DATA SIZE MAX];
static ble_gap_adv_data_t adv_data1 = {.adv_data.p_data = raw_adv_data_buffer1,
                                                                                          .adv data.len
sizeof(raw adv data buffer1),
                                       .scan rsp data.p data = raw scan rsp data buffer1, .scan rsp data.len =
sizeof(raw_scan_rsp_data_buffer1)};
/* A second advertising data buffer for later updating advertising data while advertising */
static uint8 t raw adv data buffer2[BLE GAP ADV SET DATA SIZE MAX];
static uint8 t raw scan rsp data buffer2[BLE GAP ADV SET DATA SIZE MAX];
static ble gap adv data t adv data2 = {.adv data.p data = raw adv data buffer2,
                                                                                          .adv data.len
sizeof(raw adv data buffer2),
                                       .scan rsp data.p data = raw scan rsp data buffer2, .scan rsp data.len =
sizeof(raw_scan_rsp_data_buffer2)};
int main(void)
 uint8 t adv handle = BLE GAP ADV SET HANDLE NOT SET;
 ble_gap_adv_params_t adv_params = {.properties={.type=BLE_GAP_ADV_TYPE_CONNECTABLE SCANNABLE UNDIRECTED}},
                                     .interval
                                                            = BLE GAP ADV INTERVAL MAX,
                                     .duration
                                                           = BLE GAP ADV TIMEOUT LIMITED MAX,
                                                            = {0}, /* Advertising on all the primary channels */
                                     .channel mask
                                     .max adv evts
                                                           = 0,
                                     .filter policy
                                                           = BLE GAP ADV FP ANY,
                                     .primary_phy
                                                           = BLE GAP PHY AUTO,
```

Nordic Semiconductor Page 8 of 10

```
.scan_req_notification = 1
};

/* Enable the BLE Stack */
sd_ble_enable(...);

[....]
sd_ble_gap_adv_set_configure(&adv_handle, &adv_datal, &adv_params);

/* Start advertising */
sd_ble_gap_adv_start(adv_handle, BLE_CONN_CFG_TAG_DEFAULT);

[....]
/* Update advertising data while advertising */
sd_ble_gap_adv_set_configure(&adv_handle, &adv_data2, NULL);

[....]
/* Stop advertising */
sd_ble_gap_adv_stop(adv_handle);

[....]
}
```

#### **Updated RSSI API**

The RSSI API has been changed so that the SoftDevice can provide the application with the channel index on which the reported RSSI measurements are made.

- sd\_ble\_gap\_rssi\_get() takes an additional parameter p\_ch\_index. For this parameter, provide a pointer to a location where the channel index for the RSSI measurement should be stored.
- The event structure for the BLE\_GAP\_EVT\_RSSI\_CHANGED event has a new parameter ble\_gap\_evt\_rssi\_changed\_t::ch\_index. This is the Data Channel Index (0-36) on which the RSSI is measured
- The event structure for the BLE\_GAP\_EVT\_ADV\_REPORT event has a new parameter ble\_gap\_evt\_adv\_report\_t::ch\_index. This is the Channel Index (0-39) on which the last advertising packet is received. The corresponding measured RSSI for this packet can be read from ble\_gap\_evt\_adv\_report\_t::rssi.

#### **TX power API**

Nordic Semiconductor Page 9 of 10

The TX power API now supports setting individual transmit power for each link or role.

• sd\_ble\_gap\_tx\_power\_set() takes two new parameters, role and handle, in addition to tx\_power. For available roles and TX power values, see ble\_gap.h.

## **Updated Flash API**

sd\_flash\_write() now triggers a HardFault if the application tries to write to a protected page. NRF\_ERROR\_FORBIDDEN is returned if the application tries to write to a page outside application flash area.

sd\_flash\_page\_erase() now triggers a HardFault if the application tries to erase a protected page. NRF\_ERROR\_FORBIDDEN is returned if the application tries to erase a page outside application flash area.

Nordic Semiconductor Page 10 of 10