Thermodynamics: An Engineering Approach 8th Edition

Yunus A. Çengel, Michael A. Boles McGraw-Hill, 2015

CHAPTER 6 THE SECOND LAW OF THERMODYNAMICS

Objectives

- Introduce the second law of thermodynamics.
- Identify valid processes as those that satisfy both the first and second laws of thermodynamics.
- Discuss thermal energy reservoirs, reversible and irreversible processes, heat engines, refrigerators, and heat pumps.
- Describe the Kelvin–Planck and Clausius statements of the second law of thermodynamics.
- Discuss the concepts of perpetual-motion machines.
- Apply the second law of thermodynamics to cycles and cyclic devices.
- Apply the second law to develop the absolute thermodynamic temperature scale.
- Describe the Carnot cycle.
- Examine the Carnot principles, idealized Carnot heat engines, refrigerators, and heat pumps.
- Determine the expressions for the thermal efficiencies and coefficients of performance for reversible heat engines, heat pumps, and refrigerators.

INTRODUCTION TO THE SECOND LAW



FIGURE 6-1

A cup of hot coffee does not get hotter in a cooler room.

These processes cannot occur even though they are not in violation of the first law.




FIGURE 6-2

Transferring heat to a wire will not generate electricity.




FIGURE 6-3

Transferring heat to a paddle wheel will not cause it to rotate.

MAJOR USES OF THE SECOND LAW

- The second law may be used to identify the direction of processes.
- 2. The second law also asserts that energy has *quality* as well as quantity. The first law is concerned with the quantity of energy and the transformations of energy from one form to another with no regard to its quality. The second law provides the necessary means to determine the quality as well as the degree of degradation of energy during a process.
- 3. The second law of thermodynamics is also used in determining the *theoretical limits* for the performance of commonly used engineering systems, such as heat engines and refrigerators, as well as predicting the *degree of completion* of chemical reactions.



FIGURE 6-4

Processes occur in a certain direction, and not in the reverse direction.






FIGURE 6-5

A process must satisfy both the first and second laws of thermodynamics to proceed.


THERMAL ENERGY RESERVOIRS





- A hypothetical body with a relatively large thermal energy capacity (mass x specific heat) that can supply or absorb finite amounts of heat without undergoing any change in temperature is called a thermal energy reservoir, or just a reservoir.
- In practice, large bodies of water such as oceans, lakes, and rivers as well as the atmospheric air can be modeled accurately as thermal energy reservoirs because of their large thermal energy storage capabilities or thermal masses. 5

HEAT ENGINES



HEAT ENGINES: The devices that convert heat to work.

- 1. They receive heat from a high-temperature source (solar energy, oil furnace, nuclear reactor, etc.).
- They convert part of this heat to work (usually in the form of a rotating shaft.)
- 3. They reject the remaining waste heat to a low-temperature sink (the atmosphere, rivers, etc.).
- 4. They operate on a cycle.

Heat engines and other cyclic devices usually involve a fluid to and from which heat is transferred while undergoing a cycle. This fluid is called the working fluid.

FIGURE 6-9

Part of the heat received by a heat engine is converted to work, while the rest is rejected to a sink.





FIGURE 6-8

Work can always be converted to heat directly and completely, but the reverse is not true.



A steam power plant




FIGURE 6-11

A portion of the work output of a heat engine is consumed internally to maintain continuous operation.


$$W_{\text{net,out}} = W_{\text{out}} - W_{\text{in}}$$
 (kJ)

$$W_{\text{net,out}} = Q_{\text{in}} - Q_{\text{out}}$$
 (kJ)

- Q_{in} = amount of heat supplied to steam in boiler from a high-temperature source (furnace)
- Q_{out} = amount of heat rejected from steam in condenser to a low-temperature sink (the atmosphere, a river, etc.)
- W_{out} = amount of work delivered by steam as it expands in turbine
- $W_{\rm in}$ = amount of work required to compress water to boiler pressure

Thermal efficiency

Thermal efficiency =
$$\frac{\text{Net work output}}{\text{Total heat input}}$$



$$oldsymbol{\eta_{ ext{th}}} = rac{W_{ ext{net,out}}}{Q_{ ext{in}}}$$

$$W_{\rm net,out} = Q_{\rm in} - Q_{\rm out}$$

$$\eta_{\rm th} = 1 - \frac{Q_{\rm out}}{Q_{\rm in}}$$

$$W_{\text{net,out}} = Q_H - Q_L$$

$$\eta_{\mathrm{th}} = \frac{W_{\mathrm{net,out}}}{Q_H}$$

$$\eta_{\rm th} = 1 - \frac{Q_L}{Q_H}$$




FIGURE 6-12

Some heat engines perform better than others (convert more of the heat they receive to work).

$$W_{\text{net,out}} = Q_H - Q_L$$

$$\eta_{\mathrm{th}} = rac{W_{\mathrm{net,out}}}{Q_H} \quad \mathrm{or} \quad \eta_{\mathrm{th}} = 1 - rac{Q_L}{Q_H}$$




FIGURE 6-14

Even the most efficient heat engines reject almost one-half of the energy they receive as waste heat.




FIGURE 6-15

A heat-engine cycle cannot be completed without rejecting some heat to a low-temperature sink.


Every heat engine must *waste* some energy by transferring it to a low-temperature reservoir in order to complete the cycle, even under idealized conditions.

Can we save Q_{out} ?

In a steam power plant, the condenser is the device where large quantities of waste heat is rejected to rivers, lakes, or the atmosphere.

Can we not just take the condenser out of the plant and save all that waste energy?

The answer is, unfortunately, a firm *no* for the simple reason that without a heat rejection process in a condenser, the cycle cannot be completed.



Net Power Production of a Heat Engine

$$\dot{W}_{\text{net,out}} = \dot{Q}_H - \dot{Q}_L = (80 - 50) \,\text{MW} = 30 \,\text{MW}$$

$$\eta_{\text{th}} = \frac{\dot{W}_{\text{net,out}}}{\dot{Q}_H} = \frac{30 \text{ MW}}{80 \text{ MW}} = \mathbf{0.375} \text{ (or } 37.5\%)$$

The Second Law of Thermodynamics: Kelvin–Planck Statement

It is impossible for any device that operates on a cycle to receive heat from a single reservoir and produce a net amount of work.

No heat engine can have a thermal efficiency of 100 percent, or as for a power plant to operate, the working fluid must exchange heat with the environment as well as the furnace.

The impossibility of having a 100% efficient heat engine is not due to friction or other dissipative effects. It is a limitation that applies to both the idealized and the actual heat engines.




FIGURE 6-18

A heat engine that violates the Kelvin–Planck statement of the second law.

REFRIGERATORS AND HEAT PUMPS




FIGURE 6-19

Basic components of a refrigeration system and typical operating conditions.

- The transfer of heat from a low-temperature medium to a high-temperature one requires special devices called refrigerators.
- Refrigerators, like heat engines, are cyclic devices.
- The working fluid used in the refrigeration cycle is called a refrigerant.
- The most frequently used refrigeration cycle is the vapor-compression refrigeration cycle.

In a household refrigerator, the freezer compartment where heat is absorbed by the refrigerant serves as the evaporator, and the coils usually behind the refrigerator where heat is dissipated to the kitchen air serve as the condenser.