ByteFrost Development Log - Addressing Modes Proposal (v2)

June 7 - 11, 2025

Overview

In this development log, we shall go over the new addressing modes proposal. We shall first go over the new instructions, their semantics, and example usage, with motivations for the new instructions and how they improve the ISA (with comparisons to how equivalent operations would be done in the current ISA). We shall then discuss any instructions that can be removed or deprecated. Lastly, we shall cover the required hardware changes in terms of updates to control signal assignments and new combinational logic circuits.

ISA Updates

New Instruction Semantics

There are 6 new instructions and 2 instructions with updated semantics; their names and semantics are shown below.

Instruction	Semantics	Example Usage	New or Modified?
JSR	<pre>Push PC to the stack (SP; *SP = PC[H]; SP; *SP = PC[L]), jump to DP (PC = DP)</pre>	JSR	Modified
RTS	Pop return address from the stack (SP++; DHPC = *SP; SP; PC[L] = *SP, PC[H] = DHPC; SP++; SP++;)	RTS	Modified
MAG	Rd = ARSrc[L/H]	MAG R1, %SP[H]	New
LDW	Rd = *(ARSrc + Imm)	LDW R2, 16(%BP)	New
SDW	*(ARSrc + Imm) = Rs	SDW R3, -4(%DP)	New
LDA	ARDest[L/H] = Imm	LDA %DP[L], #0x54	New
MGA	ARDest[L/H] = Rs1	MGA %BP[L], R2	New
MAA	ARDest = ARSrc + Imm	MAA %SP, %SP, #-1	New

JSR Discussion

In the proposal, the JSR instruction's operands and semantics are modified.

JSR's current semantics

In the current ISA, the JSR instruction has one immediate operand (JSR Imm) and the following semantics:

1. Push the low byte of the PC to the stack.

```
1. *SP = PC[L] (Push PC[L] to the stack)
2. SP++
```

2. Set the PC to the target address.

```
1. PC[L] = Imm (Set PC[L] to the low byte of the target address)
```

```
2. PC[H] = DHPC (Set PC[H] to DHPC which should contain the high byte of the target address)
```

This has the following issues:

- 1. JSR doesn't push PC[H] to the stack, meaning it must be done by a prior instruction.
- 2. JSR doesn't allow specifying the high byte of the target address, meaning it must be done by a prior instruction.
- 3. JSR sets PC[L] to an immediate (i.e., function pointers are not possible).
- 4. JSR is implemented for an empty-ascending stack instead of a full-descending stack.

Currently, the CALL :label assembly instruction is implemented in the following way:

- 1. Push PC[H] to the stack.
- 2. Set DHPC to the high byte of the target address.
- 3. JSR low_byte_of_target_address.

```
// 1. Push PC[H] to the stack.
LDR R0, #PC_HI_VALUE (known to assembler at compile time)
PUSH R0

// 2. Set DHPC to the high byte of the target address.
LSP %DHPC, #TARGET_ADDRESS_HI

// 3. JSR
JSR #TARGET_ADDRESS_LO
```

As we can see, the CALL assembly instruction is implemented using 4 ISA instructions and has additional unwanted semantics, such as overwriting R0 (due to the lack of a PUSH Imm ISA instruction).

JSR's new semantics

In the proposal, JSR has the following semantics:

1. Push the PC to the stack.

```
1. SP--
2. *SP = PC[H]
3. SP--
4. *SP = PC[L]
```

2. Jump to the address in DP.

```
1. PC = DP
```

This implementation resolves issues 1, 3, and 4, but doesn't fix issue 2.

- 1. Issue 1: JSR doesn't push PC[H] to the stack, meaning it must be done by a prior instruction.
- **Resolution:** JSR now pushes the entire PC to the stack, including PC[H], so that it doesn't need to be done by a prior instruction.
- 2. **Issue 2:** JSR doesn't allow specifying the high byte of the target address, meaning it must be done by a prior instruction.
- **Worse:** JSR now doesn't allow specifying the high nor low byte of the target address, meaning they must both be set by prior instructions. The target address is always assumed to be in the DP Address Register.
- 3. **Issue 3:** JSR sets PC[L] to an immediate (i.e., function pointers are not possible).
- **Resolution:** JSR sets the PC to DP, a register; hence, the target address may change during runtime (allowing for function pointer semantics).
- 4. **Issue 4:** JSR is implemented for an empty-ascending stack instead of a full-descending stack.
- **Resolution:** JSR is now implemented for a full-descending stack.

Regarding Issue 2: We can observe that JSR now doesn't take any operands for specifying the target address, and assumes that the target address is already loaded into DP. That means that calling an arbitrary address takes 3 instructions (DP[L] = target_address_low, DP[H] = target_address_hi, JSR). This is an improvement over the 4 instruction implementation of CALL and has no other unusual semantics. JSR can be modified to have an additional Immediate or GR operand to specify parts of the address, but the first option restricts the function pointer semantics (issue 3) and the second requires loading the relevant target address byte to a GR. I think that the proposed implementation is a clean way to handle this with a smaller extra instruction cost than the current implementation.

Now, the CALL :label assembly instruction can be implemented as follows:

```
1. Set DP = TARGET_ADDRESS.
2. JSR.
```

```
// 1. Set DP to the target address.
LDA %DP[L], #TARGET_ADDRESS_LOW
LDA %DP[H], #TARGET_ADDRESS_HI

// 2. JSR.
JSR
```

RTS Discussion

In the proposal, the RTS instruction's operands and semantics are modified.

RTS' current semantics

In the current ISA, the RTS instruction has the following semantics:

1. Pop the return address from the stack and load it to the PC.

```
    SP-- (SP now points at ret[L])
    SP-- (SP now points at ret[H])
    DHPC = *SP, PC[H] = DHPC (DHPC is now set to ret[H])
    SP++ (SP now points at ret[L])
    PC[L] = *SP (PC[L] is now set to ret[L])
    SP-- (SP now points at ret[H] (empty byte after end of stack))
```

This has the following issue:

1. RTS is implemented for an empty-ascending stack instead of a full-descending stack.

RTS' new semantics

In the proposal, RTS has the following semantics:

1. Pop the return address from the stack and load it to the PC. (same)

```
    SP++, DHPC = *SP. (SP points at ret[H] and DHPC is set to ret[H])
    SP--, PC[L] = *SP, PC[H] = DHPC. (SP points at ret[L] and PC[L] is set to ret[L] and PC[H] is set to DHPC, which has ret[H])
```

3. SP++, SP++. (SP now points at the byte above ret[H] (new last byte of the stack)) **Note:** DHPC is loaded first since when writing to PC[L], PC[H] reads from DHPC; hence, DHPC must have the correct value (ret[H]) BEFORE PC[L] reads ret[L].

This implementation resolves issue 1.

- 1. **Issue 1:** RTS is implemented for an empty-ascending stack instead of a full-descending stack.
- **Resolution:** RTS is now implemented for a full-descending stack.

MAG Discussion

The proposal introduces the MAG instruction, which has the following semantics:

```
1. Rd = ARSrc[L/H].
```

This instruction provides the following benefits:

- 1. **Issue 1:** In the current ISA, there is no way to write the value of an Address Register high / low byte to a General Purpose Register.
- **Resolution:** This is now possible using the MAG instruction.

LDW Discussion

The proposal introduces the LDW instruction, which has the following semantics:

```
1. Rd = *(ARSrc + Imm).
```

This instruction provides the following benefits:

- 1. **Issue 1:** Handling 16-bit addresses is complex; the current ISA mitigates some of the complexity by setting the high byte of an address in the Special Registers DP[H], SP[H], and DHPC. Then, instructions such as LMA, SMA, LMR, SMR, and Branch Absolute set the bottom byte and perform memory loads / stores / update the PC in one instruction. LMA, SMA, LMR, and SMR can only use the DP to store the address and overwrite the DP[L] byte, however.
- Improvement: Now handling addresses might be slightly simplified, since we can use dedicated Address Registers to hold addresses and avoid updating them when we have spatial (of +127/-128 byte offsets) or temporal locality in accessing memory (specifically in terms of loads / stores). LDW is better than LMA and LMR since it allows using additional Address Registers besides the DP and doesn't overwrite the DP low byte.
 - The spatial locality benefit is the same as for LMA and LMR (256 byte range), but it is now centered around the DP address instead of the page specified by DP[H]. This may be equivalent, better, or worse, depending on the situation. I think this is better for situations that require known offsets from a base address (e.g., accessing struct fields or offsets in a stack frame), since then the offset is the same every time, whereas the offset would change if the struct isn't stored at the beginning of a page (i.e., at some address {DP[H], 00}).

This instruction allows deprecating LMA and LMR.

SDW Discussion

The proposal introduces the SDW instruction, which has the following semantics:

```
1.*(ARSrc + Imm) = Rs.
```

This instruction provides the following benefits:

- 1. **Issue 1:** The current memory store instructions (SMA and SMR) can only use the DP[H] as the high byte of the address, and overwrite DP[L].
- **Improvement:** SDW allows using any ISA-addressable AR as a base address (i.e., PC, DP, SP, or BP), does not overwrite the used AR, and maintains the same amount of spatial locality now centered at the address in the used AR (better for known offsets when the address is arbitrary, such as in struct field accesses).

This instruction allows deprecating SMA and SMR.

LDA Discussion

The proposal introduces the LDA instruction, which has the following semantics:

```
1. ARDest[L/H] = Imm.
```

This instruction provides the following benefits:

- 1. **Issue 1:** The current ISA allows only setting the high byte of some ARs (DHPC, DP[H], and SP[H]) to an immediate. There is no way to set the low byte of an AR to an immediate (except for the unusual semantics of LMA and SMA that set DP[L] to their immediate operand).
- **Resolution:** LDA allows setting any byte of an ISA-addressable AR (DHPC, PC[L], DP[H/L], SP[H/L], and BP[H/L]) to an immediate.

This instruction allows removing LSP.

MGA Discussion

The proposal introduces the MGA instruction, which has the following semantics:

```
1. ARDest[L/H] = Rs1.
```

This instruction provides the following benefits:

- 1. Issue 1: The current ISA does not allow setting any AR byte to the value of a GR.
- **Resolution:** MGA allows setting any byte of an ISA-addressable AR (DHPC, PC[L], DP[H/L], SP[H/L], and BP[H/L]) to a GR.

MAA Discussion

The proposal introduces the MAA instruction, which has the following semantics:

```
1. ARDest = ARSrc + Imm.
```

This instruction provides the following benefits:

- 1. Issue 1: The current ISA does not allow setting an AR to another AR's value.
- Resolution: MAA allows setting any ISA-addressable AR (PC, DP, SP, and BP) to another ISA-addressable AR
 (i.e., with ARDest = ARSrc + 0)
- 2. Issue 2: The current ISA does not provide an easy way for performing 16-bit pointer arithmetic.
- **Resolution:** MAA allows for limited 16-bit pointer arithmetic by allowing adding an immediate offset to an ISA-addressable AR's value (the limit being that the immediate is signed 8-bit (in the range [-128, 127])).
- 2. Issue 2: The current ISA makes implementing an x86-style calling convention very difficult if not impossible. Some of the reasons for this are that an additional AR (BP) is needed, setting SP to BP and vice versa is needed, and accessing the stack from the BP with an offset is needed to access variables (taken care of by LDW and SDW).
- **Resolution:** The proposal introduces the new BP AR and MAA allows for easily setting one AR to another.

Example Code

Here are a few example programs / program snippets.

1. Stack Calling Convention

Let us attempt to implement the following calling convention (copied largely from the 32-bit x86 calling convention, see https://aaronbloomfield.github.io/pdr/book/x86-32bit-ccc-chapter.pdf):

- 1. Caller (Before Callee Runs)
 - 1. Push caller-saved registers (R0 R3).
 - Note: ARs are NOT saved. The SP and BP are always for the current function's stack frame, the PC points at the next instruction, and the DP is overridable; the caller should assume its value is not

preserved after a call to a function.

- 2. Push callee arguments (last in the order first)
- 3. Push return address and jump to callee.
- 2. Callee (Prolog)
 - The caller's return address is at the top of the stack.
 - 1. Push the current BP (save the caller's base pointer).
 - 2. Set the BP to the SP (defines the callee's base pointer).
 - 3. Make space for local variables by decrementing the SP by the total size of the callee's local variables in bytes.
- 3. Callee (Epilog) 0. (Return Value) Set the DP to the address of the return value.
 - 1. Free the stack frame by setting the SP to the BP.
 - 2. Pop the caller's BP from the stack (i.e., set the BP to $\{*(SP + 1), *SP\}$)
 - 3. Pop the return address and return to the caller.
- 4. Caller (After Callee Returns)
 - 1. Pop the callee arguments from the stack.
 - 2. Restore the caller-saved registers (R0 R3).
 - 3. (Return Value) Use return value whose address is in DP.

There's a question of how to pass the return value to the caller; I think a simple approach is to always return a pointer to it in the DP. (This may present complications / not be optimal, however, since the return value may be stored in the callee's stack frame, in which case the caller needs to make a local copy first, which may need to be implemented carefully if the return value is a type that's too large).

Let us attempt to do this for the following C code:

```
uint8_t add(uint8_t x, uint8_t y) {
    uint8_t z = x + y;
    return z;
}
int main() {
    // ...
    uint8_t a = add(3, 5);
    // ...
}
```

This is almost impossible to implement in the current ISA.

Let us attempt to implement it using the new instructions:

```
:main
   // ...
   // uint8_t a = add(3, 5);
   // 1. Push caller-saved registers
   PUSH R0
   PUSH R1
   PUSH R2
   PUSH R3
```

```
// 2. Push callee arguments
   LDR R0, #5
   PUSH R0
             // Push argument for uint8_t y
   LDR R0, #3
   PUSH R0 // Push argument for uint8 t x
   // 3. Push return address and jump to callee.
   LDA %DP[H], TARGET_ADDRESS_HI (:add[H])
   LDA %DP[L], TARGET_ADDRESS_LO (:add[L])
   JSR
   // 4. Pop the callee arguments from the stack
            // Pop argument for uint8 t x
   POP RØ
   POP R0
             // Pop argument for uint8_t y
   // 5.
          Restore the caller-saved registers
   POP R3
   POP R2
   POP R1
   POP R0
   // 6. Use return value (uint8_t a = RV = *DP); assuming that a is in R1
   LDW R1, 0(%DP)
   // ...
:add
   // Prolog
   // 1. Push the current BP. (Save the caller's BP)
   MAG R0, %BP[H] // Push BP[H]
   PUSH R0
   MAG R0, %BP[L] // Push BP[L]
   PUSH R0
   // 2. Set the BP to the SP.
   MAA %BP, %SP, #0
   // 3. Make space for local variables (1 byte for uint8_t z)
   MAA %SP, %SP, ADD LOCAL VARS OFFSET (#-1)
   // z = x + y.
   LDW R0, 4(BP) // R0 = *(BP + 4) = x
   LDW R1, 5(BP) // R1 = *(BP + 5) = y
   ADD R2, R0, R1 // R2 = R0 + R1 = x + y
   SDW R2, -1(BP) // *(BP - 1) = x + y --> z = x + y
   // Epilog
   // 0. (Return Value) Set the DP to the address of the return value.
   MAA %DP, %BP, \#-1 // DP = BP - 1 = &z
   // 1. Free the stack frame by setting the SP to the BP.
   // 2. Pop the caller's BP from the stack
   POP R0
                      // R0 = *SP = callerBP_L0
```

2. Iterating through an array of structs

Let us attempt to implement the following C code using the new proposal's instructions:

```
typedef struct {
   char * playerName;
   uint8_t health;
   uint8_t maxHealth;
   uint8_t isFighting;
} player_t Player;
int main() {
    // Let Player * players point to an array of Player structs of length 125.
   Player * healthiestPlayer = players[∅];
    for (uint8_t i = 1; i < 125; i++) {
        if (players[i]->health > healthiestPlayer->health) {
            healthiestPlayer = &(players[i]);
        }
    }
   return healthiestPlayer->health;
}
```

First, we can observe that the Player struct has size 2 + 1 + 1 + 1 = 5 bytes, with offsets playerName_offset = 0, health_offset = 2, maxHealth_offset = 3, and isFighting_offset = 4.

The assembly code for this could look as follows:

```
:main
   // Prolog
   // 1. Save the caller's BP.
   MAG R0, %BP[H] // Push BP[H]
   PUSH R0
   MAG R0, %BP[L] // Push BP[L]
   PUSH R0
   // 2. Set the BP to the SP.
   MAA %BP, %SP, #0
   // 3. Make space for local variables
   //
           sizeof(players) + sizeof(healthiestPlayer) + sizeof(i) =
               = (125 * 5) + 2 + 1 (+ 2) = 630
   //
   //
           BP --> BP[L]
```

```
//
                players[124][4]
//
                players[124][3]
//
                players[0][0]
//
//
                healthiestPlayer[H]
//
               healthiestPlayer[L]
//
//
               DPTemp[H]
//
                DPTemp[L]
//
        Therefore, SP = SP - 630
LDR R0, #4
             // R0 = 4
:sp_lv_space_for_loop // (SP local variable making space for loop)
    TST R0, #0
                                   // while (R0 > 0)
    BEQ :sp_lv_space_for_loop_end // {
   MAA %SP, %SP, #-128
                                   //
                                           SP = SP - 128;
                                   //
    DEC R0
                                           R0--;
                                  // }
    JMP :sp_lv_space_for_loop
:sp_lv_space_for_loop_end
MAA %SP, %SP, #-118
                                   // SP = SP - 118
// Player * healthiestPlayer = players[0]
MAA %DP, %SP, #5 // DP = &(players[0])
                  // R0 = (&(players[0]))[H]
MAG RØ, %DP[H]
SDW R0, 4(%SP)
MAG R0, %DP[L] // R0 = (&(players[0]))[L] SDW R0, 3(%SP) // *(SP + 1) = healthicates
                  // *(SP + 2) = healthiestPlayer[H] = &(players[0])[H]
                  // *(SP + 1) = healthiestPlayer[L] = &(players[0])[L]
LDR R0, #1
SDW R0, 2(\%SP) // uint8_t i = 1;
:for_loop_1
   TST R0, #125
                           // for (; i < 125; i++)
                           // {
    BEQ :for_loop_1_end
    // if (players[i]->health > healthiestPlayer->health)
    MAA %DP, %DP, #11 // DP = &(players[i - 1]) + sizeof(Player)
    LDW R1, health_offset(%DP) // R1 = player[i]->health
    // Save DP in DPTemp (DPTemp = DP)
   MAG R2, %DP[H]
                     // R2 = DP[H] = &players[i][H]
    SDW R2, 1(%SP)
   MAG R2, %DP[L]
                           // R2 = DP[L] = &players[i][L]
    SDW R2, 0(%SP)
    // DP = healthiestPlayer
    LDW R2, 4(%SP)
                     // R2 = healthiestPlayer[H]
    MGA %DP[H], R2
                          // DP[H] = healthiestPlayer[H]
                          // R2 = healthiestPlayer[L]
    LDW R2, 3(%SP)
    MGA %DP[L], R2
                          // DP[L] = healthiestPlayer[L]
    LDW R2, health offset(%DP) // R2 = healthiestPlayer->health
    // DP = DPTemp (&players[i])
    LDW R3, 1(%SP)
                        // R3 = &players[i][H]
    MGA %DP[H], R3
                           // DP[H] = &players[i][H]
```

```
LDW R3, 0(%SP)
                           // R3 = &players[i][L]
    MGA %DP[L], R3
                           // DP[L] = &players[i][L]
    SUB R2, R2, R1
                           // R2 = healthiestPlayer->health
                           // - player[i]->health
    BPL :after if 1
       // healthiestPlayer = &(players[i]);
        MAG R1, %DP[H] // R1 = &players[i][H]
       SDW R1, 4(%SP)  // healthiestPlayer[H] = &players[i][H]
MAG R1, %DP[L]  // R1 = &players[i][L]
SDW R1, 3(%SP)  // healthiestPlayer[L] = &players[i][L]
    :after_if_1
    // i++
    INC R0
                           // i++
    SDW R0, 2(%SP)
    JMP :for_loop_1
                         // }
:for_loop_1_end
// Epilog
// 0. (Return Value) Set the DP to the address of the return value
// return healthiestPlayer->health;
// Set DP = &(healthiestPlayer->health)
                 // R0 = healthiestPlayer[H]
LDW R0, 4(%SP)
                          // DP[H] = healthiestPlayer[H]
MGA %DP[H], R0
LDW R0, 3(%SP)
                          // R0 = healthiestPlayer[L]
MGA %DP[L], R0
                          // DP[L] = healthiestPlayer[L]
MAA %DP, %DP, health offset // DP = healthiestPlayer + health offset
// 1. Free the stack frame by setting the SP to the BP.
MAA %SP, %BP, #0 // SP = BP + 0 = BP
// 2. Pop the caller's BP from the stack
POP R0
                  // R0 = *SP = callerBP_L0
MGA %BP[L], R0
                  // BP[L] = R0 = callerBP L0
POP RØ
                  // R0 = *SP = callerBP_HI
                  // BP[H] = R0
MGA %BP[H], R0
// 3. Pop the return address and return to the caller.
RTS
```

3. Iterating through doubly linked list

Instruction String Operands Updates

There are 3 new instruction operands in this proposal. They are:

Operand	Size (in bits)	Bit Locations	Semantics
(AR) L/H	1	5	Whether the high or low byte of an AR operand is used (relevant for writing or reading a data word from / to the data bus)

Operand	Size (in bits)	Bit Locations	Semantics
ARSrc	2	Special Case; See Below	Specify which AR to read from
ARDest	2	7:6	Specify which AR to write to

Note: The ARSrc bit location depends on the opcode of the current instruction in the following way:

- 1. If the opcode is of the new MAG instruction, then ARSrc is in bits 9:8.
- 2. Otherwise, ARSrc is in bits $\{5, 0\}$ (where 0 is the lsb of the opcode).
- In both cases, the higher bit is the msb of ARSrc (9 or 5).

New Instruction Operand Values

1. (AR) L/H

Bit 0 (location: 5)	Meaning		
0	Low Byte of an AR		
1	High Byte of an AR		

2. ARSrc and ARDest

Bit 1 (location: ARSrc: 9 or 5; ARDest: 7)	Bit 0 (location: ARSrc: 8 or 0; ARDest: 6)	Meaning
0	0	PC (Note: When ARSrc is PC, then PC is {PC[H], PC[L]}; when ARDest is PC, then PC is {DHPC, PC[L]}!)
0	1	DP
1	0	SP
1	1	ВР

New Instructions

There are 6 new instructions, which require a total of 9 opcodes. They are:

Note: The opcode assignment of the new instructions assumes that the LSP instruction is removed and that none of the deprecated instructions are removed. Different opcode assignments may be required / more optimal if these assumptions are false.

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
MAG	Rd = ARSrc[L/H]	MAG R1, %SP[H]	1	0x1a

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
LDW	Rd = *(ARSrc+ Imm)	LDW R2, 16(%BP)	2	0x14 and 0x15
SDW	*(ARSrc + Imm) = Rs	SDW R3, -4(%DP)	2	0x16 and 0x17
LDA	ARDest[L/H] = Imm	LDA %DP[L], #0x54	1	0x1b
MGA	ARDest[L/H] = Rs1	MGA %BP[L], R2	1	0x1c
MAA	ARDest = ARSrc +	MAA %SP, %SP, #-1	2	0x18 and 0x19

The new instructions have the following instruction strings:

Updated Instructions

There are 4 updated instructions. They are:

Instruction	Current Semantics	New Semantics	Example New Usage	Number of Opcodes	Opcode Assignment
PUSH	*SP = Rs1, SP++	SP, *SP = Rs1	PUSH R2	1	0x0e
POP	SP, Rd = *SP	Rd = *SP, SP++	POP R2	1	0x0f
JSR	*SP = PC[L], SP++, PC[L] = Imm, PC[H] = DHPC		JSR	1	0x10
RTS	<pre>SP -= 2, DHPC = *SP, PC[H] = DHPC, SP++, PC[L] = *SP, SP</pre>	PC[L] = *SP, SP++, DHPC = *SP, PC[H] = DHPC, SP++	RTS	1	0x11

PUSH and POP are updated to support a full-descending stack instead of an empty-increasing one.

JSR and RTS are similarly updated, with JSR updated to push the full PC (return address) to the stack and jump to the address in the DP (allowing for function pointer semantics).

Note: JSR's new implementation requires hardware support to push the PC value to the stack; since AR values are written to the Data Bus via the address bus, this requires having the PC L/H byte on the Data Bus while the SP's value is on the Address Bus. To do this, writing a byte from the Address Bus to the Data Bus must involve writing to a temporary register first, which will hold the value and only write it to the Data Bus in the next cycle.

Removed Instructions

There is 1 instruction that should be removed, which frees up 1 opcode. It is:

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
LSP	<pre>ARDest[H] = Imm (where ARDest != BP)</pre>	LSP %DP, #0x30	1	0x14

The LSP instruction should be removed because it is eclipsed by the proposed LDA instruction, which is a generalization of it.

Deprecated Instructions and Instruction Operands

The following 5 instructions, in their present form, can be marked as deprecated, and eventually removed to free up 5 opcodes.

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
Branch Relative	If the condition bits C2C1C0 match the ALU flag register bits, then PC[L] = PC[L] + Immediate	BEQ +14	1	0x07

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
LMA	Rd = *({DP[H], Imm}), DP[L] = Imm	LMA R2, #0x05	1	0x09
SMA	*({DP[H], Imm}) = Rs, DP[L] = Imm	SMA R3, #0x30	1	0x0a
LMR	Rd = *({DP[H], Rs1}), DP[L] = Rs1	LMR R2,	1	0x0b
SMR	*({DP[H], Rs1}) = Rs, DP[L] = Rs1	SMR R1,	1	0x0c

- 1. Branch Relative (opcode 0x07) may be marked as deprecated since it only updates the low byte of the PC; i.e., it can only branch within an "instruction page" (i.e., the 512 byte region starting with 9 lsbs being 0 and ending with 9 lsbs being 1, with the high 7 bits unchanged). Additionally, the ByteFrost Assembler v2 only uses absolute branches, so this instruction isn't used by any ByteFrost Assembly program assembled with the ByteFrost Assembler v2.
- 2. Instructions LMA, SMA, LMR, and SMR (opcodes 0x09 to 0x0c) may be marked as deprecated since they have unexpected semantics (they overwrite the low byte of the DP address register) and are effectively deprecated by LDW and SDW (with LDA and MGA to set address register bytes with an immediate / GR).

Instructions that could be deprecated in the future

The following 2 instructions can be marked as deprecated in the future once a set of conditions is cleared.

Instruction	Semantics	Example Usage	Number of Opcodes	Opcode Assignment
OUT	Print Rs1 as an ASCII character or hex integer	OUT R2,	1	0x08
OUT Immediate	Print Immediate as an ASCII character of hex integer	OUT #0x54, I	1	0x0d

- 1. OUT and OUT Immediate (opcodes 0x08 and 0x0d, respectively) may eventually be deprecated, along with the instruction operand A/I (Display), when the following condition is cleared:
 - 1. Replace the current display with a display whose interface to the ByteFrost is part of the MMIO section of the address space.
- This will allow for the following benefits:
 - 1. Free 2 opcodes.
 - 2. Allow for a more general display interface, and potentially for a larger display (e.g., hopefully a 600×800 resolution?)

Control Signals Updates

New Control Signals

The proposal introduces 5 new control signals. They are:

Control Signal	Signal ID Assignment	Instructions that use it
loadARHorL	18	?
TmpARRead	19	?
TmpARWrite	20	?
AddressBusToDataBus	21	?
AddressHorL	22	?

Note: *loadARHorL* and *AddressHorL* match up in all the instructions that use them (or can; i.e., one might be set to a particular value and the other may be X; it is never the case that one is 1 and the other is 0 in the same cycle, for instance, and since they're both "guarded" by *loadAR* and *AddressBusToDataBus*, respectively, they're X when not used instead of 0).

Updated Control Signals

The proposal updates (renames) 2 control signals. They are:

Control Signal	Old Name	Signal ID Assignment	Instructions that use it
loadAR	Load Special Register	17	?
SP Out	RAM Address Select	14	?

Removed Control Signals

?

Combinational Logic Updates

Implementing this proposal requires updating 5 of the combinational logic units of the ByteFrost:

- 1. Decode ARSrc Operand
- 2. PC Loading (When PC[L] is loaded, set PC[H] to load from DHPC).
- 3. AR Data Bus Load Enable (Replaces the Load Special Pointer unit)
- 4. ARSelect (Replaces the Address Bus Arbiter)
- 5. AddressByteSelect

1. Decode - ARSrc Operand

Inputs:

- 1. Opcode_MAG (active low signal from opcode decoder)
- 2. INSTR[5]
- 3. INSTR[9:8]


Outputs: ARSrc (2 bits).

Logic:

Truth Table:

Opcode_MAG (active low)	Output (2 bits)
o (active)	INSTR[9:8]
1 (inactive)	{INSTR[5], INSTR[0]}

Implementation Diagram:



2. PC Loading

Remove the PC Ld Hi active low signal, and rename the PC Ld Lo active low signal to PC Ld Branch (the signal generated in the Branch (v2.0) slide 26 in CPU v2).

The PC Ld Branch signal is now sent as an input to the **AR Data Bus Load Enable** unit described in the next section.

The DHPC load enable signal comes from the AR Data Bus Load Enable unit, named DHPC Load Enable.

The PC[L] and PC[H] load enable signals come from the AR Data Bus Load Enable unit, named PC[L] + PC[H] = DHPC Load Enable.

The PC Out control signal is now an input of the **ARSelect** unit described in a further section. The 74HC245 "Read PC Low" tristate IC can be removed, as the PC may only write to the Address Bus (writing the PC to the Data Bus involves first writing the PC to the Address Bus).

Implementation Diagram: TODO

3. AR Data Bus Load Enable

Inputs:

- 1. PC Ld Branch signal
- 2. loadAR control signal

- 3. loadARHorL control signal
- 4. Opcode (INSTR[4:0])
- 5. ARDest instruction operand
- 6. (AR) L/H instruction operand

Outputs: {None (No AR reads from Data Bus), DHPC Load Enable, PC[L] + PC[H] = DHPC Load Enable, DP[H] Load Enable, DP[L] Load Enable, SP[H] Load Enable, SP[L] Load Enable, BP[H] Load Enable, BP[L] Load Enable Enable, BP[L] Load Enable

Note: There are two possible semantics when writing to the PC: Writing to the DHPC and writing to PC[L] in which case PC[L] loads from DHPC. (i.e., DHPC = Data Bus OR PC[L] = Data Bus AND PC[H] = DHPC).

Logic:

- 1. If PC Ld Branch is active (low):
- A Data Bus write to the PC is requested by a branch instruction (Branch Absolute or Branch Relative (deprecated)).
 - 1. Return PC[L] + PC[H] = DHPC Load Enable.
- 2. Else if the *loadAR* control signal is active (high):
- This means that the current instruction being executed is LDA, MGA, MAA, JSR, or RTS.
 - 1. If the PC Load control signal is active (high):
 - A Data Bus write to the PC is requested, but to which byte?
 - The request is made either by JSR or RTS; the byte is specified by the *loadARHorL* control signal.
 - 1. If *loadARHorL* (control signal) is *⊙* (L):
 - 1. Return PC[L] + PC[H] = DHPC Load Enable.
 - 2. Else:
 - 1. Return DHPC Load Enable.
 - 2. Else:
 - The request is made by the LDA, MGA, or MAA instruction, meaning that the particular AR to write to is specified by the ARDest instruction operand. Now we must identify whether the high or low byte is specified.
 - If it's made by MAA (i.e., by an instruction that involves writing to both bytes of an AR), then the byte MUST be specified by the *loadARHorL* control signal.
 - Otherwise, the byte is specified by the (AR) L/H instruction operand.

1. Return {ARDest} {(AR) L/H instruction operand} Load Enable.

3. Else:

1. Return None.

Truth Table:

1. Decoder Enable (active low)

PC Load Branch (active low)	loadAR	Decoder Enable (active low)
	X	0 (active)

PC Load Branch (active low)	loadAR	Decoder Enable (active low)
1 (inactive)	1	0 (active)
1 (inactive)	0	1 (inactive)

This truth table can be represented as the following boolean equation:

```
Decoder Enable (active low) = (PC Load Branch) AND (!loadAR).
```

2. Target AR (PC (PC[L] + PC[H] = DHPC or DHPC), DP, SP, or BP)

PC Load Branch (active low)	loadAR	PC Load	Target AR
o (active)	X	X	PC
1 (inactive)	1	0	ARDest
1 (inactive)	1	1	PC
1 (inactive)	0	X	None (X since decoder enable disabled)

This can be represented with the outputs being the 2 msbs of the 3-8 decoder address input:

PC Load Branch (active low)	loadAR	PC Load	Address Bit 2	Address Bit 1
0 (active)	X	X	0	0
1 (inactive)	1	0	ARDest[1]	ARDest[0]
1 (inactive)	1	1	0	0
1 (inactive)	0	X	X	X

This truth table can be represented as the following boolean equations:

```
Address Bit 2 = (PC Load Branch) AND !((loadAR)(PC Load)) AND ARDest[1]
Address Bit 1 = (PC Load Branch) AND !((loadAR)(PC Load)) AND ARDest[0]
```


3. Target AR Byte (high / low)

PC Load Branch (active low)	loadAR	PC Load	Opcode_MAA (active low)	Target AR Byte
o (active)	X	X	X	0 (L)
1 (inactive)	1	1	Х	loadARHorL
1 (inactive)	1	0	0	loadARHorL
1 (inactive)	1	0	1	(AR) L/H operand

PC Load Branch (active low)	loadAR	PC Load	Opcode_MAA (active low)	Target AR Byte
1 (inactive)	0	X	X	X since decoder enable disabled

This truth table can be represented as the following boolean equation:

Implementation Diagram:



4. ARSelect

Inputs:

- 1. SP Out (control signal)
- 2. TmpARWrite (control signal)
- 3. PC Out (control signal)
- 4. Bus Grant signal
- 5. FetchCycle signal
- 6. Opcode (INSTR[4:0]),
- 7. ARSrc instruction operand

Outputs: {None (Address Bus floats), PC Output Enable, DP Output Enable, SP Output Enable, BP Output Enable, TmpAR Output Enable}

Logic:

- 1. If the Bus Grant signal is active:
 - 1. Return None.
- 2. Else if the FetchCycle signal is active OR *PC Out* is active:
 - 1. Return PC Output Enable.
- 3. Else if the SP Out control signal is active:
 - 1. Return SP Output Enable.
- 4. Else if the *TmpARWrite* control signal is active:
 - 1. Return TmpAR Output Enable.

- 5. Else if the instruction has an ARSnc instruction operand:
 - This means that the instruction has the opcode of any of the following instructions: (MAG, LDW, SDW, MAA)
 - 1. Return ARSrc Output Enable.
- 6. Else:
 - Default behavior: write DP to the bus.
 - 1. Return DP Output Enable.

Truth Table:

Bus Grant	FetchCycle	PC Out	SP Out	TmpARWrite	Opcode_MAG_LDW_SDW_MAA (active low)	ARSelect
1	Χ	X	X	Χ	X	None
0	1	X	X	X	X	PC Output Enable
0	0	1	Х	X	Х	PC Output Enable
0	0	0	1	X	Х	SP Output Enable
0	0	0	0	1	Х	TmpAR Output Enable
0	0	0	0	0	0	ARSrc Output Enable
0	0	0	0	0	1	DP Output Enable

1. Decoder Enable (Active Low)


Decoder Enable (active low) = Bus Grant

2. Address Bits (2:0)

FetchCycle	PC Out	SP Out	TmpARWrite	Opcode_MAG_LDW_SDW_MAA (active low)	Address Bit 2	Address Bit 1	Address Bit 0
1	X	X	X	X	0	0	0
0	1	X	X	X	0	0	0
0	0	1	X	X	0	1	0
0	0	0	1	X	1	0	0
0	0	0	0	0	0	ARSrc[1]	ARSrc[0]
0	0	0	0	1	0	0	1

This truth table can be represented as the following boolean equations:

Implementation Diagram:



Note: that this can be improved further (removing some NOT gates).

5. AddressByteSelect

Inputs:

- 1. AddressHorL (control signal)
- 2. (AR) L/H instruction operand
- 3. Opcode (INSTR[4:0])

Outputs: {Address Bus High Register, Address Bus Low Register}


Logic:

- 1. If Opcode == MAA_OPCODE OR Opcode == JSR_OPCODE:
 - 1. If AddressHorL is active (High):
 - 1. Return Address Bus High Register.
 - 2. Else:
 - 1. Return Address Bus Low Register.
- 2. Else:
 - 1. Return Address Bus {(AR) L/H instruction operand} Register.

Truth Table:

Opcode_MAA_JSR (active low)	AddressByteSelect
0	AddressHorL
1	(AR) L/H instruction operand

Implementation Diagram:



Updated Instruction Microcode

The microcode of 10 instructions will need to be updated to implement this proposal. The instructions and their new microcode follows:

Note: In the last microinstruction of every instruction, the *PC Advance* control signal is set so that the Fetch State Machine will fetch the next instruction in the next cycle. As a result of *PC Advance* being active, the *FetchCycle* signal is high, meaning that the AR Select unit will set the *PC* to write to the Address Bus. As a result, in the last microinstruction of any instruction, no AR beside the *PC* may write to the Address Bus (this may cause some instructions to require an additional cycle just to fetch the next instruction).

Control Signal List:

Bit	Control Signal
23	Not Used.
22	AddressHorL
21	AddressBusToDataBus
20	TmpARWrite
19	TmpARRead
18	loadARHorL
17	loadAR

Bit Control Signal

DIT	Control Signal
16	Stack Pointer Increment / Decrement
15	Stack Pointer Count
14	SP Out
13	Use Rd as Source
12	Lower Address Register Load
11	Mem Write
10	Mem Read
9	PC Out
8	PC Load
7	PC Advance
6	Program Register H Write to Bus
5	Register File Input Enable
4	Register File Output Enable
3	Register File Output Select
2	ALU output enable
1	ALU load register A
0	ALU load register B

MAG Instruction Microcode

MAG Semantics: Rd = ARSrc[L/H]

Cycle	23:20	19:16	15:12	11:8	7:4	3:0	Result
1	0	0	0	0	0	0	0x00_00_00
2	2	0	0	0	a	0	0x20_00_a0

- 1. Cycle 1.
 - 1. Write ARSrc to the Address Bus.
 - 1. **ARSelect** = ARSrc.
 - Guaranteed behavior since Bus Grant is 0, FetchCycle is 0, SP Out is 0, TmpARWrite is 0, and opcode is of the MAG instruction.
- 2. Cycle 2.
 - 1. Write Address Bus L/H Register to the Data Bus.
 - 1. **AddressByteSelect** = (AR) L/H instruction operand.
 - Guaranteed behavior since the instruction isn't MAA.
 - 2. AddressBusToDataBus = 1.
 - 2. Set Rd to read from the Data Bus.

```
1. Register File Input Enable = 1.
          3. Advance PC.
                 1. PC Advance = 1.
LDW Instruction Microcode
LDW Semantics: Rd = *(ARSrc + Imm)
    1. Cycle 1.
          1. Write Imm to the Data Bus.
                 1. Program Register H Write to Bus = 1.
          2. Write ARSrc to the Address Bus.
                 1. ARSelect = ARSrc.

    Guaranteed behavior since opcode is of the LDW instruction.

          3. Set TmpAR to read (from the 16-bit adder).
                 1. TmpARRead = 1.
    2. Cycle 2.
          1. Write TmpAR to the Address Bus.
                 1. ARSelect = TmpAR.
                       1. TmpARWrite = 1.
          2. Write Memory data word to the Data Bus.
                 1. Mem Read = 1.
          3. Set Rd to read from the Data Bus.
                 1. Register File Input Enable = 1.
    3. Cycle 3.
          1. Advance PC.
                 1. PC Advance = 1.
SDW Instruction Microcode
SDW Semantics: *(ARSrc + Imm) = Rs (Rd as source)
    1. Cycle 1.
          1. Write Imm to the Data Bus.
                 1. Program Register H Write to Bus = 1.
          2. Write ARSrc to the Address Bus.
                 1. ARSelect = ARSrc.

    Guaranteed behavior since opcode is of the SDW instruction.

          3. Set TmpAR to read.
                 1. TmpARRead = 1.
    2. Cycle 2.
           1. Write TmpAR to the Address Bus.
                 1. ARSelect = TmpAR.
                       1. TmpARWrite = 1.
          2. Write Rs (Rd) to the Data Bus.
                 1. Register File Output Enable = 1.
                 2. Use Rd as a Source = 1.
          3. Set Memory to read from the Data Bus.
                 1. Mem Write = 1.
```

```
3. Cycle 3.
          1. Advance PC.
                1. PC Advance = 1.
LDA Instruction Microcode
LDA Semantics: ARDest[L/H] = Imm.
    1. Cycle 1.
          1. Write Imm to the Data Bus.
                1. Program Register H Write to Bus = 1.
          2. Set ARDest[L/H] to read from the Data Bus.
                1. AR Data Bus Load Enable = ARDest[(AR) L/H operand].
                       1. loadAR = 1.
          3. Advance PC.
                1. PC Advance = 1.
MGA Instruction Microcode
MGA Semantics: ARDest[L/H] = Rs1.
    1. Cycle 1.
          1. Write Rs1 to the Data Bus.
                1. Register File Output Enable = 1.
                2. Register File Output Select = ∅ (Rs1).
          2. Set ARDest[L/H] to read from the Data Bus.
                1. AR Data Bus Load Enable = ARDest[(AR) L/H operand].
                       1. loadAR = 1.
          3. Advance PC.
                1. PC Advance = 1.
MAA Instruction Microcode
MAA Semantics: ARDest = ARSrc + Imm.
    1. Cycle 1.
          1. Write Imm to the Data Bus.
                1. Program Register H Write to Bus = 1.
          2. Write ARSrc to the Address Bus.
                1. ARSelect = ARSrc.

    Guaranteed behavior since opcode is of the MAA instruction.

          3. Set TmpAR to read.
                1. TmpARRead = 1.
    2. Cycle 2.
          1. Write TmpAR to the Address Bus.
                1. ARSelect = TmpAR.
                       1. TmpARWrite = 1.
    3. Cycle 3.
          1. Write TmpAR to the Address Bus.
                1. ARSelect = TmpAR.
```

```
1. TmpARWrite = 1.
          2. Write Address Bus Low register to the Data Bus.
                 1. AddressByteSelect = L (∅).
                       1. AddressHorL = L(0).

    Guaranteed behavior since opcode is of the MAA instruction.

                 2. AddressBusToDataBus = 1.
          3. Set ARDest[L] to read from the Data Bus.
                 1. AR Data Bus Load Enable = ARDest[L].
                       1. loadAR = 1.
                       2. loadARHorL = L(0).

    Guaranteed behavior since opcode is of the MAA instruction.

    4. Cycle 4.
          1. Write Address Bus High register to the Data Bus.
                 1. AddressByteSelect = H (1).
                       1. AddressHorL = H(1).
                 2. AddressBusToDataBus = 1.
          2. Set ARDest[H] to read from the Data Bus.
                 1. AR Data Bus Load Enable = ARDest[H].
                       1. loadAR = 1.
                       2. loadARHorL = H(1).

    Guaranteed behavior since opcode is of the MAA instruction.

          3. Advance PC.
                 1. PC Advance = 1.
PUSH Instruction Microcode
PUSH Semantics: SP--; *SP = Rs1.
    1. Cycle 1. SP--;
          1. Decrement SP.
                 1. Stack\ Pointer\ Count = 1.
                 2. Stack Pointer Increment / Decrement = decrement (0).
    2. Cycle 2. *SP = Rs1;
          1. Write Rs1 to the Data Bus.
                 1. Register File Output Enable = 1.
                 2. Register File Output Select = Rs1 (0).
          2. Write SP to the Address Bus.
                 1. ARSelect = SP.
                       1. SP Out = 1.
          3. Set Memory to read from the Data Bus.
                 1. Mem Write = 1.
    3. Cycle 3.
          1. Advance PC.
                 1. PC Advance = 1.
POP Instruction Microcode
POP Semantics: Rd = *SP; SP++.
```

```
1. Cycle 1. Rd = *SP; SP++;
          1. Write SP to the Address Bus.
                 1. ARSelect = SP.
                       1. SP Out = 1.
          2. Set Memory to write to the Data Bus.
                 1. Mem Read = 1.
          3. Set Rd to read from the Data Bus.
                 1. Register File Input Enable = 1.
          4. Increment SP.
                 1. Stack\ Pointer\ Count = 1.
                 2. Stack Pointer Increment / Decrement = increment (1).
    2. Cycle 2.
          1. Advance PC.
                 1. PC Advance = 1.
JSR Instruction Microcode
JSR Semantics: SP--; *SP = PC[H]; SP--; *SP = PC[L]; PC = DP.
    1. Cycle 1. SP--; Address Bus Register High = PC[H].
          1. Decrement SP.
                 1. Stack\ Pointer\ Count = 1.
                 2. Stack Pointer Increment / Decrement = decrement (0).
          2. Write PC to the Address Bus.
                 1. ARSelect = PC.
                       1. PC Out = 1.
    2. Cycle 2. *SP = PC[H]; SP--;
          1. Write SP to the Address Bus.
                 1. ARSelect = SP.
                       1. SP Out = 1.
          2. Write Address Bus Register High to the Data Bus (PC[H]).
                 1. AddressByteSelect = H (1).
                       1. AddressHorL = H(1).
                 2. AddressBusToDataBus = 1.
          3. Set Memory to read from the Data Bus.
                 1. Mem Write = 1.
          4. Decrement SP.
                 1. Stack\ Pointer\ Count = 1.
                 2. Stack Pointer Increment / Decrement = decrement (0).
    3. Cycle 3. Address Bus Register Low = PC[L]
          1. Write PC to the Address Bus.
                 1. ARSelect = PC.
                       1. PC Out = 1.
    4. Cycle 4. *SP = PC[L].
          1. Write SP to the Address Bus.
                 1. ARSelect = SP.
                       1. SP Out = 1.
          2. Write Address Bus Register Low to the Data Bus (PC[L]).
```

```
1. AddressByteSelect = L (0).
                      1. AddressHorL = L(0).
                2. AddressBusToDataBus = 1.
          3. Set Memory to read from the Data Bus.
                1. Mem Write = 1.
    5. Cycle 5. Address Bus Register High = DP[H].
          1. Write DP to the Address Bus.
                1. ARSelect = DP.
                Default behavior of ARSelect.
    6. Cycle 6. DHPC = DP[H]; Address Bus Register Low = DP[L].
          1. Write DP to the Address Bus.
                1. ARSelect = DP.
                ■ Default behavior of ARSelect.
          2. Write Address Bus Register High to the Data Bus (DP[H]).
                1. AddressByteSelect = H (1).
                      1. AddressHorL = H(1).
                2. AddressBusToDataBus = 1.
          3. Set DHPC to load from the Data Bus.
                1. AR Data Bus Load Enable = DHPC.
                      1. loadAR = 1.
                      2. PC Load = 1.
                      3. loadARHorL = H(1).
    7. Cycle 7. PC[L] = DP[L] (and PC[H] = DHPC).
          1. Write Address Bus Register Low to the Data Bus (DP[L]).
                1. AddressByteSelect = L (∅).
                      1. AddressHorL = L(0).
                2. AddressBusToDataBus = 1.
          2. Set PC[L] to load from the Data Bus.
                1. AR Data Bus Load Enable = PC[L] + PC[H] = DHPC.
                      1. loadAR = 1.
                      2. PC Load = 1.
                      3. loadARHorL = L (0).
          3. Advance PC.
                1. PC Advance = 1.
RTS Instruction Microcode
RTS Semantics: SP++; DHPC = *SP; SP--; PC[L] = *SP, PC[H] = DHPC; SP++; SP++;
    1. Cycle 1. SP++;
          1. Increment SP.
                1. Stack\ Pointer\ Count = 1.
                2. Stack Pointer Increment / Decrement = increment (1).
    2. Cycle 2. DHPC = *SP; SP--;
          1. Write SP to the Address Bus.
                1. ARSelect = SP.
                      1. SP Out = 1.
          2. Set Memory to write to the Data Bus.
```

```
1. Mem Read = 1.
      3. Set DHPC to read from the Data Bus.
            1. AR Data Bus Load Enable = DHPC.
                   1. loadAR = 1.
                   2. PC Load = 1.
                   3. loadARHorL = H(1).
      4. Decrement SP.
            1. Stack\ Pointer\ Count = 1.
            2. Stack Pointer Increment / Decrement = decrement (0).
3. Cycle 3. PC[L] = *SP; SP++.
      1. Write SP to the Address Bus.
            1. ARSelect = SP.
                   1. SP Out = 1.
      2. Set Memory to write to the Data Bus.
             1. Mem Read = 1.
      3. Set PC[L] to read from the Data Bus (and PC[H] = DHPC).
            1. AR Data Bus Load Enable = PC[L] + PC[H] = DHPC.
                   1. loadAR = 1.
                   2. PC Load = 1.
                   3. loadARHorL = L(0).
      4. Increment SP.
            1. Stack\ Pointer\ Count = 1.
            2. Stack Pointer Increment / Decrement = increment (1).
4. Cycle 4. SP++;
      1. Increment SP.
            1. Stack\ Pointer\ Count = 1.
            2. Stack Pointer Increment / Decrement = increment (1).
      2. Advance PC.
            1. PC Advance = 1.
```