Team 750C Nothing But Net Code Reference Competition_2016-02-06_BCIT

Generated by Doxygen 1.8.11

ii CONTENTS

Contents

1	Clas	Index	2
	1.1	Class List	2
2	File	ndex	2
	2.1	File List	2
3	Clas	Documentation	3
	3.1	oyState Struct Reference	3
		3.1.1 Detailed Description	4
		3.1.2 Member Data Documentation	4
	3.2	MotorGroup Struct Reference	5
		3.2.1 Detailed Description	5
		3.2.2 Member Data Documentation	5
4	File	ocumentation	5
	4.1	nclude/autonrecorder.h File Reference	5
		4.1.1 Detailed Description	6
		4.1.2 Macro Definition Documentation	7
		4.1.3 Typedef Documentation	8
		4.1.4 Function Documentation	8
		4.1.5 Variable Documentation	9
	4.2	autonrecorder.h	9
	4.3	include/autonroutines.h File Reference	0
		4.3.1 Detailed Description	0
		4.3.2 Macro Definition Documentation	1
		4.3.3 Function Documentation	1
	4.4	autonroutines.h	1
	4.5	nclude/bitwise.h File Reference	1

	4.5.1	Detailed Description	. 12
	4.5.2	Macro Definition Documentation	. 12
4.6	bitwise	.h	. 13
4.7	include	e/constants.h File Reference	. 13
	4.7.1	Detailed Description	. 14
	4.7.2	Macro Definition Documentation	. 14
4.8	consta	nts.h	. 15
4.9	include	e/friendly.h File Reference	. 15
	4.9.1	Detailed Description	. 16
	4.9.2	Macro Definition Documentation	. 16
4.10	friendly	,,h	. 17
4.11	include	e/Icddiag.h File Reference	. 17
	4.11.1	Detailed Description	. 18
	4.11.2	Macro Definition Documentation	. 18
	4.11.3	Typedef Documentation	. 20
	4.11.4	Function Documentation	. 20
	4.11.5	Variable Documentation	. 21
4.12	Icddiag	j.h	. 22
4.13	include	e/Icdmsg.h File Reference	. 23
	4.13.1	Detailed Description	. 24
	4.13.2	Macro Definition Documentation	. 24
	4.13.3	Function Documentation	. 24
	4.13.4	Variable Documentation	. 25
4.14	lcdmsg	j.h	. 25
4.15	include	e/macros.h File Reference	. 25
	4.15.1	Detailed Description	. 26
	4.15.2	Macro Definition Documentation	. 26
4.16	macros	s.h	. 30

iv CONTENTS

4.17	include/main.h File Reference	30
	4.17.1 Detailed Description	31
	4.17.2 Function Documentation	32
4.18	main.h	33
4.19	include/motors.h File Reference	34
	4.19.1 Detailed Description	35
	4.19.2 Macro Definition Documentation	35
	4.19.3 Function Documentation	36
4.20	motors.h	38
4.21	include/opcontrol.h File Reference	39
	4.21.1 Detailed Description	39
	4.21.2 Function Documentation	40
	4.21.3 Variable Documentation	40
4.22	opcontrol.h	41
4.23	include/robot.h File Reference	41
	4.23.1 Detailed Description	41
	4.23.2 Macro Definition Documentation	42
4.24	robot.h	42
4.25	include/sensors.h File Reference	42
	4.25.1 Detailed Description	43
	4.25.2 Macro Definition Documentation	44
	4.25.3 Function Documentation	46
	4.25.4 Variable Documentation	47
4.26	sensors.h	48
4.27	src/auto.c File Reference	49
	4.27.1 Detailed Description	49
	4.27.2 Function Documentation	50
4.28	auto.c	50

4.29	src/autonrecorder.c File Reference	50
	4.29.1 Detailed Description	51
	4.29.2 Function Documentation	51
	4.29.3 Variable Documentation	52
4.30	autonrecorder.c	53
4.31	src/autonroutines.c File Reference	57
	4.31.1 Detailed Description	57
	4.31.2 Function Documentation	57
4.32	autonroutines.c	58
4.33	src/init.c File Reference	58
	4.33.1 Detailed Description	59
	4.33.2 Function Documentation	59
4.34	init.c	60
4.35	src/lcddiag.c File Reference	61
	4.35.1 Detailed Description	62
	4.35.2 Function Documentation	62
	4.35.3 Variable Documentation	69
4.36	lcddiag.c	70
4.37	src/lcdmsg.c File Reference	83
	4.37.1 Detailed Description	84
	4.37.2 Function Documentation	84
	4.37.3 Variable Documentation	84
4.38	lcdmsg.c	85
4.39	src/motors.c File Reference	86
	4.39.1 Detailed Description	86
	4.39.2 Function Documentation	86
4.40	motors.c	86
4.41	src/opcontrol.c File Reference	87
	4.41.1 Detailed Description	87
	4.41.2 Function Documentation	88
	4.41.3 Variable Documentation	89
4.42	opcontrol.c	90
4.43	src/sensors.c File Reference	91
	4.43.1 Detailed Description	92
	4.43.2 Function Documentation	92
	4.43.3 Variable Documentation	93
4.44	sensors.c	94

Ind	lex	95
1	Class Index	
1.1	Class List	
Her	re are the classes, structs, unions and interfaces with brief descriptions:	
	joyState Representation of the operator controller's instructions at a point in time	3
	MotorGroup Represents a logical motor grouping, to be used when testing motors	5
2	File Index	
2.1	File List	
Her	re is a list of all files with brief descriptions:	
	include/autonrecorder.h Header file for autonomous recorder functions and definitions	5
	include/autonroutines.h Header file for hard-coded autonomous routines	10
	include/bitwise.h Header file for bitwise functions and operations	11
	include/constants.h Header file for mathematical constants	13
	include/friendly.h Header file for human-readable definitions	15
	include/Icddiag.h Header file for LCD diagnostic menu functions and definitions	17
	include/lcdmsg.h Header file for LCD message code	23
	include/macros.h Header file for macro definitions	25
	include/main.h Header file for global functions	30
	include/motors.h Header file for important motor functions and definitions	34

3 Class Documentation 3

include/opcontrol.h	
Header file for operator control definitions and prototypes	39
include/robot.h	
File for robot constant definitions	41
include/sensors.h	
File for important sensor declarations and functions	42
src/auto.c	
File for autonomous code	49
src/autonrecorder.c	
File for autonomous recorder code	50
src/autonroutines.c	
File for hard-coded autonomous routines	57
src/init.c	
File for initialization code	58
src/lcddiag.c	
File for LCD diagnostic menu code	61
src/lcdmsg.c	
File for LCD message code	83
src/motors.c	
File for important motor functions	86
src/opcontrol.c	
File for operator control code	87
src/sensors.c	
File for important sensor declarations and functions	91

3 Class Documentation

3.1 joyState Struct Reference

Representation of the operator controller's instructions at a point in time.

#include <autonrecorder.h>

Public Attributes

- signed char spd
- signed char turn
- signed char sht
- signed char intk
- signed char trans
- signed char dep

3.1.1 Detailed Description

Representation of the operator controller's instructions at a point in time.

This state represents the values of the motors at a point in time. These instructions are played back at the rate polled to send the same commands the operator did.

Definition at line 67 of file autonrecorder.h.

3.1.2 Member Data Documentation

3.1.2.1 signed char joyState::dep

Speed of the lift deployment motor.

Definition at line 96 of file autonrecorder.h.

3.1.2.2 signed char joyState::intk

Speed of the intake motor.

Definition at line 86 of file autonrecorder.h.

3.1.2.3 signed char joyState::sht

Speed of the shooter motors.

Definition at line 81 of file autonrecorder.h.

3.1.2.4 signed char joyState::spd

Forward/backward speed of the drive motors.

Definition at line 71 of file autonrecorder.h.

3.1.2.5 signed char joyState::trans

Speed of the transmission motor.

Definition at line 91 of file autonrecorder.h.

3.1.2.6 signed char joyState::turn

Turning speed of the drive motors.

Definition at line 76 of file autonrecorder.h.

The documentation for this struct was generated from the following file:

· include/autonrecorder.h

3.2 MotorGroup Struct Reference

Represents a logical motor grouping, to be used when testing motors.

```
#include <lcddiag.h>
```

Public Attributes

- bool motor [11]
- char name [LCD_MESSAGE_MAX_LENGTH+1]

3.2.1 Detailed Description

Represents a logical motor grouping, to be used when testing motors.

Has flags for each motor that belongs to the group, as well as a 16-character name.

Definition at line 143 of file lcddiag.h.

3.2.2 Member Data Documentation

3.2.2.1 bool MotorGroup::motor[11]

Stores if each motor is contained in this group or not.

This array contains 11 values. Element 0 is ignored. Elements 1-10 represent the respective motor ports.

Definition at line 149 of file lcddiag.h.

```
3.2.2.2 char MotorGroup::name[LCD_MESSAGE_MAX_LENGTH+1]
```

The name of the motor group.

The name can be a maximum of 16 characters. The buffer is 17 characters to hold the null terminator.

Definition at line 157 of file lcddiag.h.

The documentation for this struct was generated from the following file:

• include/lcddiag.h

4 File Documentation

4.1 include/autonrecorder.h File Reference

Header file for autonomous recorder functions and definitions.

Classes

struct joyState

Representation of the operator controller's instructions at a point in time.

Macros

- #define AUTON TIME 15
- #define PROGSKILL TIME 60
- #define JOY POLL FREQ 50
- #define MAX_AUTON_SLOTS 10
- #define AUTON_FILENAME_MAX_LENGTH 8
- #define AUTON POT 1
- #define AUTON_BUTTON 2
- #define AUTON_POT_LOW 0
- #define AUTON_POT_HIGH 4095

Typedefs

typedef struct joyState joyState

Representation of the operator controller's instructions at a point in time.

Functions

- void initAutonRecorder ()
- · void recordAuton ()
- void saveAuton ()
- void loadAuton ()
- void playbackAuton ()

Variables

- joyState states [AUTON_TIME *JOY_POLL_FREQ]
- · int autonLoaded
- · int progSkills

4.1.1 Detailed Description

Header file for autonomous recorder functions and definitions.

This file contains definitions and function declarations for the autonomous recorder. These definitions provide fundamental constants and classes that the autonomous recorder uses. Additionally, this file defines the autonomous selection potentiometer and button. It also provides access to the autonomous recorder functions from other files. This allows for the recorder to be accessed during operator control.

Definition in file autonrecorder.h.

4.1.2 Macro Definition Documentation

4.1.2.1 #define AUTON_BUTTON 2

Button for confirming selection of an autonomous routine.

Definition at line 49 of file autonrecorder.h.

4.1.2.2 #define AUTON_FILENAME_MAX_LENGTH 8

Maximum file name length of autonomous routine files.

Definition at line 39 of file autonrecorder.h.

4.1.2.3 #define AUTON POT 1

Potentiometer for selecting which autonomous routine to load.

Definition at line 44 of file autonrecorder.h.

4.1.2.4 #define AUTON_POT_HIGH 4095

Upper limit of the autonomous routine selector potentiometer.

Definition at line 59 of file autonrecorder.h.

4.1.2.5 #define AUTON_POT_LOW 0

Lower limit of the autonomous routine selector potentiometer.

Definition at line 54 of file autonrecorder.h.

4.1.2.6 #define AUTON_TIME 15

Number of seconds the autonomous period lasts.

Definition at line 17 of file autonrecorder.h.

4.1.2.7 #define JOY_POLL_FREQ 50

Frequency to poll the joystick for recording. The joystick values will be recorded this many times per second. The joystick updates every 20 milliseconds (50 times per second).

Definition at line 29 of file autonrecorder.h.

4.1.2.8 #define MAX_AUTON_SLOTS 10

Maximum number of autonomous routines to be stored.

Definition at line 34 of file autonrecorder.h.

4.1.2.9 #define PROGSKILL_TIME 60

Number of seconds the programming skills challenge lasts.

Definition at line 22 of file autonrecorder.h.

4.1.3 Typedef Documentation

4.1.3.1 typedef struct joyState joyState

Representation of the operator controller's instructions at a point in time.

This state represents the values of the motors at a point in time. These instructions are played back at the rate polled to send the same commands the operator did.

4.1.4 Function Documentation

```
4.1.4.1 void initAutonRecorder ( )
```

Initializes autonomous recorder by setting joystick states array to zero.

Initializes autonomous recorder by setting states array to zero.

Definition at line 74 of file autonrecorder.c.

```
4.1.4.2 void loadAuton ( )
```

Loads autonomous file contents into states array for playback.

Loads autonomous file contents into states array.

Definition at line 218 of file autonrecorder.c.

```
4.1.4.3 void playbackAuton ( )
```

Replays autonomous based on loaded values in states array.

Definition at line 317 of file autonrecorder.c.

```
4.1.4.4 void recordAuton ( )
```

Records driver joystick values into states array for saving.

Records driver joystick values into states array.

Definition at line 90 of file autonrecorder.c.

4.2 autonrecorder.h 9

```
4.1.4.5 void saveAuton ( )
```

Saves contents of the states array to a file in flash memory for later playback.

Saves contents of the states array to a file in flash memory.

Definition at line 135 of file autonrecorder.c.

4.1.5 Variable Documentation

4.1.5.1 int autonLoaded

Slot number of currently loaded autonomous routine.

Definition at line 24 of file autonrecorder.c.

4.1.5.2 int progSkills

Section number (0-3) of currently loaded programming skills routine. Since programming skills lasts for 60 seconds, it can be represented by 4 standard autonomous recordings.

Section number (0-3) of currently loaded programming skills routine.

Definition at line 29 of file autonrecorder.c.

4.1.5.3 joyState states[AUTON_TIME *JOY_POLL_FREQ]

Stores the joystick state variables for moving the robot. Used for recording and playing back autonomous routines.

Definition at line 19 of file autonrecorder.c.

4.2 autonrecorder.h

```
00001
00011 #ifndef AUTONRECORDER_H
00012 #define AUTONRECORDER_H
00017 #define AUTON_TIME 15
00018
00022 #define PROGSKILL_TIME 60
00023
00029 #define JOY_POLL_FREQ 50
00030
00034 #define MAX_AUTON_SLOTS 10
00035
00039 #define AUTON_FILENAME_MAX_LENGTH 8
00040
00044 #define AUTON_POT 1
00045
00049 #define AUTON_BUTTON 2
00050
00054 #define AUTON_POT_LOW 0
00055
00059 #define AUTON_POT_HIGH 4095
00060
00067 typedef struct joyState {
00071
         signed char spd;
```

```
00072
00076
          signed char turn;
00077
00081
          signed char sht;
00082
00086
          signed char intk;
00087
00091
          signed char trans;
00092
00096
          signed char dep;
00097 } joyState;
00098
00103 extern joyState states[AUTON_TIME*JOY_POLL_FREQ];
00104
00108 extern int autonLoaded;
00109
00114 extern int progSkills;
00115
00119 void initAutonRecorder();
00120
00124 void recordAuton();
00125
00129 void saveAuton();
00130
00134 void loadAuton();
00135
00139 void playbackAuton();
00140
00141 #endif
00142
```

4.3 include/autonroutines.h File Reference

Header file for hard-coded autonomous routines.

Macros

- #define CLOSE GOAL ANGLE 15
- #define DISTANCE_TO_OTHER_SIDE 100

Functions

• void runHardCodedProgrammingSkills ()

4.3.1 Detailed Description

Header file for hard-coded autonomous routines.

This file contains function declarations and definitions for use in the hard-coded autonomous routines. These functions can be called from other files to run hard-coded autonomous routines.

Definition in file autonroutines.h.

4.4 autonroutines.h 11

4.3.2 Macro Definition Documentation

4.3.2.1 #define CLOSE_GOAL_ANGLE 15

Angle that the robot must be from the vertical to shoot into the close goal while still being able to turn without hitting the wall.

Definition at line 14 of file autonroutines.h.

```
4.3.2.2 #define DISTANCE_TO_OTHER_SIDE 100
```

Distance that the robot must travel to reach the other tile to shoot preloads.

Definition at line 19 of file autonroutines.h.

4.3.3 Function Documentation

4.3.3.1 void runHardCodedProgrammingSkills ()

Runs a pre-written programming skills routine using sensors rather than the autonomous recorder.

Runs a programming skills routine using sensors rather than the autonomous recorder. Starts in the left side of the field shooting into the closer goal.

Definition at line 13 of file autonroutines.c.

4.4 autonroutines.h

```
00001
00008 #ifndef AUTONROUTINES_H
00009 #define AUTONROUTINES_H
00010
00014 #define CLOSE_GOAL_ANGLE 15
00019 #define DISTANCE_TO_OTHER_SIDE 100
00020
00020
00024 void runHardCodedProgrammingSkills();
00025
00026 #endif
```

4.5 include/bitwise.h File Reference

Header file for bitwise functions and operations.

Macros

- #define bitRead(value, bit) (((value) >> (bit)) & 0x01)
- #define bitSet(value, bit) ((value) |= (1UL << (bit)))
- #define bitClear(value, bit) ((value) &= ~(1UL << (bit)))
- #define bitWrite(value, bit, bitvalue) (bitvalue ? bitSet(value, bit) : bitClear(value, bit))

4.5.1 Detailed Description

Header file for bitwise functions and operations.

This file provides macro definitions for bitwise manipulation of variables. These definitions provide a more human-readable way to manipulate individual bits.

Definition in file bitwise.h.

4.5.2 Macro Definition Documentation

```
4.5.2.1 #define bitClear( value, bit ) ((value) &= \sim(1UL << (bit)))
```

Clears the value of a bit in a variable to 0.

Parameters

value	the variable to clear in
bit	the bit number to clear (0 being the rightmost)

Definition at line 35 of file bitwise.h.

4.5.2.2 #define bitRead(*value*, *bit*) (((value) >> (bit)) & 0x01)

Reads the value of a bit (1 or 0) from a variable.

Parameters

value	the variable to read from
bit	the bit number to read (0 being the rightmost)

Returns

the value of the bit (1 or 0)

Definition at line 19 of file bitwise.h.

4.5.2.3 #define bitSet(value, bit) ((value) \mid = (1UL << (bit)))

Sets the value of a bit in a variable to 1.

value	the variable to set in
bit	the bit number to set (0 being the rightmost)

4.6 bitwise.h

Definition at line 27 of file bitwise.h.

4.5.2.4 #define bitWrite(value, bit, bitvalue) (bitvalue ? bitSet(value, bit) : bitClear(value, bit))

Writes a value (1 or 0) to a bit in a variable.

Parameters

value	the variable to write in
bit	the bit number to set (0 being the rightmost)
bitvalue	the value to write (1 or 0)

Definition at line 44 of file bitwise.h.

4.6 bitwise.h

4.7 include/constants.h File Reference

Header file for mathematical constants.

Macros

- #define MATH PI 3.141592653589793238462643383279
- #define MATH_E 2.718281828459045
- #define PI 3.1415926535897932384626433832795
- #define HALF PI 1.5707963267948966192313216916398
- #define TWO PI 6.283185307179586476925286766559
- #define TAU 6.283185307179586476925286766559
- #define DEG_TO_RAD 0.017453292519943295769236907684886
- #define RAD_TO_DEG 57.295779513082320876798154814105
- #define ROTATION_DEG 360
- #define ROTATION_RAD TWO_PI

4.7.1 Detailed Description

Header file for mathematical constants.

This file provides constant definitions for various mathematical values that appear frequently. These definitions provide a more human-readable way to do math operations on variables.

Definition in file constants.h.

4.7.2 Macro Definition Documentation

4.7.2.1 #define DEG_TO_RAD 0.017453292519943295769236907684886

Conversion factor from degrees to radians.

Definition at line 44 of file constants.h.

4.7.2.2 #define HALF_PI 1.5707963267948966192313216916398

Half the value of pi.

Definition at line 29 of file constants.h.

4.7.2.3 #define MATH_E 2.718281828459045

The mathematical constant e (Euler's Number).

Definition at line 19 of file constants.h.

4.7.2.4 #define MATH_PI 3.141592653589793238462643383279

The mathematical constant pi.

Definition at line 14 of file constants.h.

4.7.2.5 #define PI 3.1415926535897932384626433832795

The mathematical constant pi.

Definition at line 24 of file constants.h.

4.7.2.6 #define RAD_TO_DEG 57.295779513082320876798154814105

Conversion factor from radians to degrees.

Definition at line 49 of file constants.h.

4.8 constants.h

4.7.2.7 #define ROTATION_DEG 360

Amount of degrees in a circle.

Definition at line 54 of file constants.h.

4.7.2.8 #define ROTATION_RAD TWO_PI

Amount of radians in a circle.

Definition at line 59 of file constants.h.

4.7.2.9 #define TAU 6.283185307179586476925286766559

The mathematical constant tau (two times the value of pi).

Definition at line 39 of file constants.h.

4.7.2.10 #define TWO_PI 6.283185307179586476925286766559

Two times the value of pi (the mathematical constant tau).

Definition at line 34 of file constants.h.

4.8 constants.h

```
00001
00008 #ifndef CONSTANTS_H_
00009 #define CONSTANTS_H_
00010
00014 #define MATH_PI 3.141592653589793238462643383279
00015
00019 #define MATH_E 2.718281828459045
00020
00024 #define PI 3.1415926535897932384626433832795
00025
00029 #define HALF_PI 1.5707963267948966192313216916398
00030
00034 #define TWO_PI 6.283185307179586476925286766559
00035
00039 #define TAU 6.283185307179586476925286766559
00040
00044 #define DEG_TO_RAD 0.017453292519943295769236907684886
00045
00049 #define RAD_TO_DEG 57.295779513082320876798154814105
00050
00054 #define ROTATION_DEG 360
00055
00059 #define ROTATION_RAD TWO_PI
00060
00061 #endif
00062
```

4.9 include/friendly.h File Reference

Header file for human-readable definitions.

Macros

- #define PRESSED LOW
- #define UNPRESSED HIGH
- #define UNRELEASED LOW
- #define RELEASED HIGH

4.9.1 Detailed Description

Header file for human-readable definitions.

This file provides constant definitions for various sensory states that appear frequently. Since the button pressed state is represented by an unintuitive LOW value, these constants create definitions for the pressed and unpressed states of a button.

Definition in file friendly.h.

4.9.2 Macro Definition Documentation

4.9.2.1 #define PRESSED LOW

More readable definition for button pressed/unreleased state.

Definition at line 15 of file friendly.h.

4.9.2.2 #define RELEASED HIGH

More readable definition for button released/unpressed state.

Definition at line 30 of file friendly.h.

4.9.2.3 #define UNPRESSED HIGH

More readable definition for button unpressed/released state.

Definition at line 20 of file friendly.h.

4.9.2.4 #define UNRELEASED LOW

More readable definition for button unreleased/pressed state.

Definition at line 25 of file friendly.h.

4.10 friendly.h 17

4.10 friendly.h

```
00001
00009 #ifndef FRIENDLY_H_
00010 #define FRIENDLY_H_
00011
00015 #define PRESSED LOW
00016
00020 #define UNPRESSED HIGH
00021
00025 #define UNRELEASED LOW
00026
00030 #define RELEASED HIGH
00031
00032 #endif
```

4.11 include/lcddiag.h File Reference

Header file for LCD diagnostic menu functions and definitions.

Classes

struct MotorGroup

Represents a logical motor grouping, to be used when testing motors.

Macros

- #define LCD_MENU_COUNT 9
- #define MENU MOTOR 0
- #define MENU MOTOR MGMT 1
- #define MENU BATTERY 2
- #define MENU_CONNECTION 3
- #define MENU_ROBOT 4
- #define MENU_AUTON 5
- #define MENU BACKLIGHT 6
- #define MENU SCREENSAVER 7
- #define MENU CREDITS 8

Typedefs

typedef struct MotorGroup MotorGroup

Represents a logical motor grouping, to be used when testing motors.

Functions

- bool lcdButtonPressed (int btn)
- bool lcdAnyButtonPressed ()
- · void initGroups ()
- char * typeString (char *dest)
- void formatLCDDisplay (void *ignore)

Variables

- char menuChoices [LCD_MENU_COUNT][LCD_MESSAGE_MAX_LENGTH+1]
- TaskHandle lcdDiagTask
- MotorGroup * groups
- · int numgroups
- · bool disableOpControl

4.11.1 Detailed Description

Header file for LCD diagnostic menu functions and definitions.

This file contains function prototypes and definitions for the LCD diagnostic menu. The menu provides live debugging and testing functionality. It provides the following functions:

- · Motor testing functionality (individual and group)
- · Motor group management
- · Battery voltage information
- · Joystick connection status
- · Robot sensory data
- · Autonomous recorder status
- · LCD backlight toggle
- · Screensaver that displays during operator control
- · Credits menu

This file maintains constants and internal states regarding the menu's functionality.

The idea behind this was inspired by Team 750W and Akram Sandhu. Without them, this project would not be possible.

Note: the implementation of this feature is completely different between the two teams. No code was reused from their implementation of the LCD diagnostic menu.

Definition in file lcddiag.h.

4.11.2 Macro Definition Documentation

4.11.2.1 #define LCD_MENU_COUNT 9

The number of top-level menus available in the LCD diagnostic menu system.

Definition at line 78 of file lcddiag.h.

4.11.2.2 #define MENU_AUTON 5

Menu ID number of the autonomous recorder status indicator.

Definition at line 108 of file lcddiag.h.

4.11.2.3 #define MENU_BACKLIGHT 6

Menu ID number of the backlight toggle.

Definition at line 113 of file lcddiag.h.

4.11.2.4 #define MENU_BATTERY 2

Menu ID number of the battery voltage readout.

Definition at line 93 of file lcddiag.h.

4.11.2.5 #define MENU_CONNECTION 3

Menu ID number of the joystick connection state indicator.

Definition at line 98 of file lcddiag.h.

4.11.2.6 #define MENU_CREDITS 8

Menu ID number of the credits menu. Thanks again to Team 750W and Akram Sandhu.

Definition at line 124 of file lcddiag.h.

4.11.2.7 #define MENU_MOTOR 0

Menu ID number of the motor testing menu.

Definition at line 83 of file lcddiag.h.

4.11.2.8 #define MENU_MOTOR_MGMT 1

Menu ID number of the motor group manager.

Definition at line 88 of file lcddiag.h.

4.11.2.9 #define MENU_ROBOT 4

Menu ID number of the robot sensory state indicator.

Definition at line 103 of file lcddiag.h.

4.11.2.10 #define MENU_SCREENSAVER 7

Menu ID number of the LCD message screensaver.

Definition at line 118 of file lcddiag.h.

4.11.3 Typedef Documentation

4.11.3.1 typedef struct MotorGroup MotorGroup

Represents a logical motor grouping, to be used when testing motors.

Has flags for each motor that belongs to the group, as well as a 16-character name.

4.11.4 Function Documentation

```
4.11.4.1 void formatLCDDisplay (void * ignore)
```

Runs the LCD diagnostic menu task. The task starts in screensaver mode. Pressing any button cancels screensaver mode and enters the selection menu.

Parameters

```
ignore does nothing - required by task definition
```

Runs the LCD diagnostic menu task. This thread executes concurrently with the operator control task. The LCD diagnostic menu starts in screensaver mode. Pressing any button cancels screensaver mode and enters the selection menu.

Parameters

```
ignore does nothing - required by task definition
```

Definition at line 1298 of file lcddiag.c.

```
4.11.4.2 void initGroups ( )
```

Initializes the motor groups array to contain the standard set of groups. This includes: Left Drive, Right Drive, Full Drive, Nautilus Shooter, Intake, and Transmission.

Definition at line 230 of file lcddiag.c.

```
4.11.4.3 boollcdAnyButtonPressed() [inline]
```

Checks if the any LCD button is pressed. This function waits for the button to be released before terminating. Due to this, it can only be called once per loop iteration. Its value should be stored in a boolean variable.

Returns

true if pressed, false if not

Definition at line 64 of file lcddiag.h.

4.11.4.4 bool lcdButtonPressed (int btn) [inline]

Checks if the specified LCD button is pressed. This function's valid parameters are:

- LCD_BTN_LEFT
- LCD_BTN_RIGHT
- · LCD_BTN_CENTER.

This function waits for the specified button to be released before terminating. Due to this, it can only be called once per loop iteration. Its value should be stored in a boolean variable.

Parameters

btn the button to check

Returns

true if pressed, false if not

Definition at line 44 of file lcddiag.h.

4.11.4.5 char* typeString (char * dest)

Uses the LCD and the autonomous potentiometer to type a string. This is used to name motor groups and autonomous recordings. The maximum length of string this function can type is 16 characters.

Parameters

dest a buffer to store the typed string (must be at least 17 characters to hold null terminator)

Returns

a pointer to the buffer

Definition at line 81 of file lcddiag.c.

4.11.5 Variable Documentation

4.11.5.1 bool disableOpControl

Disables operator control loop during motor testing. Since running motors is not thread safe, it is necessary to stop operator control of the motors during testing.

Definition at line 42 of file lcddiag.c.

4.11.5.2 MotorGroup* groups

Array that stores the motor groups. As this is a dynamic array, creating and editing new motor groups is possible. These motor groups are added to the array via the Motor Group Management menu.

Definition at line 49 of file lcddiag.c.

4.11.5.3 TaskHandle lcdDiagTask

Object representing the LCD diagnostic menu task. The LCD diagnostic menu runs in a separate thread from the operator control code. The TaskHandle allows for pausing and resuming of the LCD diagnostic menu during autonomous recording.

Definition at line 31 of file lcddiag.c.

```
4.11.5.4 char menuChoices[LCD MENU COUNT][LCD MESSAGE MAX LENGTH+1]
```

Stores the top-level menu names.

Definition at line 60 of file lcddiag.c.

4.11.5.5 int numgroups

Stores the number of motor groups. This is functionally identical to the size of the motor group array.

Definition at line 55 of file lcddiag.c.

4.12 lcddiag.h

```
00026 #ifndef LCDDIAG_H
00027 #define LCDDIAG_H
00044 inline bool lcdButtonPressed(int btn) {
       if(lcdReadButtons(LCD_PORT) & btn) {
00045
00046
             do{
00047
                  delay(20);
00048
              } while (lcdReadButtons(LCD_PORT) & btn);
00049
              return true;
00050
        } else {
00051
              return false;
00052
         }
00053
          return true;
00054 }
00055
00064 inline bool lcdAnyButtonPressed() {
          if (lcdReadButtons(LCD_PORT)) {
00065
00066
              do{
00067
                  delay(20);
```

```
00068
              } while (lcdReadButtons(LCD_PORT));
00069
        return false;
00070
00071
00072
          return true;
00073 }
00074
00078 #define LCD_MENU_COUNT 9
00079
00083 #define MENU_MOTOR 0
00084
00088 #define MENU_MOTOR_MGMT 1
00089
00093 #define MENU_BATTERY 2
00094
00098 #define MENU_CONNECTION 3
00099
00103 #define MENU_ROBOT 4
00104
00108 #define MENU_AUTON 5
00109
00113 #define MENU_BACKLIGHT 6
00114
00118 #define MENU_SCREENSAVER 7
00119
00124 #define MENU_CREDITS 8
00125
00129 extern char menuChoices[LCD_MENU_COUNT][
     LCD_MESSAGE_MAX_LENGTH+1];
00130
00136 extern TaskHandle lcdDiagTask;
00137
00143 typedef struct MotorGroup {
00149
         bool motor[11];
00150
          char name[LCD_MESSAGE_MAX_LENGTH+1];
00157
00158 } MotorGroup;
00159
00165 extern MotorGroup *groups;
00166
00171 extern int numgroups;
00172
00177 extern bool disableOpControl;
00178
00183 void initGroups();
00184
00194 char* typeString(char* dest);
00195
00203 void formatLCDDisplay(void* ignore);
00204
00205 #endif
00206
```

4.13 include/lcdmsg.h File Reference

Header file for LCD message code.

Macros

- #define LCD PORT uart1
- #define LCD_750C_TITLE " \$\$\$ 750C \$\$\$ "
- #define LCD MESSAGE COUNT 48
- #define LCD_MESSAGE_MAX_LENGTH 16

Functions

- void randlcdmsg (FILE *lcdport, int line)
- void screensaver (FILE *lcdport)

```
Variables
```

```
• char * lcdmsg []
```

4.13.1 Detailed Description

Header file for LCD message code.

This file contains definitions for the LCD screensaver messages. This file also defines the LCD port. These messages display randomly while the LCD diagnostic menu is set to the screensaver mode. These messages are mainly inside jokes among the team.

Definition in file lcdmsg.h.

4.13.2 Macro Definition Documentation

4.13.2.1 #define LCD_750C_TITLE " \$\$\$ 750C \$\$\$ "

Defines title string for LCD to display.

Definition at line 21 of file lcdmsg.h.

4.13.2.2 #define LCD_MESSAGE_COUNT 48

Defines the amount of LCD messages in the master list.

Definition at line 26 of file lcdmsg.h.

4.13.2.3 #define LCD_MESSAGE_MAX_LENGTH 16

Defines the max length for LCD messages.

Definition at line 31 of file lcdmsg.h.

4.13.2.4 #define LCD_PORT uart1

Defines the port the LCD is plugged into.

Definition at line 16 of file lcdmsg.h.

4.13.3 Function Documentation

4.13.3.1 void randlcdmsg (FILE * *Icdport*, int *line*)

Displays a random LCD message from the master list.

4.14 lcdmsg.h 25

Parameters

Icdport	the port the LCD is connected to
line	the line to display the message on

Definition at line 71 of file lcdmsg.c.

```
4.13.3.2 void screensaver (FILE * Icdport )
```

Formats the LCD by displaying 750C title and message.

Parameters

Icdport the LCD is connected	O
------------------------------	---

Definition at line 90 of file lcdmsg.c.

4.13.4 Variable Documentation

```
4.13.4.1 char* lcdmsg[]
```

Master list of all LCD messages.

Definition at line 14 of file lcdmsg.c.

4.14 lcdmsg.h

```
00001
00010 #ifndef LCDMSG_H_
00011 #define LCDMSG_H_
00012
00016 #define LCD_PORT uart1
00017
00021 #define LCD_750C_TITLE " $$$ 750C $$$ "
00022
00026 #define LCD_MESSAGE_COUNT 48
00031 #define LCD_MESSAGE_MAX_LENGTH 16
00032
00036 extern char* lcdmsg[];
00044 void randlcdmsg(FILE *lcdport, int line);
00051 void screensaver(FILE *lcdport);
00052
00053 #endif
00054
```

4.15 include/macros.h File Reference

Header file for macro definitions.

Macros

- #define min(a, b) ((a)<(b)?(a):(b))
- #define MIN(a, b) ((a)<(b)?(a):(b))
- #define max(a, b) ((a)>(b)?(a):(b))
- #define MAX(a, b) ((a)>(b)?(a):(b))
- #define abs(x) ((x)>0?(x):-(x))
- #define constrain(amt, low, high) ((amt)<(low)?(low):((amt)>(high)?(high):(amt)))
- #define round(x) (((x) >=0) ?(long)((x)+0.5):(long)((x)-0.5))
- #define sign(x) ((x)>0?1:((x)<0?-1:0))
- #define radians(deg) ((deg)*DEG_TO_RAD)
- #define degrees(rad) ((rad)*RAD_TO_DEG)
- #define sq(x) ((x)*(x))
- #define SQ(x) ((x)*(x))

4.15.1 Detailed Description

Header file for macro definitions.

This file provides macro definitions for various basic functions that come about frequently.

Definition in file macros.h.

4.15.2 Macro Definition Documentation

```
4.15.2.1 #define abs(x) ((x)>0?(x):-(x))
```

Returns the absolute value of the input value.

Parameters

X	the input value

Returns

the absolute value of x

Definition at line 57 of file macros.h.

4.15.2.2 #define constrain(amt, low, high) ((amt)<(low)?(low):((amt)>(high)?(high):(amt)))

Constrains a value to a set of boundaries.

amt	the value to constrain
low	the lower bound
high	the higher bound

Returns

high, amt, or low if amt is higher, in between, or lower than the range specified, respectively

Definition at line 68 of file macros.h.

4.15.2.3 #define degrees(rad) ((rad)*RAD_TO_DEG)

Converts an angle measure in degrees to radians.

Parameters

Returns

the angle measure in degrees

Definition at line 104 of file macros.h.

4.15.2.4 #define max(a, b) ((a)>(b)?(a):(b))

Returns the maximum of the two values.

Parameters

а	the first input value
b	the second input value

Returns

the greater of the two values

Definition at line 38 of file macros.h.

4.15.2.5 #define MAX(a, b) ((a)>(b)?(a):(b))

Returns the maximum of the two values.

а	the first input value
b	the second input value

Returns

the greater of the two values

Definition at line 48 of file macros.h.

4.15.2.6 #define min(a, b) ((a)<(b)?(a):(b))

Returns the minimum of the two values.

Parameters

а	the first input value
b	the second input value

Returns

the lesser of the two values

Definition at line 18 of file macros.h.

4.15.2.7 #define MIN(a, b) ((a)<(b)?(a):(b))

Returns the minimum of the two values.

Parameters

а	the first input value
b	the second input value

Returns

the lesser of the two values

Definition at line 28 of file macros.h.

4.15.2.8 #define radians(deg) ((deg)*DEG_TO_RAD)

Converts an angle measure in degrees to radians.

deg	the angle measure in degrees
-----	------------------------------

Returns

the angle measure in radians

Definition at line 95 of file macros.h.

```
4.15.2.9 #define round( x) (((x) >=0) ?(long)((x)+0.5):(long)((x)-0.5))
```

Rounds a value to the nearest integer.

Parameters

```
x the value to round
```

Returns

the rounded value

Definition at line 77 of file macros.h.

```
4.15.2.10 #define sign(x) ((x)>0?1:((x)<0?-1:0))
```

Returns the sign of the input value.

Parameters

```
x the value to determine the sign of
```

Returns

-1, 0, or 1 if the value is negative, zero, or positive, respectively

Definition at line 86 of file macros.h.

```
4.15.2.11 #define sq( x ) ((x)*(x))
```

Squares the input value.

Parameters

```
x the value to square
```

Returns

the square of the input value

Definition at line 113 of file macros.h.

```
4.15.2.12 #define SQ( x ) ((x)*(x))
```

Squares the input value.

Parameters

```
x the value to square
```

Returns

the square of the input value

Definition at line 122 of file macros.h.

4.16 macros.h

```
00001
00007 #ifndef MACROS_H_
00008 #define MACROS_H_
00009
00018 #define min(a,b) ((a) < (b) ?(a):(b))
00019
00028 #define MIN(a,b) ((a) < (b)?(a):(b))
00029
00038 \#define max(a,b) ((a)>(b)?(a):(b))
00039
00048 #define MAX(a,b) ((a)>(b)?(a):(b))
00049 00057 #define abs(x) ((x)>0?(x):-(x))
00058
00068 #define constrain(amt,low,high) ((amt)<(low)?(low):((amt)>(high)?(high):(amt)))
00069
00077 \#define round(x) (((x) >=0) ?(long)((x)+0.5):(long)((x)-0.5))
00078
00086 \#define sign(x) ((x)>0?1:((x)<0?-1:0))
00087
00095 #define radians(deg) ((deg)*DEG_TO_RAD)
00096
00104 #define degrees(rad) ((rad)*RAD_TO_DEG)
00105
00113 #define sq(x) ((x)*(x))
00114
00122 #define SQ(x) ((x)*(x))
00123
00124 #endif
00125
```

4.17 include/main.h File Reference

Header file for global functions.

```
#include <stdint.h>
#include <string.h>
#include <API.h>
#include <constants.h>
#include <friendly.h>
#include <macros.h>
#include <bitwise.h>
#include <motors.h>
#include <robot.h>
#include <lodmsg.h>
#include <loddiag.h>
#include <autonroutines.h>
#include <autonrecorder.h>
#include <opcontrol.h>
```

Functions

- void autonomous ()
- void initializeIO ()
- void initialize ()
- void operatorControl ()

4.17.1 Detailed Description

Header file for global functions.

Any experienced C or C++ programmer knows the importance of header files. For those who do not, a header file allows multiple files to reference functions in other files without necessarily having to see the code (and therefore causing a multiple definition). To make a function in "opcontrol.c", "auto.c", "main.c", or any other C file visible to the core implementation files, prototype it here.

This file is included by default in the predefined stubs in each VEX Cortex PROS Project.

Copyright (c) 2011-2014, Purdue University ACM SIG BOTS. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Purdue University ACM SIG BOTS nor the names of its contributors may be used to endorse
 or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXP←RESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERC←HANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PURDUE UNIVERSITY ACM SIG BOTS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Purdue Robotics OS contains FreeRTOS (http://www.freertos.org) whose source code may be obtained from http://sourceforge.net/projects/freertos/files/oron request.

Definition in file main.h.

4.17.2 Function Documentation

4.17.2.1 void autonomous ()

C standard integer type header. C standard string function header. PROS main API header. Mathematical constant definitions. Useful redefinitions to make code more readable. Simple macros for performing common operations. Macros for performing bitwise operations. Sensor definitions and function declarations. Motor definitions and function declarations. Robot physical constant definitions and function declarations. LCD definitions and function declarations. LCD diagnostics menu definitions and function declarations. Hard-coded autonomous routine definitions and function declarations. Autonomous recorder definitions and function declarations. Operator control definitions and function declarations. Runs the user autonomous code. This function will be started in its own task with the default priority and stack size whenever the robot is enabled via the Field Management System or the VEX Competition Switch in the autonomous mode. If the robot is disabled or communications is lost, the autonomous task will be stopped by the kernel. Re-enabling the robot will restart the task, not re-start it from where it left off.

Code running in the autonomous task cannot access information from the VEX Joystick. However, the autonomous function can be invoked from another task if a VEX Competition Switch is not available, and it can access joystick information if called in this way.

The autonomous task may exit, unlike operatorControl() which should never exit. If it does so, the robot will await a switch to another mode or disable/enable cycle.

Definition at line 51 of file auto.c.

```
4.17.2.2 void initialize ( )
```

Runs user initialization code. This function will be started in its own task with the default priority and stack size once when the robot is starting up. It is possible that the VEXnet communication link may not be fully established at this time, so reading from the VEX Joystick may fail.

This function should initialize most sensors (gyro, encoders, ultrasonics), LCDs, global variables, and IMEs.

This function must exit relatively promptly, or the operatorControl() and autonomous() tasks will not start. An autonomous mode selection menu like the pre_auton() in other environments can be implemented in this task if desired.

Definition at line 61 of file init.c.

4.18 main.h 33

```
4.17.2.3 void initializeIO ( )
```

Runs pre-initialization code. This function will be started in kernel mode one time while the VEX Cortex is starting up. As the scheduler is still paused, most API functions will fail.

The purpose of this function is solely to set the default pin modes (pinMode()) and port states (digitalWrite()) of limit switches, push buttons, and solenoids. It can also safely configure a UART port (usartOpen()) but cannot set up an LCD (lcdlnit()).

Definition at line 45 of file init.c.

```
4.17.2.4 void operatorControl ( )
```

Runs the user operator control code. This function will be started in its own task with the default priority and stack size whenever the robot is enabled via the Field Management System or the VEX Competition Switch in the operator control mode. If the robot is disabled or communications is lost, the operator control task will be stopped by the kernel. Re-enabling the robot will restart the task, not resume it from where it left off.

If no VEX Competition Switch or Field Management system is plugged in, the VEX Cortex will run the operator control task. Be warned that this will also occur if the VEX Cortex is tethered directly to a computer via the USB A to A cable without any VEX Joystick attached.

Code running in this task can take almost any action, as the VEX Joystick is available and the scheduler is operational. However, proper use of delay() or taskDelayUntil() is highly recommended to give other tasks (including system tasks such as updating LCDs) time to run.

This task should never exit; it should end with some kind of infinite loop, even if empty.

Definition at line 153 of file opcontrol.c.

4.18 main.h

```
00001
00041 #ifndef MAIN_H_
00042 #define MAIN_H_
00043
00047 #include <stdint.h>
00048
00052 #include <string.h>
00053
00057 #include <API.h>
00058
00062 #include <constants.h>
00063
00067 #include <friendly.h>
00068
00072 #include <macros.h>
00073
00077 #include <bitwise.h>
00078
00082 #include <sensors.h>
00083
00087 #include <motors.h>
00088
00092 #include <robot.h>
00093
00097 #include <lcdmsg.h>
00098
00102 #include <lcddiag.h>
00107 #include <autonroutines.h>
```

```
00108
00112 #include <autonrecorder.h>
00117 #include <opcontrol.h>
00119 // Allow usage of this file in C++ programs
00120 #ifdef __cplusplus
00121 extern "C" {
00122 #endif
00123
00124 // A function prototype looks exactly like its declaration, but with a semicolon instead of
00125 // actual code. If a function does not match a prototype, compile errors will occur.
00126
00127 // Prototypes for initialization, operator control and autonomous
00128
00143 void autonomous();
00152 void initializeIO();
00166 void initialize();
00184 void operatorControl();
00185
00186 // End C++ export structure
00187 #ifdef __cplusplus
00188 }
00189 #endif
00190
00191 #endif
00192
```

4.19 include/motors.h File Reference

Header file for important motor functions and definitions.

Macros

- #define MOTOR_MAX 127
- #define MOTOR_MIN -127
- #define TRANSMISSION MOTOR 1
- #define LEFT MOTOR TOP 2
- #define LEFT_MOTOR_BOT 5
- #define RIGHT_MOTOR_TOP 3
- #define RIGHT_MOTOR_BOT 4
- #define SHOOTER_HAS_THREE_MOTORS
- #define NAUTILUS_SHOOTER_MOTOR_LEFT 6
- #define NAUTILUS SHOOTER MOTOR RIGHT 7
- #define NAUTILUS_SHOOTER_MOTOR_CENTER 8
- #define INTAKE_ROLLER_MOTOR 10
- #define ROBOT HAS LIFT DEPLOY MOTOR 1
- #define LIFT_DEPLOY 9

Functions

- void transmission (int spd)
- void transmissionSetPos (void *pos)
- void changeGear (int gear)
- void move (int spd, int turn)
- · void shoot (int spd)
- void intake (int spd)
- · void deploy (int spd)

4.19.1 Detailed Description

Header file for important motor functions and definitions.

This file contains the code for functions and definitions regarding motor status. Mainly, this file defines the motor ports for each mechanism. It also defines certain motor-related constants. Lastly, basic movement functions are defined as inline in this file.

Some functions are too complex to be defined as inline functions in the motors.h file. See the motors.c file for these more complicated movement functions.

See also

motors.c

Definition in file motors.h.

4.19.2 Macro Definition Documentation

4.19.2.1 #define INTAKE_ROLLER_MOTOR 10

Defines motor ports for the intake mechanism.

Definition at line 107 of file motors.h.

4.19.2.2 #define LEFT_MOTOR_BOT 5

Definition at line 63 of file motors.h.

4.19.2.3 #define LEFT_MOTOR_TOP 2

Defines motor ports for the left side of the drivetrain.

Definition at line 62 of file motors.h.

4.19.2.4 #define LIFT_DEPLOY 9

Definition at line 121 of file motors.h.

4.19.2.5 #define MOTOR_MAX 127

Defines maximum motor speed value.

Definition at line 21 of file motors.h.

```
4.19.2.6 #define MOTOR_MIN -127
Defines motor minimum speed value.
Definition at line 26 of file motors.h.
4.19.2.7 #define NAUTILUS_SHOOTER_MOTOR_CENTER 8
Definition at line 91 of file motors.h.
4.19.2.8 #define NAUTILUS_SHOOTER_MOTOR_LEFT 6
Definition at line 89 of file motors.h.
4.19.2.9 #define NAUTILUS_SHOOTER_MOTOR_RIGHT 7
Definition at line 90 of file motors.h.
4.19.2.10 #define RIGHT_MOTOR_BOT 4
Definition at line 69 of file motors.h.
4.19.2.11 #define RIGHT_MOTOR_TOP 3
Defines motor ports for the right side of the drivetrain.
Definition at line 68 of file motors.h.
4.19.2.12 #define ROBOT_HAS_LIFT_DEPLOY_MOTOR 1
Definition at line 118 of file motors.h.
4.19.2.13 #define SHOOTER_HAS_THREE_MOTORS
Defines motor ports for the nautilus gear shooting mechanism.
Definition at line 87 of file motors.h.
4.19.2.14 #define TRANSMISSION_MOTOR 1
Defines motor port for the transmission to change between driving and lifting
Definition at line 31 of file motors.h.
4.19.3 Function Documentation
4.19.3.1 void changeGear (int gear) [inline]
```

Changes the gear of the transmission to either driving or lifting. Runs a task in a separate thread to change the gear.

Parameters

gear the gear to change to

Definition at line 55 of file motors.h.

```
4.19.3.2 void deploy (int spd) [inline]
```

Definition at line 123 of file motors.h.

```
4.19.3.3 void intake (int spd) [inline]
```

Intakes balls using the intake mechanism by setting the intake motor values.

Parameters

spd	the speed to set the intake motors
-----	------------------------------------

Definition at line 114 of file motors.h.

```
4.19.3.4 void move (int spd, int turn) [inline]
```

Moves the robot by setting the drive motor values.

Parameters

spd	the forward/backward speed value
turn	the turning speed value

Definition at line 77 of file motors.h.

```
4.19.3.5 void shoot (int spd ) [inline]
```

Shoots balls from the shooter mechanism by setting the shooter motor values.

Parameters

spd	the speed to set the shooter motors
-----	-------------------------------------

Definition at line 98 of file motors.h.

```
4.19.3.6 void transmission (int spd) [inline]
```

Runs the transmission motor by setting the motor value.

Parameters

spd the speed to run the transmission motor

Definition at line 38 of file motors.h.

4.19.3.7 void transmissionSetPos (void * pos)

Sets the position of the transmission.

Parameters

pos the position to set the transmission to.

Definition at line 19 of file motors.c.

4.20 motors.h

```
00001
00015 #ifndef MOTORS H
00016 #define MOTORS_H_
00017
00021 #define MOTOR_MAX 127
00022
00026 #define MOTOR_MIN -127
00027
00031 #define TRANSMISSION_MOTOR 1
00032
00038 inline void transmission(int spd){
00039
         motorSet(TRANSMISSION_MOTOR, spd);
00040 }
00041
00047 void transmissionSetPos(void *pos);
00048
00055 inline void changeGear(int gear){
00056
          taskCreate(transmissionSetPos, TASK_DEFAULT_STACK_SIZE, (void *) (intptr_t) gear,
      TASK_PRIORITY_DEFAULT);
00057 }
00058
00062 #define LEFT_MOTOR_TOP 2
00063 #define LEFT_MOTOR_BOT 5
00064
00068 #define RIGHT_MOTOR_TOP 3
00069 #define RIGHT_MOTOR_BOT 4
00070
00077 inline void move(int spd, int turn) {
00078 motorSet(LEFT_MOTOR_TOP, spd + turn);
         motorSet(LEFT_MOTOR_BOT, spd + turn);
         motorSet(RIGHT_MOTOR_TOP, -spd + turn);
00081
         motorSet(RIGHT_MOTOR_BOT, -spd + turn);
00082 }
00083
00087 #define SHOOTER_HAS_THREE_MOTORS
00088
00089 #define NAUTILUS_SHOOTER_MOTOR_LEFT 6
00090 #define NAUTILUS_SHOOTER_MOTOR_RIGHT 7
00092
00098 inline void shoot(int spd) {
         motorSet (NAUTILUS_SHOOTER_MOTOR_LEFT, -spd);
00099
         motorSet(NAUTILUS_SHOOTER_MOTOR_RIGHT, spd);
00100
          motorSet(NAUTILUS_SHOOTER_MOTOR_CENTER, spd);
00101
00102 }
00103
```

```
00107 #define INTAKE_ROLLER_MOTOR 10
00114 inline void intake(int spd){
00115
        motorSet(INTAKE_ROLLER_MOTOR, spd);
00117
00118 #define ROBOT_HAS_LIFT_DEPLOY_MOTOR 1
00119
00120 #ifdef ROBOT_HAS_LIFT_DEPLOY_MOTOR
00121 #define LIFT_DEPLOY 9
00123 inline void deploy(int spd){
        motorSet(LIFT_DEPLOY, spd);
00124
00126 #endif
00128 #ifndef ROBOT_HAS_LIFT_DEPLOY_MOTOR
00129
00132 #define SHOOTER_ANGLE_MOTOR 10
00133
00139 inline void adjust(int spd) {
00140
        motorSet(SHOOTER_ANGLE_MOTOR, spd);
00141 }
00142 #endif /* SHOOTER_HAS_THREE_MOTORS */
00143
00144 #endif
00145
```

4.21 include/opcontrol.h File Reference

Header file for operator control definitions and prototypes.

Functions

- void recordJoyInfo ()
- void moveRobot ()

Variables

- int spd
- int turn
- · int sht
- int intk
- int trans
- int dep

4.21.1 Detailed Description

Header file for operator control definitions and prototypes.

This file contains definitions of the internal motor state variables and prototypes for functions that record these variables and move the robot based on their value.

Definition in file opcontrol.h.

```
4.21.2 Function Documentation
4.21.2.1 void moveRobot ( )
Moves the robot based on the motor state variables.
Definition at line 128 of file opcontrol.c.
4.21.2.2 void recordJoyInfo ( )
Populates the motor state variables based on the joystick's current values.
Definition at line 81 of file opcontrol.c.
4.21.3 Variable Documentation
4.21.3.1 int dep
Speed of the lift deployment motor.
Definition at line 65 of file opcontrol.c.
4.21.3.2 int intk
Speed of the intake motor.
Speed of the intake motors.
Definition at line 55 of file opcontrol.c.
4.21.3.3 int sht
Speed of the shooter motors.
Definition at line 50 of file opcontrol.c.
4.21.3.4 int spd
Forward/backward speed of the drive motors.
Definition at line 40 of file opcontrol.c.
4.21.3.5 int trans
Speed of the transmission motor.
Speed of the transmission motors.
Definition at line 60 of file opcontrol.c.
```

4.22 opcontrol.h 41

4.21.3.6 int turn

Turning speed of the drive motors.

Definition at line 45 of file opcontrol.c.

4.22 opcontrol.h

```
00001
00008 #ifndef OPCONTROL_H
00009 #define OPCONTROL_H
00010
00014 extern int spd;
00015
00019 extern int turn;
00020
00024 extern int sht;
00025
00029 extern int intk;
00030
00034 extern int trans;
00035
00039 extern int dep;
00040
00044 void recordJoyInfo();
00045
00049 void moveRobot();
00050
00051 #endif
00052
```

4.23 include/robot.h File Reference

File for robot constant definitions.

Macros

- #define DRIVE_WHEELBASE 16
- #define DRIVE_DIA 3
- #define DRIVE_GEARRATIO 1

4.23.1 Detailed Description

File for robot constant definitions.

This file contains definitions for constants regarding the robot. These definitions pertain to physical properties of the robot.

Definition in file robot.h.

4.23.2 Macro Definition Documentation

```
4.23.2.1 #define DRIVE_DIA 3
```

Defines the diameter of the robot's wheels, in inches.

Definition at line 20 of file robot.h.

```
4.23.2.2 #define DRIVE_GEARRATIO 1
```

Defines the drive's gear ratio.

Definition at line 25 of file robot.h.

4.23.2.3 #define DRIVE_WHEELBASE 16

Defines the robot's wheelbase, in inches.

This is equivalent to the distance between the midpoints of the wheels.

Definition at line 15 of file robot.h.

4.24 robot.h

```
00001
00007 #ifndef ROBOT_H_
00008 #define ROBOT_H_
00009
00015 #define DRIVE_WHEELBASE 16
00016
00020 #define DRIVE_DIA 3
00021
00025 #define DRIVE_GEARRATIO 1
00026
00027 #endif
```

4.25 include/sensors.h File Reference

File for important sensor declarations and functions.

Macros

- #define LEFT_ENC_TOP 1
- #define LEFT ENC BOT 2
- #define RIGHT_ENC_TOP 3
- #define RIGHT_ENC_BOT 4
- #define TRANSMISSION POT 2
- #define GEAR_DRIVE 1860
- #define GEAR LIFT 4095
- #define POWER EXPANDER STATUS 3
- #define POWER_EXPANDER_VOLTAGE_DIVISOR 280
- #define NUM BATTS 3
- #define BATT MAIN 0
- #define BATT BKUP 1
- #define BATT_PEXP 2
- #define GYRO PORT 4
- #define GYRO SENSITIVITY 0
- #define GYRO NET TARGET 0
- #define GYRO P 10
- #define SHOOTER_LIMIT 5
- #define ULTRASONIC_ECHO_PORT 11
- #define ULTRASONIC_PING_PORT 12

Functions

- void clearDriveEncoders ()
- · void lturn (int bodydegs)
- · void rturn (int bodydegs)
- void goForward (int inches)
- void goBackward (int inches)
- unsigned int powerLevelExpander ()

Variables

- Encoder leftenc
- Encoder rightenc
- · Gyro gyro
- Ultrasonic sonar

4.25.1 Detailed Description

File for important sensor declarations and functions.

This file contains the code for declarations and functions regarding sensors. The definitions contained herein define sensor ports. The functions contained herein process certain sensor values for later use.

Some functions defined herein are too complex to be defined as inline functions in the sensors.h file. Additionally, some sensors must be instantiated as object types. See the sensors.c file for these more object instantiations and function definitions

See also

sensors.c

Definition in file sensors.h.

4.25.2 Macro Definition Documentation 4.25.2.1 #define BATT_BKUP 1 Battery ID number of the robot's backup battery. Definition at line 126 of file sensors.h. 4.25.2.2 #define BATT_MAIN 0 Battery ID number of the robot's main battery. Definition at line 121 of file sensors.h. 4.25.2.3 #define BATT_PEXP 2 Battery ID number of the power expander's battery. Definition at line 131 of file sensors.h. 4.25.2.4 #define GEAR_DRIVE 1860 Defines potentiometer values for drive gearing. Definition at line 84 of file sensors.h. 4.25.2.5 #define GEAR_LIFT 4095 Defines potentiometer values for lift gearing. Definition at line 89 of file sensors.h. 4.25.2.6 #define GYRO_NET_TARGET 0 Defines gyroscope target angle for the opposite corner net. Definition at line 146 of file sensors.h. 4.25.2.7 #define GYRO_P 10 Defines the proportional error-correction term for the gyroscope alignment velocity control loop. Definition at line 151 of file sensors.h. 4.25.2.8 #define GYRO_PORT 4 Defines the port for the gyroscope. Definition at line 136 of file sensors.h.

4.25.2.9 #define GYRO_SENSITIVITY 0

Defines the gyroscope sensitivity. A value of zero represents the default sensitivity.

Definition at line 141 of file sensors.h.

4.25.2.10 #define LEFT ENC BOT 2

Definition at line 22 of file sensors.h.

4.25.2.11 #define LEFT_ENC_TOP 1

Defines the encoder ports on the left side of the drivetrain.

Definition at line 21 of file sensors.h.

4.25.2.12 #define NUM_BATTS 3

The number of batteries present on the robot.

Definition at line 116 of file sensors.h.

4.25.2.13 #define POWER_EXPANDER_STATUS 3

Defines power expander status port. This is used to get the power expander battery voltage.

Definition at line 95 of file sensors.h.

4.25.2.14 #define POWER_EXPANDER_VOLTAGE_DIVISOR 280

Defines power expander divisor. This varies by hardware revision. This value is for hardware revision A2. The sensor's value is divided by this to get the battery voltage.

Definition at line 102 of file sensors.h.

4.25.2.15 #define RIGHT_ENC_BOT 4

Definition at line 33 of file sensors.h.

4.25.2.16 #define RIGHT_ENC_TOP 3

Defines the encoder ports on the right side of the drivetrain.

Definition at line 32 of file sensors.h.

4.25.2.17 #define SHOOTER_LIMIT 5

Defines the port for the limit switch that is triggered when the shooter fires.

Definition at line 161 of file sensors.h.

4.25.2.18 #define TRANSMISSION_POT 2

Defines the transmission potentiometer for position determination.

Definition at line 79 of file sensors.h.

4.25.2.19 #define ULTRASONIC_ECHO_PORT 11

Defines the port for the ultrasonic echo wire (orange).

Definition at line 166 of file sensors.h.

4.25.2.20 #define ULTRASONIC_PING_PORT 12

Defines the port for the ultrasonic ping wire (yellow).

Definition at line 171 of file sensors.h.

4.25.3 Function Documentation

4.25.3.1 void clear Drive Encoders () [inline]

Clears the drive encoders by resetting their value to zero.

Definition at line 43 of file sensors.h.

4.25.3.2 void goBackward (int inches)

Moves the robot backward a specified distance.

Parameters

inches the amount of inches to move backward

Definition at line 71 of file sensors.c.

4.25.3.3 void goForward (int inches)

Moves the robot forward a specified distance.

Parameters

inches the amount of inches to move forward

Definition at line 55 of file sensors.c.

4.25.3.4 void lturn (int bodydegs)

Turns the robot left to a specified angle.

Parameters

bodydegs the amount of degrees to turn the robot

Definition at line 40 of file sensors.c.

4.25.3.5 unsigned int powerLevelExpander() [inline]

Returns the electric potential of the power expander battery in millivolts.

Returns

the power expander battery voltage, in millivolts

Definition at line 109 of file sensors.h.

4.25.3.6 void rturn (int bodydegs)

Turns the robot right to a specified angle.

Parameters

bodydegs the amount of degrees to turn the robot

Definition at line 25 of file sensors.c.

4.25.4 Variable Documentation

4.25.4.1 Gyro gyro

Object representing the gyroscope.

Definition at line 78 of file sensors.c.

4.25.4.2 Encoder leftenc

Object representing the encoder on the left side of the drivetrain.

Definition at line 18 of file sensors.c.

4.25.4.3 Encoder rightenc

Object representing the encoder on the right side of the drivetrain.

Definition at line 23 of file sensors.c.

4.25.4.4 Ultrasonic sonar

Object representing the ultrasonic sensor.

Definition at line 83 of file sensors.c.

4.26 sensors.h

```
00001
00015 #ifndef SENSORS H
00016 #define SENSORS_H_
00017
00021 #define LEFT_ENC_TOP 1
00022 #define LEFT_ENC_BOT 2
00023
00027 extern Encoder leftenc;
00028
00032 #define RIGHT_ENC_TOP 3
00033 #define RIGHT_ENC_BOT 4
00034
00038 extern Encoder rightenc;
00039
00043 inline void clearDriveEncoders(){
00044
         encoderReset(leftenc);
00045
          encoderReset(rightenc);
00046 }
00047
00053 void lturn(int bodydegs);
00054
00060 void rturn(int bodydegs);
00061
00067 void goForward(int inches);
00068
00074 void goBackward(int inches);
00075
00079 #define TRANSMISSION_POT 2
08000
00084 #define GEAR_DRIVE 1860
00085
00089 #define GEAR_LIFT 4095
00090
00095 #define POWER_EXPANDER_STATUS 3
00102 #define POWER_EXPANDER_VOLTAGE_DIVISOR 280 //Hardware revision A2
00109 inline unsigned int powerLevelExpander(){
         return analogRead(POWER_EXPANDER_STATUS) *1000/
00110
      POWER_EXPANDER_VOLTAGE_DIVISOR;
00111 }
00112
00116 #define NUM_BATTS 3
00117
00121 #define BATT_MAIN 0
00122
00126 #define BATT_BKUP 1
00127
00131 #define BATT_PEXP 2
00132
00136 #define GYRO_PORT 4
00137
00141 #define GYRO_SENSITIVITY 0
00142
00146 #define GYRO_NET_TARGET 0
00147
```

```
00151 #define GYRO_P 10
00152
00156 extern Gyro gyro;
00157
00161 #define SHOOTER_LIMIT 5
00162
00166 #define ULTRASONIC_ECHO_PORT 11
00167
00171 #define ULTRASONIC_PING_PORT 12
00172
00176 extern Ultrasonic sonar;
00177
00177 #endif
```

4.27 src/auto.c File Reference

File for autonomous code.

```
#include "main.h"
```

Functions

void autonomous ()

4.27.1 Detailed Description

File for autonomous code.

This file should contain the user autonomous() function and any functions related to it.

Copyright (c) 2011-2014, Purdue University ACM SIG BOTS. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Purdue University ACM SIG BOTS nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXP←RESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERC←HANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PURDUE UNIVERSITY ACM SIG BOTS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Purdue Robotics OS contains FreeRTOS (http://www.freertos.org) whose source code may be obtained from http://sourceforge.net/projects/freertos/files/or on request.

Definition in file auto.c.

4.27.2 Function Documentation

```
4.27.2.1 void autonomous ( )
```

C standard integer type header. C standard string function header. PROS main API header. Mathematical constant definitions. Useful redefinitions to make code more readable. Simple macros for performing common operations. Macros for performing bitwise operations. Sensor definitions and function declarations. Motor definitions and function declarations. Robot physical constant definitions and function declarations. LCD definitions and function declarations. LCD diagnostics menu definitions and function declarations. Hard-coded autonomous routine definitions and function declarations. Autonomous recorder definitions and function declarations. Operator control definitions and function declarations. Runs the user autonomous code. This function will be started in its own task with the default priority and stack size whenever the robot is enabled via the Field Management System or the VEX Competition Switch in the autonomous mode. If the robot is disabled or communications is lost, the autonomous task will be stopped by the kernel. Re-enabling the robot will restart the task, not re-start it from where it left off.

Code running in the autonomous task cannot access information from the VEX Joystick. However, the autonomous function can be invoked from another task if a VEX Competition Switch is not available, and it can access joystick information if called in this way.

The autonomous task may exit, unlike operatorControl() which should never exit. If it does so, the robot will await a switch to another mode or disable/enable cycle.

Definition at line 51 of file auto.c.

4.28 auto.c

```
00001
00035 #include "main.h"
00036
00037 /*
00038 * Runs the user autonomous code. This function will be started in its own task with the default
00039
      \star priority and stack size whenever the robot is enabled via the Field Management System or the
00040
      * VEX Competition Switch in the autonomous mode. If the robot is disabled or communications is
00041
      * lost, the autonomous task will be stopped by the kernel. Re-enabling the robot will restart
00042
       \star the task, not re-start it from where it left off.
00043
00044
      * Code running in the autonomous task cannot access information from the VEX Joystick. However,
00045
       \star the autonomous function can be invoked from another task if a VEX Competition Switch is not
00046
       * available, and it can access joystick information if called in this way
00047
00048
      * The autonomous task may exit, unlike operatorControl() which should never exit. If it does
00049
      * so, the robot will await a switch to another mode or disable/enable cycle.
00050 */
00051 void autonomous()
00052
          playbackAuton();
00053 }
00054
```

4.29 src/autonrecorder.c File Reference

File for autonomous recorder code.

```
#include "main.h"
```

Functions

- int selectAuton ()
- void initAutonRecorder ()
- void recordAuton ()
- void saveAuton ()
- void loadAuton ()
- void playbackAuton ()

Variables

- joyState states [AUTON_TIME *JOY_POLL_FREQ]
- · int autonLoaded
- · int progSkills

4.29.1 Detailed Description

File for autonomous recorder code.

This file contains the code for the saving, loading, and playback of autonomous files. When an autonomous routine is recorded, it is saved to a file to flash memory. This file is loaded and executed during the autonomous period of the game. It works by saving the motor values at a point in time. At the corresponding point in time, the values are played back.

This file also handles the recording of programming skills by stitching 4 autonomous routines together.

Definition in file autonrecorder.c.

```
4.29.2 Function Documentation
```

```
4.29.2.1 void initAutonRecorder ( )
```

Initializes autonomous recorder by setting states array to zero.

Definition at line 74 of file autonrecorder.c.

```
4.29.2.2 void loadAuton ( )
```

Loads autonomous file contents into states array.

Definition at line 218 of file autonrecorder.c.

```
4.29.2.3 void playbackAuton ( )
```

Replays autonomous based on loaded values in states array.

Definition at line 317 of file autonrecorder.c.

```
4.29.2.4 void recordAuton ( )
Records driver joystick values into states array.
Definition at line 90 of file autonrecorder.c.
4.29.2.5 void saveAuton ( )
Saves contents of the states array to a file in flash memory.
Definition at line 135 of file autonrecorder.c.
4.29.2.6 int selectAuton ( )
Selects which autonomous file to use based on the potentiometer reading.
Returns
     the autonomous selected (slot number)
Definition at line 36 of file autonrecorder.c.
4.29.3 Variable Documentation
4.29.3.1 int autonLoaded
Slot number of currently loaded autonomous routine.
Definition at line 24 of file autonrecorder.c.
4.29.3.2 int progSkills
Section number (0-3) of currently loaded programming skills routine.
Definition at line 29 of file autonrecorder.c.
4.29.3.3 joyState states[AUTON_TIME *JOY_POLL_FREQ]
Stores the joystick state variables for moving the robot. Used for recording and playing back autonomous routines.
```

Definition at line 19 of file autonrecorder.c.

4.30 autonrecorder.c 53

4.30 autonrecorder.c

```
00001
00013 #include "main.h"
00014
00019 joyState states[AUTON_TIME*JOY_POLL_FREQ];
00020
00024 int autonLoaded;
00025
00029 int progSkills;
00030
00036 int selectAuton() {
          bool done = false;
          int val;
00039
          do {
00040
               val = (float) ((float) analogRead(AUTON_POT)/(float)
     AUTON_POT_HIGH) * (MAX_AUTON_SLOTS+3);
               if (val > MAX_AUTON_SLOTS+2) {
00042
                   val = MAX_AUTON_SLOTS+2;
00043
00044
               if (val == 0) {
                   lcdSetText(LCD_PORT, 2, "NONE");
00045
00046
               } else if(val == MAX_AUTON_SLOTS+1) {
00047
                   lcdSetText(LCD_PORT, 2, "Prog. Skills");
               } else if (val == MAX_AUTON_SLOTS+2) {
00048
00049
                  lcdSetText(LCD_PORT, 2, "Hardcoded Skills");
00050
               } else {
                  char filename[AUTON_FILENAME_MAX_LENGTH];
00051
                   snprintf(filename, sizeof(filename)/sizeof(char), "a%d", val);
FILE* autonFile = fopen(filename, "r");
00052
00053
                   if (autonFile == NULL) {
00054
00055
                       lcdPrint(LCD_PORT, 2, "Slot: %d (EMPTY)", val);
00056
                   } else {
                       char name[LCD_MESSAGE_MAX_LENGTH+1];
00057
00058
                       memset(name, 0, sizeof(name));
                        fread(name, sizeof(char), sizeof(name) / sizeof(char), autonFile);
00059
                       lcdSetText(LCD_PORT, 2, name);
00060
00061
                       fclose(autonFile);
00062
                   }
00063
00064
               done = (digitalRead(AUTON_BUTTON) == PRESSED);
00065
               delay(20);
00066
          } while(!done);
          printf("Selected autonomous: %d\n", val);
00067
00068
          return val;
00069 }
00070
00074 void initAutonRecorder() {
00075
          printf("Beginning initialization of autonomous recorder...\n");
00076
          lcdClear(LCD_PORT);
          lcdSetText(LCD_PORT, 1, "Init recorder...");
lcdSetText(LCD_PORT, 2, "");
00077
00078
00079
          memset(states, 0, sizeof(*states));
00080
          printf("Completed initialization of autonomous recorder.\n");
          lcdSetText(LCD_PORT, 1, "Init-ed recorder!");
lcdSetText(LCD_PORT, 2, "");
00081
00082
00083
          autonLoaded = -1;
00084
          progSkills = 0;
00085 }
00086
00090 void recordAuton() {
00091
          lcdClear(LCD_PORT);
          for (int i = 3; i > 0; i--) {
00092
00093
               lcdSetBacklight(LCD_PORT, true);
00094
               printf("Beginning autonomous recording in %d...\n", i);
00095
               lcdSetText(LCD_PORT, 1, "Recording auton");
               lcdPrint(LCD_PORT, 2, "in %d...", i);
00096
00097
               delay(1000);
00098
00099
          printf("Ready to begin autonomous recording.\n");
          lcdSetText(LCD_PORT, 1, "Recording auton...");
lcdSetText(LCD_PORT, 2, "");
00100
00101
00102
          bool lightState = false;
00103
          for (int i = 0; i < AUTON_TIME * JOY_POLL_FREQ; i++) {</pre>
               printf("Recording state %d...\n", i);
00104
               lcdSetBacklight(LCD_PORT, lightState);
00105
00106
               lightState = !lightState;
               recordJoyInfo();
00107
               states[i].spd = spd;
00108
00109
               states[i].turn = turn;
```

```
00110
               states[i].sht = sht;
00111
               states[i].intk = intk;
00112
               states[i].trans = trans;
               states[i].dep = dep;
00113
00114
               if (joystickGetDigital(1, 7, JOY_UP)) {
00115
                    printf("Autonomous recording manually cancelled.\n");
                    lcdSetText(LCD_PORT, 1, "Cancelled record.");
lcdSetText(LCD_PORT, 2, "");
00116
00117
                    memset(states + i + 1, 0, sizeof(joyState) * (AUTON_TIME * JOY_POLL_FREQ - i
00118
      - 1));
00119
                    i = AUTON TIME * JOY POLL FREO:
00120
00121
               moveRobot();
               delay(1000 / JOY_POLL_FREQ);
00123
00124
           printf("Completed autonomous recording.\n");
           lcdSetText(LCD_PORT, 1, "Recorded auton!");
lcdSetText(LCD_PORT, 2, "");
00125
00126
00127
           motorStopAll();
00128
           delay(1000);
00129
           autonLoaded = 0;
00130 }
00131
00135 void saveAuton() {
           printf("Waiting for file selection...\n");
00136
00137
           lcdClear(LCD PORT);
           lcdSetText(LCD_PORT, 1, "Save to?");
lcdSetText(LCD_PORT, 2, "");
00138
00139
           int autonSlot;
00140
00141
           if(progSkills == 0) {
00142
               autonSlot = selectAuton();
00143
           } else {
               printf("Currently in the middle of a programming skills run.\n");
00144
00145
               autonSlot = MAX AUTON SLOTS + 1;
00146
           char name[LCD_MESSAGE_MAX_LENGTH+1];
00147
00148
           memset(name, 0, sizeof(name));
00149
           if(autonSlot == 0) {
               printf("Not saving this autonomous!\n");
00150
00151
               return;
00152
           } else if(autonSlot != MAX_AUTON_SLOTS+1) {
00153
               typeString(name);
00154
           lcdSetText(LCD_PORT, 1, "Saving auton...");
00155
00156
           char filename[AUTON_FILENAME_MAX_LENGTH];
00157
           if (autonSlot != MAX_AUTON_SLOTS + 1) {
               printf("Not doing programming skills, recording to slot d.\n", autonSlot); snprintf(filename, sizeof(filename)/sizeof(char), "a%d", autonSlot);
00158
00159
00160
                //lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
               lcdPrint(LCD_PORT, 2, "%s", name);
00161
           } else {
00162
00163
               printf("Doing programming skills, recording to section %d.\n",
      progSkills);
00164
               snprintf(filename, sizeof(filename)/sizeof(char), "p%d", progSkills);
00165
               lcdPrint(LCD_PORT, 2, "Skills Part: %d", progSkills+1);
00166
00167
           printf("Saving to file %s...\n", filename);
00168
           FILE *autonFile = fopen(filename, "w");
00169
           if (autonFile == NULL) {
00170
               printf("Error saving autonomous in file %s!\n", filename);
00171
               lcdSetText(LCD_PORT, 1, "Error saving!");
00172
               if (autonSlot != MAX_AUTON_SLOTS + 1) {
00173
                    printf("Not \ doing \ programming \ skills, \ error \ saving \ auton \ in \ slot \ %d!\n", \ autonSlot);
                    lcdSetText(LCD_PORT, 1, "Error saving!");
lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
00174
00175
00176
               } else {
00177
                    printf("Doing programming skills, error saving auton in section 0!\n");
                    lcdSetText(LCD_PORT, 1, "Error saving!");
lcdSetText(LCD_PORT, 2, "Prog. Skills");
00178
00179
00180
00181
               delay(1000);
00182
               return:
00183
00184
           if (autonSlot != MAX_AUTON_SLOTS+1) {
00185
               fwrite(name, sizeof(char), sizeof(name) / sizeof(char), autonFile);
00186
           for (int i = 0; i < AUTON_TIME * JOY_POLL_FREQ; i++) {</pre>
00187
               printf("Recording state %d to file %s...\n", i, filename);
00188
               signed char write[6] = {states[i].spd, states[i].turn, states[i].
00189
      sht, states[i].intk, states[i].trans,
00190
                                          states[i].dep};
```

4.30 autonrecorder.c 55

```
00191
                fwrite(write, sizeof(char), sizeof(write) / sizeof(char), autonFile);
00192
                delay(10);
00193
00194
           fclose(autonFile);
           printf("Completed saving autonomous to file %s.\n", filename); lcdSetText(LCD_PORT, 1, "Saved auton!");
00195
00196
00197
           if (autonSlot != MAX_AUTON_SLOTS + 1) {
00198
                printf("Not doing programming skills, recorded to slot %d.\n",autonSlot);
00199
                lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
00200
           } else {
00201
                printf("Doing programming skills, recorded to section %d.\n", progSkills);
                lcdPrint(LCD_PORT, 2, "Skills Part: %d", progSkills+1);
00202
00203
00204
           delay(1000);
00205
           if (autonSlot == MAX_AUTON_SLOTS + 1) {
00206
                printf("Proceeding to next programming skills section (%d).\n", ++
      progSkills);
00207
00208
           if (progSkills == PROGSKILL_TIME/AUTON_TIME) {
00209
                printf("Finished recording programming skills (all parts).\n");
00210
                progSkills = 0;
00211
00212
           autonLoaded = autonSlot;
00213 }
00214
00218 void loadAuton() {
00219
           lcdClear(LCD_PORT);
           bool done = false;
00220
00221
           int autonSlot:
00222
           FILE* autonFile:
00223
           char filename[AUTON_FILENAME_MAX_LENGTH];
00224
                printf("Waiting for file selection...\n");
lcdSetText(LCD_PORT, 1, "Load from?");
lcdSetText(LCD_PORT, 2, "");
00225
00226
00227
                autonSlot = selectAuton();
00228
00229
                if (autonSlot == 0) {
                    printf("Not loading an autonomous!\n");
00230
                    lcdSetText(LCD_PORT, 1, "Not loading!");
lcdSetText(LCD_PORT, 2, "");
00231
00232
00233
                    autonLoaded = 0;
00234
                    return;
00235
                } else if(autonSlot == MAX_AUTON_SLOTS + 1) {
00236
                    printf("Performing programming skills.\n");
                    lcdSetText(LCD_PORT, 1, "Loading skills...");
lcdPrint(LCD_PORT, 2, "Skills Part: 1");
00237
00238
                    autonLoaded = MAX_AUTON_SLOTS + 1;
00239
00240
                } else if (autonSlot == MAX_AUTON_SLOTS + 2) {
00241
                    printf("Performing hard-coded programming skills.\n");
                    lcdSetText(LCD_PORT, 1, "Loading skills...");
lcdPrint(LCD_PORT, 2, "Hardcoded Skills");
00242
00243
00244
                     autonLoaded = MAX_AUTON_SLOTS + 2;
00245
                     return;
00246
                } else if(autonSlot == autonLoaded) {
                    printf("Autonomous %d is already loaded.\n", autonSlot);
lcdSetText(LCD_PORT, 1, "Loaded auton!");
lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
00247
00248
00249
00250
00251
00252
                printf("Loading autonomous from slot %d...\n", autonSlot);
                if(autonSlot != MAX_AUTON_SLOTS + 1) {
00253
00254
00255
                    lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
00256
00257
                if(autonSlot != MAX_AUTON_SLOTS + 1) {
                    printf("Not doing programming skills, loading slot %d\n", autonSlot);
00258
                     snprintf(filename, sizeof(filename)/sizeof(char), "a%d", autonSlot);
00259
00260
                } else {
00261
                    printf("Doing programming skills, loading section 0.\n");
00262
                     snprintf(filename, sizeof(filename)/sizeof(char), "p0");
00263
                printf("Loading from file %s...\n",filename);
autonFile = fopen(filename, "r");
00264
00265
00266
                if (autonFile == NULL) {
00267
                    printf("No autonomous was saved in file %s!\n", filename);
00268
                     lcdSetText(LCD_PORT, 1, "No auton saved!");
                     if (autonSlot != MAX AUTON SLOTS + 1) {
00269
00270
                         printf("Not doing programming skills, no auton in slot %d!\n", autonSlot);
                         lcdSetText(LCD_PORT, 1, "No auton saved!");
lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
00271
                         lcdPrint(LCD_PORT, 2,
00272
00273
                     } else {
```

```
00274
                         printf("Doing programming skills, no auton in section 0!\n");
00275
                         lcdSetText(LCD_PORT, 1, "No skills saved!");
00276
00277
                    delay(1000);
00278
               } else {
00279
                    done = true;
00280
00281
           } while(!done);
00282
           fseek(autonFile, 0, SEEK_SET);
           char name[LCD_MESSAGE_MAX_LENGTH+1];
00283
00284
           memset(name, 0, sizeof(name));
00285
           if(autonSlot != MAX_AUTON_SLOTS + 1) {
00286
                fread(name, sizeof(char), sizeof(name) / sizeof(char), autonFile);
00287
00288
           for (int i = 0; i < AUTON_TIME * JOY_POLL_FREQ; i++) {</pre>
00289
               printf("Loading state %d from file %s...\n", i, filename);
00290
                char read[6] = \{0, 0, 0, 0, 0, 0\};
00291
                fread(read, sizeof(char), sizeof(read) / sizeof(char), autonFile);
00292
                states[i].spd = (signed char) read[0];
               states[i].turn = (signed char) read[1];
00293
               states[i].sht = (signed char) read[2];
00294
               states[i].intk = (signed char) read[3];
00295
               states[i].trans = (signed char) read[4];
00296
00297
               states[i].dep = (signed char) read[5];
00298
               delay(10);
00299
00300
           fclose(autonFile);
00301
           printf("Completed loading autonomous from file %s.\n", filename);
           if(autonSlot != MAX_AUTON_SLOTS + 1) {
00302
00303
               printf("Not doing programming skills, loaded from slot %d.\n", autonSlot);
//lcdPrint(LCD_PORT, 2, "Slot: %d", autonSlot);
lcdPrint(LCD_PORT, 2, "%s", name);
00304
00305
00306
00307
           } else {
               printf("Doing programming skills, loaded from section %d.\n", progSkills);
lcdSetText(LCD_PORT, 2, "Skills Section: 1");
00308
00309
00310
00311
           autonLoaded = autonSlot;
00312 }
00313
00317 void playbackAuton() { //must load autonomous first!
00318
           if (autonLoaded == -1 /* nothing in memory */) {
               printf("No autonomous loaded, entering loadAuton()\n");
00319
00320
                loadAuton();
00321
00322
           if(autonLoaded == 0) {
00323
               printf("autonLoaded = 0, doing nothing.\n");
00324
                return;
00325
           } else if (autonLoaded == MAX_AUTON_SLOTS + 2) {
00326
               runHardCodedProgrammingSkills();
00327
                return;
00328
00329
           printf("Beginning playback...\n");
           lcdSetText(LCD_PORT, 1, "Playing back...");
lcdSetText(LCD_PORT, 2, "");
00330
00331
00332
           lcdSetBacklight(LCD_PORT, true);
00333
           int file=0;
00334
           do{
00335
               FILE* nextFile = NULL;
                lcdPrint(LCD_PORT, 2, "File: %d", file+1);
00336
               char filename[AUTON_FILENAME_MAX_LENGTH];
00337
00338
                if(autonLoaded == MAX_AUTON_SLOTS + 1 && file <</pre>
      PROGSKILL_TIME/AUTON_TIME - 1) {
00339
                    printf("Next section: %d\n", file+1);
00340
                    snprintf(filename, sizeof(filename)/sizeof(char), "p%d", file+1);
00341
                    nextFile = fopen(filename, "r");
00342
00343
               for(int i = 0; i < AUTON_TIME * JOY_POLL_FREQ; i++) {</pre>
                    printf("Playing back state %d...\n", i);
00344
00345
                    spd = states[i].spd;
00346
                    turn = states[i].turn;
00347
                    sht = states[i].sht;
00348
                    intk = states[i].intk;
00349
                    trans = states[i].trans;
00350
                    dep = states[i].dep;
00351
                    if (joystickGetDigital(1, 7, JOY_UP) && !isOnline()) {
                        printf("Playback manually cancelled.\n");
lcdSetText(LCD_PORT, 1, "Cancelled playback.");
00352
                        lcdSetText(LCD_PORT, 1, "Cand
lcdSetText(LCD_PORT, 2, "");
00353
00354
                        i = AUTON_TIME * JOY_POLL_FREQ;
file = PROGSKILL_TIME/AUTON_TIME;
00355
00356
```

```
00357
00358
                  moveRobot();
00359
                   if(autonLoaded == MAX_AUTON_SLOTS + 1 && file <</pre>
      PROGSKILL_TIME/AUTON_TIME - 1) {
00360
                       printf("Loading state %d from file %s...\n", i, filename);
00361
                       char read[6] = \{0, 0, 0, 0, 0, 0\};
                       fread(read, sizeof(char), sizeof(read) / sizeof(char), nextFile);
00363
                       states[i].spd = (signed char) read[0];
00364
                       states[i].turn = (signed char) read[1];
                      states[i].sht = (signed char) read[2];
                       states[i].intk = (signed char) read[3];
                       states[i].trans = (signed char) read[4];
00367
00368
                       states[i].dep = (signed char) read[5];
00370
                  delay(1000 / JOY_POLL_FREQ);
00371
00372
               if(autonLoaded == MAX_AUTON_SLOTS + 1 && file <</pre>
     PROGSKILL_TIME/AUTON_TIME - 1) {
00373
                  printf("Finished with section %d, closing file.\n", file+1);
00374
                   fclose(nextFile);
00375
00376
              file++;
00377
          } while(autonLoaded == MAX_AUTON_SLOTS + 1 && file <</pre>
     PROGSKILL_TIME/AUTON_TIME);
00378
         motorStopAll();
00379
          printf("Completed playback.\n");
          lcdSetText(LCD_PORT, 1, "Played back!");
lcdSetText(LCD_PORT, 2, "");
00380
00381
          delay(1000);
00382
00383 }
00384
```

4.31 src/autonroutines.c File Reference

File for hard-coded autonomous routines.

```
#include "main.h"
```

Functions

• void runHardCodedProgrammingSkills ()

4.31.1 Detailed Description

File for hard-coded autonomous routines.

This file contains code for hard-coded autonomous routines that use sensors.

Definition in file autonroutines.c.

4.31.2 Function Documentation

4.31.2.1 void runHardCodedProgrammingSkills ()

Runs a programming skills routine using sensors rather than the autonomous recorder. Starts in the left side of the field shooting into the closer goal.

Definition at line 13 of file autonroutines.c.

4.32 autonroutines.c

```
00001
00007 #include "main.h"
00008
00013 void runHardCodedProgrammingSkills() {
00014
          int numShots = 0;
          bool shooterLimitPressed = PRESSED;
00015
00016
          shoot (-127);
          while (numShots - 1 <= 32 / \star one shot subtracted because the shooter starts uncocked \star /) {
00017
              if (shooterLimitPressed == PRESSED && digitalRead(SHOOTER_LIMIT) ==
00018
     UNPRESSED) {
00019
                  numShots++:
00020
00021
              shooterLimitPressed = digitalRead(SHOOTER_LIMIT);
00022
              delay(20);
00023
00024
          shoot (0);
00025
          while (gyroGet(gyro) % ROTATION_DEG != -90 -
00026
     CLOSE_GOAL_ANGLE /* turning right */) {
00027
              int error = (-90 - CLOSE_GOAL_ANGLE) - gyroGet(gyro) %
     ROTATION_DEG;
00028
              move(0, error * GYRO_P);
00029
00030
          while (ultrasonicGet(sonar) < DISTANCE_TO_OTHER_SIDE - 30) {</pre>
00031
             move(127, 0);
00032
00033
          while (ultrasonicGet(sonar) < DISTANCE_TO_OTHER_SIDE) {</pre>
00034
              move(64, 0);
00035
00036
          while (gyroGet(gyro) % ROTATION_DEG != -2*CLOSE_GOAL_ANGLE /* turning
00037
              int error = (-2*CLOSE_GOAL_ANGLE) - gyroGet(gyro) %
     ROTATION_DEG;
00038
              move(0, error * GYRO_P);
00039
00040
00041
          numShots = 0;
00042
          shooterLimitPressed = digitalRead(SHOOTER_LIMIT);
00043
          shoot (-127);
00044
          while (numShots - 1 <= 32 /\star one shot subtracted because the shooter starts uncocked \star/) {
00045
              if (shooterLimitPressed == PRESSED && digitalRead(SHOOTER_LIMIT) ==
     UNPRESSED) {
00046
                  numShots++;
00047
00048
              shooterLimitPressed = digitalRead(SHOOTER_LIMIT);
00049
              delay(20);
00050
00051
          shoot(0);
00052 }
00053
```

4.33 src/init.c File Reference

File for initialization code.

```
#include "main.h"
```

Functions

- void initializeIO ()
- · void initialize ()

4.33.1 Detailed Description

File for initialization code.

This file should contain the user initialize() function and any functions related to it.

Copyright (c) 2011-2014, Purdue University ACM SIG BOTS. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Purdue University ACM SIG BOTS nor the names of its contributors may be used to endorse
 or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXP←RESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERC←HANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PURDUE UNIVERSITY ACM SIG BOTS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Purdue Robotics OS contains FreeRTOS (http://www.freertos.org) whose source code may be obtained from http://sourceforge.net/projects/freertos/files/or on request.

Definition in file init.c.

4.33.2 Function Documentation

4.33.2.1 void initialize ()

Runs user initialization code. This function will be started in its own task with the default priority and stack size once when the robot is starting up. It is possible that the VEXnet communication link may not be fully established at this time, so reading from the VEX Joystick may fail.

This function should initialize most sensors (gyro, encoders, ultrasonics), LCDs, global variables, and IMEs.

This function must exit relatively promptly, or the operatorControl() and autonomous() tasks will not start. An autonomous mode selection menu like the pre_auton() in other environments can be implemented in this task if desired.

Definition at line 61 of file init.c.

```
4.33.2.2 void initializeIO ( )
```

Runs pre-initialization code. This function will be started in kernel mode one time while the VEX Cortex is starting up. As the scheduler is still paused, most API functions will fail.

The purpose of this function is solely to set the default pin modes (pinMode()) and port states (digitalWrite()) of limit switches, push buttons, and solenoids. It can also safely configure a UART port (usartOpen()) but cannot set up an LCD (lcdlnit()).

Definition at line 45 of file init.c.

4.34 init.c

```
00001
00035 #include "main.h"
00036
00037 /*
00038 \,\star\, Runs pre-initialization code. This function will be started in kernel mode one time while the
00039 * VEX Cortex is starting up. As the scheduler is still paused, most API functions will fail.
00040 *
00041
       \star The purpose of this function is solely to set the default pin modes (pinMode()) and port
00042
       \star states (digitalWrite()) of limit switches, push buttons, and solenoids. It can also safely
00043
       * configure a UART port (usartOpen()) but cannot set up an LCD (lcdInit()).
00044 */
00045 void initializeIO() {
00046 }
00047
00048 /*
00049 \,\star\, Runs user initialization code. This function will be started in its own task with the default
      * priority and stack size once when the robot is starting up. It is possible that the VEXnet
00051
       \star communication link may not be fully established at this time, so reading from the VEX
00052
       * Joystick may fail.
00053
00054
       * This function should initialize most sensors (gyro, encoders, ultrasonics), LCDs, global
00055
       * variables, and IMEs.
00056
       \star This function must exit relatively promptly, or the operatorControl() and autonomous() tasks
00058
       * will not start. An autonomous mode selection menu like the pre_auton() in other environments
00059
       * can be implemented in this task if desired.
00060
00061 void initialize() {
00062
          int seed = powerLevelMain() + powerLevelBackup();
          for(int i = 0; i < BOARD_NR_ADC_PINS; i++) {</pre>
00063
00064
              seed += analogRead(i);
00066
          srand(seed);
          pinMode(SHOOTER_LIMIT, INPUT);
00068
          leftenc = encoderInit(LEFT_ENC_TOP, LEFT_ENC_BOT, false);
          rightenc = encoderInit(RIGHT_ENC_TOP, RIGHT_ENC_BOT, false);
00070
          lcdInit(LCD_PORT);
00071
          lcdClear(LCD_PORT);
00072
          lcdSetBacklight(LCD_PORT, true);
          lcdSetText(LCD_PORT, 1, "Init-ing gyro...");
gyro = gyroInit(GYRO_PORT, GYRO_SENSITIVITY);
00073
00074
00075
          sonar = ultrasonicInit(ULTRASONIC_ECHO_PORT,
      ULTRASONIC_PING_PORT);
00076
          delay(1100);
00077
          gyroReset (gyro);
00078
          lcdSetText(LCD_PORT, 1, "Init-ed gyro!");
00079
          initAutonRecorder();
00080
          initGroups();
00081
          if(isOnline()){
00082
              loadAuton();
00083
00084 }
00085
```

4.35 src/lcddiag.c File Reference

File for LCD diagnostic menu code.

```
#include "main.h"
```

Functions

- char * typeString (char *dest)
- void saveGroups ()
- · void loadGroups ()
- void initGroups ()
- void formatMenuNameCenter (FILE *lcdport, int line, int index)
- int selectMenu ()
- void runScreensaver (FILE *Icdport)
- void runBattery (FILE *Icdport)
- int selectMotor (FILE *Icdport)
- int selectSpd (int mtr)
- void runIndivMotor (FILE *lcdport)
- int selectMotorGroup (FILE *lcdport)
- int selectSpdGroup (int mtr)
- void runGroupMotor (FILE *Icdport)
- void runMotor (FILE *Icdport)
- bool * selectMotorGroupMembers (bool *motor)
- void addMotorGroup ()
- void editMotorGroup (int mtr)
- void delMotorGroup (int mtr)
- void runMotorGroupMgmt (FILE *Icdport)
- void runConnection (FILE *Icdport)
- void runRobot (FILE *lcdport)
- void runAuton (FILE *Icdport)
- void runCredits (FILE *Icdport)
- void doMenuChoice (int choice)
- void formatLCDDisplay (void *ignore)

Variables

- TaskHandle lcdDiagTask = NULL
- bool backlight = true
- bool disableOpControl = false
- MotorGroup * groups
- int numgroups
- char menuChoices [LCD MENU COUNT][LCD MESSAGE MAX LENGTH+1]

4.35.1 Detailed Description

File for LCD diagnostic menu code.

This file contains the code for the LCD diagnostic menu. The menu provides live debugging and testing functionality. It provides the following functions:

- · Motor testing functionality (individual and group)
- · Motor group management
- · Battery voltage information
- · Joystick connection status
- · Robot sensory data
- · Autonomous recorder status
- · LCD backlight toggle
- · Screensaver that displays during operator control
- · Credits menu

The idea behind this was inspired by Team 750W and Akram Sandhu. Without them, this project would not be possible.

Note: the implementation of this feature is completely different between the two teams. No code was reused from their implementation of the LCD diagnostic menu.

Definition in file lcddiag.c.

4.35.2 Function Documentation

4.35.2.1 void addMotorGroup ()

Adds a new motor group to the dynamic array.

Definition at line 899 of file lcddiag.c.

4.35.2.2 void delMotorGroup (int mtr)

Deletes a motor group. Prompts the user whether to cancel or to proceed with deletion.

Parameters

mtr the ID number to delete

Definition at line 970 of file lcddiag.c.

4.35.2.3 void doMenuChoice (int choice)

Dispatcher function that executes the selected LCD diagnostic menu function. This function is called with the result of selectMenu().

See also

selectMenu()

Parameters

choice	the selected menu to run
--------	--------------------------

Definition at line 1276 of file lcddiag.c.

4.35.2.4 void editMotorGroup (int mtr)

Edits a motor group. Prompts the user to either edit the name or the motors in a motor group.

Parameters

it

Definition at line 915 of file lcddiag.c.

4.35.2.5 void formatLCDDisplay (void * ignore)

Runs the LCD diagnostic menu task. This thread executes concurrently with the operator control task. The LCD diagnostic menu starts in screensaver mode. Pressing any button cancels screensaver mode and enters the selection menu.

Parameters

ignore	does nothing - required by task definition
--------	--

Definition at line 1298 of file lcddiag.c.

4.35.2.6 void formatMenuNameCenter (FILE * Icdport, int line, int index)

Formats the LCD diagnostic menu name in the center of the screen.

Parameters

Icdport	the LCD screen's port (either UART1 or UART2)
line	the line on the LCD to print the name
index	the ID number of the menu

Definition at line 282 of file lcddiag.c.

```
4.35.2.7 void initGroups ( )
```

Initializes the motor groups array to contain the standard set of groups. This includes: Left Drive, Right Drive, Full Drive, Nautilus Shooter, Intake, and Transmission.

Definition at line 230 of file lcddiag.c.

```
4.35.2.8 void loadGroups ( )
```

Loads motor groups from a file on the Cortex flash memory. This is used to add custom motor groups for testing purposes.

Definition at line 198 of file lcddiag.c.

```
4.35.2.9 void runAuton (FILE * Icdport )
```

Runs the autonomous recorder status menu. Displays the autonomous that is currently loaded, and if controller playback is enabled. Controller playback is automatically disabled when plugged into the competition switch.

Parameters

Icdport the LCD screen's port (either	r UART1 or UART2)
---------------------------------------	-------------------

Definition at line 1168 of file lcddiag.c.

```
4.35.2.10 void runBattery (FILE * lcdport)
```

Displays the battery voltages, allowing for switching between batteries.

Parameters

	lcdport	the LCD screen's port (either UART1 or UART2)
--	---------	---

Definition at line 354 of file lcddiag.c.

```
4.35.2.11 void runConnection (FILE * Icdport )
```

Runs the joystick connection debugging menu. Prints whether the main and partner joysticks are connected.

Parameters

Icdport	the LCD screen's port (either UART1 or UART2)
---------	---

Definition at line 1068 of file lcddiag.c.

```
4.35.2.12 void runCredits (FILE * Icdport )
```

Runs the credits menu. The LCD diagnostic menu was inspired by Team 750W and Akram Sandhu. This would not be possible without their generosity and permissiveness to use their idea.

Note: the implementation of this feature is completely different between the two teams. No code was reused from their implementation of the LCD diagnostic menu.

Parameters

```
Icdport the LCD screen's port (either UART1 or UART2)
```

Definition at line 1233 of file lcddiag.c.

```
4.35.2.13 void runGroupMotor (FILE * Icdport )
```

Runs the motor group test. Selection of the motor group and speed is handled by other functions.

See also

```
selectMotorGroup()
selectSpdGroup()
```

Parameters

```
Icdport the LCD screen's port (either UART1 or UART2)
```

Definition at line 727 of file lcddiag.c.

```
4.35.2.14 void runIndivMotor (FILE * Icdport )
```

Runs the individual motor test. Selection of the motor and speed is handled by other functions

See also

```
selectMotor()
selectSpd()
```

Parameters

```
Icdport the LCD screen's port (either UART1 or UART2)
```

Definition at line 555 of file lcddiag.c.

```
4.35.2.15 void runMotor (FILE * Icdport )
```

Runs the top-level motor testing menu. Prompts the user to select between individual and group motor testing.

Parameters

lcdport	the LCD screen's port (either UART1 or UART2)
---------	---

Definition at line 791 of file lcddiag.c.

4.35.2.16 void runMotorGroupMgmt (FILE * Icdport)

Runs the top-level motor group management menu. Prompts the user whether to add, edit, or delete motor groups.

Parameters

```
Icdport the LCD screen's port (either UART1 or UART2)
```

Definition at line 1027 of file lcddiag.c.

4.35.2.17 void runRobot (FILE * *lcdport*)

Runs the robot sensory information menu. Displays information regarding competition switch status and gyroscope angle.

Parameters

Icdport the LCD screen's port (either UART1 or UART2)

Definition at line 1117 of file lcddiag.c.

4.35.2.18 void runScreensaver (FILE * Icdport)

Runs the screensaver that displays LCD messages.

See also

lcdmsg.c

Parameters

	lcdport	the LCD screen's port (either UART1 or UART2)
--	---------	---

Definition at line 335 of file lcddiag.c.

4.35.2.19 void saveGroups ()

Saves motor groups out to a file. This file can be loaded to add custom motor groups into memory.

Definition at line 173 of file lcddiag.c.

```
4.35.2.20 int selectMenu ( )
```

Displays the list of menus and waits for the user to select one.

Returns

the ID number of the menu selected

Definition at line 300 of file lcddiag.c.

```
4.35.2.21 int selectMotor ( FILE * Icdport )
```

Prompts the user to select an individual motor to test.

Parameters

```
Icdport the LCD screen's port (either UART1 or UART2)
```

Returns

the motor number selected

Definition at line 422 of file lcddiag.c.

4.35.2.22 int selectMotorGroup (FILE * *lcdport*)

Selects the motor group to test.

Parameters

Icdport	the LCD screen's port (either UART1 or UART2)
---------	---

Returns

the ID number of the group to test

Definition at line 618 of file lcddiag.c.

4.35.2.23 bool* selectMotorGroupMembers (bool * motor)

Selects the motors that constitute the specified motor group.

Parameters

Returns

a pointer to the array passed

Definition at line 829 of file lcddiag.c.

4.35.2.24 int selectSpd (int mtr)

Selects the speed of the motor to test.

Parameters

mtr the motor number that is being tested

Returns

the speed selected

Definition at line 490 of file lcddiag.c.

4.35.2.25 int selectSpdGroup (int mtr)

Selects the speed of the motor group to be tested.

Parameters

mtr the ID number of the motor group to be tested

Returns

the speed selected

Definition at line 665 of file lcddiag.c.

4.35.2.26 char* typeString (char * dest)

Uses the LCD and the autonomous potentiometer to type a string. This is used to name motor groups and autonomous recordings. The maximum length of string this function can type is 16 characters.

Parameters

dest a buffer to store the typed string (must be at least 17 characters to hold null terminator)

Returns

a pointer to the buffer

Definition at line 81 of file lcddiag.c.

4.35.3 Variable Documentation

4.35.3.1 bool backlight = true

Boolean representing the LCD screen's backlight state.

Definition at line 36 of file lcddiag.c.

4.35.3.2 bool disableOpControl = false

Disables operator control loop during motor testing. Since running motors is not thread safe, it is necessary to stop operator control of the motors during testing.

Definition at line 42 of file lcddiag.c.

```
4.35.3.3 MotorGroup* groups
```

Array that stores the motor groups. As this is a dynamic array, creating and editing new motor groups is possible. These motor groups are added to the array via the Motor Group Management menu.

Definition at line 49 of file lcddiag.c.

```
4.35.3.4 TaskHandle lcdDiagTask = NULL
```

Object representing the LCD diagnostic menu task. The LCD diagnostic menu runs in a separate thread from the operator control code. The TaskHandle allows for pausing and resuming of the LCD diagnostic menu during autonomous recording.

Definition at line 31 of file lcddiag.c.

4.35.3.5 char menuChoices[LCD_MENU_COUNT][LCD_MESSAGE_MAX_LENGTH+1]

Initial value:

```
"Motor Test",
"Motor Group Mgmt",
"Battery Info",
"Connection Info",
"Robot Info",
"Autonomous Info",
"Toggle Backlight",
"Screensaver",
"Credits"
```

Stores the top-level menu names.

Definition at line 60 of file lcddiag.c.

4.35.3.6 int numgroups

Stores the number of motor groups. This is functionally identical to the size of the motor group array.

Definition at line 55 of file lcddiag.c.

4.36 Icddiag.c

```
00001
00024 #include "main.h"
00031 TaskHandle lcdDiagTask = NULL;
00032
00036 bool backlight = true;
00037
00042 bool disableOpControl = false;
00043
00049 MotorGroup *groups;
00050
00055 int numgroups;
00056
00060 char menuChoices[LCD_MENU_COUNT][LCD_MESSAGE_MAX_LENGTH+1] =
00061
          "Motor Test",
00062
          "Motor Group Mgmt",
00063
          "Battery Info",
00064
          "Connection Info",
          "Robot Info",
00065
00066
          "Autonomous Info",
          "Toggle Backlight",
00067
          "Screensaver",
"Credits"
00068
00069
00070 };
00071
00081 char* typeString(char *dest){
00082
         bool done = false;
00083
          int val;
          memset(dest, 0, sizeof(*dest));
00084
          int i = 0;
typedef enum Case {
00085
00086
00087
              UPPER, LOWER, NUMBER
00088
          } Case;
00089
          Case c = UPPER;
00090
          int mult = 28;
00091
          int spacecode = 26;
00092
          int endcode = 27;
00093
00094
              bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00095
              bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00096
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00097
00098
              switch(c){
                  case UPPER:
00099
00100
                  case LOWER: mult = 28; spacecode = 26; endcode = 27; break;
00101
                  case NUMBER: mult = 12; spacecode = 10; endcode = 11; break;
00102
00103
              val = (float) ((float) analogRead(AUTON_POT)/(float)
     AUTON_POT_HIGH) * mult;
00104
             if(val > endcode) {
00105
                  val = endcode;
00106
00107
              if(val == spacecode) {
                 dest[i] = ' ';
00108
              } else if(val == endcode) {
00109
                 dest[i] = '~';
00110
00111
              } else {
00112
                 switch(c){
00113
                      case UPPER: dest[i] = val + 'A'; break;
                      case LOWER: dest[i] = val + 'a'; break;
00114
                      case NUMBER: dest[i] = val + '0'; break;
00115
00116
00117
              }
00118
00119
              int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(dest))/2;
```

4.36 lcddiag.c 71

```
00120
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00121
00122
00123
               strcat(str, dest);
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00124
00125
00126
00127
00128
               lcdSetText(LCD_PORT, 1, str);
00129
00130
               if(i > 0){
00131
00132
                    if(c == UPPER){
                        lcdSetText(LCD_PORT, 2, "DEL
                                                                   abc");
00134
                    } else if(c == LOWER) {
00135
                        lcdSetText(LCD_PORT, 2, "DEL
                                                                   123");
00136
                    } else { //NUMBER
00137
                        lcdSetText(LCD_PORT, 2, "DEL
                                                                   ABC");
                                                             SEL
00138
                    }
00139
               } else {
                    if(c == UPPER) {
00140
00141
                        lcdSetText(LCD_PORT, 2, "|
                                                                   abc");
                                                             SEL
00142
                    } else if(c == LOWER) {
00143
                        lcdSetText(LCD_PORT, 2, "|
                                                            SEL
                                                                   123");
00144
                    } else { //NUMBER
                        lcdSetText(LCD_PORT, 2, "|
00145
                                                            SEL ABC");
00146
                    }
00147
               }
00148
00149
               if((centerPressed) && val != endcode) {
00150
               i++;
} else if(leftPressed && i > 0){
00151
00152
                    dest[i] = 0;
00153
                    i--;
               } else if(rightPressed) {
00154
00155
                   switch(c){
00156
                        case UPPER: c = LOWER; break;
                        case LOWER: c = NUMBER; break;
00157
00158
                        case NUMBER: c = UPPER; break;
00159
                    }
00160
00161
00162
               done = ((centerPressed && val == endcode) || i == LCD_MESSAGE_MAX_LENGTH);
00163
               delay(20);
00164
          } while(!done);
00165
           dest[i] = 0;
00166
          return dest;
00167 }
00168
00173 void saveGroups(){
           FILE* group = fopen("grp", "w");
00174
00175
           taskPrioritySet(NULL, TASK_PRIORITY_HIGHEST-1);
           lcdSetText(LCD_PORT, 1, "Saving groups...");
lcdSetText(LCD_PORT, 2, "");
00176
00177
00178
           for(int i = 0; i < numgroups; i++) {</pre>
00179
                fwrite(groups[i].motor, sizeof(bool), sizeof(groups[i].motor) / sizeof(bool), group);
00180
                fwrite("\n", sizeof(char), sizeof("\n") / sizeof(char), group);
00181
               fwrite(groups[i].name, sizeof(char), sizeof(groups[i].name) / sizeof(char), group);
00182
               if(i == numgroups-1) {
00183
                   fwrite("\t", sizeof(char), sizeof("\t") / sizeof(char), group);
00184
               } else {
00185
                    fwrite("\n", sizeof(char), sizeof("\n") / sizeof(char), group);
00186
00187
           taskPrioritySet(NULL, TASK_PRIORITY_DEFAULT);
00188
           lcdSetText(LCD_PORT, 1, "Saved groups!");
lcdSetText(LCD_PORT, 2, "");
00189
00190
00191
           delay(1000);
00192 }
00193
00198 void loadGroups(){
00199
           FILE* group = fopen("grp", "r");
           taskPrioritySet(NULL, TASK_PRIORITY_HIGHEST-1);
lcdSetText(LCD_PORT, 1, "Loading groups...");
lcdSetText(LCD_PORT, 2, "");
00200
00201
00202
00203
           if(groups != NULL) {
00204
               free (groups);
00205
00206
           groups = NULL;
           int i = 0;
00207
00208
           bool done = false;
```

```
00209
          while(!done){
00210
               groups = (MotorGroup *) realloc(groups, sizeof(MotorGroup)*(i+1));
00211
               fread(groups[i].motor, sizeof(bool), sizeof(groups[i].motor) / sizeof(bool), group);
00212
               fread(groups[i].name, sizeof(char), sizeof(groups[i].name) / sizeof(char), group);
if(fgetc(group) == '\t'){
00213
00214
00215
                   done = true;
00216
00217
               i++;
00218
00219
          numgroups = i;
00220
          taskPrioritySet(NULL, TASK_PRIORITY_DEFAULT);
          lcdSetText(LCD_PORT, 1, "Loaded groups!");
lcdSetText(LCD_PORT, 2, "");
00221
00222
00223
          delay(1000);
00224 }
00225
00230 void initGroups(){
          FILE* group = fopen("grp", "r");
00232
          if (group == NULL) {
00233
               numgroups = 6; //LDRIVE, RDRIVE, DRIVE, SHOOT, INTK, TRANS
00234
               groups = (MotorGroup*) malloc(sizeof(MotorGroup) *
      numgroups);
00235
              if (groups == NULL) {
00236
                   return:
00237
00238
               memset(groups, 0, sizeof(*groups));
               for(int i = 0; i<numgroups; i++){</pre>
00239
                   for(int j = 0; j<=10; j++){
00240
00241
                       groups[i].motor[j] = false;
00242
00243
               }
00244
               groups[0].motor[LEFT_MOTOR_TOP] = true;
00245
               groups[0].motor[LEFT MOTOR BOT] = true;
               strcpy(groups[0].name, "Left Drive");
00246
00247
00248
               groups[1].motor[RIGHT_MOTOR_TOP] = true;
00249
               groups[1].motor[RIGHT_MOTOR_BOT] = true;
               strcpy(groups[1].name, "Right Drive");
00251
00252
               groups[2].motor[LEFT_MOTOR_TOP] = true;
00253
               groups[2].motor[LEFT_MOTOR_BOT] = true;
00254
               groups[2].motor[RIGHT_MOTOR_TOP] = true;
               groups[2].motor[RIGHT_MOTOR_BOT] = true;
00255
               strcpy(groups[2].name, "Full Drive");
00256
00257
00258
               groups[3].motor[NAUTILUS_SHOOTER_MOTOR_LEFT] = true;
               groups[3].motor[NAUTILUS_SHOOTER_MOTOR_RIGHT] = true;
00259
00260
               groups[3].motor[NAUTILUS_SHOOTER_MOTOR_CENTER] = true;
00261
               strcpy(groups[3].name, "Nautilus Shooter");
00262
00263
               groups[4].motor[INTAKE_ROLLER_MOTOR] = true;
00264
               strcpy(groups[4].name, "Intake");
00265
00266
               groups[5].motor[TRANSMISSION_MOTOR] = true;
00267
               strcpy(groups[5].name, "Transmission");
00268
00269
               //saveGroups();
00270
00271
               //loadGroups();
00272
00273 }
00274
00282 void formatMenuNameCenter(FILE* lcdport, int line, int index) {
          int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(
      menuChoices[index]))/2;
00284
          char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
          for (int i = 0; i < spaces; i++) {</pre>
00285
              strcat(str, " ");
00286
00287
00288
          strcat(str, menuChoices[index]);
          for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00289
00290
00291
00292
          lcdSetText(lcdport, line, str);
00293 }
00294
00300 int selectMenu() {
00301
          bool done = false;
00302
          int val = 0;
00303
          do {
```

4.36 lcddiag.c 73

```
00304
              bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00305
              bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00306
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00307
00308
              if(rightPressed && val != LCD_MENU_COUNT-1) val++;
              else if(rightPressed && val == LCD_MENU_COUNT-1) val = 0;
00309
00310
              else if(leftPressed && val != 0) val--;
00311
              else if(leftPressed && val == 0) val = LCD_MENU_COUNT - 1;
00312
00313
              formatMenuNameCenter(LCD_PORT, 1, val);
00314
              if(val == 0){
                  lcdSetText(LCD_PORT, 2, "<</pre>
00315
                                                            >");
00316
              } else if(val == LCD_MENU_COUNT-1) {
                  lcdSetText(LCD_PORT, 2, "<</pre>
                                                             >");
00318
              } else {
                  lcdSetText(LCD_PORT, 2, "<</pre>
00319
                                                             >");
00320
00321
              delay(20);
00322
              done = centerPressed;
00323
          } while(!done);
00324
          printf("Selected menu choice: %d\n", val);
00325
          return val:
00326 }
00327
00335 void runScreensaver(FILE *lcdport) {
00336
          int cycle = 0;
00337
          do {
              if(cycle == 0){
00338
                  screensaver(LCD_PORT);
00339
00340
00341
              delay(20);
              cycle++;
00342
              if(cycle==150){
00343
00344
                  cycle=0;
00345
00346
          } while(!lcdAnyButtonPressed());
00347 }
00348
00354 void runBattery(FILE *lcdport){
          bool done = false;
00355
          int val = BATT_MAIN;
00356
00357
00358
              bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00359
              bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00360
00361
00362
              if(rightPressed && val != BATT_PEXP) val++;
00363
              else if(rightPressed && val == BATT_PEXP) val = BATT_MAIN;
00364
              else if(leftPressed && val != BATT_MAIN) val--;
00365
              else if(leftPressed && val == BATT_MAIN) val = BATT_PEXP;
00366
00367
              int beforepoint = 0;
00368
              int afterpoint = 0;
00369
              char battdisp[LCD_MESSAGE_MAX_LENGTH+1];
00370
              char temp[LCD_MESSAGE_MAX_LENGTH+1];
00371
              memset(battdisp, 0, sizeof(battdisp));
00372
              memset(temp, 0, sizeof(temp));
00373
00374
              switch(val){
00375
                  case BATT_MAIN: beforepoint = powerLevelMain()/1000;
00376
                                   afterpoint = powerLevelMain()%1000;
00377
                                   strcat(battdisp, "Mn Batt: ");
00378
                                   break;
00379
                  case BATT_BKUP: beforepoint = powerLevelBackup()/1000;
                                   afterpoint = powerLevelBackup()%1000;
00380
                                   strcat(battdisp, "Bk Batt: ");
00381
00382
                                   break;
00383
                  case BATT_PEXP: beforepoint = powerLevelExpander()/1000;
                                   afterpoint = powerLevelExpander()%1000;
00384
00385
                                   strcat(battdisp, "Ex Batt: ");
00386
                                   break;
00387
              sprintf(temp, "%d.%d V", beforepoint, afterpoint);
00388
00389
              strcat(battdisp, temp);
00390
00391
              int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(battdisp))/2;
              char str[LCD_MESSAGE_MAX_LENGTH+1];
00392
              memset(str, 0, sizeof(str));
for(int i = 0; i < spaces; i++){
00393
00394
00395
                  strcat(str, " ");
00396
```

```
00397
               strcat(str, battdisp);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00398
00399
00400
00401
               lcdSetText(LCD_PORT, 1, str);
00402
00403
               if(val == BATT_MAIN) {
00404
                  lcdSetText(LCD_PORT, 2, "EX
                                                     ESC
                                                             BK");
00405
               } else if(val == BATT_PEXP) {
00406
                   lcdSetText(LCD_PORT, 2, "BK
                                                             MN");
00407
               } else { //BATT_BKUP
00408
                  lcdSetText(LCD_PORT, 2, "MN
                                                             EX");
00409
00410
               delay(20);
00411
               done = centerPressed;
00412
          } while(!done);
00413 }
00414
00422 int selectMotor(FILE *lcdport) {
00423
         bool done = false;
00424
          int val = 1;
00425
          do f
00426
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00427
               bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00428
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00429
00430
               if(rightPressed && val != 10) val++;
00431
               else if(rightPressed && val == 10) val = 0;
               else if(leftPressed && val != 0) val--;
00432
00433
               else if(leftPressed && val == 0) val = 10;
00434
00435
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00436
               if(val != 0){
                   char temp[LCD_MESSAGE_MAX_LENGTH+1];
00437
                   memset(motorstr, 0, sizeof(motorstr));
00438
00439
                   memset(temp, 0, sizeof(temp));
                   strcpy(motorstr, "Motor: ");
sprintf(temp, "%d", val);
00440
00441
                   strcat(motorstr, temp);
00442
00443
               } else {
00444
                   strcpy(motorstr, "Cancel");
00445
               }
00446
00447
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00448
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00449
00450
00451
00452
               strcat(str, motorstr);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00453
00454
00455
00456
00457
               lcdSetText(LCD_PORT, 1, str);
00458
00459
               done = centerPressed;
00460
               if (val == 0) {
00461
                   lcdSetText(LCD_PORT, 2, "10
                                                              1");
                                                     SEL
00462
               } else if(val == 1) {
00463
                  lcdSetText(LCD_PORT, 2, "ESC
                                                              2");
00464
               } else if(val == 10) {
00465
                   lcdSetText(LCD_PORT, 2, "9
                                                     SEL
                                                            ESC");
00466
               } else if (val == 9) {
00467
                   lcdSetText(LCD_PORT, 2, "8
                                                     SEL
                                                             10"):
00468
               } else {
00469
                   char navstr[LCD_MESSAGE_MAX_LENGTH+1];
00470
                   memset(navstr, 0, sizeof(navstr));
00471
                   sprintf(navstr, "%c SEL
                                                      %c", (val-1) + '0', (val+1) + '0');
00472
                   /*navstr[0] = (val-1) + '0';*/
00473
                   /*strcat(navstr, "
                                                     ");*/
                                            SEL
00474
                   /*navstr[LCD_MESSAGE_MAX_LENGTH] = (val+1) + '0';*/
00475
                   lcdSetText(LCD_PORT, 2, navstr);
00476
00477
              delay(20);
00478
          } while(!done);
00479
          printf("Testing motor %d.\n", val);
00480
          return val;
00481 }
00482
00490 int selectSpd(int mtr) {
00491
          bool done = false;
```

4.36 lcddiag.c 75

```
00492
           int val=0;
00493
00494
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
               /*bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT); */
00495
00496
               /*bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);*/
00497
00498
               val = (float) ((float) analogRead(AUTON_POT)/(float)
      AUTON_POT_HIGH) * 254;
00499
               val -= 127;
00500
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00501
               char temp[LCD_MESSAGE_MAX_LENGTH+1];
00502
               memset(motorstr, 0, sizeof(motorstr));
00503
               memset(temp, 0, sizeof(temp));
               strcpy(motorstr, "Motor: ");
00505
               sprintf(temp, "%d", mtr);
00506
               strcat (motorstr, temp);
00507
00508
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00509
               for(int i = 0; i < spaces; i++) {</pre>
00510
                   strcat(str, " ");
00511
00512
00513
               strcat(str, motorstr);
00514
               for(int i = 0; i < spaces; i++) {</pre>
                   strcat(str, " ");
00515
00516
00517
               lcdSetText(LCD_PORT, 1, str);
00518
00519
00520
               char speedstr[LCD_MESSAGE_MAX_LENGTH+1];
00521
               memset(speedstr, 0, sizeof(speedstr));
00522
               memset(temp, 0, sizeof(temp));
               strcpy(speedstr, "Speed: ");
sprintf(temp, "%d", val);
00523
00524
00525
               strcat(speedstr, temp);
00526
               spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(speedstr))/2;
strcpy(str, "");
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00527
00528
00529
00530
00531
00532
               strcat(str, speedstr);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00533
00534
00535
00536
00537
               lcdSetText(LCD_PORT, 2, str);
00538
00539
               done = (digitalRead(AUTON_BUTTON) == PRESSED || centerPressed);
00540
               delay(20);
00541
           } while(!done);
00542
           printf("Using speed: %d\n", val);
00543
           return val;
00544 }
00545
00555 void runIndivMotor(FILE *lcdport) {
00556
           bool done = false;
00557
           int mtr = selectMotor(lcdport);
           if(mtr == 0) return;
00558
00559
           int spd = selectSpd(mtr);
           int val = spd;
00560
00561
           disableOpControl = true;
00562
          motorStopAll();
00563
           do {
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00564
               char temp[LCD_MESSAGE_MAX_LENGTH+1];
00565
               memset(motorstr, 0, sizeof(motorstr));
00566
00567
               memset(temp, 0, sizeof(temp));
00568
               strcpy (motorstr, "Motor: ");
               sprintf(temp, "%d", mtr);
00569
00570
               strcat (motorstr, temp);
00571
00572
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
00573
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00574
               for(int i = 0; i < spaces; i++) {</pre>
                   strcat(str, " ");
00575
00576
00577
               strcat(str, motorstr);
for(int i = 0; i < spaces; i++){</pre>
00578
                   strcat(str, " ");
00579
00580
```

```
00581
00582
               lcdSetText(LCD_PORT, 1, str);
00583
00584
               char speedstr[LCD_MESSAGE_MAX_LENGTH+1];
00585
               memset(speedstr, 0, sizeof(speedstr));
00586
               memset(temp, 0, sizeof(temp));
00587
               strcpy(speedstr, "Run Speed: ");
00588
               sprintf(temp, "%d", val);
00589
               strcat(speedstr, temp);
00590
00591
               spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(speedstr))/2;
               strcpy(str, "");
for(int i = 0; i < spaces; i++){</pre>
00592
00593
00594
                  strcat(str, " ");
00595
00596
               strcat(str, speedstr);
               for(int i = 0; i < spaces; i++) {</pre>
00597
                   strcat(str, " ");
00598
00599
00600
00601
               lcdSetText(LCD_PORT, 2, str);
00602
00603
               done = lcdAnyButtonPressed();
00604
               motorSet(mtr, val);
00605
              delay(20);
00606
00607
          } while(!done);
          disableOpControl = false;
00608
00609 }
00610
00618 int selectMotorGroup(FILE *lcdport) {
          bool done = false;
00619
00620
          int val = 0:
00621
          do {
               bool centerPressed = lcdButtonPressed(LCD BTN CENTER);
00622
               bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00623
               bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00624
00625
00626
               if(rightPressed && val != numgroups-1) val++;
00627
               else if(rightPressed && val == numgroups-1) val = -1;
              else if(leftPressed && val != -1) val--;
00628
               else if(leftPressed && val == -1) val = numgroups-1;
00629
00630
00631
               char motorstr[LCD MESSAGE MAX LENGTH+1];
00632
               if (val != -1) {
00633
                   memset(motorstr, 0, sizeof(motorstr));
00634
                   strcpy(motorstr, groups[val].name);
00635
               } else {
                   strcpy(motorstr, "Cancel");
00636
00637
               }
00638
00639
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00640
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00641
00642
00643
00644
               strcat(str, motorstr);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00645
00646
00647
00648
00649
               lcdSetText(LCD_PORT, 1, str);
00650
00651
               done = centerPressed;
               lcdSetText(LCD_PORT, 2, "<</pre>
00652
                                                          >");
00653
               delay(20);
00654
          } while(!done);
00655
          return val;
00656 }
00657
00665 int selectSpdGroup(int mtr) {
00666
          bool done = false;
00667
          int val:
00668
          do {
00669
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00670
               /*bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT); */
               /*bool rightPressed = lcdButtonPressed(LCD BTN RIGHT);*/
00671
00672
              val = (float) ((float) analogRead(AUTON_POT)/(float)
00673
      AUTON_POT_HIGH) * 254;
00674
              val -= 127;
```

4.36 lcddiag.c 77

```
00675
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00676
               char temp[LCD_MESSAGE_MAX_LENGTH+1];
00677
               memset(motorstr, 0, sizeof(motorstr));
00678
               memset(temp, 0, sizeof(temp));
00679
               strcpy(motorstr, groups[mtr].name);
00680
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00681
00682
00683
               for(int i = 0; i < spaces; i++) {</pre>
                   strcat(str, " ");
00685
00686
               strcat(str, motorstr);
00687
               for(int i = 0; i < spaces; i++) {</pre>
                    strcat(str, " ");
00688
00689
00690
00691
               lcdSetText(LCD_PORT, 1, str);
00692
00693
               char speedstr[LCD_MESSAGE_MAX_LENGTH+1];
00694
               memset(speedstr, 0, sizeof(speedstr));
               memset(temp, 0, sizeof(temp));
strcpy(speedstr, "Speed: ");
00695
00696
00697
               sprintf(temp, "%d", val);
00698
               strcat(speedstr, temp);
00699
00700
               spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(speedstr))/2;
               strcpy(str, "");
for(int i = 0; i < spaces; i++){</pre>
00701
00702
                    strcat(str, " ");
00703
00704
00705
               strcat(str, speedstr);
for(int i = 0; i < spaces; i++){</pre>
00706
                    strcat(str, " ");
00707
00708
00709
               lcdSetText(LCD_PORT, 2, str);
00710
00711
               done = (digitalRead(AUTON_BUTTON) == PRESSED || centerPressed);
00712
               delay(20);
00713
00714
           } while(!done);
00715
           return val;
00716 }
00717
00727 void runGroupMotor(FILE *lcdport){
00728
           bool done = false;
00729
           int mtr = selectMotorGroup(lcdport);
00730
           if(mtr == -1) return;
00731
           int spd = selectSpdGroup(mtr);
00732
           int val = spd;
00733
           disableOpControl = true;
00734
           motorStopAll();
00735
00736
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
               char temp[LCD_MESSAGE_MAX_LENGTH+1];
00737
00738
               memset(motorstr, 0, sizeof(motorstr));
00739
               memset(temp, 0, sizeof(temp));
00740
               strcpy(motorstr, groups[mtr].name);
00741
00742
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
00743
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00744
               for(int i = 0; i < spaces; i++) {</pre>
                    strcat(str, " ");
00745
00746
00747
               strcat(str, motorstr);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00748
00749
00750
00751
00752
               lcdSetText(LCD_PORT, 1, str);
00753
00754
               char speedstr[LCD_MESSAGE_MAX_LENGTH+1];
00755
               memset(speedstr, 0, sizeof(speedstr));
00756
               memset(temp, 0, sizeof(temp));
               strcat(speedstr, "Run Speed: ");
sprintf(temp, "%d", val);
00757
00758
00759
               strcat(speedstr, temp);
00760
00761
               spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(speedstr))/2;
               strcpy(str, "");
00762
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00763
00764
```

```
00765
              strcat(str, speedstr);
for(int i = 0; i < spaces; i++){
    strcat(str, " ");</pre>
00766
00767
00768
00769
00770
00771
              lcdSetText(LCD_PORT, 2, str);
00772
00773
               for (int i = 1; i <= 10; i++) {</pre>
00774
                   if (groups[mtr].motor[i]) {
00775
                       motorSet(i, val);
00776
00777
              }
00778
00779
              done = lcdAnyButtonPressed();
00780
              delay(20);
00781
          } while(!done);
00782
          disableOpControl = false;
00783 }
00784
00791 void runMotor(FILE *lcdport) {
00792
          bool done = false;
00793
          int val = 0;
00794
          do {
00795
              bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00796
              bool leftPressed = lcdButtonPressed(LCD BTN LEFT);
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00797
00798
00799
              if(rightPressed && val != 1) val++;
00800
              else if (leftPressed && val != 0) val--;
00801
00802
              if(val){
                   lcdSetText(lcdport, 1, "Indiv Motor Test");
00803
00804
               } else {
                   lcdSetText(lcdport, 1, "Group Motor Test");
00805
00806
00807
              done = centerPressed;
              if(val == 0) {
00808
00809
                  lcdSetText(LCD_PORT, 2, "|
                                                     SEL
                                                              >");
00810
               } else if(val == 1) {
                   lcdSetText(LCD_PORT, 2, "<</pre>
00811
                                                     SEL.
                                                              |");
00812
00813
              delay(20);
          } while(!done);
00814
00815
          if(val){
00816
              runIndivMotor(lcdport);
00817
          } else {
00818
              runGroupMotor(lcdport);
00819
00820 }
00821
00829 bool* selectMotorGroupMembers(bool *motor){
00830
          bool done = false;
00831
          int val = 1;
00832
00833
              bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00834
              bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00835
              bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00836
00837
              if(rightPressed && val != 10) val++;
00838
              else if(rightPressed && val == 10) val = 0;
00839
              else if(leftPressed && val != 0) val--;
00840
              else if(leftPressed && val == 0) val = 10;
00841
00842
              char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00843
              if (val != 0) {
00844
                   char temp[LCD_MESSAGE_MAX_LENGTH+1];
00845
                   memset (motorstr, 0, sizeof (motorstr));
00846
                   memset(temp, 0, sizeof(temp));
                   strcpy (motorstr, "Motor ");
00847
00848
                   sprintf(temp, "%d:", val);
00849
                   strcat(motorstr, temp);
00850
                   if (motor[val]) {
00851
                       strcat (motorstr, " On");
00852
                   } else {
00853
                       strcat (motorstr, " Off");
00854
00855
               } else {
                   strcpy(motorstr, "Confirm");
00856
00857
              int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
00858
```

4.36 lcddiag.c 79

```
00859
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00860
00861
00862
               strcat(str, motorstr);
for(int i = 0; i < spaces; i++){
    strcat(str, " ");</pre>
00863
00864
00865
00866
00867
               lcdSetText(LCD_PORT, 1, str);
00868
00869
00870
               done = (centerPressed && val == 0);
00871
               if(centerPressed && val != 0) {
00872
                   motor[val] = !motor[val];
00873
00874
               if (val == 0) {
00875
                   lcdSetText(LCD_PORT, 2, "10
                                                       SEL
                                                               1");
00876
               } else if(val == 1) {
                   lcdSetText(LCD_PORT, 2, "ESC
00877
                                                                2");
00878
               } else if(val == 10) {
00879
                   lcdSetText(LCD_PORT, 2, "9
                                                       SEL
                                                             ESC");
00880
               } else if (val == 9) {
00881
                   lcdSetText(LCD_PORT, 2, "8
                                                       SEL
                                                              10");
00882
               } else {
00883
                   char navstr[LCD_MESSAGE_MAX_LENGTH+1];
00884
                   memset(navstr, 0, sizeof(navstr));
sprintf(navstr, "%c SEL %c
00885
                                                        %c", (val-1) + '0', (val+1) + '0');
                    /*navstr[0] = (val-1) + '0';*/
00886
                    /*strcat(navstr, "
                                                      ");*/
00887
                                            SEL
                    /*navstr[LCD_MESSAGE_MAX_LENGTH] = (val+1) + '0';*/
00888
                   lcdSetText(LCD_PORT, 2, navstr);
00889
00890
00891
               delay(20);
00892
           } while(!done);
00893
           return motor:
00894 }
00895
00899 void addMotorGroup(){
00900
          MotorGroup *temp = (MotorGroup*) realloc(groups, sizeof(
     MotorGroup) * (numgroups+1));
00901
          if(temp == NULL) return;
           groups = temp;
00902
00903
           numgroups++;
00904
           memset(&groups[numgroups-1], 0, sizeof(groups[numgroups-1]));
00905
           typeString(groups[numgroups-1].name);
00906
           selectMotorGroupMembers(groups[numgroups-1].motor);
00907 }
00908
00915 void editMotorGroup(int mtr){
00916
           if(mtr == -1) return;
00917
           bool done = false;
00918
           int val = 0;
00919
           FILE *lcdport = LCD_PORT;
00920
00921
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00922
               bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00923
               bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00924
00925
               if(rightPressed && val != 1) val++;
00926
               else if(leftPressed && val != 0) val--;
00927
00928
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00929
               memset(motorstr, 0, sizeof(motorstr));
00930
00931
               if(val){
00932
                   strcpy(motorstr, "Edit Name");
               } else {
00933
00934
                   strcpy (motorstr, "Edit Motors");
00935
00936
00937
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
00938
               char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00939
               for(int i = 0; i < spaces; i++) {</pre>
                   strcat(str, " ");
00940
00941
00942
               strcat(str, motorstr);
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00943
00944
00945
00946
00947
               lcdSetText(lcdport, 1, str);
```

```
00948
00949
               done = centerPressed;
00950
               if(val == 0){
00951
                   lcdSetText(LCD_PORT, 2, "|
                                                      SEL
                                                               >");
00952
               } else if(val == 1) {
00953
                   lcdSetText(LCD_PORT, 2, "<</pre>
                                                      SEL
                                                               |");
00954
00955
               delay(20);
00956
          } while(!done);
00957
          if(val){
00958
              typeString(groups[mtr].name);
00959
             else {
00960
               selectMotorGroupMembers(groups[mtr].motor);
00961
00962 }
00963
00970 void delMotorGroup(int mtr){
00971
          if (mtr == -1) return;
          int val = 0;
00972
00973
          FILE *lcdport = LCD_PORT;
00974
          bool done = false;
00975
          do {
00976
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
00977
               bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
00978
               bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
00979
00980
               if(rightPressed && val != 1) val++;
               else if(leftPressed && val != 0) val--;
00981
00982
00983
               char motorstr[LCD_MESSAGE_MAX_LENGTH+1];
00984
               memset (motorstr, 0, sizeof (motorstr));
00985
00986
               if(val){
                   strcpy(motorstr, "Delete Forever");
00987
00988
               } else {
00989
                   strcpy(motorstr, "Cancel Delete");
00990
00991
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(motorstr))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
00992
00993
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00994
00995
00996
00997
               strcat(str, motorstr);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00998
00999
01000
01001
01002
               lcdSetText(lcdport, 1, str);
01003
01004
               done = centerPressed;
01005
               if(val == 0) {
01006
                   lcdSetText(LCD_PORT, 2, "|
                                                               >");
01007
               } else if(val == 1) {
01008
                   lcdSetText(LCD_PORT, 2, "<</pre>
                                                      SEL
                                                               |");
01009
01010
               delay(20);
01011
          } while(!done);
01012
          if(val){
01013
               memset(&groups[mtr], 0, sizeof(groups[mtr]));
01014
               for(int i = mtr; i < numgroups - 1; i++){</pre>
01015
                   memcpy(&groups[i], &groups[i+1], sizeof(groups[i]));
01016
01017
               numgroups--;
01018
01019 }
01020
01027 void runMotorGroupMgmt (FILE *lcdport) {
          bool done = false;
01028
01029
          int val = 0;
01030
          do {
01031
               bool centerPressed = lcdButtonPressed(LCD_BTN_CENTER);
               bool leftPressed = lcdButtonPressed(LCD_BTN_LEFT);
01032
01033
               bool rightPressed = lcdButtonPressed(LCD_BTN_RIGHT);
01034
01035
               if (rightPressed && val != 3) val++;
01036
               else if(rightPressed && val == 3) val = 0;
               else if (leftPressed && val != 0) val--;
01037
01038
               else if(leftPressed && val == 0) val = 3;
01039
01040
               switch(val){
```

4.36 lcddiag.c 81

```
01041
                    case 0: lcdSetText(lcdport, 1, "Add Motor Group"); break;
                    case 1: lcdSetText(lcdport, 1, "Edit Motor Group"); break;
case 2: lcdSetText(lcdport, 1, "Del Motor Group"); break;
01042
01043
                    case 3: lcdSetText(lcdport, 1, "Cancel Grp. Mgmt"); break;
01044
01045
01046
               done = centerPressed;
               if (val == 0) {
01047
01048
                   lcdSetText(LCD_PORT, 2, "<</pre>
                                                        SEL
                                                                 >");
01049
               } else {
                   lcdSetText(LCD_PORT, 2, "<</pre>
                                                                 >");
01050
01051
01052
               delay(20);
01053
          } while(!done);
          switch(val){
01055
               case 0: addMotorGroup(); break;
01056
               case 1: editMotorGroup(selectMotorGroup(lcdport)); break;
01057
               case 2: delMotorGroup(selectMotorGroup(lcdport)); break;
01058
               case 3: break;
01059
01060 }
01061
01068 void runConnection(FILE *lcdport) {
01069
          do {
01070
               char strjoy1[LCD_MESSAGE_MAX_LENGTH+1] = "";
01071
               char strjoy2[LCD_MESSAGE_MAX_LENGTH+1] = "";
01072
               if(isJoystickConnected(1)){
01073
                   strcat(strjoy1, "J1: Connected");
01074
               } else {
01075
                   strcat(strjoy1, "J1: Disconnected");
01076
01077
               if(isJoystickConnected(2)){
                   strcat(strjoy2, "J2: Connected");
01078
01079
               l else (
                    strcat(strjoy2, "J2: Disconnected");
01080
01081
01082
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy1))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
01083
01084
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01085
01086
01087
01088
               strcat(str, strjoy1);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01089
01090
01091
01092
01093
               lcdSetText(lcdport, 1, str);
01094
01095
               spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy2))/2;
                strcpy(str, "");
01096
               for(int i = 0; i < spaces; i++) {
   strcat(str, " ");</pre>
01097
01098
01099
01100
               strcat(str, strjoy2);
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01101
01102
01103
01104
               lcdSetText(lcdport, 2, str);
01105
01106
01107
               delay(20);
01108
           } while(!lcdAnyButtonPressed());
01109 }
01110
01117 void runRobot(FILE *lcdport) {
01118
               char strjoy1[LCD_MESSAGE_MAX_LENGTH+1] = "";
01119
               char strjoy2[LCD_MESSAGE_MAX_LENGTH+1] = "";
01120
01121
               if(isOnline()){
01122
                    strcat(strjoy1, "Competition Mode");
01123
               } else {
01124
                   strcat(strjoy1, "Practice Mode");
01125
               /*if(isEnabled()){
01126
                   strcat(strjoy2, "Robot Enabled");
01127
01128
               } else {
                   strcat(strjoy2, "Robot Disabled");
01129
01130
01131
               sprintf(strjoy2, "Angle: %d", gyroGet(gyro));
01132
01133
               int spaces = (LCD MESSAGE MAX LENGTH - strlen(strjov1))/2:
```

```
01134
                char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
               for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01135
01136
01137
               strcat(str, strjoy1);
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01138
01139
01140
01141
01142
               lcdSetText(lcdport, 1, str);
01143
01144
                spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy2))/2;
01145
               strcpy(str, "");
for(int i = 0; i < spaces; i++){</pre>
01146
01147
01148
                    strcat(str, " ");
01149
01150
                strcat(str. striov2);
               for(int i = 0; i < spaces; i++) {</pre>
01151
                    strcat(str, " ");
01152
01153
01154
01155
               lcdSetText(lcdport, 2, str);
01156
01157
               delay(20);
           } while(!lcdAnyButtonPressed());
01158
01159 }
01160
01168 void runAuton(FILE *lcdport) {
01169
         do {
               char strjoy1[LCD_MESSAGE_MAX_LENGTH+1] = "";
01170
               char strjoy2[LCD_MESSAGE_MAX_LENGTH+1] = "";
01171
01172
                if (autonLoaded == -1) {
01173
                    strcat(strjoy1, "No Auton Loaded");
01174
               } else if(autonLoaded == 0){
               strcat(strjoy1, "Empty Auton");
} else if(autonLoaded == MAX_AUTON_SLOTS + 1){
01175
01176
01177
                    strcat(strjoy1, "Prog. Skills");
01178
                } else {
01179
                    FILE* autonFile;
01180
                    char filename[AUTON_FILENAME_MAX_LENGTH];
                    snprintf(filename, sizeof(filename)/sizeof(char), "a%d", autonLoaded);
01181
01182
                    autonFile = fopen(filename, "r");
                    char name[LCD_MESSAGE_MAX_LENGTH+1];
01183
01184
                    memset(name, 0, sizeof(name));
01185
                    fread(name, sizeof(char), sizeof(name) / sizeof(char), autonFile);
01186
                    strcpy(strjoy1, name);
01187
                    fclose(autonFile);
01188
               if(isOnline()){
01189
01190
                    strcat(strjoy2, "Recorder Off");
01191
                } else {
01192
                    strcat(strjoy2, "Recorder On");
01193
01194
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy1))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
01195
01196
01197
                for(int i = 0; i < spaces; i++) {</pre>
01198
                    strcat(str, " ");
01199
01200
                strcat(str, strjoy1);
                for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01201
01202
01203
01204
01205
                lcdSetText(lcdport, 1, str);
01206
01207
                spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy2))/2;
                strcpy(str, "");
01208
                for(int i = 0; i < spaces; i++) {</pre>
01209
                    strcat(str, " ");
01210
01211
01212
                strcat(str, strjov2);
                for(int i = 0; i < spaces; i++) {</pre>
01213
                    strcat(str, " ");
01214
01215
01216
01217
               lcdSetText(lcdport, 2, str);
01218
01219
               delay(20);
           } while(!lcdAnyButtonPressed());
01220
01221 }
```

```
01222
01233 void runCredits(FILE *lcdport) {
        do {
             char strjoy1[LCD_MESSAGE_MAX_LENGTH+1] = "";
01235
               char strjoy2[LCD_MESSAGE_MAX_LENGTH+1] = "";
01237
               strcat(strjoy1, "Thanks Team 750W");
01238
               strcat(strjoy2, "Akram Sandhu");
01239
               int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(strjoy1))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
01240
01241
              for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
01243
01244
             strcat(str, strjoy1);
for(int i = 0; i < spaces; i++){
    strcat(str, " ");</pre>
01245
01246
01248
01249
01250
               lcdSetText(lcdport, 1, str);
01251
01252
               spaces = (LCD MESSAGE MAX LENGTH - strlen(strjov2))/2;
               strcpy(str, "");
for(int i = 0; i < spaces; i++){
01253
01254
01255
                  strcat(str, " ");
01256
             strcat(str, strjoy2);
for(int i = 0; i < spaces; i++){
   strcat(str, " ");</pre>
01257
01258
01259
01260
01261
01262
               lcdSetText(lcdport, 2, str);
01263
01264
              delav(20);
           } while(!lcdAnyButtonPressed());
01265
01266 }
01267
01276 void doMenuChoice(int choice) {
01277
         switch(choice) {
01278
              case MENU_SCREENSAVER: runScreensaver(
     LCD_PORT); break;
          case MENU_BATTERY: runBattery(LCD_PORT); break;
01279
01280
               case MENU_MOTOR: runMotor(LCD_PORT); break;
01281
               case MENU_MOTOR_MGMT: runMotorGroupMgmt(
      LCD_PORT); break;
          case MENU_CONNECTION: runConnection(LCD_PORT); break;
01282
01283
               case MENU_ROBOT: runRobot(LCD_PORT); break;
01284
            case MENU_AUTON: runAuton(LCD_PORT); break;
01285
               case MENU_BACKLIGHT: lcdSetBacklight(LCD_PORT, !
     backlight); backlight = !backlight; break;
01286
              case MENU_CREDITS: runCredits(LCD_PORT); break;
01287
01288 }
01289
01298 void formatLCDDisplay(void *ignore) {
01299 lcdSetBacklight(LCD_PORT, backlight);
01300
           doMenuChoice (MENU_SCREENSAVER);
01301
         while(true){
01302
               doMenuChoice(selectMenu());
01303
01304 }
01305
```

4.37 src/lcdmsg.c File Reference

File for LCD message code.

```
#include "main.h"
```

Functions

- void randlcdmsg (FILE *lcdport, int line)
- void screensaver (FILE *lcdport)

Variables

• char * lcdmsg []

4.37.1 Detailed Description

File for LCD message code.

This file contains the code for the LCD screensaver messages. These messages display randomly while the LCD diagnostic menu is set to the screensaver mode. These messages are mainly inside jokes among the team.

Definition in file lcdmsg.c.

4.37.2 Function Documentation

4.37.2.1 void randlcdmsg (FILE * *lcdport*, int *line*)

Displays a random LCD message from the master list.

Parameters

Icdport	the port the LCD is connected to
line	the line to display the message on

Definition at line 71 of file lcdmsg.c.

4.37.2.2 void screensaver (FILE * Icdport)

Formats the LCD by displaying 750C title and message.

Parameters

lcdport	the port the LCD is connected to
---------	----------------------------------

Definition at line 90 of file lcdmsg.c.

4.37.3 Variable Documentation

4.37.3.1 char* lcdmsg[]

Master list of all LCD messages.

Definition at line 14 of file lcdmsg.c.

4.38 lcdmsg.c 85

4.38 lcdmsg.c

```
00001
00009 #include "main.h"
00010
00014 char* lcdmsg[] = {
            "Hint of Lime",
00015
            "Review Committee",
00016
            "Exacerbate",
00017
00018
            "Get Schwifty"
            "Hot Knife",
00019
00020
            "Mikel",
            "Michael",
00021
            "Donald J. Trump",
00022
            "Nautilus Gears",
00023
            "Drop and Pop",
00024
            "More Flip",
00025
            "Alfred & Robin",
00026
00027
            "Quinnipiac",
00028
            "Yeah",
            "YEAH",
00029
            "YEAH!",
00030
            "Did You Get That",
00031
00032
            "On Video",
            "MGNT",
"LC/DC",
00033
00034
00035
            "You Seem Tense",
00036
            "Root Theta Gears",
00037
            "Money Shot",
00038
            "Jaskirat Vig",
            "Torsionify",
00039
00040
            "Chortler",
            "750 Crust",
00041
00042
            "Crusty Teeth",
00043
            "Moneyballs",
00044
            "dooDAH",
00045
            "Wobbly Pobbly",
00046
            "Hallen Key",
00047
            "24 Motors",
00048
            "Complicate THIS!",
00049
            "Meshing",
00050
            "Shikhar Crustogi",
00051
            "Neural Network",
00052
            "easyAuton()",
00053
            "Loctite",
00054
            "Skin Irritant",
00055
            "Akram Sandhu",
00056
            "Therapy Dogs",
            "Staples Bands",
00057
00058
            "New Nautilus",
            "Nauty Gears",
"New 'n' Nauty",
00059
00060
00061
            "TURBO GEARS",
00062
            "itoa() Sucks"
00063 };
00064
00071 void randlcdmsg(FILE *lcdport, int line) {
            int index = rand() % LCD_MESSAGE_COUNT;
00072
           int spaces = (LCD_MESSAGE_MAX_LENGTH - strlen(lcdmsg[index]))/2;
char str[LCD_MESSAGE_MAX_LENGTH+1] = "";
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00073
00074
00075
00076
00077
           strcat(str, lcdmsg[index]);
for(int i = 0; i < spaces; i++) {
    strcat(str, " ");</pre>
00078
00079
00080
00081
00082
            lcdSetText(lcdport, line, str);
00083 }
00084
00090 void screensaver(FILE *lcdport) {
            lcdSetText(lcdport, 1, LCD_750C_TITLE);
00091
00092
            randlcdmsg(lcdport, 2);
00093 }
00094
```

4.39 src/motors.c File Reference

File for important motor functions.

```
#include "main.h"
```

Functions

void transmissionSetPos (void *pos)

4.39.1 Detailed Description

File for important motor functions.

This file contains the code for functions regarding motor status. These functions are too complex to be defined as inline functions in the motors.h file.

See the motors.h file for the basic movement functions.

See also

motors.h

Definition in file motors.c.

4.39.2 Function Documentation

4.39.2.1 void transmissionSetPos (void * pos)

Sets the position of the transmission.

Parameters

```
pos the position to set the transmission to.
```

Definition at line 19 of file motors.c.

4.40 motors.c

```
00001
00012 #include "main.h"
00013
00019 void transmissionSetPos(void *pos){
00020    int pot = (intptr_t) pos;
```

```
00021
         printf("Target: %d\n", pot);
00022
         if(analogRead(TRANSMISSION_POT) < pot) {</pre>
00023
             while(analogRead(TRANSMISSION_POT) < pot) {</pre>
00024
                  printf("Current: %d, Target: %d\n", analogRead(TRANSMISSION_POT), pot);
00025
                  transmission(sign(analogRead(TRANSMISSION_POT)-pot)*50);
00026
                  delay(20);
00028
        } else if(analogRead(TRANSMISSION_POT) > pot) {
00029
             while (analogRead(TRANSMISSION_POT) > pot) {
00030
                  printf("Current: %d, Target: %d\n", analogRead(TRANSMISSION_POT), pot);
00031
                  transmission(sign(analogRead(TRANSMISSION_POT)-pot)*50);
00032
                  delay(20);
00033
             }
00034
00035
         printf("Task loop completed.\n");
00036
         transmission(0);
00037 }
00038
```

4.41 src/opcontrol.c File Reference

File for operator control code.

```
#include "main.h"
```

Functions

- void targetNet (int target)
- void recordJoyInfo ()
- void moveRobot ()
- void operatorControl ()

Variables

- int spd
- int turn
- int sht
- · int intk
- · int trans
- int dep

4.41.1 Detailed Description

File for operator control code.

This file should contain the user operatorControl() function and any functions related to it.

Copyright (c) 2011-2014, Purdue University ACM SIG BOTS. All rights reserved.

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

 Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.

- Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials provided with the distribution.
- Neither the name of Purdue University ACM SIG BOTS nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXP← RESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERC← HANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PURDUE UNIVERSITY ACM SIG BOTS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Purdue Robotics OS contains FreeRTOS (http://www.freertos.org) whose source code may be obtained from http://sourceforge.net/projects/freertos/files/or on request.

Definition in file opcontrol.c.

```
4.41.2 Function Documentation
```

```
4.41.2.1 void moveRobot ( )
```

Moves the robot based on the motor state variables.

Definition at line 128 of file opcontrol.c.

```
4.41.2.2 void operatorControl ( )
```

Runs the user operator control code. This function will be started in its own task with the default priority and stack size whenever the robot is enabled via the Field Management System or the VEX Competition Switch in the operator control mode. If the robot is disabled or communications is lost, the operator control task will be stopped by the kernel. Re-enabling the robot will restart the task, not resume it from where it left off.

If no VEX Competition Switch or Field Management system is plugged in, the VEX Cortex will run the operator control task. Be warned that this will also occur if the VEX Cortex is tethered directly to a computer via the USB A to A cable without any VEX Joystick attached.

Code running in this task can take almost any action, as the VEX Joystick is available and the scheduler is operational. However, proper use of delay() or taskDelayUntil() is highly recommended to give other tasks (including system tasks such as updating LCDs) time to run.

This task should never exit; it should end with some kind of infinite loop, even if empty.

Definition at line 153 of file opcontrol.c.

```
4.41.2.3 void recordJoyInfo ( )
```

Populates the motor state variables based on the joystick's current values.

Definition at line 81 of file opcontrol.c.

```
4.41.2.4 void targetNet (int target)
```

Faces the robot towards the desired gyroscope angle by turning it. This function implements a simple PID control loop in order to correct for error.

Parameters

Definition at line 73 of file opcontrol.c.

4.41.3 Variable Documentation

4.41.3.1 int dep

Speed of the lift deployment motor.

Definition at line 65 of file opcontrol.c.

4.41.3.2 int intk

Speed of the intake motors.

Definition at line 55 of file opcontrol.c.

4.41.3.3 int sht

Speed of the shooter motors.

Definition at line 50 of file opcontrol.c.

4.41.3.4 int spd

Forward/backward speed of the drive motors.

Definition at line 40 of file opcontrol.c.

4.41.3.5 int trans

Speed of the transmission motors.

Definition at line 60 of file opcontrol.c.

4.41.3.6 int turn

Turning speed of the drive motors.

Definition at line 45 of file opcontrol.c.

4.42 opcontrol.c

```
00001
00035 #include "main.h"
00036
00040 int spd;
00041
00045 int turn;
00046
00050 int sht;
00051
00055 int intk;
00056
00060 int trans;
00061
00065 int dep;
00066
00073 void targetNet(int target){
          int error = gyroGet(gyro) % ROTATION_DEG - target;
00074
00075
          turn = error * GYRO P:
00076 }
00077
00081 void recordJoyInfo(){
          spd = joystickGetAnalog(1, 3);
00082
00083
          turn = joystickGetAnalog(1, 1);
          sht = 0;
00084
00085
          intk = 0;
          trans = 0;
00086
          if(joystickGetDigital(1, 6, JOY_UP) || joystickGetDigital(2, 6, JOY_UP)){
00087
00088
00089
          } else if(joystickGetDigital(1, 6, JOY_DOWN) || joystickGetDigital(2, 6, JOY_DOWN)){
00090
             sht = -127;
00091
          } else {
00092
              sht = 0;
00093
          if(joystickGetDigital(1, 5, JOY_UP) || joystickGetDigital(2, 5, JOY_UP)){
00094
00095
              intk = 127;
          } else if(joystickGetDigital(1, 5, JOY_DOWN) || joystickGetDigital(2, 5, JOY_DOWN)){
00096
00097
             intk = -127;
00098
          } else {
              intk = 0;
00099
00100
00101
          if(joystickGetDigital(1, 8, JOY_LEFT)){
00102
              trans = 80;
00103
              /*changeGear(GEAR_LIFT);*/
00104
          } else if(joystickGetDigital(1, 8, JOY_RIGHT)){
00105
              trans = -80;
00106
              /*changeGear(GEAR_DRIVE);*/
00107
          } else {
00108
              trans = 0;
00109
00110
          if(joystickGetDigital(1, 8, JOY_UP) || joystickGetDigital(2, 8, JOY_UP)){
              dep = 127;
00111
00112
          } else if(joystickGetDigital(1, 8, JOY_DOWN) || joystickGetDigital(2, 8, JOY_DOWN)){
00113
             dep = -127;
00114
          } else {
00115
             dep = 0;
00116
00117
00118
          if(joystickGetDigital(1, 7, JOY_DOWN)){
00119
              targetNet(GYRO_NET_TARGET);
00120
          } else if(joystickGetDigital(1, 7, JOY_UP)){
00121
              gyroReset(gyro);
00122
00123 }
00124
00128 void moveRobot(){
         move(spd, turn);
00130
          shoot(sht);
00131
          intake(intk);
00132
          transmission(trans);
00133
          deploy(dep);
00134 }
00135
00153 void operatorControl() {
00154
          lcdSetBacklight(LCD_PORT, true);
00155
          while (true) {
              if(isOnline() || progSkills == 0){
00156
00157
                  if (lcdDiagTask == NULL) {
00158
                      lcdDiagTask = taskCreate(formatLCDDisplay,
```

```
TASK_DEFAULT_STACK_SIZE, NULL, TASK_PRIORITY_DEFAULT);
00159
              } else if(taskGetState(lcdDiagTask) == TASK_SUSPENDED) {
00160
                        taskResume(lcdDiagTask);
00161
00162
                   if(!disableOpControl){
00163
                        recordJoyInfo();
00164
                        if (joystickGetDigital(1, 7, JOY_RIGHT) && !isOnline()) {
00165
                             taskSuspend(lcdDiagTask);
00166
                            recordAuton();
00167
                            lcdSetBacklight(LCD_PORT, true);
00168
                             saveAuton();
00169
                        } else if (joystickGetDigital(1, 7, JOY_LEFT) && !isOnline()) {
00170
                            taskSuspend(lcdDiagTask);
00171
                             lcdSetBacklight(LCD_PORT, true);
00172
                             loadAuton();
00173
                            playbackAuton();
00174
00175
                        moveRobot();
00176
                   }
00177
               } else {
                   motorStopAll();
lcdSetText(LCD_PORT, 1, "Press 7R");
lcdPrint(LCD_PORT, 2, "Last Skills: %d", progSkills);
if (joystickGetDigital(1, 7, JOY_RIGHT) && !isOnline()) {
00178
00179
00180
00181
00182
                        recordAuton();
00183
                        saveAuton();
                  } else if(joystickGetDigital(1, 7, JOY_UP) && !isOnline()) {
00184
00185
                        progSkills = 0;
00186
00187
               delay(20);
00188
00189
00190 }
00191
```

4.43 src/sensors.c File Reference

File for important sensor declarations and functions.

```
#include "main.h"
```

Functions

- void rturn (int bodydegs)
- void lturn (int bodydegs)
- · void goForward (int inches)
- void goBackward (int inches)

Variables

- Encoder leftenc
- Encoder rightenc
- Gyro gyro
- · Ultrasonic sonar

4.43.1 Detailed Description

File for important sensor declarations and functions.

This file contains the code for declarations and functions regarding sensors. The definitions contained herein define objects representing more complex sensors. The functions contained herein are too complex to be defined as inline functions in the sensors.h file.

See the sensors.h file for the basic sensory definitions and functions.

See also

sensors.h

Definition in file sensors.c.

4.43.2 Function Documentation

4.43.2.1 void goBackward (int inches)

Moves the robot backward a specified distance.

Parameters

to move backward	the amount of inches	inches
------------------	----------------------	--------

Definition at line 71 of file sensors.c.

4.43.2.2 void goForward (int inches)

Moves the robot forward a specified distance.

Parameters

inches	the amount of inches to move forward
--------	--------------------------------------

Definition at line 55 of file sensors.c.

4.43.2.3 void lturn (int bodydegs)

Turns the robot left to a specified angle.

Parameters

bodydegs	the amount of degrees to turn the robot
----------	---

Definition at line 40 of file sensors.c. 4.43.2.4 void rturn (int bodydegs) Turns the robot right to a specified angle. **Parameters** bodydegs the amount of degrees to turn the robot Definition at line 25 of file sensors.c. 4.43.3 Variable Documentation 4.43.3.1 Gyro gyro Object representing the gyroscope. Definition at line 78 of file sensors.c. 4.43.3.2 Encoder leftenc Object representing the encoder on the left side of the drivetrain. Definition at line 18 of file sensors.c. 4.43.3.3 Encoder rightenc Object representing the encoder on the right side of the drivetrain. Definition at line 23 of file sensors.c. 4.43.3.4 Ultrasonic sonar Object representing the ultrasonic sensor. Definition at line 83 of file sensors.c.

4.44 sensors.c

```
00001
00013 #include "main.h"
00014
00018 Encoder leftenc;
00019
00023 Encoder rightenc;
00024
00025 void rturn(int bodydegs) {
00026
          clearDriveEncoders();
00027
          float turndeg;
          float encdegperbodydeg = DRIVE_WHEELBASE / (DRIVE_DIA *
00028
     DRIVE_GEARRATIO);
00029
          turndeg = encdegperbodydeg * bodydegs;
00030
00031
          while(abs(encoderGet(rightenc)) < abs(turndeg)) {</pre>
00032
              move(0, MOTOR_MAX);
              delay(20);
00033
00034
00035
00036
          move(0, 0);
00037
          clearDriveEncoders();
00038 }
00039
00040 void lturn(int bodydegs) {
00041
          clearDriveEncoders();
00042
          float turndeg;
00043
          float encdegperbodydeg = DRIVE_WHEELBASE / (DRIVE_DIA *
     DRIVE_GEARRATIO);
00044
          turndeg = encdegperbodydeg * bodydegs;
00045
00046
          while(abs(encoderGet(leftenc)) < abs(turndeg)) {</pre>
00047
              move(0, -MOTOR_MAX);
00048
              delay(20);
00049
00050
00051
          move(0, 0);
00052
          clearDriveEncoders();
00053 }
00054
00055 void goForward(int inches) {
00056
          int deg;
00057
          float encperinch;
          encperinch = 360/(DRIVE_DIA * PI * DRIVE_GEARRATIO);
00058
00059
          deg = encperinch * (float)inches;
00060
00061
          clearDriveEncoders();
00062
          while(abs(encoderGet(rightenc)) < abs(deg))</pre>
00063
00064
              move(sign(inches) * 127, 0);
              delay(20);
00065
00066
00067
          move(0,0);
00068
          clearDriveEncoders();
00069 }
00070
00071 void goBackward(int inches) {
00072
          goForward(-inches);
00073 }
00074
00078 Gyro gyro;
00079
00083 Ultrasonic sonar;
00084
```

Index

AUTON_BUTTON	saveAuton, 8
autonrecorder.h, 7	states, 9
AUTON_FILENAME_MAX_LENGTH	autonroutines.c
autonrecorder.h, 7	runHardCodedProgrammingSkills, 57
AUTON_POT_HIGH	autonroutines.h
autonrecorder.h, 7	CLOSE_GOAL_ANGLE, 11
AUTON_POT_LOW	DISTANCE_TO_OTHER_SIDE, 11
autonrecorder.h, 7	runHardCodedProgrammingSkills, 11
AUTON_POT	DATT DIVID
autonrecorder.h, 7	BATT_BKUP
AUTON_TIME	sensors.h, 44
autonrecorder.h, 7	BATT_MAIN
abs	sensors.h, 44
macros.h, 26	BATT_PEXP
addMotorGroup	sensors.h, 44
lcddiag.c, 62	backlight
auto.c	lcddiag.c, 69
autonomous, 50	bitClear
autonLoaded	bitwise.h, 12
autonrecorder.c, 52	bitRead
autonrecorder.h, 9	bitwise.h, 12
autonomous	bitSet
auto.c, 50	bitwise.h, 12
main.h, 32	bitWrite
autonrecorder.c	bitwise.h, 13
autonLoaded, 52	bitwise.h
initAutonRecorder, 51	bitClear, 12
loadAuton, 51	bitRead, 12
playbackAuton, 51	bitSet, 12
progSkills, 52	bitWrite, 13
recordAuton, 51	OLOGE COAL ANOLE
saveAuton, 52	CLOSE_GOAL_ANGLE
selectAuton, 52	autonroutines.h, 11
states, 52	changeGear
autonrecorder.h	motors.h, 36
AUTON BUTTON, 7	clearDriveEncoders
AUTON_FILENAME_MAX_LENGTH, 7	sensors.h, 46
AUTON POT HIGH, 7	constants.h
AUTON POT LOW, 7	DEG_TO_RAD, 14
AUTON POT, 7	HALF_PI, 14
AUTON TIME, 7	MATH_PI, 14
autonLoaded, 9	MATH_E, 14
initAutonRecorder, 8	PI, 14
JOY POLL FREQ, 7	RAD_TO_DEG, 14
joyState, 8	ROTATION_DEG, 14
loadAuton, 8	ROTATION_RAD, 15
MAX_AUTON_SLOTS, 7	TAU, 15
PROGSKILL_TIME, 7	TWO_PI, 15
	constrain
playbackAuton, 8	macros.h, 26
progSkills, 9	DEC TO PAD
recordAuton, 8	DEG_TO_RAD

constants.h, 14	sensors.c, 92
DISTANCE_TO_OTHER_SIDE	sensors.h, 46
autonroutines.h, 11	groups
DRIVE_DIA	lcddiag.c, 69
robot.h, 42	lcddiag.h, 22
DRIVE_GEARRATIO	gyro
robot.h, 42	sensors.c, 93
DRIVE_WHEELBASE	sensors.h, 47
robot.h, 42	HALF PI
degrees	constants.h, 14
macros.h, 27	Constants.n, 14
delMotorGroup	INTAKE_ROLLER_MOTOR
lcddiag.c, 62	motors.h, 35
dep	include/autonrecorder.h, 5, 9
joyState, 4	include/autonroutines.h, 10, 11
opcontrol b 40	include/bitwise.h, 11, 13
opcontrol.h, 40	include/constants.h, 13, 15
deploy	include/friendly.h, 15, 17
motors.h, 37	include/lcddiag.h, 17, 22
disableOpControl lcddiag.c, 69	include/lcdmsg.h, 23, 25
leddiag.h, 21	include/macros.h, 25, 30
doMenuChoice	include/main.h, 30, 33
leddiag.e, 62	include/motors.h, 34, 38
10ddiag.0, 02	include/opcontrol.h, 39, 41
editMotorGroup	include/robot.h, 41, 42
lcddiag.c, 63	include/sensors.h, 42, 48
	init.c
formatLCDDisplay	initialize, 59
lcddiag.c, 63	initializeIO, 59
lcddiag.h, 20	initAutonRecorder
formatMenuNameCenter	autonrecorder.c, 51
lcddiag.c, 63	autonrecorder.h, 8
friendly.h	initGroups
PRESSED, 16	Icddiag.c, 64
RELEASED, 16	lcddiag.h, 20
UNPRESSED, 16	initialize
LINDEL EACED 16	
UNRELEASED, 16	init.c, 59
	main.h, 32
GEAR_DRIVE	main.h, 32 initializeIO
GEAR_DRIVE sensors.h, 44	main.h, 32 initializeIO init.c, 59
GEAR_DRIVE sensors.h, 44 GEAR_LIFT	main.h, 32 initializeIO init.c, 59 main.h, 32
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44	main.h, 32 initializeIO init.c, 59 main.h, 32 intake
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44 GYRO_P	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40 JOY_POLL_FREQ
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44 GYRO_P sensors.h, 44	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40 JOY_POLL_FREQ autonrecorder.h, 7
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40 JOY_POLL_FREQ autonrecorder.h, 7 joyState, 3
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P sensors.h, 44 goBackward sensors.c, 92	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40 JOY_POLL_FREQ autonrecorder.h, 7 joyState, 3 autonrecorder.h, 8
GEAR_DRIVE sensors.h, 44 GEAR_LIFT sensors.h, 44 GYRO_NET_TARGET sensors.h, 44 GYRO_PORT sensors.h, 44 GYRO_SENSITIVITY sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P sensors.h, 44 GYRO_P	main.h, 32 initializeIO init.c, 59 main.h, 32 intake motors.h, 37 intk joyState, 4 opcontrol.c, 89 opcontrol.h, 40 JOY_POLL_FREQ autonrecorder.h, 7 joyState, 3

sht, 4	runMotorGroupMgmt, 66
spd, 4	runRobot, 66
trans, 4	runScreensaver, 66
turn, 4	saveGroups, 66
	selectMenu, 66
LCD_750C_TITLE	selectMotor, 67
lcdmsg.h, 24	selectMotorGroup, 67
LCD_MENU_COUNT	selectMotorGroupMembers, 67
Icddiag.h, 18	selectSpd, 68
LCD_MESSAGE_COUNT	selectSpdGroup, 68
lcdmsg.h, 24	typeString, 68
LCD_MESSAGE_MAX_LENGTH	lcddiag.h
lcdmsg.h, 24	disableOpControl, 21
LCD_PORT	formatLCDDisplay, 20
lcdmsg.h, 24	groups, 22
LEFT_ENC_BOT	initGroups, 20
sensors.h, 45	LCD_MENU_COUNT, 18
LEFT_ENC_TOP	IcdAnyButtonPressed, 20
sensors.h, 45	IcdButtonPressed, 21
LEFT_MOTOR_BOT	lcdDiagTask, 22
motors.h, 35	MENU_AUTON, 18
LEFT_MOTOR_TOP	MENU_BACKLIGHT, 19
motors.h, 35	MENU_BATTERY, 19
LIFT_DEPLOY	MENU_CONNECTION, 19
motors.h, 35	MENU_CREDITS, 19
IcdAnyButtonPressed	MENU_MOTOR_MGMT, 19
lcddiag.h, 20	MENU_MOTOR, 19
IcdButtonPressed	MENU_ROBOT, 19
Icddiag.h, 21	MENU_SCREENSAVER, 19
IcdDiagTask	menuChoices, 22
Icddiag.c, 69	MotorGroup, 20
Icddiag.h, 22	numgroups, 22
lcddiag.c	typeString, 21
addMotorGroup, 62	lcdmsg
backlight, 69	lcdmsg.c, 84
delMotorGroup, 62	lcdmsg.h, 25
disableOpControl, 69	lcdmsg.c
doMenuChoice, 62	Icdmsg, 84
editMotorGroup, 63	randlcdmsg, 84
formatLCDDisplay, 63	screensaver, 84
formatMenuNameCenter, 63	lcdmsg.h
groups, 69	LCD_750C_TITLE, 24
initGroups, 64	LCD_MESSAGE_COUNT, 24
lcdDiagTask, 69	LCD_MESSAGE_MAX_LENGTH, 24
loadGroups, 64	LCD_PORT, 24
menuChoices, 69	lcdmsg, 25
numgroups, 69	randlcdmsg, 24
runAuton, 64	screensaver, 25
runBattery, 64	leftenc
runConnection, 64	sensors.c, 93
runCredits, 64	sensors.h, 47
runGroupMotor, 65	loadAuton
runIndivMotor, 65	autonrecorder.c, 51
runMotor, 65	autonrecorder.h, 8

loadGroups	initializeIO, 32
lcddiag.c, 64	operatorControl, 33
lturn	max
sensors.c, 92	macros.h, 27
sensors.h, 46	menuChoices
MATIL DI	lcddiag.c, 69
MATH_PI	lcddiag.h, 22
constants.h, 14	min
MATH_E	macros.h, 28
constants.h, 14	motor
MAX_AUTON_SLOTS	MotorGroup, 5
autonrecorder.h, 7	MotorGroup, 5
MAX	lcddiag.h, 20
macros.h, 27	motor, 5
MENU_AUTON	name, 5
Icddiag.h, 18	motors.c
MENU_BACKLIGHT	transmissionSetPos, 86
Icddiag.h, 19	motors.h
MENU_BATTERY	changeGear, 36
lcddiag.h, 19	deploy, 37
MENU_CONNECTION	INTAKE_ROLLER_MOTOR, 35
lcddiag.h, 19	intake, 37
MENU_CREDITS	LEFT_MOTOR_BOT, 35
lcddiag.h, 19	LEFT_MOTOR_TOP, 35
MENU_MOTOR_MGMT	LIFT_DEPLOY, 35
lcddiag.h, 19	MOTOR_MAX, 35
MENU_MOTOR	MOTOR_MIN, 35
lcddiag.h, 19	move, 37
MENU_ROBOT	NAUTILUS_SHOOTER_MOTOR_CENTER, 36
lcddiag.h, 19	NAUTILUS_SHOOTER_MOTOR_LEFT, 36
MENU_SCREENSAVER	NAUTILUS_SHOOTER_MOTOR_RIGHT, 36
lcddiag.h, 19	RIGHT_MOTOR_BOT, 36
MIN	RIGHT_MOTOR_TOP, 36
macros.h, 28	ROBOT_HAS_LIFT_DEPLOY_MOTOR, 36
MOTOR_MAX	SHOOTER_HAS_THREE_MOTORS, 36
motors.h, 35	shoot, 37
MOTOR_MIN	TRANSMISSION_MOTOR, 36
motors.h, 35	transmission, 37
macros.h	transmissionSetPos, 38
abs, 26	move
constrain, 26	motors.h, 37
degrees, 27	moveRobot
MAX, 27	opcontrol.c, 88
MIN, 28	opcontrol.h, 40
max, 27	NAUTUUG GUGOTED MOTOD GENTED
min, 28	NAUTILUS_SHOOTER_MOTOR_CENTER
radians, 28	motors.h, 36
round, 29	NAUTILUS_SHOOTER_MOTOR_LEFT
sign, 29	motors.h, 36
SQ, 29	NAUTILUS_SHOOTER_MOTOR_RIGHT
sq, 29	motors.h, 36
main.h	NUM_BATTS
autonomous, 32	sensors.h, 45
initialize, 32	name

MotorGroup, 5	sensors.h, 45
numgroups	RIGHT_MOTOR_BOT
lcddiag.c, 69	motors.h, 36
lcddiag.h, 22	RIGHT_MOTOR_TOP
	motors.h, 36
opcontrol.c	ROBOT_HAS_LIFT_DEPLOY_MOTOR
dep, 89	motors.h, 36
intk, 89	ROTATION_DEG
moveRobot, 88	constants.h, 14
operatorControl, 88	ROTATION_RAD
recordJoyInfo, 88	constants.h, 15
sht, 89	radians
spd, 89	
targetNet, 88	macros.h, 28
trans, 89	randlcdmsg
turn, 89	lcdmsg.c, 84
opcontrol.h	lcdmsg.h, 24
•	recordAuton
dep, 40	autonrecorder.c, 51
intk, 40	autonrecorder.h, 8
moveRobot, 40	recordJoyInfo
recordJoyInfo, 40	opcontrol.c, 88
sht, 40	opcontrol.h, 40
spd, 40	rightenc
trans, 40	sensors.c, 93
turn, 40	sensors.h, 47
operatorControl	robot.h
main.h, 33	
opcontrol.c, 88	DRIVE_DIA, 42
•	DRIVE_GEARRATIO, 42
POWER_EXPANDER_STATUS	DRIVE_WHEELBASE, 42
sensors.h, 45	round
POWER_EXPANDER_VOLTAGE_DIVISOR	macros.h, 29
sensors.h, 45	rturn
PRESSED	sensors.c, 93
friendly.h, 16	sensors.h, 47
PROGSKILL TIME	runAuton
autonrecorder.h, 7	lcddiag.c, 64
PI	runBattery
	lcddiag.c, 64
constants.h, 14	runConnection
playbackAuton	lcddiag.c, 64
autonrecorder.c, 51	runCredits
autonrecorder.h, 8	lcddiag.c, 64
powerLevelExpander	runGroupMotor
sensors.h, 47	lcddiag.c, 65
progSkills	<u> </u>
autonrecorder.c, 52	runHardCodedProgrammingSkills
autonrecorder.h, 9	autonroutines.c, 57
	autonroutines.h, 11
RAD_TO_DEG	runIndivMotor
constants.h, 14	lcddiag.c, 65
RELEASED	runMotor
friendly.h, 16	lcddiag.c, 65
RIGHT_ENC_BOT	runMotorGroupMgmt
sensors.h, 45	lcddiag.c, 66
RIGHT_ENC_TOP	runRobot

lcddiag.c, 66	LEFT_ENC_TOP, 45
runScreensaver	leftenc, 47
Icddiag.c, 66	Iturn, 46
CHOOTER HAS TURES MOTORS	NUM_BATTS, 45
SHOOTER_HAS_THREE_MOTORS	POWER_EXPANDER_STATUS, 45
motors.h, 36	POWER_EXPANDER_VOLTAGE_DIVISOR, 45
SHOOTER_LIMIT	powerLevelExpander, 47
sensors.h, 45 saveAuton	RIGHT_ENC_BOT, 45 RIGHT_ENC_TOP, 45
	rightenc, 47
autonrecorder.c, 52	rturn, 47
autonrecorder.h, 8 saveGroups	SHOOTER LIMIT, 45
lcddiag.c, 66	sonar, 48
screensaver	TRANSMISSION_POT, 45
Icdmsg.c, 84	ULTRASONIC_ECHO_PORT, 46
lcdmsg.h, 25	ULTRASONIC_PING_PORT, 46
selectAuton	shoot
autonrecorder.c, 52	motors.h, 37
selectMenu	sht
Icddiag.c, 66	joyState, 4
selectMotor	opcontrol.c, 89
Icddiag.c, 67	opcontrol.h, 40
selectMotorGroup	sign
Icddiag.c, 67	macros.h, 29
selectMotorGroupMembers	sonar
lcddiag.c, 67	sensors.c, 93
selectSpd	sensors.h, 48
lcddiag.c, 68	spd
selectSpdGroup	joyState, 4
lcddiag.c, 68	opcontrol.c, 89
sensors.c	opcontrol.h, 40
goBackward, 92	SQ
goForward, 92	macros.h, 29
gyro, 93	sq
leftenc, 93	macros.h, 29
Iturn, 92	src/auto.c, 49, 50
rightenc, 93	src/autonrecorder.c, 50, 53
rturn, 93	src/autonroutines.c, 57, 58
sonar, 93	src/init.c, 58, 60
sensors.h	src/lcddiag.c, 61, 70
BATT_BKUP, 44	src/lcdmsg.c, 83, 85
BATT_MAIN, 44	src/motors.c, 86
BATT_PEXP, 44	src/opcontrol.c, 87, 90
clearDriveEncoders, 46	src/sensors.c, 91, 94
GEAR_DRIVE, 44	states
GEAR_LIFT, 44	autonrecorder.c, 52
GYRO_NET_TARGET, 44	autonrecorder.h, 9
GYRO_PORT, 44	TALL
GYRO_SENSITIVITY, 44	TAU
GYRO_P, 44	constants.h, 15
goBackward, 46	TRANSMISSION_MOTOR
goForward, 46	motors.h, 36 TRANSMISSION POT
gyro, 47 LEFT_ENC_BOT, 45	sensors.h, 45
LLI 1_LINO_DO1, 43	3G113U13.11, 40

```
TWO_PI
    constants.h, 15
targetNet
    opcontrol.c, 88
trans
    joyState, 4
    opcontrol.c, 89
    opcontrol.h, 40
transmission
    motors.h, 37
transmissionSetPos
    motors.c, 86
    motors.h, 38
turn
    joyState, 4
    opcontrol.c, 89
    opcontrol.h, 40
typeString
    Icddiag.c, 68
    Icddiag.h, 21
ULTRASONIC_ECHO_PORT
    sensors.h, 46
ULTRASONIC_PING_PORT
    sensors.h, 46
UNPRESSED
    friendly.h, 16
UNRELEASED
    friendly.h, 16
```