







## 

PROFESSIONAL WOMLERS ASSOCIATION.  Official Lane Maintenance and Capital Equipment Provider																3					Select N	fachine		<b>—</b>		ر	ı	Г	7	L	) [	<b>1</b>	<u> </u>	<u> </u>	T		<b>=</b>		_
Pattern Information											Pattern Parameters												Supplies Information																
Date									Pattern Number														Lane Cleaner								Brunswick Invincible								
Pattern Type Competitive								Pattern Name							2015 BMC							Cleaner Mixture Ratio								:	1	l							
Pattern Difficulty Medium							Mode							Clean & Oil						Cleaner Transition Distance									42		Auth	ority2	22						
Pattern Designer Pat Mitchell							Forward Speed							Max Clean							Cleaner Spray End Distance								53 Envoy										
Pattern Volume (ml) 24.15										Sta	art C	lean	er S <sub>l</sub>	pray		0																							
Surface Information									Start Squeegee													Lane Conditione									r Brunswick Logic								
Surfa	Surface Type Synthetic										Start Oiling							6				N	otes	es Bowling Chamartin															
Surface Brand Brunswick Glo Anvil - 3/8"									Split Pattern							Ю						Madrid, Spain																	
Age																																							
			_							_	_			_								_				_				_				_					
_				Zone	one 1 2 nce 12 19									3			4		5					6			1	7			8			l					
Z	one	End	Dist	ance					9				27		3		33			40	40									1 1									
		2 5	5 :	1	1	2.8	в:	1	Г	3.3		1		3 2	:	1	1	###	:	1		###	:	1	1	###	:	1	1 1	###	:	1							
	Z	one F	Ratio	R		, <u>.</u> 5 :						-			1						###	•	<u>.</u> 1		###		1		###		1	1	###	÷	<u>-</u>	l			
Zone Volume													3.3 : 1			3.2 : 1				ппп				ппп		. '		mmn	0.00				0.00	•	l				
Zone Volume (ml) 13.03 5.62									J_	3.72						1.79 0.00						0.00					0.00				0.00								
ZONE		7 Pin Side																Board Number						10 Pin Side															
ZUNE	L1	L2	L3	L4	L5	L6	L7	L8	L9	L1	10 L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	4 R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	33	33	33	33	33	35	37	46	88	88	8 88	88	88	88	88	88	22	88	88	88	88	88	88	88	88	88	88	88	88	88	88	46	37	35	33	33	33	33	33

ZONE		7 Pin Side															Вс	oard	Num	ber				10 Pin Side															
ZONE	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1
1	33	33	33	33	33	35	37	46	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	88	46	37	35	33	33	33	33	33
2	22	22	22	22	22	24	26	38	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	66	38	26	24	22	22	22	22	22
3	12	12	12	12	12	12	13	15	24	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	41	24	15	13	12	12	12	12	12	12
4	8	8	8	8	8	8	9	11	13	18	27	27	27	27	27	27	27	27	27	27	27	27	27	27	27	27	27	27	27	18	13	11	9	8	8	8	8	8	8
5	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
6																																							
7																																							
8				_											-										_												_		

