#### **ECE 341**

#### Lecture # 16

Instructor: Zeshan Chishti zeshan@ece.pdx.edu

**November 24, 2014** 

**Portland State University** 

## **Lecture Topics**


- The Memory System
  - Basic Concepts
  - Semiconductor RAM Memories
    - Organization of Memory Devices
    - Static RAM (SRAM)
    - Dynamic RAM (DRAM)
    - Structure of Larger Memories
  - Read-only Memories (ROM)
  - Memory Hierarchy
  - Cache Memories

#### Reference:

Chapter 8: Sections 8.1, 8.2, 8.3, 8.5 and 8.6 (Pages 268 – 285 and 289 – 290 of textbook)

## **Basic Concepts**

- Each memory location is specified by an *address*
- Max. size of main memory (also called the size of address space) is determined by the no. of address bits
  - e.g., a computer with 32-bit addresses can access  $2^{32} = 4$  G (giga) memory locations
- Memory transfers usually happen in word granularities



# **Basic Concepts (cont.)**

- Measures for memory speed:
  - Memory access time: Time elapsed between the initiation of an operation to transfer data from/to memory and the completion of that operation
  - Memory cycle time: Time required between initiation of two successive memory accesses
- Most important issue in memory systems design is to provide a computer with as large and fast a memory as possible, within a given cost target
- Cost of a memory device depends on both its capacity (total no. of bits) and its density (bits per unit area)
- For a fixed capacity, higher density => less chip area => less cost per bit
- Different memory technologies have different cost & speed characteristics
- Typically memory speed & memory cost are competing constraints


# Random Access Memory (RAM)

- A memory unit is called a random-access memory (RAM), if the access time to any location is the same, independent of the location's address
- In non-RAM storage devices, such as magnetic and optical disks, access time depends on the address or position of data
- Two types of RAMs:
  - Static Random Access Memory (SRAM)
  - Dynamic Random Access Memory

# **Organization of Memory Devices**

- A memory chip is made up of a combination of memory cells
- Each memory cell can hold one bit of information
- Memory cells are organized in the form of a 2-dimensional array
- All cells in a row are connected to a common line, known as the "word line"
- Word line is connected to the address decoder
- All cells in a column are connected to a common line, known as the "bit line"
- Sense/write circuits are connected to both the bit lines and the data input/output lines of the memory chip

#### Example: 16 x 8 memory array




#### Static Random Access Memory (SRAM)

- Consists of circuits that are capable of retaining their state as long as the power is applied
- SRAMs are volatile memories, because their contents are lost when power is interrupted
- SRAM use a complex memory cell structure, typically six transistors per memory cell
  - High cost per bit
  - Fast access times (few nanoseconds)
- Used to implement on-chip caches, where speed is of critical concern

#### **Basic SRAM Cell**

- Two inverters cross connected to implement a D flip-flop
- Cell connected to one word line and two bit lines by transistors T1 & T2
- T1 and T2 act as switches.
  - when word line is deactivated, T1 & T2 are turned off and the cell retains state




# **Basic SRAM Cell (cont.)**

#### Read operation:

- word line is activated to close switches T1 and T2
- sense/write circuits at the bottom monitor the state of b and b' to read the bit value


#### Write operation:

- word line is activated to close switches T1 and T2
- sense/write circuits write the bir cell by placing appropriate values on b and b'




#### **Dynamic Random Access Memory (DRAM)**

- Memory cells in DRAMs are much simpler than in SRAMs
  - Each DRAM cell requires only one transistor and one capacitor
- Consequently, DRAMs are less expensive than SRAMs but have longer access times than SRAMs
- DRAMs are typically used as main memory, not as cache
- DRAM cells lose their state over time and need to be periodically refreshed to prevent loss of stored state




#### Example: A 32M x 8 DRAM Chip



- Word size = 8-bits (1B), so there are 8 data lines  $(D_7 - D_0)$
- There are 16384 rows, each row can store 2048 bytes(16348 \* 2048 = 32M words)
- 14 bits  $(A_{24} A_{11})$  to select a row, and 11 bits  $(A_{10} A_0)$  to select a byte within a row
  - First apply the row address, RAS signal latches the row address. Then apply the column address, CAS signal latches the column address.
- Memory timing is controlled by a specialized unit which generates RAS and CAS
- This DRAM is asynchronous

### **Example: Large Memories**



<u>Problem:</u> Implement a memory unit of 2M words of 32 bits each by using 512Kx8 memory chips.

**Solution:** (shown on left)

- We need 16 total chips, arranged in 4 rows and 4 columns
- Each chip provides 8 bits of the 32-bit word
- A chip is selected by setting its chip select control line to 1.
- On a memory access, the 2-bit decoder decides which row provides the required word, all chips in that row are selected


#### **Fast Page Mode**

- Suppose we want to read the consecutive bytes in a row
- This can be done without having to re-read the entire row every time
  - Add a latch (called row buffer) at the output of sense/write circuits
  - When the row is selected, the sense circuit reads the row contents and transfers them into the row buffer
  - Subsequent accesses can read the row contents from the row buffer
- Consecutive sequence of column addresses can be applied under the control signal CAS, without reselecting the row
  - Allows a data block to be transferred much faster than random accesses
- This capability is referred to as the fast page mode feature.

### **Memory Controller**

- Recall that accessing a DRAM chip requires multiplexed addresses,
- Each DRAM address is divided into two parts:
  - High-order address bits select a row in the DRAM array. They are provided first, and latched using RAS signal
  - Low-order address bits select a column in the row. They are provided later, and latched using CAS signal
- However, the address sent by processor includes all the address bits at the same time
- In order to achieve the multiplexing, memory controller circuit is inserted between the processor and memory
- Memory controller acts as a bridge between processor and memory
- It receives a memory request from the processor and then generates the appropriate signals (R/W, row and column address, RAS, CAS) with appropriate timing to access the memory

## **Memory Controller (cont.)**



## **Read-only Memories (ROM)**

- SRAM and DRAM chips are volatile
  - Retain contents only while power is turned on
- Many applications require memory devices that retain their contents after power is turned off (non-volatile memories)
  - For example, the program that starts the bootstrap process of loading the OS from hard disk into main memory
- Non-volatile memory is read in same manner as volatile memory
- A special writing process is needed to place information into a non-volatile memory
- Since normal operation involves only reading the stored data, this type of memory is called a Read-Only memory

### **Example: Flash Memory**

#### Flash memory

- Reads can happen at single cell granularity, but writes must happen at block granularity (a block is several thousand bits)
- Before writing to a location, the entire block must be erased
  - Write usually much slower (10x to 100x) than reads
- Flash devices have a limited endurance; cells wear out after a certain number of writes
- Flash devices have higher density than DRAM => Lower cost/bit
- Power consumption of flash memory is very low, making it attractive for use in battery-powered devices
- Single flash chips are not sufficiently large, so larger memory modules are implemented using flash cards and flash drives

#### **Memory System Design Tradeoffs**

 A big challenge in memory system design is to provide a sufficiently large memory capacity, with reasonable speed at an affordable cost

#### SRAM

Complex basic cell circuit => fast access, but high cost per bit

#### DRAM


Simpler basic cell circuit => less cost per bit, but slower than SRAMs

#### Flash memory and Magnetic disks

- DRAMs provide more storage than SRAM but less than what is necessary
- Disks provide a large amount of storage, but are much slower than DRAMs

No single memory technology can provide both large capacity and fast speed at an affordable cost

#### **Memory Hierarchy**



- Memory system implemented as a multi-level hierarchy to provide both large capacity and fast access
- Higher levels made of small but fast SRAMs
  - Fast access speed in the common case
- Lower levels made of DRAM and hard disk
- Large capacity at low cost
  Key idea is to reduce average
  memory access time by
  bringing instructions and data
  that will be used in the near
  future as close to the processor
  as possible

#### **Cache Memories**

#### Memory Wall Problem:

- Processor is much faster than the main memory
- Main memory speed cannot be increased beyond a certain point
- Processor has to spend much of its time waiting while instructions/data are being fetched from memory

#### Solution: Cache Memory


- Cache memory is an architectural arrangement that makes the main memory appear faster to the processor than it really is
- Cache memory is based on the property of computer programs that is known as "<u>locality of reference"</u>

### **Locality of Reference**

- Analysis of programs indicates that many instructions in localized areas of a program are executed repeatedly during some period of time, while other instructions are executed relatively less frequently
  - Example: loops, nested loops or few procedures calling each other repeatedly
  - This is called <u>"locality of reference"</u>
- Temporal locality of reference
  - Recently executed instruction is likely to be executed again very soon
  - Recently accessed data is likely to be accessed very soon
- Spatial locality of reference
  - Instructions/data with addresses close to a recently accessed instruction/data are likely to be accessed soon

A cache is designed to take advantage of both types of "locality of reference"

#### **Use of a Cache Memory**



- Small and fast SRAM cache inserted between processor and main memory
- Data organized at the granularity of <u>cache blocks</u>
- When the processor issues a request for a memory address, an entire block (e.g., 64 bytes) is transferred from the main memory to the cache
- Later references to same address can be serviced by the cache (temporal locality)
- References to other addresses in this block can also be serviced by the cache (spatial locality)

Higher locality => More requests serviced by the cache