





Note list: Please check every note beforr your design. PCB Layout Note Application Note Host Design note When you using SPI2 Interface other Host pin should be NC if unused. (Optional) HOST HWE# HOST HRD HOST HCS HOST HD C DB0~DB16 GPIO Design note GPIO should be NC if unused. (Optional) GPIO0~GPIO7 GPIO8~GPIO15 SDCE Dseign note When IT8951 control the SHR, the SDCE must be selected SHR = 0 ; SDCE N0 = Output SHR = 1 ; SDCE_N1 = Output EPD Source Data bus (D0~D15) EPD Source Data bus(DO~D15) need equal length SPI Flash SPI Flash need initial Firmware at first, and then you can use USB or SPI interface to download Firmware. The SPI Flash size recommend 4MBytes Layout note Document Number Size Rev DK-IT8951 application circuit <RevCode> Wednesday, August 08, 2018