

# **Project Four**

ENEE 447: Operating Systems – Spring 2020 Assigned: Week of Mar 2; Due: Week of Mar 9

## **Purpose**

In this project you will implement context switching on the Raspberry Pi, using perhaps the simplest possible scheduling algorithm: on every timer tick you will switch back and forth between two processes (i.e., if thread 0 is running, change to thread 1; if thread 1 is running, change to thread 0). The two threads will be in the same address space, so we will not have to worry about saving and restoring anything other than the register file contents (for instance, once we have virtual memory running, you will have to save special control registers related to that). Context switching obviously represents the underpinning of all multitasking and multiprocessing and is thus one of the operating system's most fundamental and powerful mechanisms. From this point, you will be able to implement much more sophisticated scheduling algorithms and juggle any number of simultaneous threads.

## **Context Switch in ARM**

Recall the register-file arrangement in the ARM architecture:

User/System	FIQ	IRQ	SVC	Undef	Abort
r0	r0	r0	r0	r0	r0
r1	r1	r1	r1	r1	r1
r2	r2	r2	r2	r2	r2
r3	r3	r3	r3	r3	r3
r4	r4	r4	r4	r4	r4
r5	r5	r5	r5	r5	r5
r6	r6	r6	r6	r6	r6
r7	r7	r7	r7	r7	r7
r8	r8_fiq	r8	r8	r8	r8
r9	r9_fiq	r9	r9	r9	r9
r10	r10_fiq	r10	r10	r10	r10
r11	r11 fiq	r11	r11	r11	r11
r12	r12 fiq	r12	r12	r12	r12
r13/SP	r13 fiq	r13 irq	r13 svc	r13 undef	r13 abort
r14/LR	r14_fiq	r14_irq	r14_svc	r14_undef	r14_abort
r15/PC	r15/PC	r15/PC	r15/PC	r15/PC	r15/PC
cpsr	-	-	-	-	-
-	spsr_fiq	spsr_irq	spsr_svc	spsr_undef	spsr_abort

The IRQ vector shares a number of registers with code running in USR mode: r0–r12 and the program counter are **common**, while the IRQ vector runs in a mode that has its own stack pointer (r13) and link register (r14).

Among many other things, what this means is that, assuming you have a register-save area of sufficient size, located at *threadSave*, then the following code will save all of the registers visible in USR and SYS modes:

```
save r13 irq: .word 0
irq nop:
       // save the registers
             r13, save_r13_irq
      str
                                  @ save the IRQ stack pointer
             r13, =threadSave
      ldr
                                  @ load the IRQ stack pointer with address of TCB
                                  @ jump to middle of TCB for store up and store down
             r13, r13, #56
      add
      stmia sp, {sp, lr}^
                                 @ store USR stack pointer & link register, upwards
             {r0-r12, lr}
                                  @ store USR regs 0-12, IRQ link register, downwards
      @ regs saved, we can now destroy stuff
              clear timer interrupt (we get here from timer)
      11
      bl clear_timer_interrupt
              clobber the user stack - simulates effect of another thread running
      a
             clobber the user stack - simulates effect of another thread running
             clobber the user stack - simulates effect of another thread running
             r2, # SYS mode
      msr
             cpsr c, r2
             r0,badval
      ldr
      ldr
             r1, badval
             r2,badval
      ldr
             r3,badval
      ldr
      ldr
             r4,badval
      ldr
             r5,badval
      ldr
             r6,badval
      ldr
             r7,badval
      ldr
             r8,badval
      ldr
             r9,badval
      ldr
             r10,badval
      ldr
             r11,badval
             r12,badval
      ldr
      ldr
             r13,badval
      ldr
             r14,badval
             r2, # IRQ mode
      mov
             cpsr c, r2
      msr
             clobber the user stack - simulates effect of another thread running
             clobber the user stack - simulates effect of another thread running
             clobber the user stack - simulates effect of another thread running
      // reset the timer
      b1
             set timer
      // restore the registers with address of TCB
      ldr r13, =threadSave @ load the IRQ stack pointer
             gog
       ldmia sp, {sp, lr}^
                                  @ evidently it's a good idea to put NOP after LDMIA
      nop
             r13, save_r13_irq @ restore the IRQ stack pointer from way above pc. lr. #4 @ return from exception
      ldr
       subs
             pc, lr, #4
                                   @ return from exception
```

This code does several things. First, it saves the stack pointer *sp/r13* into a known location. Then, it saves the thread context on an array of words pointed to by *threadSave*: this is done by first jumping into the middle of the array, storing two values upward, and then storing 14 values downwards. Once those values are saved, it is free to destroy the register file contents (which simulates a context switch to

another thread). The handler changes to SYS mode, which shares the same register file as USR mode, and it loads a garbage value into registers 0–14. Then it jumps back into the IRQ handler's mode, restores the previously saved state, and exits.

This code is given to you in the project source directory for Project 4. The entire project, as presented to you, compiles and runs, with the exception of the code you have written for Project 3. With it, you will build the penultimate feature of The Simplest Possible Operating System™ — the preemptive context switch.

# The Simplest Possible Operating System™

As said before, at its simplest, an OS is nothing more than a collection of vectors: it does nothing unless it is responding to interrupts. This is what we will be building in Projects 3, 4, and 5. Project 3 implemented a system-call facility and provided an extremely rudimentary shell that runs in user mode — but still within the kernel proper, for now. Project 4 adds to that the preemptive context switch and a rudimentary scheduler: switch processes every time quantum. The code for saving and restoring state is provided above, and your job is to use this to create the scheduler and context-switch mechanism.

The scheduler will be invoked through a timer interrupt that comes into the kernel through the IRQ vector. Routines in the *time.c* module have been written for you, to interface with the timer. The IRQ interrupt is invoked 100 times per second by setting the appropriate value in the *set timer()* routine in *time.c*:

If you put a smaller/larger value in the first line, the IRQ interrupt will fire less/more frequently. Feel free to set the kernel's interrupt frequency to different values to see what happens — for instance, how fast can you interrupt the core before it becomes noticeable? You can speed the timer up faster than 1/ms, but it requires you to comment out the line that does the "1000x downsample." At some point, the frequency of interrupts will overwhelm the processor.

#### **Implement Context Switch**

There are two "user applications" to switch between:

- **run\_shell()** in **z\_shell.c** This is the shell that you have been given for Project 3, except that the while() loop has been edited so that it simply prints out the prompt, waits about a second, and skips back to the top of the loop. This means that the shell simply prints something to the screen at a regular time interval. We will override that at the end.
- **do\_blinker()** in **z\_blinker.c** This application blinks the LED in a repeating 1, 2, 3, 4, 1, 2, 3, 4 pattern (it blinks once, then twice, then three times, etc.).

Thus, we have two tasks that should run in USR mode and which perform regular I/O, but to non-conflicting devices (one is to the LED, the other is to the UART). Your task is to write code that will swap between two different apps. Knowing that the code above works, this should be straightforward, as the code above is a context-switch code. It is a bit more involved, however, as you must perform the following functions:

- Every interrupt, you must save the currently executing context and restore the other
- You must start up the second thread (do\_blinker()) if it is not already running

If your code is implemented correctly, it should look like both threads are running "simultaneously." If you slow the timer interrupt down in *time.c*, for instance once every second or even every ten seconds, you should see only one app working at a time. If you speed the timer up, you should see problems as the cost of handling the interrupts grows significant.

# The Problem: Long-Latency Input

Once you have the project working, you are done writing code, but there is one more step to perform, so that you understand a big problem that operating systems face. Comment out the code in  $z\_shell.c$  that loops back to the top of the while() loop without doing any input. What happens? The reason why it happens can be seen in uart.c ... when you ask the kernel to READ the UART on your behalf, it ultimately calls  $uart \ recv()$  — which blocks. A short section of the uart.c module is shown below:

```
//-----
unsigned int uart recv ( void )
{
     while(1)
         if(GET32(AUX MU LSR REG)&0x01) break;
     return(GET32(AUX MU IO REG)&0xFF);
unsigned int uart recycheck ( void )
     if(GET32(AUX MU LSR REG)&0x01) return(1);
     return(0);
//-----
unsigned int uart sendcheck ( void )
     if(GET32(AUX MU LSR REG)&0x20) return(1);
    return(0);
//-----
void uart send ( unsigned int c )
     while(1)
          if(GET32(AUX MU LSR REG)&0x20) break;
     PUT32 (AUX MU IO REG, c);
}
```

The first thing that <code>uart\_send()</code> and <code>uart\_recv()</code> do is hang indefinitely. The IRQ interrupt is set up not to interrupt the kernel in SVC mode, so the entire time this code is blocking, the timer interrupt is being ignored. Next project, we will address that. Start thinking now about how you would address it.

# Build It, Load It, Run It

Once you have it working, show us.