allplot.py

This program is a python script that is used to analyze the ALL.TXT files generated by WSJT-X software. These files contain reception reports based upon the received SNR of the station heard. One of the main uses of this program is to compare the reception capabilities of two antennas when hearing the simultaneous signal for the same source. Hence, the usual method for using the program requires two ALL.TXT files recorded simultaneously, usually using a different antenna or receiver.

The program has a simple command structure. Here are the listed commands that you get if you issue a \mathbf{H} ELP command.

```
Commands:
FA Specify the A data file
FB specify the B data file
CF Combine Files - Find simultaneous matches
PO POlar plot - process signal matches
BA specify the Bands for data plot
AR Animate Raw ALL.TXT file(s) on map
AB animation of SNR A - SNR B data on map
PR Polar plot against a Reference
MS Map Signals - SNR A-B
MR Map compared to A reference: B-A - C-A => B-C
CX set color scale Maximum SNR A-B
CN set color scale Minimum SNR A-B
SX set polar plot scale Maximum
SN set polar plot scale Minimum
ST
   status
DP set figure and animation resolution DPI
FS set figure size, x-inches, y-inches
   turn on/off curve fit, F+/F-, Fourier degree, N (int)
FT
\mathsf{DT}
   set time between frames for animation (minutes)
IT set data collection time for frame (minutes)
LO specify longitude, Latitude of observer
MX set max SNR for interval to reject signals
VW plot view: WOrld, NAmerica, AMericas, NHemisphere
PL Plot Output: I+ inline console; S+ saved to file; I-, S- turn off
XM print out XML data
XD reset allplot.xml to defaults and quit
Q
    Quit
   Help - this info...
Η
->
```

Work Flow Summary

The two letter commands let you quickly process the files in the way you want. Typical work flow involves the commands in the following sequence:

```
->FA Get the first ALL.TXT file and enter a brief description.
->FB Get the second ALL.TXT file and enter a brief description.
```

```
->CF Combine the files by finding simultaneous reception matches.
->PO Generate a polar plot of the difference in SNR between the received signals
->BA 20m Select a desired band from the data.
->MS Map the SNR differences on the globe
```

If the data contains several bands, each band can be examined in turn with polar plots PO, and relative signal strengths, MS

Reception reports from a single file or a pair of the raw files can be animated as on a global map using AR.

Best for a single band, the difference in SNR between the two receivers can be animated on the global map using AB. Beware that this is noisy because no time averages are computed.

Two pairs of comparison files can make use of the first file, FA, as a reference. The A file for each pair must have the same description. For each pair of files, go through the steps to combine the files, CF, and process the matches by grid that happens with PO. At this point the PR command will generate a polar plot of the differences in grid-square averages between the B and C files (the first pair B file becomes the C file). Similarly MR will map the SNR B-C differences on the globe. The data is noisier that with simultaneous measurements, but some trends can be obtained this way when information about a single antenna may be desired under different conditions by comparing to a fixed reference antenna.

Paths and directories

Various temporary working files are created in the working directory where allplot.py resides when running the program. The working folder should contain the dependencies listed below.

Plots are saved to the directory where the 'A' data file resides. Setting up a directory for a particular experimental run is recommended.

Local Dependencies

allplot.py the main script
config.py the XML congiurator
allplot.xml XML configuration file

Python Packages used

pandas
numpy
symfit
matlibplot
cartopy
tkinter
BeautifulSoup

Users wishing to run the program in Python on their machines should be sure

that the dependant packages are installed or install them as necessary.

Compiled allplot.exe

allplot has been successfully complied into as stand-alone distribution on Windows systems using the Nuitka compiler. The compiled version runs at least twice as fast on CPU-intensive automation generation. The down-side is that the distribution is very large, approximately 1.2 GB for the distribution folder.

When running the compiled version, run 'allplot.exe' from the working directory, 'allplot.dist'.

Commands

AB Generates animated map of SNR differences. Requires a pair of matched (CF) and processed (PO) files. Best for a single band since color scale has no band information otherwise.

AR Generates animated map of raw signal report occurrences. Requires one or two input files.

BA bnd Selects band for data to plot. valid options: bnd = '10m', '12m', '15m', '17m', '20m', '30m', '40m', '80m', '160m'. Empty response, <CR>, selects 'all bands'.

CF Combine Files -- takes the A and B files and finds all of the simultaneous reception reports. Temporary file, Matches.csv is saved.

CN mn Sets minimum value for colorbar plots, mn in decimal dB. Empty response checks for minimum value of data set and sets that value.

CX mx Sets maximum value for colorbar plots, mx in decimal dB. Empty response checks for maximum value of data set and sets that value.

DP dpi Sets the "dots per inch" resolution for the graphics, dpi integer.

DT t Sets the time between frames for animations, t integer minutes. Default 3 minutes.

FA Select the 'A' ALL.TXT raw data file. You will be prompted for a short description as well.

FB Select the 'B' ALL.TXT raw data file. Again, you will be prompted for a description.

FS w h Sets the figure size in width w and height h in inches. Overall number of pixels is $dpi^2 \times w \times h$.

FT [str][n] Turns on/off, str = `F+'/`F-', curve fitting for polar plot data. The curve fit is with a Fourier series with n = order.

Help - prints out the command list.

IT t Sets the integration time t, in minutes, over which data is collected to be displayed in a single frame.

LO lon lat Home longitude and latitude, determines bearing angles and central location of map plots.

MR Map SNR differences from a reference antenna for one antenna in two configurations. Requires a saved 'Lastmatchsort.csv' file from previous antenna pair, and requires that antenna 'A' descriptors be identical. Use CF, PO on the pairs of files first. Then use PR to generate polar plot, and lastly MR.

MS Map SNR differences between two antennas. First use CF and PO to process the data, then MS.

MX Sets the maximum SNR report value during a transmission period to still accept the other data during that period. Default is 40, which never happens. Use this on radios that easily overload on strong signals.

PL str Sets how plots are displayed and saved. str = 'I+'turns on inline console plots; str = 'S+' turns on plots saved to a file; 'I-', 'S-' turn these off.

Processes the matched signal reports and generates a polar plot of the SNR differences.

PR Generates a polar plot for two configurations of an antenna compared to a reference antenna. Requires a saved 'Lastmatchsort.csv' file from previous antenna pair, and requires that the antenna 'A' descriptors be identical. Use CF, PO on the pairs of files first, then PR.

Q Quit the program. Also ^C works.

SN mn Set the minimum scale marking for polar plots, mn in dB.

ST Prints out program status info, including program version and build date, to the console.

SX ms Set the maximum scale marking for polar plots, mx in dB.

VW str Sets the extent of the map plot view. str = `WO' World; 'NA' North America; 'AM' North and South America; 'NH' North hemisphere.

XD Resets 'allplot.xml' to start-up default and quits.

XM Lists the 'allplot.xml' file to the console.