MODFLOW-MT3DMS with Flopy

project topics & contaminant transport simulation

Harry Lee 3/12/2018

CEE 696

Potential project topics

Ana Contaminant Transport?

Bing Fresh GW-Seawater interaction?

Brytne Hydraulic conductivity estimation

Chris Regional aquifer GW flow modeling?

Olkeba Python-based estimation

Sabrina Resident time optimization/contaminant degradation

Shelby Unsaturated flow?

Harrison Fresh GW - seawater interaction?

Potential applications covered in next two weeks

- · Contaminant transport modeling
- 1D Unsaturated Flow
- GW-Seawater interaction
- · Model Parameter Estimation

Potential optimization application ideas

- · Pumping rate optimization
 - · for pump & treatment/capture zone delineation Ana, Sabrina
 - · for sustainable yield determination Chris
 - · for seawater intrusion prevention Bing/Harrison
- · Hydraulic conductivity estimation Brytne & Olkeba
- Unsaturated Flow? Shelby

HW3

- Due on Friday 3/23
- · Choose one application with your description
- Show initial simulation results if possible

Contaminant transport in MT3DMS

- MODPATH: Particle-tracking post-processing program based on MODFLOW
- MT3DMS: Modular 3-D Multi-Species Transport Model for Simulation of Advection, Dispersion, and Chemical Reactions of Contaminants in Groundwater Systems

We will learn how to use MT3MDS

MT3DMS installation

For Windows:

- 1. Download executable
 - from https://hydro.geo.ua.edu/mt3d/mt3dms_530.exe
 - or go to MT3DMS webpage: https://hydro.geo.ua.edu/mt3d/index.htm and click "MT3DMS 5.3"
- 2. Unzip the folders and copy bin/mt3dms5s.exe and bin/mt3dms5b.exe to your flopy working directory

For Mac and Linux:

- Download or clone pyMake (https://github.com/modflowpy/pymake)
- 2. go to "examples" folder and run make_mt3d.py
- 3. copy "mt3dms" to your working directory

Example 2 (adaptive from Example 1)


A horizontal confined aquifer (1000 x 1000 x 50 m) with constant head on the western and eastern boundaries (h_{west} = 10 m, h_{east} = 0 m), no flow condition on northern and southern boundaries. Horizontal and vertical hydraulic conductivity are given by 10 m/d. A injection well at x = 100, y = 500 was installed and a conservative tracer C = 10 is injected with the flow rate of 1000 m^3 /d into the aquifer for 1000 days. Longitudinal and transverse dispersity values are 10 m and 1 m respectively.

Run MODFLOW-MT3DMS simulation


Download a script from

```
https://www2.hawaii.edu/~jonghyun/classes/S18/CEE696/files/my_first_flopy_mt3dms_example.py and run the script.
```


Results: C in day 200



Results: C in day 500



Results: C in day 1000



Governing equations (1)

Flow equation (as solved in MODFLOW)

· solve hydraulic h (then post-process q or v from h)

Transport equation (as solved in MT3DMS)

· solve concentration C

Governing equations (2)

Flow equation (in MODFLOW)

$$S_{s} \frac{\partial h}{\partial t} = \frac{\partial}{\partial t} \left(K \frac{\partial h}{\partial x} \right) + q_{s} \tag{1}$$

Transport equation (in MT3DMS) when porosity (θ) is constant

$$R\frac{\partial C}{\partial t} = \frac{\partial}{\partial x} \left(D \frac{\partial C}{\partial x} \right) - \frac{\partial}{\partial x} \left(vC \right) + q_s C_s + \sum_{k=1}^{N} R_k$$
 (2)

my_first_flopy_mt3dms_scipt.py

- 1. Create a MODFLOW model object
- 2. Define packages (DIS, BAS, LPF, WELL, OC, PCG)
- 3. Add LMT (Link-MT3DMS) package
- 4. Write MODFLOW inputs
- 5. Run MODFLOW
- 6. Create a MT3DMS model object
- 7. Define MT3DMS packages (BTN, ADV)
- 8. Write MODFLOW inputs
- 9. Run MT3DMS
- 10. Post-process and plot results

MT3DMS Input-Output structure




Figure 1: from http://inside.mines.edu/~epoeter/583CSM/12-1_MT3D.pdf

my_first_flopy_mt3dms_scipt.py

- 1. MODFLOW simulation with LMT package
- 2. Create a MT3DMS model object
- 3. Define MT3DMS BTN packages (BTN)
- 4. Define MT3DMS Advection packages (ADV)
- 5. Define MT3DMS Dispersion packages (DSP)
- 6. Define MT3DMS Source/Sink Mixing packages (SSM)
- 7. Define MT3DMS Matrix Solver packages (GCG)
- 8. Write MT3DMS inputs
- 9. Run MT3DMS

Flopy MT3DMS modeling

Basic Transport Package (BTN)

```
btn = flopy.mt3d.Mt3dBtn(mt, prsity=0.3, icbund = sconc=0.0, ncomp=1, perlen = 1000, nper=1, nstp = 51, tsmult = 1.0, nprs = -1, nprobs = 10, cinact = -1, chkmas=True)
```

Basic Transport Package (BTN)

- Basic information
- Spatial discretization (same as MODFLOW)
- · Boundary and initial conditions
- · Output control
- Temporal discretization

Boundary Conditions

- · No-flow boundary in MODFLOW Zero mass flux boundary
- all other boundaries in MODFLOW, treated as specified mass flux boundary with mass flux Q*C

Basic Transport Package (BTN) - Temporal discretization

- PERLEN: An array of the stress period lengths (for steady-state, total simulation time)
- · NSTP: Number of time steps in each stress period
- TSMULT : Time step multiplier
- DT0: initial transport stepsize
- TTSMULT: transport stepsize multiplier within a flow multiplier within a flow-model time model time step
- TTSMAX: maximum transport stepsize within a flow-model time step

Advection Package (ADV)

Solution method (mixelm)

- · Finite Difference Method (FDM)
- MOC : Method of Characteristics (MOC)
- · MMOC: Modified Method of Characteristics (MMOC)
- HMOC: Hybrid Method of Characteristics (HMOC)
- TVD (MIXELM = -1 try to use this one)

percel is the Courant number for numerical stability (\leq 1)




Figure 2: MT3DMS userguide (Report SERDP-99-1) Figure 1 - Illustration of common numerical errors in contaminant transport modeling

Dispersion Package (DSP)

Under some assumption:

$$D_L = \alpha_L V_L + D^*$$

$$D_T = \alpha_T V_T + D^*$$

- al (α_L) : longitudinal dispersivity [L]
- tprt: ratio of horizontal transverse dispersivity vs longitudinal dispersivity (0.01 - 0.1)
- trpv: ratio of vertical transverse (0.001 0.01) dispersivity vs longitudinal dispersivity
- dmcoef (D^*): diffusion coefficient [L^2/T]

Source/Sink Mixing Package (SSM)

Matrix Solver Package (GCG)

gcg = flopy.mt3d.Mt3dGcg(mt, cclose=1e-6)

cclose the convergence criterion in terms of relative concentration

Write input files for MT3DMS and Execution

```
# write mt3dms input
mt.write_input()
# run mt3dms
mt.run_model()
#mt.run_model(silent=True)
```

Simulation screen (1)

```
MT3DMS - Modular 3-D Multi-Species Transport Model [Version 5.30]
Developed at University of Alabama for U.S. Department of Defense
Using NAME File: mf-mt.nam
STRESS PERIOD NO. 1
TIME STEP NO.
FROM TIME = 0.0000
                      TO
                           20.000
Transport Step: 1 Step Size: 7.678 Total Elapsed Time: 7.6784
Outer Iter. 1 Inner Iter. 1: Max. DC = 8.272
                                                 [K, I, J]
                                                           1 26
Outer Iter. 1 Inner Iter. 2: Max. DC = 0.6572E-01 [K,I,J] 1 25
Outer Iter, 1 Inner Iter, 3: Max. DC = 0.1469E-03 [K.I.J] 1 27
                                                                 6
Outer Iter. 1 Inner Iter. 4: Max. DC = 0.2146E-05 [K,I,J] 1 26
Outer Iter. 1 Inner Iter. 5: Max. DC = 0.7451E-08 [K,I,J]
Transport Step: 2 Step Size: 7.678 Total Elapsed Time: 15.357
Outer Iter. 1 Inner Iter. 1: Max. DC = 2.228
                                                           1 26
                                                 [K.I.J]
Outer Iter. 1 Inner Iter. 2: Max. DC = 0.1770E-01 [K,I,J]
                                                             25
Outer Iter. 1 Inner Iter. 3: Max. DC = 0.4137E-04 [K,I,J] 1 26
```

Simulation screen (2)

```
Outer Iter. 1 Inner Iter. 4: Max. DC = 0.5684E-13 [K,I,J] 1 16
TIME STEP NO.
             50
FROM TIME = 980.00
                  TO
                          1000.0
Transport Step:
             1 Step Size: 7.678 Total Elapsed Time: 987.68
Outer Iter. 1 Inner Iter. 1: Max. DC = 1.246 [K,I,J] 1 26
Outer Iter. 1 Inner Iter. 2: Max. DC = 0.9935E-02 [K,I,J] 1
                                                           2.5
Outer Iter. 1 Inner Iter. 3: Max. DC = 0.2354E-04 [K,I,J] 1 26
Outer Iter. 1 Inner Iter. 4: Max. DC = 0.1788E-06 [K,I,J] 1 27
                   Step Size: 7.678 Total Elapsed Time: 995.36
Transport Step: 2
Outer Iter. 1 Inner Iter. 1: Max. DC = 1.246
                                               [K.I.J]
                                                        1 26
                                                                 6
Outer Iter. 1 Inner Iter. 2: Max. DC = 0.9936E-02 [K,I,J] 1
                                                           2.5
                                                                 7
Outer Iter. 1 Inner Iter. 3: Max. DC = 0.2354E-04 [K,I,J] 1
                                                           26
Outer Iter. 1 Inner Iter. 4: Max. DC = 0.1788E-06 [K,I,J]
                                                        1 27
Transport Step:
                3 Step Size: 4.643 Total Elapsed Time: 1000.0
Outer Iter, 1 Inner Iter, 1: Max. DC = 0.7532
                                               [K,I,J] 1 26
                                                                 6
Outer Iter. 1 Inner Iter. 2: Max. DC = 0.2588E-02 [K,I,J] 1 25
                                                                 7
Outer Iter. 1 Inner Iter. 3: Max. DC = 0.2265E-05 [K,I,J] 1 27
                                                                 5
Outer Iter. 1 Inner Iter. 4: Max. DC = 0.7105E-14 [K.I.J] 1 16
                                                                10
```

Plotting results

```
ucnobj = bf.UcnFile('MT3D001.UCN')

times = ucnobj.get_times() # simulation time
#times1 = times[round(len(times)/5.)-1] # 1/5 simulation
#times2 = times[round(len(times)/2.)-1] # 1/2 simulation
mytime = times[-1] # the last simulation time
conc = ucnobj.get_data(totim=mytime)
```