
Why Learn Assembly Languages

Z. Gu

Fall 2025


IEEE Spectrum's Top Programming Languages 2022

https://spectrum.ieee.org/top-programming-languages-2022




Assembly: Not just another language

- Assembly vs high level languages (HLLs).
 - Most embedded systems are programmed in HLLs
 - Assembly disadvantages
 - difficult to develop, read, and maintain
 - bug prone
 - not portable
- However, assembly isn't "just another language".
 - Interface between hardware and software
 - Implements high-level languages



Assembly: Learn how processors work

- Learn about the inner workings of a processor
 - Data representation
 - Registers
 - Computer arithmetic
 - Memory addressing
 - Instruction set
 - I/O
- Provide background knowledge for later courses
 - computer architecture,
 - operating systems,
 - compiler




Assembly: Faster and smaller

Assembly program runs faster than HLLs.

- Performance critical codes must be written in assembly.
- Use profiling tools to find the performance bottleneck and rewrite that code section in assembly
- Latency-sensitive applications, such as aircraft controller
- Some C compilers do not use some special Thumb instructions, such as ROR (Rotate Right) and RRX (Rotate Right Extended).

Cost-sensitive applications

- Assembly consumes little memory
- Embedded devices, where the size of code is limited, wash machine controller, automobile controllers



brilliant.org

Assembly: The only choice sometimes

- Hardware/processor specific code,
 - Special instructions not supported by a compiler

```
    CPSID I ; Disable IRQ by setting PRIMASK
    CPSIE I ; Enable IRQ by clearing PRIMASK
    MSR/MSR ; Read/write to special registers
    WFI ; Enter low-power & wait for interrupt
```

```
// Enable Interrupts
  _attribute__( ( always_inline ) )
static inline void __enable_irq(void)
      __asm("<mark>cpsie i</mark>");
// Disable Interrupts
  _attribute__( ( always_inline ) )
static inline void __disable_irq(void)
     __asm("<mark>cpsid i</mark>");
```

cmsis_armcc.h

Assembly: The only choice sometimes

Hardware/processor specific code,

- Special instructions not supported by a compiler
 - ▶ **CPSID I** ; Disable IRQ by setting PRIMASK
 - ▶ CPSIE I ; Enable IRQ by clearing PRIMASK
 - ▶ MSR/MSR ; Read/write to special registers
 - ▶ WFI ; Enter low-power & wait for interrupt

Startup Code

- the stack and heap areas
- interrupt vector table
- default implementation of ISRs
- written in assembly, and possible in C with inline assembly
- C version is toolchain dependent

```
Stack Size EQU 0x400;
          AREA STACK, NOINIT, READWRITE, ALIGN=3
Stack Mem SPACE Stack Size
initial sp
Heap Size EQU 0x200;
         AREA HEAP, NOINIT, READWRITE, ALIGN=3
 heap base
Heap Mem SPACE Heap Size
 _heap_limit
 Vectors
  DCD initial sp
                        ; Top of Stack
  DCD Reset Handler
                        : Reset Handler
  DCD NMI Handler
                         ; NMI Handler
  DCD HardFault_Handler ; Hard Fault Handler
  DCD MemManage_Handler ; MPU Fault Handler
  DCD BusFault Handler
                         ; Bus Fault Handler
  DCD UsageFault Handler; Usage Fault Handler
```

Assembly: The only choice sometimes

Hardware/processor specific code,

- Special instructions not supported by a compiler
 - ▶ **CPSID I** ; Disable IRQ by setting PRIMASK
 - ▶ CPSIE I ; Enable IRQ by clearing PRIMASK
 - ▶ MSR/MRS ; Read/write to special registers
 - ▶ WFI ; Enter low-power & wait for interrupt

Startup code

- the stack and heap areas
- interrupt vector table
- ▶ default implementation of ISRs
- written in assembly, and possible in C with inline assembly
- ▶ C version is toolchain dependent

Device driver

- access machine-dependent registers and I/O
- control exact code behavior in critical sections

```
static inline u8 __raw_readb(const volatile
void __iomem *addr) {
 u8 val;
  asm volatile("ldrb %0, %1"
    : "=r" (val)
    : "Qo" (*(volatile u8 __force *)addr));
  return val;
static inline void __raw_writeb(u8 val,
volatile void __iomem *addr) {
  asm volatile("strb %1, %0"
    :: "Qo" (*(volatile u8 __force *)addr),
      "r" (val));
```

Linux 5.6, /arch/arm/include/asm/io.h

- Help you understand and write HLLs better
 - Low-level data representation
 - C Pointers
 - Reference & dereference
 - Passing parameters to functions:
 - Pass by reference
 - Pass by value
 - Variables declared as volatile or static
 - Inefficiency of recursive function: stack operations

```
Stack grows in recursive phase
```

```
int* pi;
int volatile* pvi;
int* volatile vpi;
```

Frame for caller
Frame for factorial(5)
Frame for factorial(4)
Frame for factorial(3)
Frame for factorial(2)

Frame for factorial(I)

Stack shrinks in regression phase

```
uint32_t x = 1;
int32_t y = -1;

if (x > y)
   printf("Of course.")
else
   printf("Something is wrong!");
```

```
Output:
Something is wrong!

r0 = 0x00000001 ; x = 1
r1 = 0xFFFFFFFF ; y = -1

CMP r0, r1
BLS else ; Branch on Unsigned Lower than or Same
```


```
compiling main.c...
linking...
Program Size: Code=640 RO-data=424 RW-data=8 ZI-data=5472
FromELF: creating hex file...
".\Objects\project.axf" - 0 Error(s), 0 Warning(s).
Build Time Elapsed: 00:00:01
```


The C standard dictates that when a signed integer and an unsigned integer of the same size are compared, the signed integer is converted to an unsigned integer, hence 0xFFFFFFF=2^32-1=4,294,967,295 (UINT MAX), instead of -1

```
uint32_t x = 1;
int32_t y = -1;

if ((int32_t) x > y)
  printf("Of course.")
else
  printf("Something is wrong!");
```


$$x = 1;$$






What is the final value of x?

$$x = 1;$$






$$x = 4, 6, 9;$$

```
x = 1;
                 LWR r0, =x
                                       LWR r2, =x
                 LWR r1, [r0]
                                       LWR r3, [r2]
                 ADD r1, r1, #3
                                       ADD r3, r3, #5
                                       STR r3, [r2]
                 STR r1, [r0]
x = 4, 6, 9;
```

```
x = 1;
                LWR r0, =x
                LWR r1, [r0]
                ADD r1, r1, #3
                STR r1, [r0]
                                      LWR r2, =x
                                      LWR r3, [r2]
                                      ADD r3, r3, #5
                                      STR r3, [r2]
```

```
x = 1;
                LWR r0, =x
                LWR r1, [r0]
                ADD r1, r1, #3
                                       LWR r2, =x
                                       LWR r3, [r2]
                                       ADD r3, r3, #5
                                       STR r3, [r2]
                STR r1, [r0]
```



Why should we learn Assembly?

- Assembly isn't "just another language".
 - ▶ Help you understand how does the processor work
- Assembly program runs faster than high-level language.
 - Performance critical codes may need to be written in assembly.
 - Use the profiling tools to find the performance bottle and rewrite that code section in assembly
 - Latency-sensitive applications, such as aircraft controller
 - Standard C compilers do not use some operations available on ARM processors, such ROR (Rotate Right) and RRX (Rotate Right Extended).
- Hardware/processor specific code,
 - Processor booting code
 - Device drivers
 - Compiler, assembler, linker
 - A test-and-set atomic assembly instruction can be used to implement locks and semaphores.
- Cost-sensitive applications
 - Embedded devices, where the size of code is limited, wash machine controller, automobile controllers
- Better understand high-level programming languages

Recap: Why Learn Assembly?

- Gain insights about what is under the hood of a processor
- Assembly should be used for performance critical sessions
- Assembly must be used for processor-dependent instructions that are not supported by compilers
- Understanding assembly helps us write better HLLs

