Embedded Systems with ARM Cortex-M3 Microcontrollers in Assembly Language and C


Chapter 9 64-bit Data Processing

Z. Gu

Fall 2025


64-bit Addition

It uses ADDS (add with carry update) and ADC (add with carry) instructions to compute the 64-bit result across two 32-bit parts with carry propagation.



64-bit Subtraction

It uses SUBS (subtract with carry update) and SBC (subtract with carry) instructions with borrow (= not Carry) to handle the two-part subtraction.



```
; Subtracting two 64-bit integers A (r1:r0) and B (r3:r2).
; C (r5:r4) = A (r1:r0) - B (r3:r2)
; A = 00000002FFFFFFFF, B = 000000040000001
LDR r0, =0xFFFFFFFF ; A's lower 32 bits
LDR r1, =0x00000002 ; A's upper 32 bits
LDR r2, =0x00000001 ; B's lower 32 bits
LDR r3, =0x00000004 ; B's upper 32 bits

; Subtract A from B
SUBS r4, r0, r2 ; C[31:0] = A[31:0] - B[31:0], update Carry
SBC r5, r1, r3 ; C[64:32] = A[64:32] - B[64:32] + Carry - 1
```

64-bit Counting Leading Zeroes

```
; 64-bit input data = (r1:r0), r1 = upper word, r0 = lower word
 ; r2 = # of leading zero bits in the 64-bit data
 ; Counting # of leading zeroes in upper word
CLZ r2, r1 ; CLZ = Count leading zeroes. It counts how
many zero bits appear from MSB downwards in the 32-bit value in r1,
and places that count (0-32) into r2
 ; Counting # of leading zeroes in lower word
CMP r2, #32 ; Compare r2 with 32
CLZEQ r3, r0 ; if r2 == 32, then count leading zero
bits of the lower word
ADDEQ r2, r2, r3; if all bits of the upper word are zero,
                     ; add the leading zeroes of the lower word
```

64-bit Counting Leading Zeroes: Explanations

- Run CLZ on the upper 32 bits: CLZ r2, r1; if r1 ≠ 0, r2 already equals the 64-bit leading-zero count since leading zeros must lie entirely in the upper half for a nonzero upper word.
- Compare r2 with 32: CMP r2, #32; if equal, the upper word is zero, so count lower: CLZEQ r3, r0; then ADDEQ r2, r2, r3 to add the lower's leading zeros for the total over 64 bits.

Edge cases:

- If $r1 \neq 0$, the lower word is ignored because the first 1-bit lies in the upper word, making r2 the final answer directly from CLZ r1.
- If r1 = 0 and $r0 \neq 0$, the total is 32 + CLZ(r0), as there are 32 leading zeros from the upper word plus those from the lower word until its first 1-bit.
- If rI = 0 and r0 = 0, the total is 64; the slide's conditional path computes r2 = 32 + 32 = 64 via CLZ on both halves.

64-bit Sign Extension

```
; r0 = Lower word of 64-bit data
; r1 = Upper word of 64-bit data

TST r0, 0x80000000  ; Check the sign bit
LDRNE r1, =0xFFFFFFFF  ; If MSB is 1, duplicate 1 in upper word
LDREQ r1, =0x000000000  ; If MSB is 0, duplicate 0 in upper word
```

TST (test) performs a bitwise AND between operands to test bits, updates condition flags (notably Z and N), and discards the result. This is effectively "ANDS without write-back," used to check whether specific bits are set or clear before a conditional operation.

TST r0, 0x80000000 checks the sign bit of the low 32 bits by ANDing r0 with the mask and sets condition flags without storing a result. Z=0 implies MSB=1 (negative), Z=1 implies MSB=0 (non-negative).

LDRNE r1, =0xFFFFFFF; if Z=0, sign bit set MSB=1 (result non-zero \rightarrow NE), set upper 32 = all 1s

LDREQ r1, =0x000000000; if Z=1, sign bit clear MSB=0 (result zero \rightarrow EQ), set upper 32 = all 0s

64-bit Multiplication

```
; product (r5:r4) = multiplier (r1:r0) × multiplicand (r3:r2)
; (r5:r4) = r0 × r2 + 2<sup>32</sup> × (r1 × r2 + r0 × r3) + 2<sup>64</sup> × r1 × r3
; The last item exceeds 64 bits and thus it is ignored.

UMULL r4, r5, r0, r2  ; (r5:r4) = r0 * r2
MLA r5, r1, r2, r5  ; r5 = r5 + r1 * r2
MLA r5, r0, r3, r5  ; r5 = r5 + r0 * r3
```

UMULL r4, r5, r0, r2 computes the 64-bit product of the low words and places the low 32 bits in r4 and the high 32 bits in r5, establishing the initial 64-bit accumulator. MLA Multiply Accumulate: MLA Rd, Rn, Rm, Ra computes Rd = $(Ra + (Rn \times Rm))$ mod 2^32. Only the least-significant 32 bits of the sum are written to Rd; any higher bits are discarded.

MLA r5, r1, r2 adds the cross term r1 r2 (which conceptually belongs at bit position 32) into the high half r5

MLA r5, r0, r3, r5 similarly adds the other cross term r0 r3 into r5, completing the contribution of both cross terms at the correct alignment; overflow beyond 32 bits of r5 is discarded, ignoring the 2^64 (r1 r3) part.