1 Basic Concept

1.1 SNR

SNR, the signal noise ratio is defined as the ratio of power of a signal to the power of background noise

$$SNR = \frac{P_{signal}}{P_{noise}}$$

SNR in decibels

$$P_{signal,dB} = 10log_{10}(P_{signal})P_{noise,dB} = 10log_{10}(P_{noise})$$

SNR in dB is

$$10log_{10}(\frac{P_{signal}}{P_{noise}})$$

$$=10log_{10}(P_{signal}) - 10log_{10}(P_{noise})$$

$$=P_{signal,dB} - P_{noise,dB}$$

2 Nonlinear Effect

Nonlinear effect means when a signal is passed into a device, the relationship between the output and input is not linear. This article aims to provide an explanation of the nonlinear process.

2.1 Harmonics

Suppose we have an input signal with a voltage

$$v_i(t) = V_{im} cos(\omega_i t)$$

The output signal can be approximated by Taylor's expansion

$$v_o(t) = a_1 V_{im} cos(\omega_i t) + a_2 V_{im}^2 cos^2(\omega_i t) + a_3 V_{im}^3 cos^3(\omega_i t)$$

= $\frac{1}{2} a_2 V_{im}^2 + (a_1 V_{im} + \frac{3}{4} a_3 V_{im}^3) cos(\omega_i t) + \frac{a_2}{2} V_{im}^2 cos(2\omega_i t)$

All the terms with $cos(n\omega_i t)$ are nonlinear terms. Therefore, an input signal with frequency ω has output with frequency $n\omega$, and this is called nonlinear effect. All the signal component with frequency $n\omega$ are called harmonics.

2.2 Gain compression

In the above derivation, the amplitude of $cosw_i t$ is $a_1V_{im} + \frac{3}{4}a_3V_{im}^3$ is the gain to the input signal g_m . In most cases $a_3 < 0$, when v_{im} is sufficiently small, the first term dominates so the gain is equal to $log(a_1)$. But when v_m is large enough, the second term is not negligible so the gain decreases from $log(a_1)$. We define **1db compression point** as the input power when the gain is decreased by 1dB from $log(a_1)$

2.3 Intermodulation

Suppose we have two input signals

$$V_i(t) = V_{1m}cos(\omega_1 t) + V_{2m}cos(\omega_2 t)$$

The third order output power term has two components

$$P_3 = \frac{3}{4}a_3V_{1m}^2V_{2m}cos(2\omega_1 - \omega_2)t + \frac{3}{4}a_3V_{1m}V_{2m}^2cos(2\omega_2 - \omega_1)t$$

if $V_{1m} = V_{2m} = V_m$

$$P_{3} = \frac{3}{4}a_{3}V_{m}^{3}[\cos(2\omega_{1} - \omega_{2})t + \cos(2\omega_{2} - \omega_{1})t]$$

Since this power term has two frequency components, we call it **intermodulation power**, and we cal P_3 as **third order intermodulation power**.

2.4 3rd order intercept point

The output power at base frequency

$$P_{o1} = \frac{1}{2}(a_1 V_m)^2 \equiv = G_1 P_i$$

The output power at intermodulation frequency

$$P_{o3} = \frac{1}{2} (\frac{3}{4} a_3 V_m^3)^2 \equiv = G_3 P_i^3$$

So

$$P_{o1} = 10logG_1 + 10logP_i$$
$$P_{o3} = 30logG_3 + 30logP_i$$

So both P_{o1} and P_{o3} has a linear relationship with P_i . The above equations represent two lines, but the slope of P_{o3} is 3 times of that of P_{o1} . The third-order intercept point(IP3) is defined as the intercept point of the above two lines(P_{o1} and P_{o3}). We can use the slope relation to find the intercept point.

$$\frac{IP_3 - P_{o3}}{IP_3 - P_{o1}} = 3$$

Therefore

$$IP_3 = \frac{1}{2}(3P_{o1} - P_{o3})$$