#### **ACKNOWLEDGEMENT**

By utilizing this website and/or documentation, I hereby acknowledge as follows:

Effective October 1, 2012, QUALCOMM Incorporated completed a corporate reorganization in which the assets of certain of its businesses and groups, as well as the stock of certain of its direct and indirect subsidiaries, were contributed to Qualcomm Technologies, Inc. (QTI), a whollyowned subsidiary of QUALCOMM Incorporated that was created for purposes of the reorganization.

Qualcomm Technology Licensing (QTL), the Company's patent licensing business, continues to be operated by QUALCOMM Incorporated, which continues to own the vast majority of the Company's patent portfolio. Substantially all of the Company's products and services businesses, including QCT, as well as substantially all of the Company's engineering, research and development functions, are now operated by QTI and its direct and indirect subsidiaries <sup>1</sup>. Neither QTI nor any of its subsidiaries has any right, power or authority to grant any licenses or other rights under or to any patents owned by QUALCOMM Incorporated.

No use of this website and/or documentation, including but not limited to the downloading of any software, programs, manuals or other materials of any kind or nature whatsoever, and no purchase or use of any products or services, grants any licenses or other rights, of any kind or nature whatsoever, under or to any patents owned by QUALCOMM Incorporated or any of its subsidiaries. A separate patent license or other similar patent-related agreement from QUALCOMM Incorporated is needed to make, have made, use, sell, import and dispose of any products or services that would infringe any patent owned by QUALCOMM Incorporated in the absence of the grant by QUALCOMM Incorporated of a patent license or other applicable rights under such patent.

Any copyright notice referencing QUALCOMM Incorporated, Qualcomm Incorporated, QUALCOMM Inc., Qualcomm Inc., Qualcomm or similar designation, and which is associated with any of the products or services businesses or the engineering, research or development groups which are now operated by QTI and its direct and indirect subsidiaries, should properly reference, and shall be read to reference, QTI.

<sup>&</sup>lt;sup>1</sup> The products and services businesses, and the engineering, research and development groups, which are now operated by QTI and its subsidiaries include, but are not limited to, QCT, Qualcomm Mobile & Computing (QMC), Qualcomm Atheros (QCA), Qualcomm Internet Services (QIS), Qualcomm Government Technologies (QGOV), Corporate Research & Development, Qualcomm Corporate Engineering Services (QCES), Office of the Chief Technology Officer (OCTO), Office of the Chief Scientist (OCS), Corporate Technical Advisory Group, Global Market Development (GMD), Global Business Operations (GBO), Qualcomm Ventures, Qualcomm Life (QLife), Quest, Qualcomm Labs (QLabs), Snaptracs/QCS, Firethorn, Qualcomm MEMS Technologies (QMT), Pixtronix, Qualcomm Innovation Center (QuIC), Qualcomm iskoot, Qualcomm Poole and Xiam.



## QMI QCMAP 1.3 for MPSS.NI.3.0.x

## QMI Qualcomm Mobile Access Point Svc Spec

80-N9986-34 B

September 6, 2012

Submit technical questions at:

https://support.cdmatech.com

### **Qualcomm Confidential and Proprietary**

**Restricted Distribution.** Not to be distributed to anyone who is not an employee of either Qualcomm or a subsidiary of Qualcomm without the express approval of Qualcomm's Configuration Management.

Not to be used, copied, reproduced in whole or in part, nor its contents revealed in any manner to others without the express written permission of Qualcomm.

Qualcomm reserves the right to make changes to the product(s) or information contained herein without notice. No liability is assumed for any damages arising directly or indirectly by their use or application. The information provided in this document is provided on an "as is" basis.

This document contains Qualcomm confidential and proprietary information and must be shredded when discarded.

QUALCOMM is a registered trademark of QUALCOMM Incorporated in the United States and may be registered in other countries. Other product and brand names may be trademarks or registered trademarks of their respective owners. CDMA2000 is a registered certification mark of the Telecommunications Industry Association, used under license. ARM is a registered trademark of ARM Limited.

This technical data may be subject to U.S. and international export, re-export, or transfer (export) laws. Diversion contrary to U.S. and international law is strictly prohibited.

QUALCOMM Incorporated
5775 Morehouse Drive
San Diego, CA 92121-1714
U.S.A.
Copyright © 2012 QUALCOMM Incorporated.
All rights reserved.

## **Contents**

| 1 | Intro   | oduction   | 8  |
|---|---------|--|----|
|   | 1.1     | Purpose  | 8  |
|   | 1.2     | Scope  |    |
|   | 1.3     | Conventions  | 8  |
|   | 1.4     | References   | S  |
|   | 1.5     | Technical Assistance   | 9  |
|   | 1.6     | Acronyms   | ç  |
|   |         | Acronyms  ory of Operation  Generalized QMI Service Compliance   |    |
| 2 |         | ory of Operation   | 11 |
|   | 2.1     | Generalized QMI Service Compliance   | 11 |
|   | 2.2     | QCMAP Service Type   | 11 |
|   | 2.3     | Message Definition Template  | 11 |
|   |         | 2.3.1 Response Message Result TLV  | 11 |
|   | 2.4     | QMI_QCMAP Fundamental Concepts   | 12 |
|   | 2.5     | Service State Variables  | 12 |
|   |         | 2.5.1 Shared State Variables   | 12 |
|   |         | 2.5.2 State Variables Per Control Point  | 12 |
|   | <b></b> | Generalized QMI Service Compliance  QCMAP Service Type  Message Definition Template  2.3.1 Response Message Result TLV  QMI_QCMAP Fundamental Concepts  Service State Variables  2.5.1 Shared State Variables  2.5.2 State Variables Per Control Point  QCMAP Messages | 10 |
| 3 |         | _QCMAP Messages  QMI QCMAP MOBILE AP ENABLE  |    |
|   | 3.1     |  |    |
|   |         | 3.1.1 Request - QMI_QCMAP_MOBILE_AP_ENABLE_REQ   |    |
|   |         | 3.1.2 Response - QMI_QCMAP_MOBILE_AP_ENABLE_RESP   |    |
|   | 0.0     | 3.1.3 Description of QMI_QCMAP_MOBILE_AP_ENABLE REQ/RESP   |    |
|   | 3.2     | QMI_QCMAP_MOBILE_AP_DISABLE  |    |
|   |         | 3.2.1 Request - QMI_QCMAP_MOBILE_AP_DISABLE_REQ  |    |
|   |         | 3.2.2 Response - QMI_QCMAP_DISABLE_RESP  |    |
|   |         | 3.2.3 Description of QMI_QCMAP_MOBILE_AP_DISABLE REQ/RESP  |    |
|   | 3.3     | QMI_QCMAP_BRING_UP_WWAN  |    |
|   |         | 3.3.1 Request - QMI_QCMAP_BRING_UP_WWAN_REQ  |    |
|   |         | 3.3.2 Response - QMI_QCMAP_BRING_UP_WWAN_RESP  |    |
|   |         | 3.3.3 Description of QMI_QCMAP_BRING_UP_WWAN REQ/RESP  |    |
|   |         | 3.3.4 Indication - QMI_QCMAP_BRING_UP_WWAN_IND   |    |
|   |         | 3.3.5 Description of QMI_QCMAP_BRING_UP_WWAN_IND   |    |
|   | 3.4     | QMI_QCMAP_TEAR_DOWN_WWAN   |    |
|   |         | 3.4.1 Request - QMI_QCMAP_TEAR_DOWN_WWAN_REQ   |    |
|   |         | 3.4.2 Response - QMI_QCMAP_TEAR_DOWN_WWAN_RESP   |    |
|   |         | 3.4.3 Description of QMI_QCMAP_TEAR_DOWN_WWAN REQ/RESP   | 25 |
|   |         | 3.4.4 Indication - QMI_QCMAP_TEAR_DOWN_WWAN_IND  |    |
|   |         | 3.4.5 Description of QMI_QCMAP_TEAR_DOWN_WWAN_IND  |    |
|   | 3.5     | QMI QCMAP GET WWAN STATUS  | 27 |

|      | 3.5.1 Request - QMI_QCMAP_GET_WWAN_STATUS_REQ                        | 27 |
|------|--|----|
|      | 3.5.2 Response - QMI_QCMAP_GET_WWAN_STATUS_RESP                      | 28 |
|      | 3.5.3 Description of QMI_QCMAP_GET_WWAN_STATUS REQ/RESP              | 29 |
| 3.6  | QMI_QCMAP_WWAN_STATUS_IND_REG  |    |
|      | 3.6.1 Request - QMI_QCMAP_WWAN_STATUS_IND_REG_REQ                    |    |
|      | 3.6.2 Response - QMI_QCMAP_WWAN_STATUS_IND_REG_RESP                  | 31 |
|      | 3.6.3 Description of QMI_QCMAP_WWAN_STATUS_IND_REG REQ/RESP          |    |
| 3.7  | QMI_QCMAP_WWAN_STATUS_IND  |    |
|      | 3.7.1 Indication - QMI_QCMAP_WWAN_STATUS_IND                         |    |
|      | 3.7.2 Description of QMI_QCMAP_WWAN_STATUS_IND                       |    |
| 3.8  | QMI_QCMAP_SET_IPSEC_VPN_PASS_THROUGH                                 |    |
|      | 3.8.1 Request - QMI_QCMAP_SET_IPSEC_VPN_PASS_THROUGH_REQ             |    |
|      | 3.8.2 Response - QMI_QCMAP_SET_IPSEC_VPN_PASS_THROUGH_RESP           | 35 |
|      | 3.8.3 Description of QMI_QCMAP_SET_IPSEC_VPN_PASS_THROUGH REQ/RESP   | 35 |
| 3.9  | QMI_QCMAP_GET_IPSEC_VPN_PASS_THROUGH                                 |    |
|      | 3.9.1 Request - QMI_QCMAP_GET_IPSEC_VPN_PASS_THROUGH_REQ             | 36 |
|      | 3.9.2 Response - QMI_QCMAP_GET_IPSEC_VPN_PASS_THROUGH_RESP           | 37 |
|      | 3.9.3 Description of QMI_QCMAP_GET_IPSEC_VPN_PASS_THROUGH REQ/RESP   | 37 |
| 3.10 | QMI_QCMAP_SET_PPTP_VPN_PASS_THROUGH                                  |    |
|      | 3.10.1 Request - QMI_QCMAP_SET_PPTP_VPN_PASS_THROUGH_REQ             |    |
|      | 3.10.2 Response - QMI_QCMAP_SET_PPTP_VPN_PASS_THROUGH_RESP           | 39 |
|      | 3.10.3 Description of QMI_QCMAP_SET_PPTP_VPN_PASS_THROUGH REQ/RESP . |    |
| 3.11 | QMI_QCMAP_GET_PPTP_VPN_PASS_THROUGH                                  |    |
|      | 3.11.1 Request - QMI_QCMAP_GET_PPTP_VPN_PASS_THROUGH_REQ             |    |
|      | 3.11.2 Response - QMI_QCMAP_GET_PPTP_VPN_PASS_THROUGH_RESP           |    |
| 0.40 | 3.11.3 Description of QMI_QCMAP_GET_PPTP_VPN_PASS_THROUGH REQ/RESP . |    |
| 3.12 | QMI_QCMAP_SET_L2TP_VPN_PASS_THROUGH                                  | 42 |
|      | 3.12.1 Request - QMI_QCMAP_SET_L2TP_VPN_PASS_THROUGH_REQ             |    |
|      | 3.12.2 Response - QMI_QCMAP_SET_L2TP_VPN_PASS_THROUGH_RESP           | 43 |
| 0.40 | 3.12.3 Description of QMI_QCMAP_SET_L2TP_VPN_PASS_THROUGH REQ/RESP . |    |
| 3.13 | QMI_QCMAP_GET_L2TP_VPN_PASS_THROUGH                                  |    |
|      | 3.13.1 Request - QMI_QCMAP_GET_L2TP_VPN_PASS_THROUGH_REQ             |    |
|      | 3.13.3 Description of QMI_QCMAP_GET_L2TP_VPN_PASS_THROUGH_RESP       | 40 |
| 2 1/ | QMI_QCMAP_SET_DYNAMIC_NAT_ENTRY_TIMEOUT                              |    |
| 3.14 | 3.14.1 Request - QMI_QCMAP_SET_DYNAMIC_NAT_ENTRY_TIMEOUT_REQ         |    |
|      | 3.14.2 Response - QMI_QCMAP_SET_DYNAMIC_NAT_ENTRY_TIMEOUT_RESP       |    |
|      | 3.14.3 Description of QMI QCMAP SET DYNAMIC NAT ENTRY -              | 77 |
|      | TIMEOUT REQ/RESP   | 47 |
| 3 15 | QMI_QCMAP_GET_DYNAMIC_NAT_ENTRY_TIMEOUT                              |    |
| 0.10 | 3.15.1 Request - QMI_QCMAP_GET_DYNAMIC_NAT_ENTRY_TIMEOUT_REQ         | 48 |
|      | 3.15.2 Response - QMI_QCMAP_GET_DYNAMIC_NAT_ENTRY_TIMEOUT_RESP       |    |
|      | 3.15.3 Description of QMI QCMAP GET DYNAMIC NAT ENTRY -              |    |
|      | TIMEOUT REQ/RESP   | 49 |
| 3.16 | QMI_QCMAP_ADD_STATIC_NAT_ENTRY                                       |    |
| 21.0 | 3.16.1 Request - QMI QCMAP ADD STATIC NAT ENTRY REQ                  |    |
|      | 3.16.2 Response - QMI_QCMAP_ADD_STATIC_NAT_ENTRY_RESP                |    |
|      | 3.16.3 Description of QMI_QCMAP_ADD_STATIC_NAT_ENTRY REQ/RESP        |    |
| 3.17 | QMI_QCMAP_DELETE_STATIC_NAT_ENTRY                                    |    |
|      | 3.17.1 Request - QMI QCMAP DELETE STATIC NAT ENTRY REQ               |    |

|      | 3.17.2 Response - QMI_QCMAP_DELETE_STATIC_NAT_ENTRY_RESP          | 53  |
|------|---|-----|
|      | 3.17.3 Description of QMI_QCMAP_DELETE_STATIC_NAT_ENTRY REQ/RESP  | 53  |
| 3.18 | QMI_QCMAP_GET_STATIC_NAT_ENTRIES                                  | 54  |
|      | 3.18.1 Request - QMI_QCMAP_GET_STATIC_NAT_ENTRIES_REQ             | 54  |
|      | 3.18.2 Response - QMI_QCMAP_GET_STATIC_NAT_ENTRIES_RESP           | 55  |
|      | 3.18.3 Description of QMI_QCMAP_GET_STATIC_NAT_ENTRIES REQ/RESP   | 56  |
| 3.19 | QMI_QCMAP_SET_DMZ   | 57  |
|      | 3.19.1 Request - QMI_QCMAP_SET_DMZ_REQ                            |     |
|      | 3.19.2 Response - QMI_QCMAP_SET_DMZ_RESP                          | 58  |
|      | 3.19.3 Description of QMI_QCMAP_SET_DMZ REQ/RESP                  | 58  |
| 3 20 | QMI_QCMAP_GET_DMZ   |     |
| 0.20 | 3.20.1 Request - QMI_QCMAP_GET_DMZ_REQ                            |     |
|      | 3.20.2 Response - QMI_QCMAP_GET_DMZ_RESP                          | 60  |
|      | 3.20.3 Description of QMI_QCMAP_GET_DMZ_REQ/RESP                  | 60  |
| 2 21 | QMI_QCMAP_DELETE_DMZ  | 61  |
| 5.21 | 3.21.1 Request - QMI_QCMAP_DELETE_DMZ_REQ                         | 61  |
|      | 2.21.2 Pospones OMLOCMAP DELETE DMZ DESP                          | 62  |
|      | 3.21.2 Response - QMI_QCMAP_DELETE_DMZ_RESP                       | 62  |
| 2.00 | ONLOCMAR OFT MINAN CONFIC   | 62  |
| 3.22 | QMI_QCMAP_GET_WWAN_CONFIG   | 00  |
|      | 3.22.1 Request - QMI_QCMAP_GET_WWAN_CONFIG_REQ                    | 63  |
|      | 3.22.2 Response - QMI_QCMAP_GET_WWAN_CONFIG_RESP                  | 64  |
|      | 3.22.3 Description of QMI_QCMAP_GET_WWAN_CONFIG REQ/RESP          | 65  |
| 3.23 | QMI_QCMAP_ENABLE_FIREWALL_SETTING                                 |     |
|      | 3.23.1 Request - QMI_QCMAP_ENABLE_FIREWALL_SETTING_REQ            | 66  |
|      | 3.23.2 Response - QMI_QCMAP_ENABLE_FIREWALL_SETTING_RESP          | 67  |
|      | 3.23.3 Description of QMI_QCMAP_ENABLE_FIREWALL_SETTING REQ/RESP  |     |
| 3.24 | QMI_QCMAP_GET_FIREWALL_SETTING                                    |     |
|      | 3.24.1 Request - QMI_QCMAP_GET_FIREWALL_SETTING_REQ               | 68  |
|      | 3.24.2 Response - QMI_QCMAP_GET_FIREWALL_SETTING_RESP             | 69  |
|      | 3.24.3 Description of QMI_QCMAP_GET_FIREWALL_SETTING REQ/RESP     | 70  |
| 3.25 | QMI_QCMAP_DISABLE_FIREWALL_SETTING                                |     |
|      | 3.25.1 Request - QMI_QCMAP_DISABLE_FIREWALL_SETTING_REQ           |     |
|      | 3.25.2 Response - QMI_QCMAP_DISABLE_FIREWALL_SETTING_RESP         |     |
|      | 3.25.3 Description of QMI_QCMAP_DISABLE_FIREWALL_SETTING REQ/RESP | 72  |
| 3.26 | QMI_QCMAP_ADD_FIREWALL_CONFIG                                     |     |
|      | 3.26.1 Request - QMI_QCMAP_ADD_FIREWALL_CONFIG_REQ                | 73  |
|      | 3.26.2 Response - QMI_QCMAP_ADD_FIREWALL_CONFIG_RESP              | 74  |
|      | 3.26.3 Description of QMI_QCMAP_ADD_FIREWALL_CONFIG REQ/RESP      | 75  |
| 3.27 | QMI QCMAP DELETE FIREWALL CONFIG                                  | 76  |
|      | 3.27.1 Request - QMI_QCMAP_DELETE_FIREWALL_CONFIG_REQ             | 76  |
|      | 3.27.2 Response - QMI_QCMAP_DELETE_FIREWALL_CONFIG_RESP           | 77  |
|      | 3.27.3 Description of QMI_QCMAP_DELETE_FIREWALL_CONFIG REQ/RESP   | 77  |
| 3.28 | QMI_QCMAP_GET_FIREWALL_CONFIG                                     | 78  |
| 0.20 | 3.28.1 Request - QMI_QCMAP_GET_FIREWALL_CONFIG_REQ                | 78  |
|      | 3.28.2 Response - QMI_QCMAP_GET_FIREWALL_CONFIG_RESP              | 79  |
|      | 3.28.3 Description of QMI_QCMAP_GET_FIREWALL_CONFIG REQ/RESP      | 80  |
| 3 20 | QMI QCMAP STATION MODE ENABLE                                     | 81  |
| 0.23 | 3.29.1 Request - QMI_QCMAP_STATION_MODE_ENABLE_REQ                | 81  |
|      | 3.29.2 Response - QMI_QCMAP_STATION_MODE_ENABLE_RESP              |     |
|      | 3.29.3 Description of QMI QCMAP STATION MODE ENABLE REQ/RESP      |     |
|      | J. C. DESCRIPTION OF VIVIEW OF A PARTICINARY ENABLE DECYMENT      | -02 |

|   | 3.30 | QMI_QCMAP_STATION_MODE_DISABLE                                     | 83  |
|---|------|--|-----|
|   |      | 3.30.1 Request - QMI_QCMAP_STATION_MODE_DISABLE_REQ                | 83  |
|   |      | 3.30.2 Response - QMI_QCMAP_STATION_MODE_DISABLE_RESP              | 84  |
|   |      | 3.30.3 Description of QMI_QCMAP_STATION_MODE_DISABLE REQ/RESP      | 84  |
|   | 3.31 | QMI_QCMAP_GET_STATION_MODE   | 85  |
|   |      | 3.31.1 Request - QMI_QCMAP_GET_STATION_MODE_REQ                    | 85  |
|   |      | 3.31.2 Response - QMI_QCMAP_GET_STATION_MODE_RESP                  | 86  |
|   |      | 3.31.3 Description of QMI_QCMAP_GET_STATION_MODE REQ/RESP          | 86  |
|   | 3.32 | QMI_QCMAP_ADD_EXTD_FIREWALL_CONFIG                                 | 87  |
|   |      | 3.32.1 Request - QMI_QCMAP_ADD_EXTD_FIREWALL_CONFIG_REQ            | 87  |
|   |      | 3.32.2 Response - QMI_QCMAP_ADD_EXTD_FIREWALL_CONFIG_RESP          | 90  |
|   |      | 3.32.3 Description of QMI_QCMAP_ADD_EXTD_FIREWALL_CONFIG REQ/RESP  | 91  |
|   | 3.33 | QMI_QCMAP_GET_EXTD_FIREWALL_CONFIG                                 | 92  |
|   |      | 3.33.1 Request - QMI_QCMAP_GET_EXTD_FIREWALL_CONFIG_REQ            | 92  |
|   |      | 3.33.2 Response - QMI_QCMAP_GET_EXTD_FIREWALL_CONFIG_RESP          | 93  |
|   |      | 3.33.3 Description of QMI_QCMAP_GET_EXTD_FIREWALL_CONFIG REQ/RESP  | 96  |
|   | 3.34 | QMI_QCMAP_GET_FIREWALL_CONFIG_HANDLE_LIST                          |     |
|   |      | 3.34.1 Request - QMI_QCMAP_GET_FIREWALL_CONFIG_HANDLE_LIST_REQ     |     |
|   |      | 3.34.2 Response - QMI_QCMAP_GET_FIREWALL_CONFIG_HANDLE_LIST_RESP . | 98  |
|   |      | 3.34.3 Description of QMI_QCMAP_GET_FIREWALL_CONFIG                |     |
|   |      | HANDLE_LIST REQ/RESP   | 99  |
|   | 3.35 | QMI_QCMAP_CHANGE_NAT_TYPE  | 100 |
|   |      | 3.35.1 Request - QMI_QCMAP_CHANGE_NAT_TYPE_REQ                     |     |
|   |      | 3.35.2 Response - QMI_QCMAP_CHANGE_NAT_TYPE_RESP                   |     |
|   |      | 3.35.3 Description of QMI_QCMAP_CHANGE_NAT_TYPE REQ/RESP           |     |
|   | 3.36 | QMI_QCMAP_GET_NAT_TYPE   |     |
|   |      | 3.36.1 Request - QMI_QCMAP_GET_NAT_TYPE_REQ                        |     |
|   |      | 3.36.2 Response - QMI_QCMAP_GET_NAT_TYPE_RESP                      |     |
|   |      | 3.36.3 Description of QMI_QCMAP_GET_NAT_TYPE REQ/RESP              |     |
|   |      | End Reasons Call End Reasons                                       | 40- |
| A | Call | End Reasons  | 105 |
|   | A.1  | Call End Reasons   | 105 |
|   | A.2  | Verbose Call End Reasons   | 107 |


## **List of Tables**

| 1-1 | Reference documents and standards | 9  |
|-----|-----------------------------------|----|
| 1-2 | Acronyms                          | ç  |
| 3-1 | QMI_QCMAP messages                | 13 |
| A-1 | Call end reasons                  | )! |
| A-2 | Verhose call end reasons          | ١. |



## **Revision History**

| Revision | Date     | Description  |
|----------|----------|--|
| A        | May 2012 | Initial release. Created from 80-VB816-34 A.   |
| В        | Sep 2012 | Updates for this revision include minor version 2 and minor version 3.                                   |
|          |          | Updated sections 2.3.1 and 3.1.3.  |
|          |          | Added new TLVs:  • SSID2 IP address info  • NAT type info  |
|          |          | Added new messages:  • QMI_QCMAP_CHANGE_NAT_TYPE (Section 3.35)  • QMI_QCMAP_GET_NAT_TYPE (Section 3.36) |



## 1 Introduction

## 1.1 Purpose

This specification documents Major Version 1 of the Qualcomm Messaging Interface (QMI) for Qualcomm Mobile Access Point Service (QMI\_QCMAP).

QMI\_QCMAP provides a command set to interface with a wireless mobile station to access mobile AP services.

## 1.2 Scope

This document is intended for software developers using QMI\_QCMAP on a host processor and interacting with a Qualcomm MSM<sup>TM</sup> device for controlling Qualcomm mobile access point functionality.

This document provides the following details about QMI\_QCMAP:

- Theory of operation Chapter 2 provides the theory of operation of QMI\_QCMAP. The chapter includes messaging conventions, assigned QMI service type, fundamental service concepts, and state variables related to the service.
- Message formats, syntax, and semantics Chapter 3 provides the specific syntax and semantics of messages included in this version of the QMI\_QCMAP specification.
- Additional information Appendix A provides tables for call end reasons and verbose call end reasons.

### 1.3 Conventions

Function declarations, function names, type declarations, and code samples appear in a different font. For example, #include.

Parameter types are indicated by arrows:

- → Designates an input parameter
- ← Designates an output parameter
- → Designates a parameter used for both input and output

#### 1.4 References

Table 1-1 lists reference documents, which may include Qualcomm documents and non-Qualcomm standards and resources. Reference documents that are no longer applicable are deleted from this table; therefore, reference numbers might not be sequential.

Table 1-1 Reference documents and standards

| Ref.       | Document   |                     |  |  |  |  |  |
|------------|--|---------------------|--|--|--|--|--|
| Qual       | Qualcomm   |                     |  |  |  |  |  |
| Q1         | Application Note: Software Glossary for Customers CL93-V3077-1 |                     |  |  |  |  |  |
| Q2         | Qualcomm MSM™ Interface (QMI) Architecture                     | 80-VB816-1          |  |  |  |  |  |
| Q3         | QMI WDS for MPSS.NI.3.0.x, QMI Wireless Data Svc Spec          | 80-N9986-5          |  |  |  |  |  |
| Stand      | dards  |                     |  |  |  |  |  |
| <b>S</b> 1 | User Datagram Protocol   | RFC 768 (Aug 1980)  |  |  |  |  |  |
| S2         | Internet Protocol DARPA Internet Program Protocol              | RFC 791 (Sep 1981)  |  |  |  |  |  |
|            | Specification  | 6                   |  |  |  |  |  |
| S3         | Internet Control Message Protocol DARPA Internet Program       | RFC 792 (Sep 1981)  |  |  |  |  |  |
|            | Protocol Specification   | ec,                 |  |  |  |  |  |
| S4         | Transmission Control Protocol DARPA Internet Program           | RFC 793 (Sep 1981)  |  |  |  |  |  |
|            | Protocol Specification   |                     |  |  |  |  |  |
| S5         | Internet Protocol Version 6 (IPv6) Specification               | RFC 2460 (Dec 1998) |  |  |  |  |  |
| <b>S</b> 6 | Internet Protocol Version 6 (IPv6) Addressing Architecture     | RFC 3513 (Apr 2003) |  |  |  |  |  |
| S7         | IP Encapsulating Security Payload (ESP)                        | RFC 4303 (Dec 2005) |  |  |  |  |  |

## 1.5

Technical Assistance
stance or clarification on information in the ogies at https:// For assistance or clarification on information in this guide, submit a case to Qualcomm CDMA Technologies at https://support.cdmatech.com.

If you do not have access to the CDMATech Support Services website, register for access or send email to support.cdmatech@qualcomm.com.

#### **Acronyms** 1.6

For definitions of terms and abbreviations, refer to [Q1]. Table 1-2 lists terms that are specific to this document.

Table 1-2 Acronyms

| Acronym   | Definition  |  |  |  |
|---|---|--|--|--|
| AP  | access point  |  |  |  |
| DMZ (sometimes referred to as a perimeter network) is a physical or log |   |  |  |  |
|   | subnetwork that contains and exposes an organization's external services to a larger  |  |  |  |
|   | untrusted network, usually the Internet. The purpose of a DMZ is to add an additional |  |  |  |
|   | layer of security to an organization's LAN.   |  |  |  |
| DNS   | domain name service   |  |  |  |
| ESP   | Encapsulating Security Payload Protocol   |  |  |  |
| ICMP  | Internet Control Message Protocol   |  |  |  |

**Table 1-2 Acronyms (cont.)** 

| Acronym | Definition                           |  |  |  |  |  |  |
|---------|--------------------------------------|--|--|--|--|--|--|
| IPSec   | Internet Protocol security           |  |  |  |  |  |  |
| L2TP    | L2TP Layer 2 Tunneling Protocol      |  |  |  |  |  |  |
| MIP     | , ,                                  |  |  |  |  |  |  |
| NAT     | network address translation          |  |  |  |  |  |  |
| PPTP    | Point-to-Point Tunneling Protocol    |  |  |  |  |  |  |
| QCMAP   | Qualcomm Mobile Access Point Service |  |  |  |  |  |  |
| QMI     | Qualcomm messaging interface         |  |  |  |  |  |  |
| SNAT    | static NAT                           |  |  |  |  |  |  |
| SSID    | service set identifier               |  |  |  |  |  |  |
| STA     | station                              |  |  |  |  |  |  |
| TCP     | Transmission Control Protocol        |  |  |  |  |  |  |
| TE      | terminal equipment                   |  |  |  |  |  |  |
| TLV     | type-length-value                    |  |  |  |  |  |  |
| TOS     | type of service                      |  |  |  |  |  |  |
| UDP     | User Datagram Protocol               |  |  |  |  |  |  |
| VPN     |                                      |  |  |  |  |  |  |
|         | virtual private network              |  |  |  |  |  |  |
|         |                                      |  |  |  |  |  |  |

### 2 Theory of Operation

#### 2.1 **Generalized QMI Service Compliance**

The QMI\_QCMAP service complies with the generalized QMI service specification, including the rules for messages, indications and responses, byte ordering, arbitration, constants, result, and error code values described in [Q2]. Extensions to the generalized QMI service theory of operation are noted in subsequent sections of this chapter.

## 2.2

QCMAP is assigned QMI service type 0x1E.

## 2.3

### 2.3.1

Message Definition Template

Response Message Result TLV

-Length-Value (TLV) is present the Indication message. This Type-Length-Value (TLV) is present in all Response messages defined in this document. It is not present in the Indication messages.

|             | Name | Version introduced | Version last modified |
|-------------|------|--------------------|-----------------------|
| Result Code | :05  | Corresponding      | N/A                   |
|             | ,    | command's Version  |                       |
|             |      | introduced         |                       |

| Field  | Field         | Field  | Parameter  | Size   | Description                              |  |
|--------|---------------|--------|------------|--------|--|--|
|        | value         | type   |            | (byte) |  |  |
| Туре   | 0x02          |        |            | 1      | Result Code                              |  |
| Length | 4             |        |            | 2      |  |  |
| Value  | $\rightarrow$ | uint16 | qmi_result | 2      | Result code                              |  |
|        |               |        |            |        | • QMI_RESULT_SUCCESS                     |  |
|        |               |        |            |        | • QMI_RESULT_FAILURE                     |  |
|        |               | uint16 | qmi_error  | 2      | Error code – Possible error code values  |  |
|        |               |        |            |        | are described in the error codes section |  |
|        |               |        |            |        | of each message definition               |  |

## 2.4 QMI\_QCMAP Fundamental Concepts

QMI\_QCMAP provides a command set to interface with a wireless mobile station to access mobile AP services. The QMI\_QCMAP service supports only one client per QMI control channel.

### 2.5 Service State Variables

### 2.5.1 Shared State Variables

No QMI\_QCMAP state variables are shared across control points.

### 2.5.2 State Variables Per Control Point

| Name                | Description                             | Possible | Default |
|---------------------|---|----------|---------|
|                     |   | values   | value   |
| register_indication | WWAN status indication registration per | • FALSE  | FALSE   |
|                     | mobile AP handle                        | • TRUE   |         |

# QMI\_QCMAP Messages

Table 3-1 QMI\_QCMAP messages

| Command                       | ID         | Description                                |
|-------------------------------|------------|--|
| QMI_QCMAP_MOBILE_AP_ENABLE    | 0x0020     | Enables the mobile AP functionality via    |
|                               |            | a single mobile AP instance on the         |
|                               |            | modem.                                     |
| QMI_QCMAP_MOBILE_AP_DISABLE   | 0x0021     | Disables the mobile AP functionality       |
|                               |            | for a mobile AP instance on the modem.     |
| QMI_QCMAP_BRING_UP_WWAN       | 0x0022     | Invokes bringing up the WWAN from          |
|                               | 2.0022     | the mobile AP.                             |
| QMI_QCMAP_BRING_UP_WWAN_IND   | 0x0022     | Indicates the completion of processing a   |
|                               | indication | QMI_QCMAP_BRING_UP_WWAN_                   |
| OM OCHAR TEAR ROUNI WINAN     | 0.0022     | REQ.                                       |
| QMI_QCMAP_TEAR_DOWN_WWAN      | 0x0023     | Tears down the WWAN.                       |
| QMI_QCMAP_TEAR_DOWN_WWAN_IND  | 0x0023     | Indicates the completion of processing a   |
| QM_QeMH_IBM_BeMI_WML_HB       | indication | QMI_QCMAP_TEAR_DOWN_                       |
| 4 12 08                       | , exe,     | WWAN_REQ.                                  |
| QMI_QCMAP_GET_WWAN_STATUS     | 0x0024     | Queries the current WWAN status.           |
| Ontile 01 430                 |            |  |
| QMI_QCMAP_WWAN_STATUS_IND_REG | 0x003A     | Registers/deregisters the control point to |
| 2 501                         |            | receive QMI_QCMAP_WWAN_                    |
| 100                           |            | STATUS_IND.                                |
| QMI_QCMAP_WWAN_STATUS_IND     | 0x003E     | Indicates a change in the current mobile   |
|                               |            | AP WWAN connection status.                 |
| QMI_QCMAP_SET_IPSEC_VPN_PASS_ | 0x0026     | Configures the Internet Protocol           |
| THROUGH                       |            | security (IPSec) Virtual Private Network   |
|                               |            | (VPN) passthrough setting.                 |
| QMI_QCMAP_GET_IPSEC_VPN_PASS_ | 0x0025     | Queries the IPSec VPN passthrough          |
| THROUGH                       |            | setting.                                   |
| QMI_QCMAP_SET_PPTP_VPN_PASS_  | 0x0028     | Configures the Point-to-Point Tunneling    |
| THROUGH                       |            | Protocol (PPTP) VPN passthrough            |
|                               |            | setting.                                   |
| QMI_QCMAP_GET_PPTP_VPN_PASS_  | 0x0027     | Queries the PPTP VPN passthrough           |
| THROUGH                       |            | setting.                                   |
| QMI_QCMAP_SET_L2TP_VPN_PASS_  | 0x002A     | Configures the Layer 2 Tunneling           |
| THROUGH                       |            | Protocol (L2TP) VPN passthrough            |
|                               | 0.0000     | setting.                                   |
| QMI_QCMAP_GET_L2TP_VPN_PASS_  | 0x0029     | Queries the L2TP VPN passthrough           |
| THROUGH                       |            | setting.                                   |

Table 3-1 QMI\_QCMAP messages (cont.)

| Command                                       | ID     | Description  |
|---|--------|--|
| QMI_QCMAP_SET_DYNAMIC_NAT_                    | 0x002C | Sets the Network Address Translation                           |
| ENTRY_TIMEOUT                                 |        | (NAT) entry timeout.   |
| QMI_QCMAP_GET_DYNAMIC_NAT_                    | 0x002B | Queries the NAT entry timeout.                                 |
| ENTRY_TIMEOUT                                 |        |  |
| QMI_QCMAP_ADD_STATIC_NAT_ENTRY                | 0x002D | Adds a static NAT entry.                                       |
| QMI_QCMAP_DELETE_STATIC_NAT_<br>ENTRY         | 0x002E | Deletes a static NAT entry.                                    |
| QMI_QCMAP_GET_STATIC_NAT_ENTRIES              | 0x002F | Queries all static NAT entries.                                |
| QMI_QCMAP_SET_DMZ                             | 0x0030 | Sets the DMZ (perimeter network) IP address for the mobile AP. |
| QMI_QCMAP_GET_DMZ                             | 0x0032 | Queries the DMZ IP address on the mobile AP.                   |
| QMI_QCMAP_DELETE_DMZ                          | 0x0031 | Deletes the DMZ entry or DMZ IP address.                       |
| QMI_QCMAP_GET_WWAN_CONFIG                     | 0x0033 | Queries the WWAN IP configuration.                             |
| QMI_QCMAP_ENABLE_FIREWALL_<br>SETTING         | 0x0034 | Enables the firewall setting.                                  |
| QMI_QCMAP_GET_FIREWALL_SETTING                | 0x0035 | Queries the firewall setting.                                  |
| QMI_QCMAP_DISABLE_FIREWALL_<br>SETTING        | 0x0036 | Disables the firewall setting.                                 |
| QMI_QCMAP_ADD_FIREWALL_CONFIG                 | 0x0037 | Adds a firewall configuration rule.                            |
| QMI_QCMAP_DELETE_FIREWALL_CONFIG              | 0x0039 | Deletes a firewall configuration rule.                         |
| QMI_QCMAP_GET_FIREWALL_CONFIG                 | 0x0038 | Queries the firewall configuration rules.                      |
| QMI_QCMAP_STATION_MODE_ENABLE                 | 0x003B | Enables Station (STA) mode                                     |
| (   |        | functionality for a mobile AP instance                         |
|   |        | on the modem.  |
| QMI_QCMAP_STATION_MODE_DISABLE                | 0x003C | Disables STA mode functionality for a                          |
|   |        | mobile AP instance on the modem.                               |
| QMI_QCMAP_GET_STATION_MODE                    | 0x003D | Queries the STA mode functionality for                         |
|   |        | a mobile AP instance on the modem.                             |
| QMI_QCMAP_ADD_EXTD_FIREWALL_                  | 0x003F | Adds IP filter-based firewall rules                            |
| CONFIG  |        | (extended firewall).   |
| QMI_QCMAP_GET_EXTD_FIREWALL_<br>CONFIG        | 0x0040 | Gets the firewall rules.                                       |
| QMI_QCMAP_GET_FIREWALL_CONFIG_<br>HANDLE_LIST | 0x0041 | Gets the handles of all the firewall rules.                    |
| QMI_QCMAP_CHANGE_NAT_TYPE                     | 0x0042 | Changes the currently existing NAT type.                       |
| QMI_QCMAP_GET_NAT_TYPE                        | 0x0043 | Gets the currently enabled NAT type.                           |

#### 3.1 QMI\_QCMAP\_MOBILE\_AP\_ENABLE

Enables the mobile AP functionality via a single mobile AP instance on the modem.

**QCMAP** message ID

0x0020

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_MOBILE\_AP\_ENABLE\_REQ 3.1.1

### **Mandatory TLVs**

| Message type   | _    |                    |                       |
|----------------|------|--------------------|-----------------------|
| Request        |      |                    |                       |
| Sender         |      | Secre              |                       |
| Control point  |      | Trade              |                       |
| Mandatory TLVs |      | Contain            |                       |
|                | Name | Version introduced | Version last modified |
| IP Family      |      | 8. 0 1.0           | 1.0                   |
|                |      | ntial 08: 35key    |                       |

| Field  | Field         | Field | Parameter     | Size   | Description                          |
|--------|---------------|-------|---------------|--------|--------------------------------------|
|        | value         | type  | (01, 5.0, 030 | (byte) |                                      |
| Туре   | 0x01          |       | 002-02-       | 1      | IP Family                            |
| Length | 4             |       | . 250         | 2      |                                      |
| Value  | $\rightarrow$ | enum  | ip_family     | 4      | Determines whether mobile AP IPv4 or |
|        |               |       |               |        | IPv6 must be enabled. Values:        |
|        |               |       |               |        | • 4 – IPv4                           |
|        |               |       |               |        | • 6 – IPv6                           |

### **Optional TLVs**

| Name                  | Version introduced | Version last modified |
|-----------------------|--------------------|-----------------------|
| IP Address            | 1.0                | 1.0                   |
| Network Policy        | 1.0                | 1.0                   |
| SSID2 IP Address Info | 1.2                | 1.2                   |
| NAT Type Info         | 1.3                | 1.3                   |

| Field  | Field | Field | Parameter | Size   | Description |
|--------|-------|-------|-----------|--------|-------------|
|        | value | type  |           | (byte) |             |
| Туре   | 0x10  |       |           | 1      | IP Address  |
| Length | 28    |       |           | 2      |             |

| Field    | Field         | Field  | Parameter               | Size   | Description   |
|----------|---------------|--------|-------------------------|--|---|
|          | value         | type   |                         | (byte)   |   |
| Value    | $\rightarrow$ | uint32 | subnet_mask             | 4  | Subnet mask.  |
|          |               | uint32 | nat_ip_addr             | 4  | NAT IP address.                                     |
|          |               | uint32 | nat_dns_addr            | 4  | NAT Domain Name Service (DNS)                       |
|          |               |        |                         |  | address.  |
|          |               | uint32 | usb_rmnet_ip_addr       | 4  | RmNet USB Terminal Equipment (TE)                   |
|          |               |        |                         |  | address.  |
|          |               | uint32 | usb_rmnet_gateway_addr  | 4  | RmNet USB gateway address.                          |
|          |               | uint32 | apps_rmnet_ip_addr      | 4  | RmNet applications IP address.                      |
|          |               | uint32 | apps_rmnet_gateway_addr | 4  | RmNet applications gateway address.                 |
| Type     | 0x11          |        |                         | 1  | Network Policy                                      |
| Length   | 10            |        |                         | 2  |   |
| Value    | $\rightarrow$ | mask   | tech_pref               | 8  | Bitmap indicating the technology                    |
|          |               |        |                         |  | preference. A single connection is                  |
|          |               |        |                         |  | attempted using the following specified             |
|          |               |        |                         |  | technology preferences:                             |
|          |               |        |                         |  | • Bit 0 – 3GPP                                      |
|          |               |        |                         |  | • Bit 1 – 3GPP2                                     |
|          |               |        |                         |  | All other bits are reserved and ignored             |
|          |               |        |                         |  | even if they are set in the request. If a           |
|          |               |        |                         | ontal  | single value of the technology preference           |
|          |               |        |                         | 0,00   | bitmask is set, the device attempts to use          |
|          |               |        | Ves.                    | NA   | that technology. If two or more bits in             |
|          |               |        | No. 18                  | 5.   | the technology preference bitmask are               |
|          |               |        | 13 08:1                 | bitmask is set, the device attempts to use that technology. If two or more bits in the technology preference bitmask are set, the device determines the technolog to be used from those specified. |   |
|          |               | : .0   | C1 11 22 2              | to be used from those specified.   |   |
|          |               | uint8  | profile_id_3gpp2        | 1  | CDMA profile ID.                                    |
| _        | 0-12          | uint8  | profile_id_3gpp         | 1  | UMTS profile ID. SSID2 IP Address Info              |
| Туре     | 0x12          |        | 20,000                  | 1  | SSID2 IP Address Info                               |
| Length   | 8             | wim+22 | odda .                  | 2 4  | IDv4 address as smasified in the IDv4               |
| Value    | $\rightarrow$ | uint32 | addr                    | 4  | IPv4 address as specified in the IPv4               |
|          |               | :      |                         | 4  | protocol specification (RFC 791 [S2]).              |
|          |               | uint32 | subnet_mask             | 4  | IPv4 subnet mask as specified in the IPv4           |
| <b>T</b> | 012           |        |                         | 1  | protocol specification (RFC 791 [S2]).              |
| Type     | 0x13          |        |                         | 1  | NAT Type Info                                       |
| Length   | 4             | onima  | gaman not tree info     | 2  | NAT type specified during mobile AD                 |
| Value    | $\rightarrow$ | enum   | qcmap_nat_type_info     | 4  | NAT type specified during mobile AP enable. Values: |
|          |               |        |                         |  |   |
|          |               |        |                         |  | • 0x00 – QCMAP_NAT_TYPE_                            |
|          |               |        |                         |  | SYMMETRIC – Symmetric NAT                           |
|          |               |        |                         |  | • 0x01 – QCMAP_NAT_TYPE_PORT_                       |
|          |               |        |                         |  | RESTRICTED_CONE – Port restricted                   |
|          |               |        |                         |  | cone NAT  |

## 3.1.2 Response - QMI\_QCMAP\_MOBILE\_AP\_ENABLE\_RESP

| V | les | sag | e tv | /pe |
|---|-----|-----|------|-----|
|   |     |     |      |     |

Response

Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### Optional TLVs

| Name             | Version introduced | Version last modified |
|------------------|--------------------|-----------------------|
| Mobile AP Handle | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                               |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   |                  | (byte) |   |
| Туре   | 0x10          |        |                  | 10     | Mobile AP Handle                          |
| Length | 4             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call     |
|        |               |        | Moderation       | 5. C   | instance.                                 |
|        |               |        | 3.3              | 1ey    | The mobile AP handle must be retained     |
|        |               |        | 2000 1 00        | 5      | by the control point and specified in all |
|        |               |        | 11001-100        |        | mobile AP-specific QCMAP messages.        |
|        |               |        | (01,5)           |        | For example, QMI_QCMAP_DISABLE,           |
|        |               |        | 2012             |        | QMI_QCMAP_BRING_UP_WWAN,                  |
|        |               |        | : 250            |        | etc.                                      |

### **Error codes**

| QMI_ERR_NONE          | No error in the request                                   |
|-----------------------|---|
| QMI_ERR_INTERNAL      | Unexpected error occurred during processing               |
| QMI_ERR_MALFORMED_MSG | Message was not formulated correctly by the control point |
|                       | or the message was corrupted during transmission          |
| QMI_ERR_MISSING_ARG   | Some TLV was missing                                      |
| QMI_ERR_NOT_SUPPORTED | Operation is not supported                                |
| QMI_ERR_NO_EFFECT     | Mobile AP instance is already enabled                     |

### 3.1.3 Description of QMI\_QCMAP\_MOBILE\_AP\_ENABLE REQ/RESP

This command enables the mobile AP functionality at the modem. The control point passes the network policy that is used to bring up the WWAN when QMI\_QCMAP\_BRING\_UP\_WWAN is called. After QMI\_QCMAP\_MOBILE\_AP\_ENABLE is successfully processed, any subsequent RmNet call using the same network policy is brought up in the Mobile AP mode. If the IP family is QCMAP\_IP\_V4, the control point must fill in the optional IP Address TLV.

The control point is expected to store the mobile AP handle that is returned and to pass it in all mobile AP-specific messages.

The Network Policy TLV provides the network policy that is used by the mobile AP to select the WWAN network. If this value is not specified, the default WWAN network is selected.

The IP Address TLV is required when the mobile AP IPv4 is enabled. The value is ignored when the mobile AP IPv6 is enabled. If the TLV is not specified when enabling the mobile AP IPv4, a QMI\_ERR\_MISSING\_ARG error is returned.

The SSID2 IP Address Info TLV is required when the mobile AP IPv4 Service Set Identifier 2 (SSID2) is enabled. The value is ignored when the mobile AP IPv6 is enabled. If this TLV is not specified when enabling the mobile AP IPv4, it is assumed that SSID2 is not enabled.

The mobile AP instance enabled by this command remains enabled until the control point or client issues a QMI\_QCMAP\_MOBILE\_AP\_DISABLE\_REQ request or until the control point disassociates from the service.

#### 3.2 QMI\_QCMAP\_MOBILE\_AP\_DISABLE

Disables the mobile AP functionality for a mobile AP instance on the modem.

**QCMAP** message ID

0x0021

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_MOBILE\_AP\_DISABLE\_REQ 3.2.1

### **Mandatory TLVs**

| Message type     |      |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    | 5                     |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 0. 1.0             | 1.0                   |
|                  |      | otial 08: 35key    |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

### **Optional TLVs**

None

#### 3.2.2 Response - QMI QCMAP DISABLE RESP

Message type

Response

Sender

Service

#### Mandatory TLVs

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

#### **Optional TLVs**

#### **Error codes**

| None Error codes       | Secrets   |
|------------------------|---|
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NO_EFFECT      | WWAN is connected or in a transient state; the control point    |
| fide                   | must terminate the WWAN connection using                        |
| (0/1,7:0               | QMI_QCMAP_TEAR_DOWN_WWAN_REQ and wait for                       |
| 202-5                  | the final WWAN status before disabling the mobile AP            |

#### Description of QMI QCMAP MOBILE AP DISABLE REQ/RESP 3.2.3

This command disables the mobile AP functionality at the modem for a single mobile AP instance. After the request is successfully processed, the ongoing RmNet and WWAN calls (if any) are torn down and subsequent RmNet calls are brought up in the non-Mobile AP mode. If the RmNet call is up in the Mobile AP mode at the time this command is sent, the control point considers that the packet data connection state is unchanged until notified of a state change via QMI\_WDS\_PKT\_SRVC\_STATUS\_IND (refer to Q3) for the RmNet session. If the WWAN call is active, the mobile AP is not disabled and a QMI ERR NO EFFECT error is returned.

The mobile AP instance associated with the control point can be disabled using either this command or when the control point disconnects from the QMI\_QCMAP service. Qualcomm recommends that the client disable the mobile AP instances specifically using this command and then proceed by disconnecting from the service.

All NAT-specific functionalities associated with this mobile AP instance are disabled when the command is used or when the control point disassociates from the QMI QCMAP service. The control point must reactivate or set functionalities such as the DMZ, VPN passthrough, static NAT, and the firewall after enabling the mobile AP again.

#### QMI\_QCMAP\_BRING\_UP\_WWAN 3.3

Invokes bringing up the WWAN from the mobile AP.

**QCMAP** message ID

0x0022

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_BRING\_UP\_WWAN\_REQ 3.3.1

### **Mandatory TLVs**

| Message type     |      |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    | 5                     |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 0021-02-         | 1      | Mobile AP Handle                        |
| Length | 4             |        | 1.250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

### **Optional TLVs**

None

### Response - QMI QCMAP BRING UP WWAN RESP

### Message type

Response

### Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

#### **Optional TLVs**

#### **Error codes**

| None                   | x5  |
|------------------------|---|
| Error codes            | Secree  |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NO_EFFECT      | WWAN is already up or a previous request is still in process    |
| Fide                   | (WWAN is connecting)  |

#### Description of QMI\_QCMAP\_BRING\_UP\_WWAN REQ/RESP 3.3.3

This command brings up the WWAN connection. The call is established using the stored network policy that enabled the mobile AP via QMI\_QCMAP\_MOBILE\_AP\_ENABLE\_REQ.

If the response returned is SUCCESS, the corresponding QMI QCMAP BRING UP WWAN IND indication determines that the request has been completely processed by the modem.

The WWAN status can be queried using QMI\_QCMAP\_GET\_WWAN\_STATUS or sent as an indication for registered clients. See QMI\_QCMAP\_WWAN\_STATUS\_IND\_REG (Section 3.6) for information on registration.

If the control point issues multiple requests in short intervals, a QMI ERR NO EFFECT error is returned indicating that the previous request is still in process.

### 3.3.4 Indication - QMI QCMAP BRING UP WWAN IND

Message type

Indication

Sender

Service

Indication scope

Unicast

### **Mandatory TLVs**

| Name             | Version introduced | Version last modified |
|------------------|--------------------|-----------------------|
| Mobile AP Handle | 1.0                | 1.0                   |
| IP Family        | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                           |
|--------|---------------|--------|------------------|--------|---------------------------------------|
|        | value         | type   |                  | (byte) | <                                     |
| Туре   | 0x01          |        |                  | Olas   | Mobile AP Handle                      |
| Length | 4             |        | Yes              | 2      | ~                                     |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4 0    | Handle identifying the mobile AP call |
|        |               |        | :12 08:1         | rey    | instance.                             |
| Туре   | 0x02          |        | 180, 37 99       | 1      | IP Family                             |
| Length | 4             |        | 110 11 20 G      | 2      |                                       |
| Value  | $\rightarrow$ | enum   | ip_family        | 4      | Determines whether the mobile AP is   |
|        |               |        | 12-1411111       |        | IPv4 or IPv6. Values:                 |
|        |               |        | .75              |        | • 4 – IPv4                            |
|        |               |        | )                |        | • 6 – IPv6                            |

### **Optional TLVs**

None

## 3.3.5 Description of QMI\_QCMAP\_BRING\_UP\_WWAN\_IND

This indication communicates the completion of processing a QMI\_QCMAP\_BRING\_UP\_WWAN\_REQ received from the control point. If the client registered for the QMI\_QCMAP\_WWAN\_STATUS\_IND indication, it receives the corresponding event indication that reports the WWAN status. Alternatively, the control point can issue QMI\_QCMAP\_GET\_WWAN\_STATUS\_REQ to query the current WWAN status.

#### QMI\_QCMAP\_TEAR\_DOWN\_WWAN 3.4

Tears down the WWAN.

**QCMAP** message ID

0x0023

**Version introduced** 

Major - 1, Minor - 0

## Request - QMI\_QCMAP\_TEAR\_DOWN\_WWAN\_REQ

### **Mandatory TLVs**

|                    | 5                     |
|--------------------|-----------------------|
| Secre              |                       |
| Trade              |                       |
| Contain            |                       |
| Version introduced | Version last modified |
| 8. 0 1.0           | 1.0                   |
|                    | A COLLAND             |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

### **Optional TLVs**

None

### Response - QMI QCMAP TEAR DOWN WWAN RESP

Message type

Response

Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### **Optional TLVs**

#### **Error codes**

| None                   | ars.  |
|------------------------|---|
| Error codes            | Secre   |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NO_EFFECT      | WWAN is already down or a previous request is still in          |
| Fide                   | process (WWAN is disconnecting)                                 |

#### Description of QMI\_QCMAP\_TEAR\_DOWN\_WWAN REQ/RESP 3.4.3

This command tears down the mobile AP WWAN interface that was brought up via QMI\_QCMAP\_BRING\_UP\_WWAN.

If the response returned is SUCCESS, the corresponding QMI QCMAP TEAR DOWN WWAN IND indication determines that the request has been completely processed by the modem.

The WWAN status can be queried using QMI\_QCMAP\_GET\_WWAN\_STATUS or sent as an indication for registered clients. See QMI\_QCMAP\_WWAN\_STATUS\_IND\_REG (Section 3.6) for information on registration.

If the control point issues multiple requests in short intervals, a QMI ERR NO EFFECT error is returned indicating that the previous request is still in process.

## 3.4.4 Indication - QMI\_QCMAP\_TEAR\_DOWN\_WWAN\_IND

Message type

Indication

Sender

Service

Indication scope

Unicast

### **Mandatory TLVs**

| Name             | Version introduced | Version last modified |
|------------------|--------------------|-----------------------|
| Mobile AP Handle | 1.0                | 1.0                   |
| IP Family        | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                           |
|--------|---------------|--------|------------------|--------|---------------------------------------|
|        | value         | type   |                  | (byte) | <                                     |
| Туре   | 0x01          |        |                  | Olas   | Mobile AP Handle                      |
| Length | 4             |        | Yes              | 2      | ~                                     |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4 0    | Handle identifying the mobile AP call |
|        |               |        | :12 08:1         | rey    | instance.                             |
| Туре   | 0x02          |        | 180, 37 99       | 1      | IP Family                             |
| Length | 4             |        | 110 11 20 G      | 2      |                                       |
| Value  | $\rightarrow$ | enum   | ip_family        | 4      | Determines whether the mobile AP is   |
|        |               |        | 12-1411111       |        | IPv4 or IPv6. Values:                 |
|        |               |        | .75              |        | • 4 – IPv4                            |
|        |               |        | )                |        | • 6 – IPv6                            |

### **Optional TLVs**

None

## 3.4.5 Description of QMI\_QCMAP\_TEAR\_DOWN\_WWAN\_IND

This indication communicates the completion of processing a

QMI\_QCMAP\_TEAR\_DOWN\_WWAN\_REQ received from the control point. If the client registered for the QMI\_QCMAP\_WWAN\_STATUS\_IND indication, it receives the corresponding event indication that reports the WWAN status. Alternatively, the control point can issue

QMI\_QCMAP\_GET\_WWAN\_STATUS\_REQ to query the current WWAN status.

#### QMI\_QCMAP\_GET\_WWAN\_STATUS 3.5

Queries the current WWAN status.

**QCMAP** message ID

0x0024

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_WWAN\_STATUS\_REQ 3.5.1

### **Mandatory TLVs**

| •                | _    | _      | _          |                |                       |
|------------------|------|--------|------------|----------------|-----------------------|
| Message type     |      |        |            | 1              |                       |
| Request          |      |        |            | N              | ×5                    |
| Sender           |      |        |            | Secre          |                       |
| Control point    |      |        | <b>6</b> 0 | Trade          |                       |
| Mandatory TLVs   |      |        | Conta      | W.             |                       |
|                  | Name |        | Vers       | ion introduced | Version last modified |
| Mobile AP Handle |      |        | May 8:     | 1.0            | 1.0                   |
|                  |      | ortial | 08: Stey   |                |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 0021-02-         | 1      | Mobile AP Handle                        |
| Length | 4             |        | 1.250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

### **Optional TLVs**

None

## 3.5.2 Response - QMI\_QCMAP\_GET\_WWAN\_STATUS\_RESP

### Message type

Response

### Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### **Optional TLVs**

| Name                    | Version introduced | Version last modified |
|-------------------------|--------------------|-----------------------|
| Call End Reason         | 1.0                | 1.0                   |
| Verbose Call End Reason | 1.0                | 1.0                   |
| Packet Service Status   | 1.0                | 1.0                   |

| Field  | Field         | Field | Parameter               | Size    | Description                              |
|--------|---------------|-------|-------------------------|---------|--|
|        | value         | type  |                         | (byte)  |  |
| Туре   | 0x10          |       | Va .                    | \lambda | Call End Reason                          |
| Length | 4             |       | No. 1917                | 2       |  |
| Value  | $\rightarrow$ | enum  | call_end_reason         | Le4     | Reason the call ended; see Table A-1 for |
|        |               |       | 18477 83                | 0,      | the definition of these values.          |
| Туре   | 0x11          |       | 110 11 200              | 1       | Verbose Call End Reason                  |
| Length | 4             |       | 000000                  | 2       |  |
| Value  | $\rightarrow$ | enum  | verbose_call_end_reason | 4       | Reason the call ended (verbose); see     |
|        |               |       | :05                     |         | Table A-2 for the definition of these    |
|        |               |       | ,                       |         | values.                                  |
| Type   | 0x12          |       |                         | 1       | Packet Service Status                    |
| Length | 4             |       |                         | 2       |  |
| Value  | $\rightarrow$ | enum  | wwan_status             | 4       | If the response is QMI_ERR_NONE,         |
|        |               |       |                         |         | this indicates the WWAN status. Values:  |
|        |               |       |                         |         | • 1 – Connecting                         |
|        |               |       |                         |         | • 2 – Connected                          |
|        |               |       |                         |         | • 3 – Disconnecting                      |
|        |               |       |                         |         | • 4 – Disconnected                       |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NO_MEMORY      | Device could not allocate memory to formulate a response        |
| QMI_ERR_MISSING_ARG    | One or more mandatory TLVs are missing                          |

## 3.5.3 Description of QMI\_QCMAP\_GET\_WWAN\_STATUS REQ/RESP

This command queries the state of the WWAN instantaneously corresponding to the mobile AP handle. The WWAN state could have changed for the following reasons:

- The WWAN state was earlier changed via QMI\_QCMAP\_BRING\_UP\_WWAN or QMI\_QCMAP\_TEAR\_DOWN\_WWAN
- If the network-initiated call status changes

#### QMI\_QCMAP\_WWAN\_STATUS\_IND\_REG 3.6

Registers/deregisters the control point to receive QMI\_QCMAP\_WWAN\_STATUS\_IND.

**QCMAP** message ID

0x003A

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_WWAN\_STATUS\_IND\_REG\_REQ 3.6.1

Message type

### **Mandatory TLVs**

| Message type        |      |       |                    |                       |
|---------------------|------|-------|--------------------|-----------------------|
| Request             |      |       |                    | 5                     |
| Sender              |      |       | Secre              |                       |
| Control point       |      |       | O, Liage           |                       |
| Mandatory TLVs      |      |       | ontain             |                       |
|                     | Name |       | Version introduced | Version last modified |
| Mobile AP Handle    |      | MI    | 3. (2.1.0)         | 1.0                   |
| Register Indication |      | 13 08 | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter           | Size   | Description                                  |
|--------|---------------|---------|---------------------|--------|--|
|        | value         | type    | 002-02-             | (byte) |  |
| Туре   | 0x01          |         | . 250               | 1      | Mobile AP Handle                             |
| Length | 4             |         | 3                   | 2      |  |
| Value  | $\rightarrow$ | uint32  | mobile_ap_handle    | 4      | Handle identifying the mobile AP call        |
|        |               |         |                     |        | instance.                                    |
|        |               |         |                     |        | The value must be the handle previously      |
|        |               |         |                     |        | returned by QMI_QCMAP_MOBILE_                |
|        |               |         |                     |        | AP_ENABLE_REQ.                               |
| Туре   | 0x02          |         |                     | 1      | Register Indication                          |
| Length | 1             |         |                     | 2      |  |
| Value  | $\rightarrow$ | boolean | register_indication | 1      | Specifies the registration. Values:          |
|        |               |         |                     |        | • 0 – Do not register or deregister if       |
|        |               |         |                     |        | already registered                           |
|        |               |         |                     |        | • 1 – Register for the indication; ignore if |
|        |               |         |                     |        | already registered                           |

### **Optional TLVs**

None

#### 3.6.2 Response - QMI\_QCMAP\_WWAN\_STATUS\_IND\_REG\_RESP

### Message type

Response

#### Sender

Service

### **Mandatory TLVs**

### **Optional TLVs**

### **Error codes**

| The Result Code TLV (defined in Section 2.3.1) is always present in the response. |   |  |  |  |
|---|---|--|--|--|
| Optional TLVs   | Secret  |  |  |  |
| None  | a Clade   |  |  |  |
| Error codes   | Contain   |  |  |  |
| QMI_ERR_NONE  | No error in the request   |  |  |  |
| QMI_ERR_INTERNAL  | Unexpected error occurred during processing                     |  |  |  |
| QMI_ERR_MALFORMED_MSG   | Message was not formulated correctly by the control point       |  |  |  |
| S chi   | or the message was corrupted during transmission                |  |  |  |
| QMI_ERR_INVALID_HANDLE  | Mobile AP handle provided in the request is not valid, i.e., it |  |  |  |
| Course  | is not assigned to the control point                            |  |  |  |
| QMI_ERR_NO_MEMORY   | Device could not allocate memory to formulate a response        |  |  |  |
| QMI_ERR_MISSING_ARG   | One or more of mandatory TLVs are missing                       |  |  |  |

#### Description of QMI QCMAP WWAN STATUS IND REG REQ/RESP 3.6.3

This command registers/deregisters the control point to receive the QMI\_QCMAP\_WWAN\_STATUS\_IND indication.

## QMI\_QCMAP\_WWAN\_STATUS\_IND

Indicates a change in the current mobile AP WWAN connection status.

**QCMAP** message ID

0x003E

Version introduced

Major - 1, Minor - 0

#### Indication - QMI\_QCMAP\_WWAN\_STATUS\_IND 3.7.1

| 3.7.1 Indication - QMI_QCMAP_WWA | AN_STATUS_IND       |                       |  |  |  |  |
|----------------------------------|---------------------|-----------------------|--|--|--|--|
| Message type                     | 1.                  |                       |  |  |  |  |
| Indication                       |                     | 9                     |  |  |  |  |
| Sender                           | Secre               |                       |  |  |  |  |
| Service                          | Andication  Service |                       |  |  |  |  |
| Indication scope                 | ntain               |                       |  |  |  |  |
| Unicast                          | Co, Ch,             |                       |  |  |  |  |
| Mandatory TLVs                   | Contain Contain     |                       |  |  |  |  |
| Name                             | Version introduced  | Version last modified |  |  |  |  |
| Mobile AP Handle                 | 1.0                 | 1.0                   |  |  |  |  |
| IP Family                        | 1.0                 | 1.0                   |  |  |  |  |
| Packet Service Status            | 1.0                 | 1.0                   |  |  |  |  |
| Reconfiguration Required         | 1.0                 | 1.0                   |  |  |  |  |

| Field  | Field         | Field  | Parameter        | Size   | Description                           |
|--------|---------------|--------|------------------|--------|---------------------------------------|
|        | value         | type   |                  | (byte) |                                       |
| Туре   | 0x01          |        |                  | 1      | Mobile AP Handle                      |
| Length | 4             |        |                  | 2      |                                       |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call |
|        |               |        |                  |        | instance.                             |
| Туре   | 0x02          |        |                  | 1      | IP Family                             |
| Length | 4             |        |                  | 2      |                                       |
| Value  | $\rightarrow$ | enum   | ip_family        | 4      | Determines whether the mobile AP is   |
|        |               |        |                  |        | IPv4 or IPv6. Value:                  |
|        |               |        |                  |        | • 4 – IPv4                            |
|        |               |        |                  |        | • 6 – IPv6                            |
| Туре   | 0x03          |        |                  | 1      | Packet Service Status                 |
| Length | 4             |        |                  | 2      |                                       |

| Field  | Field         | Field | Parameter         | Size   | Description                              |
|--------|---------------|-------|-------------------|--------|--|
|        | value         | type  |                   | (byte) |  |
| Value  | $\rightarrow$ | enum  | wwan_status       | 4      | Indicates the WWAN status. Values:       |
|        |               |       |                   |        | • 1 – Connecting                         |
|        |               |       |                   |        | • 2 – Connected                          |
|        |               |       |                   |        | • 3 – Disconnecting                      |
|        |               |       |                   |        | • 4 – Disconnected                       |
| Туре   | 0x04          |       |                   | 1      | Reconfiguration Required                 |
| Length | 1             |       |                   | 2      |  |
| Value  | $\rightarrow$ | uint8 | reconfig_required | 1      | Indicates whether the IP reconfiguration |
|        |               |       |                   |        | is required by the control point.        |

#### **Optional TLVs**

| Name                    | Version introduced | Version last modified |
|-------------------------|--------------------|-----------------------|
| Call End Reason         | 1.0                | 1.0                   |
| Verbose Call End Reason | 1.0                | 1.0                   |

| Field  | Field         | Field | Parameter               | Size   | Description                              |
|--------|---------------|-------|-------------------------|--------|--|
|        | value         | type  |                         | (byte) |  |
| Туре   | 0x10          |       |                         |        | Call End Reason                          |
| Length | 4             |       |                         | 20     | ^  |
| Value  | $\rightarrow$ | enum  | call_end_reason         | 4      | Reason the call ended; see Table A-1 for |
|        |               |       | 2.7                     | ey.    | the definition of these values.          |
| Туре   | 0x11          |       | Atla Oo                 | 1      | Verbose Call End Reason                  |
| Length | 4             |       | "96, Y J, VO.           | 2      |  |
| Value  | $\rightarrow$ | enum  | verbose_call_end_reason | 4      | Reason the call ended (verbose); see     |
|        |               |       |                         |        | Table A-2 for the definition of these    |
|        |               |       | 2501                    |        | values.                                  |

## 3.7.2 Description of QMI\_QCMAP\_WWAN\_STATUS\_IND

This indication communicates changes in the WWAN state.

The indication is also sent when the WWAN technology changes after a handoff is performed on the modem. The Reconfiguration Required TLV value will be set to indicate that an IP address reconfiguration is required by the control point.

If the indication is sent due to a WWAN Down state, the optional Call End Reason TLV and optional Verbose Call End Reason TLV are included and will contain the reason the call was terminated. These reasons include network and user-generated reasons. See Table A-1 for the call end reasons. See Table A-2 for the verbose call end reasons.

The Call End Reason TLV has been kept for backward compatibility. All new QMI clients must use the Verbose Call End Reason TLV. Any new call end reason will be added to the Verbose Call End Reason TLV.

#### QMI\_QCMAP\_SET\_IPSEC\_VPN\_PASS\_THROUGH 3.8

Configures the Internet Protocol security (IPSec) Virtual Private Network (VPN) passthrough setting.

### **QCMAP** message ID

0x0026

#### Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_SET\_IPSEC\_VPN\_PASS\_THROUGH\_REQ 3.8.1

Message type

### **Mandatory TLVs**

| Message type          |                    |                       |
|-----------------------|--------------------|-----------------------|
| Request               |                    | 5                     |
| Sender                | Secre              |                       |
| Control point         | Logical Linde      |                       |
| Mandatory TLVs        | Ontain             |                       |
| Name                  | Version introduced | Version last modified |
| Mobile AP Handle      | 1.0                | 1.0                   |
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter              | Size   | Description                             |
|--------|---------------|---------|------------------------|--------|---|
|        | value         | type    | 022                    | (byte) |   |
| Туре   | 0x01          |         | 1,250                  | 1      | Mobile AP Handle                        |
| Length | 4             |         | 100                    | 2      |   |
| Value  | $\rightarrow$ | uint32  | mobile_ap_handle       | 4      | Handle identifying the mobile AP call   |
|        |               |         |                        |        | instance.                               |
|        |               |         |                        |        | The value must be the handle previously |
|        |               |         |                        |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |         |                        |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |         |                        | 1      | VPN Passthrough Value                   |
| Length | 1             |         |                        | 2      |   |
| Value  | $\rightarrow$ | boolean | vpn_pass_through_value | 1      | Indicates whether an IPSec VPN          |
|        |               |         |                        |        | passthrough is allowed; boolean value.  |

### **Optional TLVs**

None

#### 3.8.2 Response - QMI\_QCMAP\_SET\_IPSEC\_VPN\_PASS\_THROUGH\_-**RESP**

#### Message type

Response

#### Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### **Optional TLVs**

#### **Error codes**

| The Result Code 1LV (defined in Section 2.3.1) is atways present in the response. |   |  |  |  |  |  |
|---|---|--|--|--|--|--|
| Optional TLVs   |   |  |  |  |  |  |
| None  | ain Th  |  |  |  |  |  |
| Error codes   |   |  |  |  |  |  |
| QMI_ERR_NONE  | No error in the request   |  |  |  |  |  |
| QMI_ERR_INTERNAL  | Unexpected error occurred during processing                     |  |  |  |  |  |
| QMI_ERR_MALFORMED_MSG   | Message was not formulated correctly by the control point       |  |  |  |  |  |
| THO   | or the message was corrupted during transmission                |  |  |  |  |  |
| QMI_ERR_MISSING_ARG   | Some TLV was missing  |  |  |  |  |  |
| QMI_ERR_INVALID_HANDLE  | Mobile AP handle provided in the request is not valid, i.e., it |  |  |  |  |  |
| 105   | is not assigned to the control point                            |  |  |  |  |  |
| QMI_ERR_INVALID_ARG   | Argument is not correct   |  |  |  |  |  |
| QMI_ERR_NOT_SUPPORTED   | Operation is not supported                                      |  |  |  |  |  |

#### 3.8.3 Description of QMI\_QCMAP\_SET\_IPSEC\_VPN\_PASS\_THROUGH **REQ/RESP**

This command sets the IPSec VPN passthrough on the device. The command handler overwrites any previously configured value with the current value.

# 3.9 QMI\_QCMAP\_GET\_IPSEC\_VPN\_PASS\_THROUGH

Queries the IPSec VPN passthrough setting.

**QCMAP** message ID

0x0025

Version introduced

Major - 1, Minor - 0

# 3.9.1 Request - QMI\_QCMAP\_GET\_IPSEC\_VPN\_PASS\_THROUGH\_REQ

Message type

Request

Sender

Control point

## **Mandatory TLVs**

|                  | Name | Version introduced | Version last modified |
|------------------|------|--------------------|-----------------------|
| Mobile AP Handle | Mo   | 6. (1.0            | 1.0                   |

On Trade Secrets

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# 3.9.2 Response - QMI\_QCMAP\_GET\_IPSEC\_VPN\_PASS\_THROUGH\_RESP

Message type

Response

Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name                  | Version introduced | Version last modified |
|-----------------------|--------------------|-----------------------|
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter              | Size    | Description                            |
|--------|---------------|---------|------------------------|---------|--|
|        | value         | type    |                        | (byte)  |  |
| Туре   | 0x10          |         |                        |         | VPN Passthrough Value                  |
| Length | 1             |         | May                    | 2       | lu.                                    |
| Value  | $\rightarrow$ | boolean | vpn_pass_through_value | b. T.c. | Indicates whether an IPSec VPN         |
|        |               |         | tial 08.               | Ye,     | passthrough is allowed; boolean value. |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.9.3 Description of QMI\_QCMAP\_GET\_IPSEC\_VPN\_PASS\_THROUGH REQ/RESP

This command queries the IPSec VPN passthrough value on the device.

#### QMI QCMAP SET PPTP VPN PASS THROUGH 3.10

Configures the Point-to-Point Tunneling Protocol (PPTP) VPN passthrough setting.

**QCMAP** message ID

0x0028

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_SET\_PPTP\_VPN\_PASS\_THROUGH\_REQ 3.10.1

Message type

## **Mandatory TLVs**

| Message type          |                    |                       |
|-----------------------|--------------------|-----------------------|
| Request               |                    | 9                     |
| Sender                | Secre              |                       |
| Control point         | CO Trade           |                       |
| Mandatory TLVs        | Contain            |                       |
| Name                  | Version introduced | Version last modified |
| Mobile AP Handle      | 8. 0 1.0           | 1.0                   |
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter              | Size   | Description                             |
|--------|---------------|---------|------------------------|--------|---|
|        | value         | type    | 002                    | (byte) |   |
| Туре   | 0x01          |         | 1,250                  | 1      | Mobile AP Handle                        |
| Length | 4             |         | 100                    | 2      |   |
| Value  | $\rightarrow$ | uint32  | mobile_ap_handle       | 4      | Handle identifying the mobile AP call   |
|        |               |         |                        |        | instance.                               |
|        |               |         |                        |        | The value must be the handle previously |
|        |               |         |                        |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |         |                        |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |         |                        | 1      | VPN Passthrough Value                   |
| Length | 1             |         |                        | 2      |   |
| Value  | $\rightarrow$ | boolean | vpn_pass_through_value | 1      | Indicates whether an IPSec VPN          |
|        |               |         |                        |        | passthrough is allowed; boolean value.  |

## **Optional TLVs**

None

#### 3.10.2 Response - QMI\_QCMAP\_SET\_PPTP\_VPN\_PASS\_THROUGH\_-**RESP**

#### Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

#### **Error codes**

| The Result Code TEV (defined in Section 2. | 3.1) is diways present in the response.                         |
|--|---|
| Optional TLVs                              | Col rade S  |
| None                                       | rain ii   |
| Error codes                                | Lay Concent   |
| QMI_ERR_NONE                               | No error in the request   |
| QMI_ERR_INTERNAL                           | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG                      | Message was not formulated correctly by the control point       |
| THOO                                       | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG                        | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE                     | Mobile AP handle provided in the request is not valid, i.e., it |
| 105  | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG                        | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED                      | Operation is not supported                                      |

#### 3.10.3 Description of QMI\_QCMAP\_SET\_PPTP\_VPN\_PASS\_THROUGH **REQ/RESP**

This command sets the PPTP VPN passthrough on the device. The command handler overwrites any previously configured value with the current value.

#### QMI\_QCMAP\_GET\_PPTP\_VPN\_PASS\_THROUGH 3.11

Queries the PPTP VPN passthrough setting.

**QCMAP** message ID

0x0027

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_PPTP\_VPN\_PASS\_THROUGH\_REQ 3.11.1

## **Mandatory TLVs**

| Message type     |      |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    |                       |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# 3.11.2 Response - QMI\_QCMAP\_GET\_PPTP\_VPN\_PASS\_THROUGH\_-RESP

Message type

Response

Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name                  | Version introduced | Version last modified |
|-----------------------|--------------------|-----------------------|
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter              | Size    | Description                            |
|--------|---------------|---------|------------------------|---------|--|
|        | value         | type    |                        | (byte)  |  |
| Туре   | 0x10          |         |                        |         | VPN Passthrough Value                  |
| Length | 1             |         | May                    | 2       | lu.                                    |
| Value  | $\rightarrow$ | boolean | vpn_pass_through_value | b. T.c. | Indicates whether an IPSec VPN         |
|        |               |         | tial 08.               | Ye,     | passthrough is allowed; boolean value. |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.11.3 Description of QMI\_QCMAP\_GET\_PPTP\_VPN\_PASS\_THROUGH REQ/RESP

This command queries the PPTP VPN passthrough value on the device.

#### QMI\_QCMAP\_SET\_L2TP\_VPN\_PASS\_THROUGH 3.12

Configures the Layer 2 Tunneling Protocol (L2TP) VPN passthrough setting.

**QCMAP** message ID

0x002A

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_SET\_L2TP\_VPN\_PASS\_THROUGH\_REQ 3.12.1

Message type

## **Mandatory TLVs**

| Message type          |                    |                       |
|-----------------------|--------------------|-----------------------|
| Request               |                    | 5                     |
| Sender                | Secre              |                       |
| Control point         | CO Trade           |                       |
| Mandatory TLVs        | ontain             |                       |
| Name                  | Version introduced | Version last modified |
| Mobile AP Handle      | 8. 1.0             | 1.0                   |
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter              | Size   | Description                             |
|--------|---------------|---------|------------------------|--------|---|
|        | value         | type    | 002                    | (byte) |   |
| Туре   | 0x01          |         | 1,250                  | 1      | Mobile AP Handle                        |
| Length | 4             |         | 100                    | 2      |   |
| Value  | $\rightarrow$ | uint32  | mobile_ap_handle       | 4      | Handle identifying the mobile AP call   |
|        |               |         |                        |        | instance.                               |
|        |               |         |                        |        | The value must be the handle previously |
|        |               |         |                        |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |         |                        |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |         |                        | 1      | VPN Passthrough Value                   |
| Length | 1             |         |                        | 2      |   |
| Value  | $\rightarrow$ | boolean | vpn_pass_through_value | 1      | Indicates whether an IPSec VPN          |
|        |               |         |                        |        | passthrough is allowed; boolean value.  |

## **Optional TLVs**

None

## 3.12.2 Response - QMI\_QCMAP\_SET\_L2TP\_VPN\_PASS\_THROUGH\_-RESP

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

None

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
| THOO                   | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
| 125                    | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.12.3 Description of QMI\_QCMAP\_SET\_L2TP\_VPN\_PASS\_THROUGH REQ/RESP

This command sets the L2TP VPN passthrough on the device. The command handler overwrites any previously configured value with the current value.

#### QMI\_QCMAP\_GET\_L2TP\_VPN\_PASS\_THROUGH 3.13

Queries the L2TP VPN passthrough setting.

**QCMAP** message ID

0x0029

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_L2TP\_VPN\_PASS\_THROUGH\_REQ 3.13.1

## **Mandatory TLVs**

| o.io.i ileques   | t - Qivii_QOi | WAI _GEI_EZII _VI N_I AGG_ | .miloodii_ned         |
|------------------|---------------|----------------------------|-----------------------|
| Message type     |               | 1                          |                       |
| Request          |               |                            | 5                     |
| Sender           |               | Secre                      |                       |
| Control point    |               | 1 O Trade                  |                       |
| Mandatory TLVs   |               | Contain                    |                       |
|                  | Name          | Version introduced         | Version last modified |
| Mobile AP Handle |               | 8. 1.0                     | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 002.02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | 1.250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# 3.13.2 Response - QMI\_QCMAP\_GET\_L2TP\_VPN\_PASS\_THROUGH\_-**RESP**

Message type

Response

Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name                  | Version introduced | Version last modified |
|-----------------------|--------------------|-----------------------|
| VPN Passthrough Value | 1.0                | 1.0                   |

| Field    | Field         | Field   | Parameter              | Size    | Description                            |
|----------|---------------|---------|------------------------|---------|--|
|          | value         | type    |                        | (byte)  | <                                      |
| Туре     | 0x10          |         |                        | 010     | VPN Passthrough Value                  |
| Length   | 1             |         | May                    | 2       | lu.                                    |
| Value    | $\rightarrow$ | boolean | vpn_pass_through_value | b. T'c. | Indicates whether an IPSec VPN         |
|          |               |         | 4131 08.               | Ye,     | passthrough is allowed; boolean value. |
| Error co | des           |         | Coulded 157 08008      |         |  |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.13.3 Description of QMI\_QCMAP\_GET\_L2TP\_VPN\_PASS\_THROUGH **REQ/RESP**

This command queries the L2TP VPN passthrough value on the device.

#### QMI\_QCMAP\_SET\_DYNAMIC\_NAT\_ENTRY\_TIMEOUT 3.14

Sets the Network Address Translation (NAT) entry timeout.

**QCMAP** message ID

0x002C

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_SET\_DYNAMIC\_NAT\_ENTRY\_TIMEOUT\_-3.14.1 **REQ**

## **Mandatory TLVs**

| nEQ              |           |                    |                       |
|------------------|-----------|--------------------|-----------------------|
| Message type     |           | N                  |                       |
| Request          |           | Gecret             |                       |
| Sender           |           | (Tade)             |                       |
| Control point    |           | ontain             |                       |
| Mandatory TLVs   | 10,194    | Cou. Chy,          |                       |
|                  | Name      | Version introduced | Version last modified |
| Mobile AP Handle | 413, 08.  | 1.0                | 1.0                   |
| Timeout          | 7 6 2 6 P | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 105              | (byte) |   |
| Туре   | 0x01          |        |                  | 1      | Mobile AP Handle                        |
| Length | 4             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | Timeout                                 |
| Length | 2             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint16 | timeout          | 2      | NAT entry timeout.                      |

## **Optional TLVs**

None

#### 3.14.2 Response - QMI\_QCMAP\_SET\_DYNAMIC\_NAT\_ENTRY\_-**TIMEOUT RESP**

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

#### **Error codes**

| The Result Code TEV (defined in Section 2. | 3.1) is aiways present in the response.                         |
|--|---|
| Optional TLVs                              | Col stade St  |
| None                                       | rain ii   |
| Error codes                                | Lay Congress  |
| QMI_ERR_NONE                               | No error in the request   |
| QMI_ERR_INTERNAL                           | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG                      | Message was not formulated correctly by the control point       |
| THO  | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG                        | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE                     | Mobile AP handle provided in the request is not valid, i.e., it |
| 125  | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG                        | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED                      | Operation is not supported                                      |

# 3.14.3 Description of QMI\_QCMAP\_SET\_DYNAMIC\_NAT\_ENTRY\_-**TIMEOUT REQ/RESP**

This command sets the NAT entry timeout on the device.

#### 3.15 QMI QCMAP GET DYNAMIC NAT ENTRY TIMEOUT

Queries the NAT entry timeout.

**QCMAP** message ID

0x002B

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_DYNAMIC\_NAT\_ENTRY\_TIMEOUT\_-3.15.1 **REQ**

#### **Mandatory TLVs**

| 3.15.1     | REQ       | WI_QCMAP_GET_ | _DYNAMIC_NAI_E     | NIRY_IIMEOUI          |
|------------|-----------|---------------|--------------------|-----------------------|
| Message t  | ype       |               | N                  | 6                     |
| Request    |           |               | Cecre              |                       |
| Sender     |           |               | Oligdes            |                       |
| Control po | int       |               | tain               |                       |
| Mandatory  | / TLVs    | 10            | Courent            |                       |
|            | Nam       |               | Version introduced | Version last modified |
| Mobile A   | AP Handle | 413, 08.      | 1.0                | 1.0                   |
|            |           | 100000        | 0                  |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 30, 30,          | (byte) |   |
| Туре   | 0x01          |        | . 25             | 1      | Mobile AP Handle                        |
| Length | 4             |        | ,                | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

**Optional TLVs** 

# 3.15.2 Response - QMI\_QCMAP\_GET\_DYNAMIC\_NAT\_ENTRY\_-**TIMEOUT RESP**

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name    | Version introduced | Version last modified |
|---------|--------------------|-----------------------|
| Timeout | 1.0                | 1.0                   |

| Field    | Field         | Field  | Parameter        | Size   | Description                |
|----------|---------------|--------|------------------|--------|----------------------------|
|          | value         | type   |                  | (byte) |                            |
| Туре     | 0x10          |        |                  | C10    | Timeout                    |
| Length   | 2             |        | May              | 2      | in.                        |
| Value    | $\rightarrow$ | uint16 | timeout          | 2      | Dynamic NAT entry timeout. |
| Error co | des           |        | Confidential Ob. | ste,   |                            |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### 3.15.3 Description of QMI\_QCMAP\_GET\_DYNAMIC\_NAT\_ENTRY\_-**TIMEOUT REQ/RESP**

This command queries the NAT entry timeout on the device.

#### QMI\_QCMAP\_ADD\_STATIC\_NAT\_ENTRY 3.16

Adds a static NAT entry.

**QCMAP** message ID

0x002D

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_ADD\_STATIC\_NAT\_ENTRY\_REQ 3.16.1

## **Mandatory TLVs**

| Message type             | 1                  |                       |
|--------------------------|--------------------|-----------------------|
| Request                  |                    | 9                     |
| Sender                   | Secre              |                       |
| Control point            | O Trade            |                       |
| Mandatory TLVs           | Contain            |                       |
| Name                     | Version introduced | Version last modified |
| Mobile AP Handle         | 6. (0.1.0)         | 1.0                   |
| SNAT Entry Configuration | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 02/2             | (byte) |   |
| Туре   | 0x01          |        | 1,250            | 1      | Mobile AP Handle                        |
| Length | 4             |        | 100              | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | SNAT Entry Configuration                |
| Length | 9             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | private_ip_addr  | 4      | Private IP address.                     |
|        |               | uint16 | private_port     | 2      | Private port.                           |
|        |               | uint16 | global_port      | 2      | Global port.                            |
|        |               | uint8  | protocol         | 1      | Protocol.                               |

## **Optional TLVs**

None

#### 3.16.2 Response - QMI\_QCMAP\_ADD\_STATIC\_NAT\_ENTRY\_RESP

## Message type

Response

#### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

#### **Optional TLVs**

#### **Error codes**

| The Result Code TLV (defined in Section 2.3.1) is always present in the response. |   |  |  |  |  |
|---|---|--|--|--|--|
| Optional TLVs   | ade Secrets   |  |  |  |  |
| None  | CO Trade  |  |  |  |  |
| Error codes   | Ontain  |  |  |  |  |
| QMI_ERR_NONE  | No error in the request   |  |  |  |  |
| QMI_ERR_INTERNAL  | Unexpected error occurred during processing                     |  |  |  |  |
| QMI_ERR_MALFORMED_MSG   | Message was not formulated correctly by the control point       |  |  |  |  |
| an'i  | or the message was corrupted during transmission                |  |  |  |  |
| QMI_ERR_MISSING_ARG   | Some TLV was missing  |  |  |  |  |
| QMI_ERR_INVALID_HANDLE  | Mobile AP handle provided in the request is not valid, i.e., it |  |  |  |  |
| 2012  | is not assigned to the control point                            |  |  |  |  |
| QMI_ERR_INVALID_ARG   | Argument is not correct   |  |  |  |  |
| QMI_ERR_NOT_SUPPORTED   | Operation is not supported                                      |  |  |  |  |
| QMI_ERR_MAX_LIMIT_REACHED   | Maximum limit was reached for the static NAT entry              |  |  |  |  |
| QMI_ERR_DUPLICATE_ENTRY   | Entry already exists  |  |  |  |  |

#### Description of QMI\_QCMAP\_ADD\_STATIC\_NAT\_ENTRY REQ/RESP 3.16.3

This command adds a static NAT entry.

#### QMI\_QCMAP\_DELETE\_STATIC\_NAT\_ENTRY 3.17

Deletes a static NAT entry.

**QCMAP** message ID

0x002E

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_DELETE\_STATIC\_NAT\_ENTRY\_REQ 3.17.1

Message type

## **Mandatory TLVs**

| Message type             |                    |                       |
|--------------------------|--------------------|-----------------------|
| Request                  |                    | 5                     |
| Sender                   | Secre              |                       |
| Control point            | O Trade            |                       |
| Mandatory TLVs           | Contain            |                       |
| Name                     | Version introduced | Version last modified |
| Mobile AP Handle         | 3. (1.0            | 1.0                   |
| SNAT Entry Configuration | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 0202             | (byte) |   |
| Туре   | 0x01          |        | 250              | 1      | Mobile AP Handle                        |
| Length | 4             |        | 100              | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | SNAT Entry Configuration                |
| Length | 9             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | private_ip_addr  | 4      | Private IP address.                     |
|        |               | uint16 | private_port     | 2      | Private port.                           |
|        |               | uint16 | global_port      | 2      | Global port.                            |
|        |               | uint8  | protocol         | 1      | Protocol.                               |

## **Optional TLVs**

None

#### 3.17.2 Response - QMI\_QCMAP\_DELETE\_STATIC\_NAT\_ENTRY\_RESP

#### Message type

Response

#### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

#### **Error codes**

| The Result Code TLV (defined in Section 2.3.1) is always present in the response. |   |  |  |  |  |
|---|---|--|--|--|--|
| Optional TLVs   |   |  |  |  |  |
| None  | CO Trade  |  |  |  |  |
| Error codes   | Contain   |  |  |  |  |
| QMI_ERR_NONE  | No error in the request   |  |  |  |  |
| QMI_ERR_INTERNAL  | Unexpected error occurred during processing                     |  |  |  |  |
| QMI_ERR_MALFORMED_MSG   | Message was not formulated correctly by the control point       |  |  |  |  |
| an'i  | or the message was corrupted during transmission                |  |  |  |  |
| QMI_ERR_MISSING_ARG   | Some TLV was missing  |  |  |  |  |
| QMI_ERR_INVALID_HANDLE  | Mobile AP handle provided in the request is not valid, i.e., it |  |  |  |  |
| 20100   | is not assigned to the control point                            |  |  |  |  |
| QMI_ERR_INVALID_ARG   | Argument is not correct   |  |  |  |  |
| QMI_ERR_NOT_SUPPORTED   | Operation is not supported                                      |  |  |  |  |
| QMI_ERR_NO_ENTRY  | Entry was not found   |  |  |  |  |

#### Description of QMI\_QCMAP\_DELETE\_STATIC\_NAT\_ENTRY 3.17.3 **REQ/RESP**

This command deletes a static NAT entry.

#### QMI\_QCMAP\_GET\_STATIC\_NAT\_ENTRIES 3.18

Queries all static NAT entries.

**QCMAP** message ID

0x002F

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_STATIC\_NAT\_ENTRIES\_REQ 3.18.1

## **Mandatory TLVs**

| Message type     |      |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    |                       |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# 3.18.2 Response - QMI\_QCMAP\_GET\_STATIC\_NAT\_ENTRIES\_RESP

## Message type

Response

#### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name               | Version introduced | Version last modified |
|--------------------|--------------------|-----------------------|
| SNAT Configuration | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter          | Size   | Description                     |
|--------|---------------|--------|--------------------|--------|---------------------------------|
|        | value         | type   |                    | (byte) | 7                               |
| Туре   | 0x10          |        |                    | 10     | SNAT Configuration              |
| Length | Var           |        |                    | 02     |                                 |
| Value  | $\rightarrow$ | uint8  | snat_config_len    | \L     | Number of sets of the following |
|        |               |        | MICE               | 5. 0   | elements:                       |
|        |               |        | 3 nfidential 08:15 | rey.   | • private_ip_addr               |
|        |               |        | 18/11/27 03        | 5      | • private_port                  |
|        |               |        | £1007.100          |        | • global_port                   |
|        |               |        | (01,57.0)          |        | • protocol                      |
|        |               | uint32 | private_ip_addr    | 4      | Private IP address.             |
|        |               | uint16 | private_port       | 2      | Private port.                   |
|        |               | uint16 | global_port        | 2      | Global port.                    |
|        |               | uint8  | protocol           | 1      | Protocol.                       |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.18.3 Description of QMI\_QCMAP\_GET\_STATIC\_NAT\_ENTRIES REQ/RESP

This command queries all static NAT entries. The response message contains the number of entries followed by the value of these entries sequentially.



#### 3.19 QMI\_QCMAP\_SET\_DMZ

Sets the DMZ (perimeter network) IP address for the mobile AP.

## **QCMAP** message ID

0x0030

#### **Version introduced**

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_SET\_DMZ\_REQ 3.19.1

## **Mandatory TLVs**

| 3.13.1 neques    | ot - Wivii_QCIVIAP_3 |                    |                       |
|------------------|----------------------|--------------------|-----------------------|
| Message type     |                      | 1.                 |                       |
| Request          |                      |                    | 9                     |
| Sender           |                      | Secre              |                       |
| Control point    |                      | CO Trade           |                       |
| Mandatory TLVs   |                      | Contain            |                       |
|                  | Name                 | Version introduced | Version last modified |
| Mobile AP Handle |                      | 0. 1.0             | 1.0                   |
| DMZ IP Address   | الهازر               | 8. 1.0             | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 0202             | (byte) |   |
| Туре   | 0x01          |        | : 250.           | 1      | Mobile AP Handle                        |
| Length | 4             |        | 3                | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | DMZ IP Address                          |
| Length | 4             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | dmz_ip_addr      | 4      | DMZ IP address.                         |

#### **Optional TLVs**

## Response - QMI\_QCMAP\_SET\_DMZ\_RESP

Message type

Response

Sender

Service

**Mandatory TLVs** 

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

**Optional TLVs** 

## **Error codes**

| Optional TEVS          |   |
|------------------------|---|
| None                   | ats   |
| Error codes            | Secre   |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### 3.19.3 Description of QMI\_QCMAP\_SET\_DMZ REQ/RESP

This command sets the DMZ IP address for the mobile AP.

#### 3.20 QMI\_QCMAP\_GET\_DMZ

Queries the DMZ IP address on the mobile AP.

**QCMAP** message ID

0x0032

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_DMZ\_REQ 3.20.1

## **Mandatory TLVs**

| 3.20.1 Reques    | t - QIVII_QCIV | IAP_GEI_DWZ_REQ    |                       |
|------------------|----------------|--------------------|-----------------------|
| Message type     |                |                    |                       |
| Request          |                |                    | 5                     |
| Sender           |                | Secre              |                       |
| Control point    |                | Trade              |                       |
| Mandatory TLVs   |                | ontain on the same |                       |
|                  | Name           | Version introduced | Version last modified |
| Mobile AP Handle |                | 8. 0 1.0           | 1.0                   |
|                  |                | 0.7 0.7            |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

## 3.20.2 Response - QMI QCMAP GET DMZ RESP

## Message type

Response

#### Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name           | Version introduced | Version last modified |
|----------------|--------------------|-----------------------|
| DMZ IP Address | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter   |     | Size   | Description     |
|--------|---------------|--------|-------------|-----|--------|-----------------|
|        | value         | type   |             |     | (byte) | 7               |
| Туре   | 0x10          |        |             |     | 10     | DMZ IP Address  |
| Length | 4             |        |             |     | 02     |                 |
| Value  | $\rightarrow$ | uint32 | dmz_ip_addr | Kan | 4      | DMZ IP address. |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
| 10                     | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.20.3 Description of QMI\_QCMAP\_GET\_DMZ REQ/RESP

This command queries the DMZ entry that was previously set via QMI\_QCMAP\_SET\_DMZ.

If no DMZ is set at the modem, an IP address of 0.0.0.0 is returned.

#### 3.21 QMI\_QCMAP\_DELETE\_DMZ

Deletes the DMZ entry or DMZ IP address.

**QCMAP** message ID

0x0031

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_DELETE\_DMZ\_REQ 3.21.1

## **Mandatory TLVs**

| Message type     | _    |                    |                       |
|------------------|------|--------------------|-----------------------|
| wessage type     |      |                    |                       |
| Request          |      |                    |                       |
| Sender           |      | Secre              |                       |
| Control point    |      | CO Trade           |                       |
| Mandatory TLVs   |      | ontain             |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |
|                  | ( ), | antial 08: askey   |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 0021-02-         | 1      | Mobile AP Handle                        |
| Length | 4             |        | 1.250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# Response - QMI\_QCMAP\_DELETE\_DMZ\_RESP

Message type

Response

Sender

Service

#### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

#### **Optional TLVs**

## **Error codes**

| Optional TEVS          |   |
|------------------------|---|
| None                   | X5  |
| Error codes            | Secree  |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### Description of QMI\_QCMAP\_DELETE\_DMZ REQ/RESP 3.21.3

This command deletes the DMZ entry that was previously set via QMI\_QCMAP\_SET\_DMZ.

#### QMI\_QCMAP\_GET\_WWAN\_CONFIG 3.22

Queries the WWAN IP configuration.

**QCMAP** message ID

0x0033

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_WWAN\_CONFIG\_REQ 3.22.1

## **Mandatory TLVs**

| 3.22.1 neques    | t - Qivii_QCiviA | IP_GET_WWAN_CONFIG_F | 1EQ                   |
|------------------|------------------|----------------------|-----------------------|
| Message type     |                  | 1                    |                       |
| Request          |                  |                      | 5                     |
| Sender           |                  | Secre                |                       |
| Control point    |                  | Trade                |                       |
| Mandatory TLVs   |                  | Contain              |                       |
|                  | Name             | Version introduced   | Version last modified |
| Mobile AP Handle |                  | 1.0                  | 1.0                   |
| Address Type     |                  | 1.0                  | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 002              | (byte) |   |
| Туре   | 0x01          |        | 250              | 1      | Mobile AP Handle                        |
| Length | 4             |        | 70               | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | Address Type                            |
| Length | 8             |        |                  | 2      |   |
| Value  | $\rightarrow$ | mask   | addr_type_op     | 8      | WWAN configuration mask values:         |
|        |               |        |                  |        | • 1 – IPv4 address                      |
|        |               |        |                  |        | • 2 – IPv6 address                      |
|        |               |        |                  |        | • 4 – IPv4 DNS address                  |
|        |               |        |                  |        | • 8 – IPv6 DNS address                  |

## **Optional TLVs**

None

# 3.22.2 Response - QMI\_QCMAP\_GET\_WWAN\_CONFIG\_RESP

## Message type

Response

#### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name                       | Version introduced | Version last modified |
|----------------------------|--------------------|-----------------------|
| IPv4 Address               | 1.0                | 1.0                   |
| IPv6 Address               | 1.0                | 1.0                   |
| IPv4 Primary DNS Address   | 1.0                | 1.0                   |
| IPv4 Secondary DNS Address | 1.0                | 1.0                   |
| IPv6 Primary DNS Address   | 1.0                | 1.0                   |
| IPv6 Secondary DNS Address | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                 |
|--------|---------------|--------|------------------|--------|-----------------------------|
|        | value         | type   | 30,000           | (byte) |                             |
| Туре   | 0x10          |        | . (0.5)          | 1      | IPv4 Address                |
| Length | 4             |        | )                | 2      |                             |
| Value  | $\rightarrow$ | uint32 | v4_addr          | 4      | IPv4 address.               |
| Туре   | 0x11          |        |                  | 1      | IPv6 Address                |
| Length | 16            |        |                  | 2      |                             |
| Value  | $\rightarrow$ | uint8  | v6_addr          | 16     | IPv6 address.               |
| Туре   | 0x12          |        |                  | 1      | IPv4 Primary DNS Address    |
| Length | 4             |        |                  | 2      |                             |
| Value  | $\rightarrow$ | uint32 | v4_prim_dns_addr | 4      | IPv4 primary DNS address.   |
| Туре   | 0x13          |        |                  | 1      | IPv4 Secondary DNS Address  |
| Length | 4             |        |                  | 2      |                             |
| Value  | $\rightarrow$ | uint32 | v4_sec_dns_addr  | 4      | IPv4 secondary DNS address. |
| Туре   | 0x14          |        |                  | 1      | IPv6 Primary DNS Address    |
| Length | 16            |        |                  | 2      |                             |
| Value  | $\rightarrow$ | uint8  | v6_prim_dns_addr | 16     | IPv6 primary DNS address.   |
| Туре   | 0x15          |        |                  | 1      | IPv6 Secondary DNS Address  |
| Length | 16            |        |                  | 2      |                             |
| Value  | $\rightarrow$ | uint8  | v6_sec_dns_addr  | 16     | IPv6 secondary DNS address. |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## 3.22.3 Description of QMI\_QCMAP\_GET\_WWAN\_CONFIG REQ/RESP

This command queries the WWAN IP configuration for the mobile AP. The command must be issued by the control point after QCMAP\_WWAN\_STATUS\_IND has indicated a successful WWAN bringup, otherwise a QMI\_ERR\_INTERNAL error is returned.

#### QMI\_QCMAP\_ENABLE\_FIREWALL\_SETTING 3.23

Enables the firewall setting.

**QCMAP** message ID

0x0034

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_ENABLE\_FIREWALL\_SETTING\_REQ 3.23.1

## **Mandatory TLVs**

| Message type     |      |        |                    |                       |
|------------------|------|--------|--------------------|-----------------------|
| Request          |      |        |                    | 5                     |
| Sender           |      |        | Secre              |                       |
| Control point    |      | 10     | O, Liage           |                       |
| Mandatory TLVs   |      |        | ontain             |                       |
|                  | Name |        | Version introduced | Version last modified |
| Mobile AP Handle |      | la la  | 8. (2.1.0          | 1.0                   |
| Packets Allowed  |      | : 3 38 | 1.0                | 1.0                   |

| Field  | Field         | Field   | Parameter        | Size   | Description                             |
|--------|---------------|---------|------------------|--------|---|
|        | value         | type    | 002-02-          | (byte) |   |
| Туре   | 0x01          |         | . 250            | 1      | Mobile AP Handle                        |
| Length | 4             |         | 7                | 2      |   |
| Value  | $\rightarrow$ | uint32  | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |         |                  |        | instance.                               |
|        |               |         |                  |        | The value must be the handle previously |
|        |               |         |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |         |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |         |                  | 1      | Packets Allowed                         |
| Length | 1             |         |                  | 2      |   |
| Value  | $\rightarrow$ | boolean | pkts_allowed     | 1      | Packets allowed operation. Values:      |
|        |               |         |                  |        | • TRUE – Packets matching the firewall  |
|        |               |         |                  |        | rule are allowed                        |
|        |               |         |                  |        | • FALSE – Packets matching the firewall |
|        |               |         |                  |        | rule are dropped                        |

## **Optional TLVs**

None

#### 3.23.2 Response - QMI\_QCMAP\_ENABLE\_FIREWALL\_SETTING\_RESP

#### Message type

Response

#### Sender

Service

## **Mandatory TLVs**

#### **Optional TLVs**

#### **Error codes**

| The Result Code TLV (defined in Section 2. | 3.1) is always present in the response.                         |
|--|---|
| Optional TLVs                              | Secret  |
| None                                       | Trade   |
| Error codes                                | Ontain  |
| QMI_ERR_NONE                               | No error in the request   |
| QMI_ERR_INTERNAL                           | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG                      | Message was not formulated correctly by the control point       |
| S chi                                      | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG                        | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE                     | Mobile AP handle provided in the request is not valid, i.e., it |
| 20200                                      | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG                        | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED                      | Operation is not supported                                      |

#### Description of QMI\_QCMAP\_ENABLE\_FIREWALL\_SETTING 3.23.3 **REQ/RESP**

This command enables the firewall and sets the condition whether the packets matching the firewall rule are to be allowed or dropped.

#### QMI\_QCMAP\_GET\_FIREWALL\_SETTING 3.24

Queries the firewall setting.

**QCMAP** message ID

0x0035

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_FIREWALL\_SETTING\_REQ 3.24.1

## **Mandatory TLVs**

| Message type     |      | 1                  |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    | 5                     |
| Sender           |      | Secre              |                       |
| Control point    |      | (O) Trade          |                       |
| Mandatory TLVs   |      | Contain            |                       |
| N                | lame | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

# 3.24.2 Response - QMI\_QCMAP\_GET\_FIREWALL\_SETTING\_RESP

## Message type

Response

#### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name             | Version introduced | Version last modified |
|------------------|--------------------|-----------------------|
| Firewall Enabled | 1.0                | 1.0                   |
| Packets Allowed  | 1.0                | 1.0                   |

| Packets Allowed |               |         |                  | 1.0    | 1.0              |                           |
|-----------------|---------------|---------|------------------|--------|------------------|---------------------------|
|                 |               |         |                  |        | rade             |                           |
| Field           | Field         | Field   | Parameter        | Size   |                  | Description               |
|                 | value         | type    |                  | (byte) | <u> </u>         |                           |
| Туре            | 0x10          |         |                  | Olas   | Firewall Enable  | ed                        |
| Length          | 1             |         | Va.              | 2      | <u> </u>         |                           |
| Value           | $\rightarrow$ | boolean | firewall_enabled | 5 1 0  | Whether the fire | ewall is enabled; boolean |
|                 |               |         | 13 08.           | rey    | value.           |                           |
| Туре            | 0x11          |         | 180, 37 33       | 1      | Packets Allowe   | d                         |
| Length          | 1             |         | 110 11 200       | 2      |                  |                           |
| Value           | $\rightarrow$ | boolean | pkts_allowed     | 1      | Whether packet   | s are allowed; boolean    |
|                 |               |         | 20,000           |        | value.           |                           |

#### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## 3.24.3 Description of QMI\_QCMAP\_GET\_FIREWALL\_SETTING REQ/RESP

This command queries the firewall setting.



#### QMI\_QCMAP\_DISABLE\_FIREWALL\_SETTING 3.25

Disables the firewall setting.

**QCMAP** message ID

0x0036

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_DISABLE\_FIREWALL\_SETTING\_REQ 3.25.1

## **Mandatory TLVs**

| Message type     |      | 1                  |                       |  |  |  |
|------------------|------|--------------------|-----------------------|--|--|--|
| Request          |      |                    | 5                     |  |  |  |
| Sender           |      | Secre              |                       |  |  |  |
| Control point    |      | (O) Trade          |                       |  |  |  |
| Mandatory TLVs   |      |                    |                       |  |  |  |
| N                | lame | Version introduced | Version last modified |  |  |  |
| Mobile AP Handle |      | 1.0                | 1.0                   |  |  |  |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

## Response - QMI\_QCMAP\_DISABLE\_FIREWALL\_SETTING\_RESP

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

## **Error codes**

| None                   | 15  |
|------------------------|---|
| Error codes            | Secret  |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## Description of QMI\_QCMAP\_DISABLE\_FIREWALL\_SETTING 3.25.3 **REQ/RESP**

This command disables the firewall setting.

#### QMI\_QCMAP\_ADD\_FIREWALL\_CONFIG 3.26

Adds a firewall configuration rule.

**QCMAP** message ID

0x0037

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_ADD\_FIREWALL\_CONFIG\_REQ 3.26.1

## **Mandatory TLVs**

| 0.20.1 Ticquest - Qivii_c | KOMAI _ADD_I IIIEWALL_OOM | Id_IIEG               |
|---------------------------|---------------------------|-----------------------|
| Message type              |                           |                       |
| Request                   |                           | 9                     |
| Sender                    | Secre                     |                       |
| Control point             | Trade                     |                       |
| Mandatory TLVs            | Contain                   |                       |
| Name                      | Version introduced        | Version last modified |
| Mobile AP Handle          | 8. 1.0                    | 1.0                   |
| Firewall Configuration    | 1.0                       | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                                |
|--------|---------------|--------|------------------|--------|--|
|        | value         | type   | 002              | (byte) |  |
| Туре   | 0x01          |        | : 250.           | 1      | Mobile AP Handle                           |
| Length | 4             |        |                  | 2      |  |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call      |
|        |               |        |                  |        | instance.                                  |
|        |               |        |                  |        | The value must be the handle previously    |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_              |
|        |               |        |                  |        | AP_ENABLE_REQ.                             |
| Туре   | 0x02          |        |                  | 1      | Firewall Configuration                     |
| Length | 5             |        |                  | 2      |  |
| Value  | $\rightarrow$ | uint16 | start_dest_port  | 2      | Start value of the destination port range. |
|        |               | uint16 | end_dest_port    | 2      | End value of the destination port range.   |
|        |               | uint8  | protocol         | 1      | Protocol value.                            |

## **Optional TLVs**

None

## 3.26.2 Response - QMI\_QCMAP\_ADD\_FIREWALL\_CONFIG\_RESP

## Message type

Response

### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name            | Version introduced | Version last modified |
|-----------------|--------------------|-----------------------|
| Firewall Handle | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter       | Size   | Description                           |
|--------|---------------|--------|-----------------|--------|---------------------------------------|
|        | value         | type   | MICH            | (byte) | P*                                    |
| Туре   | 0x10          |        | Ja 08:          | ver.   | Firewall Handle                       |
| Length | 4             |        | 1800 27 00      | 2      |                                       |
| Value  | $\rightarrow$ | uint32 | firewall_handle | 4      | Handle identifying the firewall rule. |

### **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |
| QMI_ERR_NO_MEMORY      | Maximum number of supported firewall rules was exceeded;        |
|                        | cannot add any more firewall rules                              |

## 3.26.3 Description of QMI\_QCMAP\_ADD\_FIREWALL\_CONFIG REQ/RESP

This command adds a firewall configuration rule.



#### QMI\_QCMAP\_DELETE\_FIREWALL\_CONFIG 3.27

Deletes a firewall configuration rule.

**QCMAP** message ID

0x0039

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_DELETE\_FIREWALL\_CONFIG\_REQ 3.27.1

Message type

## **Mandatory TLVs**

| Message type     |      |  |                       |
|------------------|------|--|-----------------------|
| Request          |      | a de la companya de l | 9                     |
| Sender           |      | Secre  |                       |
| Control point    |      | CO Trade   |                       |
| Mandatory TLVs   |      | ontain   |                       |
|                  | Name | Version introduced   | Version last modified |
| Mobile AP Handle |      | 1.0  | 1.0                   |
| Firewall Handle  |      | 1.0  | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 002-02-          | (byte) |   |
| Туре   | 0x01          |        | . 250            | 1      | Mobile AP Handle                        |
| Length | 4             |        | 7                | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | Firewall Handle                         |
| Length | 4             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | firewall_handle  | 4      | Handle identifying the firewall entry.  |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_ADD_              |
|        |               |        |                  |        | FIREWALL_CONFIG_RESP or                 |
|        |               |        |                  |        | QMI_QCMAP_GET_FIREWALL_                 |
|        |               |        |                  |        | CONFIG_RESP.                            |

## **Optional TLVs**

None

#### 3.27.2 Response - QMI\_QCMAP\_DELETE\_FIREWALL\_CONFIG\_RESP

### Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

### **Error codes**

| The Result Code TLV (defined in Section 2. | 3.1) is always present in the response.                         |
|--|---|
| Optional TLVs                              | Secret  |
| None                                       | CO Trade  |
| Error codes                                | Contain   |
| QMI_ERR_NONE                               | No error in the request   |
| QMI_ERR_INTERNAL                           | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG                      | Message was not formulated correctly by the control point       |
| S CH                                       | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG                        | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE                     | Mobile AP handle provided in the request is not valid, i.e., it |
| 2022                                       | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG                        | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED                      | Operation is not supported                                      |

### Description of QMI\_QCMAP\_DELETE\_FIREWALL\_CONFIG 3.27.3 **REQ/RESP**

This command deletes a firewall rule.

#### QMI\_QCMAP\_GET\_FIREWALL\_CONFIG 3.28

Queries the firewall configuration rules.

**QCMAP** message ID

0x0038

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_FIREWALL\_CONFIG\_REQ 3.28.1

## **Mandatory TLVs**

| 3.20.1 Request - QIVII_QCI | WAP_GET_FIREWALL_CONF | IG_NEW                |
|----------------------------|-----------------------|-----------------------|
| Message type               |                       |                       |
| Request                    |                       | 9                     |
| Sender                     | Secre                 |                       |
| Control point              | Trade                 |                       |
| Mandatory TLVs             | Contain               |                       |
| Name                       | Version introduced    | Version last modified |
| Mobile AP Handle           | 8. 0 1.0              | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02           | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

None

## 3.28.2 Response - QMI\_QCMAP\_GET\_FIREWALL\_CONFIG\_RESP

| Messag | e tvpe |
|--------|--------|
|        |        |

Response

### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## Optional TLVs

| Name                   | Version introduced | Version last modified |
|------------------------|--------------------|-----------------------|
| Firewall Configuration | 1.0                | 1.0                   |

| Field  | Field         | Field  | Parameter           | Size   | Description                                |
|--------|---------------|--------|---------------------|--------|--|
|        | value         | type   |                     | (byte) |  |
| Туре   | 0x10          |        |                     | 10     | Firewall Configuration                     |
| Length | Var           |        |                     | 02     |  |
| Value  | $\rightarrow$ | uint8  | firewall_config_len | \A     | Number of sets of the following            |
|        |               |        | MICE                | 5      | elements:                                  |
|        |               |        | 10 8:1 (6)          |        | firewall_handle                            |
|        |               |        | 18/1/22 03          | 5      | • start_dest_port                          |
|        |               |        | FIDE 7. 100         |        | • end_dest_port                            |
|        |               |        | (0), 2.0, 0,0       |        | • protocol                                 |
|        |               | uint32 | firewall_handle     | 4      | Handle identifying the firewall rule.      |
|        |               | uint16 | start_dest_port     | 2      | Start value of the destination port range. |
|        |               | uint16 | end_dest_port       | 2      | End value of the destination port range.   |
|        |               | uint8  | protocol            | 1      | Protocol value.                            |

## **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## 3.28.3 Description of QMI QCMAP GET FIREWALL CONFIG REQ/RESP

This command queries all the firewall entries. The response message contains the number of entries followed by the value of these entries sequentially.



#### QMI\_QCMAP\_STATION\_MODE\_ENABLE 3.29

Enables Station (STA) mode functionality for a mobile AP instance on the modem.

**QCMAP** message ID

0x003B

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_STATION\_MODE\_ENABLE\_REQ 3.29.1

## **Mandatory TLVs**

| 3.29.1 Request - Qivii_QCi | WAP_STATION_WODE_ENAB | LE_NEW                |
|----------------------------|-----------------------|-----------------------|
| Message type               |                       |                       |
| Request                    |                       | 9                     |
| Sender                     | Secre                 |                       |
| Control point              | Trade                 |                       |
| Mandatory TLVs             | Contain               |                       |
| Name                       | Version introduced    | Version last modified |
| Mobile AP Handle           | 0.0                   | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | : 350            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

None

#### Response - QMI QCMAP STATION MODE ENABLE RESP 3.29.2

Message type

Response

Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### **Optional TLVs**

### **Error codes**

| None                   | x5  |
|------------------------|---|
| Error codes            | Secree  |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### Description of QMI QCMAP STATION MODE ENABLE REQ/RESP 3.29.3

This command enables STA mode functionality at the modem for a single mobile AP instance.

After this request is successfully processed, all packet connectivity to an outside network occurs through the WLAN station. The modem routing engine appropriately handles the packet routing into and out of the modem.

### QMI\_QCMAP\_STATION\_MODE\_DISABLE 3.30

Disables STA mode functionality for a mobile AP instance on the modem.

**QCMAP** message ID

0x003C

Version introduced

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_STATION\_MODE\_DISABLE\_REQ 3.30.1

## **Mandatory TLVs**

| Message type     |      |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    | 5                     |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP Handle |      | 1.0                | 1.0                   |
|                  |      | ntial 08: 35Key    |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

None

#### Response - QMI QCMAP STATION MODE DISABLE RESP 3.30.2

Message type

Response

Sender

Service

### **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

### **Optional TLVs**

### **Error codes**

| None                   | 15  |
|------------------------|---|
| Error codes            | Secret  |
| QMI_ERR_NONE           | No error in the request   |
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

### Description of QMI\_QCMAP\_STATION\_MODE\_DISABLE 3.30.3 **REQ/RESP**

This command disables STA mode functionality at the modem for a single mobile AP instance. When this request has been successfully processed, the control point invokes bringing up the WWAN from the mobile AP.

#### QMI\_QCMAP\_GET\_STATION\_MODE 3.31

Queries the STA mode functionality for a mobile AP instance on the modem.

**QCMAP** message ID

0x003D

**Version introduced** 

Major - 1, Minor - 0

#### Request - QMI\_QCMAP\_GET\_STATION\_MODE\_REQ 3.31.1

## **Mandatory TLVs**

| Message type     |     | 1.                 |                       |
|------------------|-----|--------------------|-----------------------|
| Request          |     |                    |                       |
| Sender           |     | Secre              |                       |
| Control point    |     | CO Trade           |                       |
| Mandatory TLVs   |     | Contain            |                       |
| N                | ame | Version introduced | Version last modified |
| Mobile AP Handle |     | 8. 0 1.0           | 1.0                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 0, 00,      | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP Handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

None

## Response - QMI QCMAP GET STATION MODE RESP

## Message type

Response

### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name         | Version introduced | Version last modified |
|--------------|--------------------|-----------------------|
| Station Mode | 1.0                | 1.0                   |

| Field                             | Field         | Field   | Parameter    | Size          | Description                        |
|-----------------------------------|---------------|---------|--------------|---------------|------------------------------------|
|                                   | value         | type    |              | (byte)        |                                    |
| Туре                              | 0x10          |         |              | 10            | Station Mode                       |
| Length                            | 1             |         |              | 02            |                                    |
| Value                             | $\rightarrow$ | boolean | station_mode | Da Ke         | Whether STA mode has been enabled; |
|                                   |               |         | , ku         | 78. CC        | boolean value.                     |
| Error codes Confidential 08. 25ke |               |         |              |               |                                    |
| OMI I                             | DD NI         | ANTE    | U 2 A NV     | an in tha nac |                                    |

## **Error codes**

| QMI_ERR_NONE           | No error in the request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### 3.31.3 Description of QMI QCMAP GET STATION MODE REQ/RESP

This command queries the STA mode functionality at the modem for a single mobile AP instance.

## QMI QCMAP ADD EXTD FIREWALL CONFIG

Adds IP filter-based firewall rules (extended firewall).

**QCMAP** message ID

0x003F

**Version introduced** 

Major - 1, Minor - 1

#### Request - QMI\_QCMAP\_ADD\_EXTD\_FIREWALL\_CONFIG\_REQ 3.32.1

## **Mandatory TLVs**

| Message type         | 1                  |                       |
|----------------------|--------------------|-----------------------|
| Request              |                    | 9                     |
| Sender               | Secre              |                       |
| Control point        | O Trade            |                       |
| Mandatory TLVs       | Contain            |                       |
| Name                 | Version introduced | Version last modified |
| Mobile AP Handle     | 8. C 1.1           | 1.1                   |
| Next Header Protocol | 1.1                | 1.1                   |

| Field  | Field         | Field  | Parameter        | Size   | Description  |
|--------|---------------|--------|------------------|--------|--|
|        | value         | type   | 002-02           | (byte) |  |
| Туре   | 0x01          |        | . 250            | 1      | Mobile AP Handle   |
| Length | 4             |        | 3                | 2      |  |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call instance.  The value must be the handle previously returned by QMI_QCMAP_MOBILE_AP_ENABLE_REQ. |
| Туре   | 0x02          |        |                  | 1      | Next Header Protocol   |
| Length | 4             |        |                  | 2      |  |

| Field | Field         | Field | Parameter     | Size   | Description                              |
|-------|---------------|-------|---------------|--------|--|
|       | value         | type  |               | (byte) |  |
| Value | $\rightarrow$ | enum  | next_hdr_prot | 4      | IPv4/IPv6 next header protocol after the |
|       |               |       |               |        | IP header. Values:                       |
|       |               |       |               |        | • 0x01 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_TCP – Transmission Control         |
|       |               |       |               |        | Protocol                                 |
|       |               |       |               |        | • 0x02 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_UDP – User Datagram Protocol       |
|       |               |       |               |        | • 0x03 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_ICMP – Internet Control            |
|       |               |       |               |        | Message Protocol                         |
|       |               |       |               |        | • 0x04 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_ICMP6 – Internet Control           |
|       |               |       |               |        | Message Protocol version 6               |
|       |               |       |               |        | • 0x05 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_ESP – Encapsulating Security       |
|       |               |       |               |        | Payload Protocol                         |
|       |               |       |               |        | • 0x06 – QCMAP_EXTD_FIREWALL_            |
|       |               |       |               |        | PROTO_TCP_UDP – Transmission             |
|       |               |       |               |        | Control Protocol/User Datagram           |
|       |               |       |               | Yal'   | Protocol                                 |

## **Optional TLVs**

|                               | Protocol           |                       |  |  |  |  |  |
|-------------------------------|--------------------|-----------------------|--|--|--|--|--|
| Optional TLVs                 |                    |                       |  |  |  |  |  |
| Name                          | Version introduced | Version last modified |  |  |  |  |  |
| TCP/UDP Source                | 1.1                | 1.1                   |  |  |  |  |  |
| TCP/UDP Destination           | 1.1                | 1.1                   |  |  |  |  |  |
| ICMP Type                     | 1.1                | 1.1                   |  |  |  |  |  |
| ICMP Code                     | 1.1                | 1.1                   |  |  |  |  |  |
| ESP Security Parameters Index | 1.1                | 1.1                   |  |  |  |  |  |
| IPv4 Source Address           | 1.1                | 1.1                   |  |  |  |  |  |
| IPv4 Destination Address      | 1.1                | 1.1                   |  |  |  |  |  |
| IPv4 TOS                      | 1.1                | 1.1                   |  |  |  |  |  |
| IPv6 Source Address           | 1.1                | 1.1                   |  |  |  |  |  |
| IPv6 Destination Address      | 1.1                | 1.1                   |  |  |  |  |  |
| IPv6 Traffic Class            | 1.1                | 1.1                   |  |  |  |  |  |

| Field  | Field         | Field  | Parameter | Size   | Description                            |
|--------|---------------|--------|-----------|--------|--|
|        | value         | type   |           | (byte) |  |
| Туре   | 0x10          |        |           | 1      | TCP/UDP Source                         |
| Length | 4             |        |           | 2      |  |
| Value  | $\rightarrow$ | uint16 | port      | 2      | TCP/UDP port as specified in the       |
|        |               |        |           |        | TCP/UDP protocol (RFC 793 [S4] and     |
|        |               |        |           |        | RFC 768 [S1]).                         |
|        |               | uint16 | range     | 2      | TCP/UDP port range as specified in the |
|        |               |        |           |        | TCP/UDP protocol (RFC 793 [S4] and     |
|        |               |        |           |        | RFC 768 [S1]).                         |

| Field  | Field         | Field  | Parameter   | Size   | Description                               |
|--------|---------------|--------|-------------|--------|---|
|        | value         | type   |             | (byte) |   |
| Туре   | 0x11          |        |             | 1      | TCP/UDP Destination                       |
| Length | 4             |        |             | 2      |   |
| Value  | $\rightarrow$ | uint16 | port        | 2      | TCP/UDP port as specified in the          |
|        |               |        |             |        | TCP/UDP protocol (RFC 793 [S4] and        |
|        |               |        |             |        | RFC 768 [S1]).                            |
|        |               | uint16 | range       | 2      | TCP/UDP port range as specified in the    |
|        |               |        |             |        | TCP/UDP protocol (RFC 793 [S4] and        |
|        |               |        |             |        | RFC 768 [S1]).                            |
| Туре   | 0x12          |        |             | 1      | ICMP Type                                 |
| Length | 1             |        |             | 2      |   |
| Value  | $\rightarrow$ | uint8  | icmp_type   | 1      | ICMP type as specified in the ICMP        |
|        |               |        |             |        | specification (RFC 792 [S3]).             |
| Туре   | 0x13          |        |             | 1      | ICMP Code                                 |
| Length | 1             |        |             | 2      |   |
| Value  | $\rightarrow$ | uint8  | icmp_code   | 1      | ICMP code as specified in the ICMP        |
|        |               |        |             |        | specification (RFC 792 [S3]).             |
| Туре   | 0x14          |        |             | 1      | ESP Security Parameters Index             |
| Length | 4             |        |             | 2      | 1400                                      |
| Value  | $\rightarrow$ | uint32 | esp_spi     | 4      | Security parameters index as specified in |
|        |               |        |             | (Kal)  | the ESP protocol (RFC 4303 [S7]).         |
| Туре   | 0x15          |        |             | 010    | IPv4 Source Address                       |
| Length | 8             |        | Ve .        | 2      | CC CC                                     |
| Value  | $\rightarrow$ | uint32 | addr        | 4 0    | IPv4 address as specified in the IPv4     |
|        |               |        | ::31 08:2   | rey.   | protocol specification (RFC 791 [S2]).    |
|        |               | uint32 | subnet_mask | 4      | IPv4 subnet mask as specified in the IPv4 |
|        |               |        | 110 1.10 O  |        | protocol specification (RFC 791 [S2]).    |
| Туре   | 0x16          |        | (0) 22 , 95 | 1      | IPv4 Destination Address                  |
| Length | 8             |        | 30, 30,     | 2      |   |
| Value  | $\rightarrow$ | uint32 | addr        | 4      | IPv4 address as specified in the IPv4     |
|        |               |        |             |        | protocol specification (RFC 791 [S2]).    |
|        |               | uint32 | subnet_mask | 4      | IPv4 subnet mask as specified in the IPv4 |
|        |               |        |             |        | protocol specification (RFC 791 [S2]).    |
| Туре   | 0x17          |        |             | 1      | IPv4 TOS                                  |
| Length | 2             |        |             | 2      |   |
| Value  | $\rightarrow$ | uint8  | value       | 1      | TOS value as specified in the IPv4        |
|        |               |        |             |        | protocol specification (RFC 791 [S2]).    |
|        |               | uint8  | mask        | 1      | IPv4 TOS mask.                            |
| Туре   | 0x18          |        |             | 1      | IPv6 Source Address                       |
| Length | 17            |        |             | 2      |   |
| Value  | $\rightarrow$ | uint8  | addr        | 16     | IPv6 address as specified in the IPv6     |
|        |               |        |             |        | protocol specification (RFC 2460 [S5]).   |
|        |               | uint8  | prefix_len  | 1      | IPv6 prefix length as specified in the    |
|        |               |        |             |        | IPv6 protocol addressing architecture     |
|        |               |        |             |        | specification (RFC 3513 [S6]).            |
| Туре   | 0x19          |        |             | 1      | IPv6 Destination Address                  |
| Length | 17            |        |             | 2      |   |

| Field  | Field         | Field | Parameter  | Size   | Description                                  |
|--------|---------------|-------|------------|--------|--|
|        | value         | type  |            | (byte) |  |
| Value  | $\rightarrow$ | uint8 | addr       | 16     | IPv6 address as specified in the IPv6        |
|        |               |       |            |        | protocol specification (RFC 2460 [S5]).      |
|        |               | uint8 | prefix_len | 1      | IPv6 prefix length as specified in the       |
|        |               |       |            |        | IPv6 protocol addressing architecture        |
|        |               |       |            |        | specification (RFC 3513 [S6]).               |
| Туре   | 0x1A          |       |            | 1      | IPv6 Traffic Class                           |
| Length | 2             |       |            | 2      |  |
| Value  | $\rightarrow$ | uint8 | value      | 1      | IPv6 traffic class value as specified in the |
|        |               |       |            |        | IPv6 protocol specification (RFC 2460        |
|        |               |       |            |        | [S5]).                                       |
|        |               | uint8 | mask       | 1      | IPv6 traffic class mask.                     |

## 3.32.2 Response - QMI\_QCMAP\_ADD\_EXTD\_FIREWALL\_CONFIG\_RESP

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name            | Version introduced | Version last modified |
|-----------------|--------------------|-----------------------|
| Firewall handle | 1.1                | 1.1                   |

| Field  | Field         | Field  | Parameter       | Size   | Description                           |
|--------|---------------|--------|-----------------|--------|---------------------------------------|
|        | value         | type   |                 | (byte) |                                       |
| Туре   | 0x10          |        |                 | 1      | Firewall handle                       |
| Length | 4             |        |                 | 2      |                                       |
| Value  | $\rightarrow$ | uint32 | firewall_handle | 4      | Handle identifying the added firewall |
|        |               |        |                 |        | rule.                                 |

## **Error codes**

| QMI_ERR_NONE          | No error in request                                       |
|-----------------------|---|
| QMI_ERR_INTERNAL      | Unexpected error occurred during processing               |
| QMI_ERR_MALFORMED_MSG | Message was not formulated correctly by the control point |
|                       | or the message was corrupted during transmission          |
| QMI_ERR_MISSING_ARG   | Some TLV was missing                                      |

| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|------------------------|---|
|                        | is not assigned to the control point                            |
| QMI_ERR_INVALID_ARG    | Argument is not correct   |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |
| QMI_ERR_NO_MEMORY      | Maximum number of supported firewall rules was exceeded;        |
|                        | cannot add any more firewall rules                              |

# 3.32.3 Description of QMI\_QCMAP\_ADD\_EXTD\_FIREWALL\_CONFIG REQ/RESP

This command adds a single IP filter-based firewall rule. The control point must specify the source/destination port and range when the value of the Next Header Protocol TLV is TCP/UDP. Otherwise, a QMI\_ERR\_MISSING\_ARG error is returned.

#### QMI\_QCMAP\_GET\_EXTD\_FIREWALL\_CONFIG 3.33

Gets the firewall rules.

**QCMAP** message ID

0x0040

**Version introduced** 

Major - 1, Minor - 1

#### Request - QMI\_QCMAP\_GET\_EXTD\_FIREWALL\_CONFIG\_REQ 3.33.1

## **Mandatory TLVs**

| Message type    |      |                    |                       |
|-----------------|------|--------------------|-----------------------|
| Request         |      |                    | 5                     |
| Sender          |      | Secre              |                       |
| Control point   |      | 1 O Trade          |                       |
| Mandatory TLVs  |      | Contain            |                       |
|                 | Name | Version introduced | Version last modified |
| Firewall Handle |      | 8. 0 1.1           | 1.1                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01, 5.0, 030    | (byte) |   |
| Туре   | 0x01          |        | 002-02-          | 1      | Mobile AP handle                        |
| Length | 4             |        | . 250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |
| Туре   | 0x02          |        |                  | 1      | Firewall Handle                         |
| Length | 4             |        |                  | 2      |   |
| Value  | $\rightarrow$ | uint32 | firewall_handle  | 4      | Handle identifying the firewall entry.  |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by one of the following:       |
|        |               |        |                  |        | • QMI_QCMAP_ADD_FIREWALL_               |
|        |               |        |                  |        | CONFIG_RESP                             |
|        |               |        |                  |        | • QMI_QCMAP_GET_FIREWALL_               |
|        |               |        |                  |        | CONFIG_RESP                             |
|        |               |        |                  |        | • QMI_QCMAP_ADD_EXTD_                   |
|        |               |        |                  |        | FIREWALL_CONFIG_RESP                    |
|        |               |        |                  |        | • QMI_QCMAP_GET_FIREWALL_               |
|        |               |        |                  |        | CONFIG_HANDLE_LIST_RESP                 |

## **Optional TLVs**

None

#### Response - QMI\_QCMAP\_GET\_EXTD\_FIREWALL\_CONFIG\_RESP 3.33.2

## Message type

Response

### Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

Optional TLVs

| Name                          | Version introduced | Version last modified |
|-------------------------------|--------------------|-----------------------|
| Next Header Protocol          | 1.1                | 1.1                   |
| TCP/UDP Source                | 1.1                | 1.1                   |
| TCP/UDP Destination           | C (5 1.1           | 1.1                   |
| ICMP Type                     | 1. A C (1.1        | 1.1                   |
| ICMP Code                     | 9. 1.1             | 1.1                   |
| ESP Security Parameters Index | 1.1                | 1.1                   |
| IPv4 Source Address           | 1.1                | 1.1                   |
| IPv4 Destination Address      | 1.1                | 1.1                   |
| IPv4 TOS                      | 1.1                | 1.1                   |
| IPv6 Source Address           | 1.1                | 1.1                   |
| IPv6 Destination Address      | 1.1                | 1.1                   |
| IPv6 Traffic Class            | 1.1                | 1.1                   |

| Field  | Field | Field | Parameter | Size   | Description          |
|--------|-------|-------|-----------|--------|----------------------|
|        | value | type  |           | (byte) |                      |
| Туре   | 0x10  |       |           | 1      | Next Header Protocol |
| Length | 4     |       |           | 2      |                      |

| Field  | Field         | Field  | Parameter     | Size   | Description  |
|--------|---------------|--------|---------------|--------|--|
|        | value         | type   |               | (byte) | 2000.  |
| Value  | $\rightarrow$ | enum   | next_hdr_prot | 4      | IPv4/IPv6 next header protocol after the                         |
| value  | ′             | Cham   | next_nar_prot | '      | IP header. Values:   |
|        |               |        |               |        | • 0x01 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO_TCP – Transmission Control                                 |
|        |               |        |               |        | Protocol   |
|        |               |        |               |        | • 0x02 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO_UDP – User Datagram Protocol                               |
|        |               |        |               |        | • 0x03 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO_ICMP – Internet Control                                    |
|        |               |        |               |        | Message Protocol   |
|        |               |        |               |        | • 0x04 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO_ICMP6 – Internet Control                                   |
|        |               |        |               |        | Message Protocol for IPv6  |
|        |               |        |               |        | • 0x05 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO_ESP – Encapsulating Security                               |
|        |               |        |               |        | Payload Protocol   |
|        |               |        |               |        | • 0x06 – QCMAP_EXTD_FIREWALL_                                    |
|        |               |        |               |        | PROTO TCP UDP – Transmission                                     |
|        |               |        |               |        | Control Protocol/User Datagram                                   |
|        |               |        |               | V is   | Protocol   |
| Туре   | 0x11          |        |               |        | TCP/UDP Source   |
| Length | 4             |        |               | 2      | Terrebr source   |
| Value  | $\rightarrow$ | uint16 | port          | 2      | TCP/UDP port as specified in the                                 |
|        | <i>'</i>      |        |               | b. 4.0 | TCP/UDP protocol (RFC 793 [S4] and                               |
|        |               |        | 25/21/08:1    | Sto.   | RFC 768 [S1]).   |
|        |               | uint16 | range         | 2      | TCP/UDP port range as specified in the                           |
|        |               |        | CONT. 01 020  |        | TCP/UDP protocol (RFC 793 [S4] and                               |
|        |               |        | 0 2 2         |        | RFC 768 [S1]).   |
| Туре   | 0x12          |        | 7 50          | 1      | TCP/UDP Destination  |
| Length | 4             |        | 10            | 2      |  |
| Value  | $\rightarrow$ | uint16 | port          | 2      | TCP/UDP port as specified in the                                 |
|        |               |        |               |        | TCP/UDP protocol (RFC 793 [S4] and                               |
|        |               |        |               |        | RFC 768 [S1]).   |
|        |               | uint16 | range         | 2      | TCP/UDP port range as specified in the                           |
|        |               |        |               |        | TCP/UDP protocol (RFC 793 [S4] and                               |
|        |               |        |               |        | RFC 768 [S1]).   |
| Туре   | 0x13          |        |               | 1      | ICMP Type  |
| Length | 1             |        |               | 2      |  |
| Value  | $\rightarrow$ | uint8  | icmp_type     | 1      | ICMP type as specified in the ICMP                               |
|        |               |        |               |        | specification (RFC 792 [S3]).                                    |
| Туре   | 0x14          |        |               | 1      | ICMP Code  |
| Length | 1             |        |               | 2      |  |
| Value  | 1             |        |               |        |  |
|        | $\rightarrow$ | uint8  | icmp_code     | 1      | ICMP code as specified in the ICMP                               |
|        | _             | uint8  | icmp_code     | 1      | ICMP code as specified in the ICMP specification (RFC 792 [S3]). |
| Туре   | _             | uint8  | icmp_code     | 1      | _  |

| Field  | Field         | Field  | Parameter       | Size   | Description                                  |
|--------|---------------|--------|-----------------|--------|--|
|        | value         | type   |                 | (byte) |  |
| Value  | $\rightarrow$ | uint32 | esp_spi         | 4      | Security parameters index as specified in    |
|        |               |        |                 |        | the ESP protocol (RFC 4303 [S7]).            |
| Туре   | 0x16          |        |                 | 1      | IPv4 Source Address                          |
| Length | 8             |        |                 | 2      |  |
| Value  | $\rightarrow$ | uint32 | addr            | 4      | IPv4 address as specified in the IPv4        |
|        |               |        |                 |        | protocol specification (RFC 791 [S2]).       |
|        |               | uint32 | subnet_mask     | 4      | IPv4 subnet mask as specified in the IPv4    |
|        |               |        |                 |        | protocol specification (RFC 791 [S2]).       |
| Туре   | 0x17          |        |                 | 1      | IPv4 Destination Address                     |
| Length | 8             |        |                 | 2      |  |
| Value  | $\rightarrow$ | uint32 | addr            | 4      | IPv4 address as specified in the IPv4        |
|        |               |        |                 |        | protocol specification (RFC 791 [S2]).       |
|        |               | uint32 | subnet_mask     | 4      | IPv4 subnet mask as specified in the IPv4    |
|        |               |        |                 |        | protocol specification (RFC 791 [S2]).       |
| Туре   | 0x18          |        |                 | 1      | IPv4 TOS                                     |
| Length | 2             |        |                 | 2      | - ec   |
| Value  | $\rightarrow$ | uint8  | value           |        | TOS value as specified in the IPv4           |
|        |               |        |                 |        | protocol specification (RFC 791 [S2]).       |
|        |               | uint8  | mask            | 1.,    | IPv4 TOS mask.                               |
| Туре   | 0x19          |        |                 | 10     | IPv6 Source Address                          |
| Length | 17            |        |                 | 02     |  |
| Value  | $\rightarrow$ | uint8  | addr            | 16     | IPv6 address as specified in the IPv6        |
|        |               |        | Mode            | 5. C   | protocol specification (RFC 2460 [S5]).      |
|        |               | uint8  | prefix_len      | (el)   | IPv6 prefix length as specified in the       |
|        |               |        | 18/10/200       | 5      | IPv6 protocol addressing architecture        |
|        |               |        | 11007.100       |        | specification (RFC 3513 [S6]).               |
| Туре   | 0x1A          |        | addr prefix_len | 1      | IPv6 Destination Address                     |
| Length | 17            |        | 30, 30,         | 2      |  |
| Value  | $\rightarrow$ | uint8  | addr            | 16     | IPv6 address as specified in the IPv6        |
|        |               |        | )               |        | protocol specification (RFC 2460 [S5]).      |
|        |               | uint8  | prefix_len      | 1      | IPv6 prefix length as specified in the       |
|        |               |        |                 |        | IPv6 protocol addressing architecture        |
|        |               |        |                 |        | specification (RFC 3513 [S6]).               |
| Туре   | 0x1B          |        |                 | 1      | IPv6 Traffic Class                           |
| Length | 2             |        |                 | 2      |  |
| Value  | $\rightarrow$ | uint8  | value           | 1      | IPv6 traffic class value as specified in the |
|        |               |        |                 |        | IPv6 protocol specification (RFC 2460        |
|        |               |        |                 |        | [S5]).                                       |
|        |               | uint8  | mask            | 1      | IPv6 traffic class mask.                     |

### **Error codes**

| QMI_ERR_NONE           | No error in request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

# 3.33.3 Description of QMI\_QCMAP\_GET\_EXTD\_FIREWALL\_CONFIG REQ/RESP

This command gets a firewall rule associated with a single firewall handle.

#### QMI QCMAP GET FIREWALL CONFIG HANDLE LIST 3.34

Gets the handles of all the firewall rules.

**QCMAP** message ID

0x0041

**Version introduced** 

Major - 1, Minor - 1

## Request - QMI\_QCMAP\_GET\_FIREWALL\_CONFIG\_HANDLE\_-3.34.1 LIST REQ

## **Mandatory TLVs**

| LIST_REQ                | NFIG_HANDLE           |
|-------------------------|-----------------------|
| Message type            |                       |
| Request                 | , et s                |
| Sender                  |                       |
| Control point           |                       |
| Mandatory TLVs          |                       |
| Name Version introduced | Version last modified |
| Mobile AP handle 1.1    | 1.1                   |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | 30, 30,          | (byte) |   |
| Туре   | 0x01          |        | . 25             | 1      | Mobile AP handle                        |
| Length | 4             |        | ,                | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

**Optional TLVs** 

None

## 3.34.2 Response - QMI\_QCMAP\_GET\_FIREWALL\_CONFIG\_HANDLE\_-LIST\_RESP

Message type

Response

Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name                 | Version introduced | Version last modified |
|----------------------|--------------------|-----------------------|
| Firewall Handle List | 1.1 50             | 1.1                   |

| Field  | Field         | Field  | Parameter                | Size   | Description                     |
|--------|---------------|--------|--------------------------|--------|---------------------------------|
|        | value         | type   |                          | (byte) | K                               |
| Type   | 0x10          |        |                          |        | Firewall Handle List            |
| Length | Var           |        | May                      | . \2   | CC.                             |
| Value  | $\rightarrow$ | uint8  | firewall_handle_list_len | ). T'. | Number of sets of the following |
|        |               |        | tia, 08.                 | Ye,    | elements:                       |
|        |               |        | 16 57 60                 |        | firewall_handle_list            |
|        |               | uint32 | firewall_handle_list     | Var    | Firewall handle list.           |

### **Error codes**

| QMI_ERR_NONE           | No error in request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## 3.34.3 Description of QMI\_QCMAP\_GET\_FIREWALL\_CONFIG\_-HANDLE LIST REQ/RESP

This command gets all the firewall handles associated with a single mobile AP instance.



#### 3.35 QMI\_QCMAP\_CHANGE\_NAT\_TYPE

Changes the currently existing NAT type.

**QCMAP** message ID

0x0042

**Version introduced** 

Major - 1, Minor - 3

#### Request - QMI\_QCMAP\_CHANGE\_NAT\_TYPE\_REQ 3.35.1

## **Mandatory TLVs**

| •                | _    | _          |                    | _                     |
|------------------|------|------------|--------------------|-----------------------|
| Message type     |      |            |                    |                       |
| Request          |      |            | N                  | X5                    |
| Sender           |      |            | Sec                | ( ·                   |
| Control point    |      |            | Trade              |                       |
| Mandatory TLVs   |      |            | Contain            |                       |
|                  | Name | 10         | Version introduced | Version last modified |
| Mobile AP handle |      | Moderation | 1.3                | 1.3                   |
|                  |      | Offial 08: | Ster               |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 002-02/          | 1      | Mobile AP handle                        |
| Length | 4             |        | 250              | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

| Name            | Version introduced | Version last modified |
|-----------------|--------------------|-----------------------|
| NAT Type Option | 1.3                | 1.3                   |

| Field  | Field | Field | Parameter | Size   | Description     |
|--------|-------|-------|-----------|--------|-----------------|
|        | value | type  |           | (byte) |                 |
| Туре   | 0x10  |       |           | 1      | NAT Type Option |
| Length | 4     |       |           | 2      |                 |

| Field | Field         | Field | Parameter       | Size   | Description                         |
|-------|---------------|-------|-----------------|--------|-------------------------------------|
|       | value         | type  |                 | (byte) |                                     |
| Value | $\rightarrow$ | enum  | nat_type_option | 4      | NAT type specified for the NAT type |
|       |               |       |                 |        | change. Values:                     |
|       |               |       |                 |        | • 0x00 – QCMAP_NAT_TYPE_            |
|       |               |       |                 |        | SYMMETRIC – Symmetric NAT           |
|       |               |       |                 |        | • 0x01 – QCMAP_NAT_TYPE_PORT_       |
|       |               |       |                 |        | RESTRICTED_CONE – Port restricted   |
|       |               |       |                 |        | cone NAT                            |

#### 3.35.2 Response - QMI\_QCMAP\_CHANGE\_NAT\_TYPE\_RESP

Message type

Response

Sender

Service

**Mandatory TLVs** 

On Trade Secrets The Result Code TLV (defined in Section 2.3.1) is always present in the response.

**Optional TLVs** 

None

### **Error codes**

| QMI_ERR_NONE           | No error in request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

#### Description of QMI\_QCMAP\_CHANGE\_NAT\_TYPE REQ/RESP 3.35.3

This command changes the NAT type associated with a mobile AP instance. When the NAT type is changed, the old NAT table data is cleaned and all existing connections are lost. If an IPv6 handle is passed, a QMI\_ERR\_INVALID\_HANDLE error is returned.

#### 3.36 QMI\_QCMAP\_GET\_NAT\_TYPE

Gets the currently enabled NAT type.

**QCMAP** message ID

0x0043

Version introduced

Major - 1, Minor - 3

#### Request - QMI\_QCMAP\_GET\_NAT\_TYPE\_REQ 3.36.1

## **Mandatory TLVs**

| Message type     | _    |                    |                       |
|------------------|------|--------------------|-----------------------|
| Request          |      |                    | 5                     |
| Sender           |      | Secre              |                       |
| Control point    |      | Trade              |                       |
| Mandatory TLVs   |      | Contain            |                       |
|                  | Name | Version introduced | Version last modified |
| Mobile AP handle |      | 1.3                | 1.3                   |
|                  |      | antial 08: askey   |                       |

| Field  | Field         | Field  | Parameter        | Size   | Description                             |
|--------|---------------|--------|------------------|--------|---|
|        | value         | type   | (01,10,000       | (byte) |   |
| Туре   | 0x01          |        | 0021-02-         | 1      | Mobile AP handle                        |
| Length | 4             |        | 1.250            | 2      |   |
| Value  | $\rightarrow$ | uint32 | mobile_ap_handle | 4      | Handle identifying the mobile AP call   |
|        |               |        |                  |        | instance.                               |
|        |               |        |                  |        | The value must be the handle previously |
|        |               |        |                  |        | returned by QMI_QCMAP_MOBILE_           |
|        |               |        |                  |        | AP_ENABLE_REQ.                          |

## **Optional TLVs**

None

## 3.36.2 Response - QMI\_QCMAP\_GET\_NAT\_TYPE\_RESP

## Message type

Response

## Sender

Service

## **Mandatory TLVs**

The Result Code TLV (defined in Section 2.3.1) is always present in the response.

## **Optional TLVs**

| Name             | Version introduced | Version last modified |
|------------------|--------------------|-----------------------|
| Current NAT Type | 1.3                | 1.3                   |

| Field  | Field         | Field | Parameter       | Size   | Description                       |
|--------|---------------|-------|-----------------|--------|-----------------------------------|
|        | value         | type  |                 | (byte) |                                   |
| Туре   | 0x10          |       |                 | 10     | Current NAT Type                  |
| Length | 4             |       |                 | 02     |                                   |
| Value  | $\rightarrow$ | enum  | nat_type_option | 4      | NAT type currently on the modem.  |
|        |               |       | MICE            | 5.     | Values:                           |
|        |               |       | :: (2) 08:2     | rey.   | • 0x00 – QCMAP_NAT_TYPE_          |
|        |               |       | 18/1/22 03      | 5      | SYMMETRIC – Symmetric NAT         |
|        |               |       | 11007.100       |        | • 0x01 – QCMAP_NAT_TYPE_PORT_     |
|        |               |       | (0) 20 98       |        | RESTRICTED_CONE – Port restricted |
|        |               |       | 301 005         |        | cone NAT                          |

## **Error codes**

| QMI_ERR_NONE           | No error in request   |
|------------------------|---|
| QMI_ERR_INTERNAL       | Unexpected error occurred during processing                     |
| QMI_ERR_MALFORMED_MSG  | Message was not formulated correctly by the control point       |
|                        | or the message was corrupted during transmission                |
| QMI_ERR_MISSING_ARG    | Some TLV was missing  |
| QMI_ERR_INVALID_HANDLE | Mobile AP handle provided in the request is not valid, i.e., it |
|                        | is not assigned to the control point                            |
| QMI_ERR_NOT_SUPPORTED  | Operation is not supported                                      |

## 3.36.3 Description of QMI\_QCMAP\_GET\_NAT\_TYPE REQ/RESP

This command gets the currently enabled NAT type associated with a mobile AP instance. If an IPv6 handle is passed, a QMI\_ERR\_INVALID\_HANDLE is returned.



# A Call End Reasons

## A.1 Call End Reasons

Table A-1 lists the call end reasons.

Table A-1 Call end reasons

| Value | Name                                |
|-------|-------------------------------------|
| 1     | QCMAP_CER_UNSPECIFIED               |
| 2     | QCMAP_CER_CLIENT_END                |
| 3     | QCMAP_CER_NO_SRV                    |
| 4     | QCMAP_CER_FADE                      |
| 5     | QCMAP_CER_REL_NORMAL                |
| 6     | QCMAP_CER_ACC_IN_PROG               |
| 7     | QCMAP_CER_ACC_FAIL                  |
| 8     | QCMAP_CER_REDIR_OR_HANDOFF          |
| 9     | QCMAP_CER_CLOSE_IN_PROGRESS         |
| 10    | QCMAP_CER_AUTH_FAILED               |
| 11    | QCMAP_CER_INTERNAL_CALL_END         |
| 500   | QCMAP_CER_CDMA_LOCK                 |
| 501   | QCMAP_CER_INTERCEPT                 |
| 502   | QCMAP_CER_REORDER                   |
| 503   | QCMAP_CER_REL_SO_REJ                |
| 504   | QCMAP_CER_INCOM_CALL                |
| 505   | QCMAP_CER_ALERT_STOP                |
| 506   | QCMAP_CER_ACTIVATION                |
| 507   | QCMAP_CER_MAX_ACCESS_PROBE          |
| 508   | QCMAP_CER_CCS_NOT_SUPP_BY_BS        |
| 509   | QCMAP_CER_NO_RESPONSE_FROM_BS       |
| 510   | QCMAP_CER_REJECTED_BY_BS            |
| 511   | QCMAP_CER_INCOMPATIBLE              |
| 512   | QCMAP_CER_ALREADY_IN_TC             |
| 513   | QCMAP_CER_USER_CALL_ORIG_DURING_GPS |
| 514   | QCMAP_CER_USER_CALL_ORIG_DURING_SMS |
| 515   | QCMAP_CER_NO_CDMA_SRV               |
| 1000  | QCMAP_CER_CONF_FAILED               |
| 1001  | QCMAP_CER_INCOM_REJ                 |
| 1002  | QCMAP_CER_NO_GW_SRV                 |
| 1003  | QCMAP_CER_NETWORK_END               |
| 1004  | QCMAP_CER_LLC_SNDCP_FAILURE         |
| 1005  | QCMAP_CER_INSUFFICIENT_RESOURCES    |

## Table A-1 Call end reasons (cont.)

| Value | Name  |
|-------|---|
| 1006  | QCMAP_CER_OPTION_TEMP_OOO                     |
| 1007  | QCMAP_CER_NSAPI_ALREADY_USED                  |
| 1008  | QCMAP_CER_REGULAR_DEACTIVATION                |
| 1009  | QCMAP_CER_NETWORK_FAILURE                     |
| 1010  | QCMAP_CER_UMTS_REATTACH_REQ                   |
| 1011  | QCMAP_CER_PROTOCOL_ERROR                      |
| 1012  | QCMAP_CER_OPERATOR_DETERMINED_BARRING x       |
| 1013  | QCMAP_CER_UNKNOWN_APN                         |
| 1014  | QCMAP_CER_UNKNOWN_PDP                         |
| 1015  | QCMAP_CER_GGSN_REJECT                         |
| 1016  | QCMAP_CER_ACTIVATION_REJECT                   |
| 1017  | QCMAP_CER_OPTION_NOT_SUPP                     |
| 1018  | QCMAP_CER_OPTION_UNSUBSCRIBED                 |
| 1019  | QCMAP_CER_QOS_NOT_ACCEPTED                    |
| 1020  | QCMAP_CER_TFT_SEMANTIC_ERROR                  |
| 1021  | QCMAP_CER_TFT_SYNTAX_ERROR                    |
| 1022  | QCMAP_CER_UNKNOWN_PDP_CONTEXT                 |
| 1023  | QCMAP_CER_FILTER_SEMANTIC_ERROR               |
| 1024  | QCMAP_CER_FILTER_SYNTAX_ERROR                 |
| 1025  | QCMAP_CER_PDP_WITHOUT_ACTIVE_TFT              |
| 1026  | QCMAP_CER_INVALID_TRANSACTION_ID              |
| 1027  | QCMAP_CER_MESSAGE_INCORRECT_SEMANTIC          |
| 1028  | QCMAP_CER_INVALID_MANDATORY_INFO              |
| 1029  | QCMAP_CER_MESSAGE_TYPE_UNSUPPORTED            |
| 1030  | QCMAP_CER_MSG_TYPE_NONCOMPATIBLE_STATE        |
| 1031  | QCMAP_CER_UNKNOWN_INFO_ELEMENT                |
| 1032  | QCMAP_CER_CONDITIONAL_IE_ERROR                |
| 1033  | QCMAP_CER_MSG_AND_PROTOCOL_STATE_UNCOMPATIBLE |
| 1034  | QCMAP_CER_APN_TYPE_CONFLICT                   |
| 1035  | QCMAP_CER_NO_GPRS_CONTEXT                     |
| 1036  | QCMAP_CER_FEATURE_NOT_SUPPORTED               |
| 1500  | QCMAP_CER_CD_GEN_OR_BUSY                      |
| 1501  | QCMAP_CER_CD_BILL_OR_AUTH                     |
| 1502  | QCMAP_CER_CHG_HDR                             |
| 1503  | QCMAP_CER_EXIT_HDR                            |
| 1504  | QCMAP_CER_HDR_NO_SESSION                      |
| 1505  | QCMAP_CER_HDR_ORIG_DURING_GPS_FIX             |
| 1506  | QCMAP_CER_HDR_CS_TIMEOUT                      |
| 1507  | QCMAP_CER_HDR_RELEASED_BY_CM                  |

## A.2 Verbose Call End Reasons

Table A-2 lists the verbose call end reasons.

Table A-2 Verbose call end reasons

| Value    | Name   |
|----------|--|
| 0        | QCMAP_VCER_UNSPECIFIED                                 |
| MIP      |  |
| 65600    | QCMAP_VCER_MIP_FA_REASON_UNSPECIFIED                   |
| 65601    | QCMAP_VCER_MIP_FA_ADMIN_PROHIBITED                     |
| 65602    | QCMAP_VCER_MIP_FA_INSUFFICIENT_RESOURCES               |
| 65603    | QCMAP_VCER_MIP_FA_MOBILE_NODE_AUTH_FAILURE             |
| 65604    | QCMAP_VCER_MIP_FA_HA_AUTH_FAILURE                      |
| 65605    | QCMAP_VCER_MIP_FA_REQ_LIFETIME_TOO_LONG                |
| 65606    | QCMAP_VCER_MIP_FA_MALFORMED_REQUEST                    |
| 65607    | QCMAP_VCER_MIP_FA_MALFOMED_REPLY                       |
| 65608    | QCMAP_VCER_MIP_FA_ENCAPSULATION_UNAVAILABLE            |
| 65609    | QCMAP_VCER_MIP_FA_VJHC_UNAVAILABLE                     |
| 65610    | QCMAP_VCER_MIP_FA_REV_TUNNEL_UNAVAILABLE               |
| 65611    | QCMAP_VCER_MIP_FA_REV_TUNNEL_IS_MAND_AND_T_BIT_NOT_SET |
| 65615    | QCMAP_VCER_MIP_FA_DELIVERY_STYLE_NOT_SUPP              |
| 65633    | QCMAP_VCER_MIP_FA_MISSING_NAI                          |
| 65634    | QCMAP_VCER_MIP_FA_MISSING_HA                           |
| 65635    | QCMAP_VCER_MIP_FA_MISSING_HOME_ADDR                    |
| 65640    | QCMAP_VCER_MIP_FA_UNKNOWN_CHALLENGE                    |
| 65641    | QCMAP_VCER_MIP_FA_MISSING_CHALLENGE                    |
| 65642    | QCMAP_VCER_MIP_FA_STALE_CHALLENGE                      |
| 65664    | QCMAP_VCER_MIP_HA_REASON_UNSPECIFIED                   |
| 65665    | QCMAP_VCER_MIP_HA_ADMIN_PROHIBITED                     |
| 65666    | QCMAP_VCER_MIP_HA_INSUFFICIENT_RESOURCES               |
| 65667    | QCMAP_VCER_MIP_HA_MOBILE_NODE_AUTH_FAILURE             |
| 65668    | QCMAP_VCER_MIP_HA_FA_AUTH_FAILURE                      |
| 65669    | QCMAP_VCER_MIP_HA_REGISTRATION_ID_MISMATCH             |
| 65670    | QCMAP_VCER_MIP_HA_MALFORMED_REQUEST                    |
| 65672    | QCMAP_VCER_MIP_HA_UNKNOWN_HA_ADDR                      |
| 65673    | QCMAP_VCER_MIP_HA_REV_TUNNEL_UNAVAILABLE               |
| 65674    | QCMAP_VCER_MIP_HA_REV_TUNNEL_IS_MAND_AND_T_BIT_NOT_SET |
| 65675    | QCMAP_VCER_MIP_HA_ENCAPSULATION_UNAVAILABLE            |
| 131071   | QCMAP_VCER_MIP_HA_REASON_UNKNOWN                       |
| Internal |  |
| 131273   | QCMAP_VCER_INTERNAL_INTERNAL_ERROR                     |
| 131274   | QCMAP_VCER_INTERNAL_CALL_ENDED                         |
| 131275   | QCMAP_VCER_INTERNAL_INTERNAL_UNKNOWN_CAUSE_CODE        |
| 131276   | QCMAP_VCER_INTERNAL_UNKNOWN_CAUSE_CODE                 |
| 131277   | QCMAP_VCER_INTERNAL_CLOSE_IN_PROGRESS                  |
| 131278   | QCMAP_VCER_INTERNAL_NW_INITIATED_TERMINATION           |
| 131279   | QCMAP_VCER_INTERNAL_APP_PREEMPTED                      |

## Table A-2 Verbose call end reasons (cont.)

| Value       | Name  |
|-------------|---|
| Call manage | r   |
| 197108      | QCMAP_VCER_CM_CDMA_LOCK                               |
| 197109      | QCMAP_VCER_CM_INTERCEPT                               |
| 197110      | QCMAP_VCER_CM_REORDER                                 |
| 197111      | QCMAP_VCER_CM_REL_SO_REJ                              |
| 197112      | QCMAP_VCER_CM_INCOM_CALL                              |
| 197113      | QCMAP_VCER_CM_ALERT_STOP                              |
| 197114      | QCMAP_VCER_CM_ACTIVATION                              |
| 197115      | QCMAP_VCER_CM_MAX_ACCESS_PROBE                        |
| 197116      | QCMAP_VCER_CM_CCS_NOT_SUPP_BY_BS                      |
| 197117      | QCMAP_VCER_CM_NO_RESPONSE_FROM_BS                     |
| 197118      | QCMAP_VCER_CM_REJECTED_BY_BS                          |
| 197119      | QCMAP_VCER_CM_INCOMPATIBLE                            |
| 197120      | QCMAP_VCER_CM_ALREADY_IN_TC                           |
| 197121      | QCMAP_VCER_CM_USER_CALL_ORIG_DURING_GPS               |
| 197122      | QCMAP_VCER_CM_USER_CALL_ORIG_DURING_SMS               |
| 197123      | QCMAP_VCER_CM_NO_CDMA_SRV                             |
| 197127      | QCMAP_VCER_CM_RETRY_ORDER                             |
| 197608      | QCMAP_VCER_CM_CONF_FAILED                             |
| 197609      | QCMAP_VCER_CM_INCOM_REJ                               |
| 197616      | QCMAP_VCER_CM_NO_GW_SERV                              |
| 197617      | QCMAP_VCER_CM_NO_GPRS_CONTEXT                         |
| 197618      | QCMAP_VCER_CM_ILLEGAL_MS                              |
| 197619      | QCMAP_VCER_CM_ILLEGAL_ME                              |
| 197620      | QCMAP_VCER_CM_GPRS_SERV_AND_NON_GPRS_SERV_NOT_ALLOWED |
| 197621      | QCMAP_VCER_CM_GPRS_SERV_NOT_ALLOWED                   |
| 197622      | QCMAP_VCER_CM_MS_IDENTITY_CANNOT_BE_DERIVED_BY_THE_   |
|             | NETWORK   |
| 197623      | QCMAP_VCER_CM_IMPLICITLY_DETACHED                     |
| 197624      | QCMAP_VCER_CM_PLMN_NOT_ALLOWED                        |
| 197625      | QCMAP_VCER_CM_LA_NOT_ALLOWED                          |
| 197626      | QCMAP_VCER_CM_GPRS_SERV_NOT_ALLOWED_IN_THIS_PLMN      |
| 197627      | QCMAP_VCER_CM_PDP_DUPLICATE                           |
| 197628      | QCMAP_VCER_CM_UE_RAT_CHANGE                           |
| 197629      | QCMAP_VCER_CM_CONGESTION                              |
| 197630      | QCMAP_VCER_CM_NO_PDP_CONTEXT_ACTIVATED                |
| 197631      | QCMAP_VCER_CM_ACCESS_CLASS_DSAC_REJECTION             |
| 198108      | QCMAP_VCER_CM_CD_GEN_OR_BUSY                          |
| 198109      | QCMAP_VCER_CM_CD_BILL_OR_AUTH                         |
| 198110      | QCMAP_VCER_CM_CHG_HDR                                 |
| 198111      | QCMAP_VCER_CM_EXIT_HDR                                |
| 198112      | QCMAP_VCER_CM_HDR_NO_SESSION                          |
| 198113      | QCMAP_VCER_CM_HDR_ORIG_DURING_GPS_FIX                 |
| 198114      | QCMAP_VCER_CM_HDR_CS_TIMEOUT                          |
| 198115      | QCMAP_VCER_CM_HDR_RELEASED_BY_CM                      |
| 198118      | QCMAP_VCER_CM_NO_HYBR_HDR_SRV                         |

## Table A-2 Verbose call end reasons (cont.)

| Value      | Name  |  |  |
|------------|---|--|--|
| 198608     | QCMAP_VCER_CM_CLIENT_END                            |  |  |
| 198609     | QCMAP_VCER_CM_NO_SRV                                |  |  |
| 198610     | QCMAP_VCER_CM_FADE                                  |  |  |
| 198611     | QCMAP_VCER_CM_REL_NORMAL                            |  |  |
| 198612     | QCMAP_VCER_CM_ACC_IN_PROG                           |  |  |
| 198613     | QCMAP_VCER_CM_ACC_FAIL                              |  |  |
| 198614     | QCMAP_VCER_CM_REDIR_OR_HANDOFF                      |  |  |
| 3GPP speci | 3GPP specification                                  |  |  |
| 393224     | QCMAP_VCER_3GPP_OPERATOR_DETERMINED_BARRING         |  |  |
| 393241     | QCMAP_VCER_3GPP_LLC_SNDCP_FAILURE                   |  |  |
| 393242     | QCMAP_VCER_3GPP_INSUFFICIENT_RESOURCES              |  |  |
| 393243     | QCMAP_VCER_3GPP_UNKNOWN_APN                         |  |  |
| 393244     | QCMAP_VCER_3GPP_UNKNOWN_PDP                         |  |  |
| 393245     | QCMAP_VCER_3GPP_AUTH_FAILED                         |  |  |
| 393246     | QCMAP_VCER_3GPP_GGSN_REJECT                         |  |  |
| 393247     | QCMAP_VCER_3GPP_ACTIVATION_REJECT                   |  |  |
| 393248     | QCMAP_VCER_3GPP_OPTION_NOT_SUPPORTED                |  |  |
| 393249     | QCMAP_VCER_3GPP_OPTION_UNSUBSCRIBED                 |  |  |
| 393250     | QCMAP_VCER_3GPP_OPTION_TEMP_OOO                     |  |  |
| 393251     | QCMAP_VCER_3GPP_NSAPI_ALREADY_USED                  |  |  |
| 393252     | QCMAP_VCER_3GPP_REGULAR_DEACTIVATION                |  |  |
| 393253     | QCMAP_VCER_3GPP_QOS_NOT_ACCEPTED                    |  |  |
| 393254     | QCMAP_VCER_3GPP_NETWORK_FAILURE                     |  |  |
| 393255     | QCMAP_VCER_3GPP_UMTS_REACTIVATION_REQ               |  |  |
| 393256     | QCMAP_VCER_3GPP_FEATURE_NOT_SUPP                    |  |  |
| 393257     | QCMAP_VCER_3GPP_TFT_SEMANTIC_ERROR                  |  |  |
| 393258     | QCMAP_VCER_3GPP_TFT_SYTAX_ERROR                     |  |  |
| 393259     | QCMAP_VCER_3GPP_UNKNOWN_PDP_CONTEXT                 |  |  |
| 393260     | QCMAP_VCER_3GPP_FILTER_SEMANTIC_ERROR               |  |  |
| 393261     | QCMAP_VCER_3GPP_FILTER_SYTAX_ERROR                  |  |  |
| 393262     | QCMAP_VCER_3GPP_PDP_WITHOUT_ACTIVE_TFT              |  |  |
| 393297     | QCMAP_VCER_3GPP_INVALID_TRANSACTION_ID              |  |  |
| 393311     | QCMAP_VCER_3GPP_MESSAGE_INCORRECT_SEMANTIC          |  |  |
| 393312     | QCMAP_VCER_3GPP_INVALID_MANDATORY_INFO              |  |  |
| 393313     | QCMAP_VCER_3GPP_MESSAGE_TYPE_UNSUPPORTED            |  |  |
| 393314     | QCMAP_VCER_3GPP_MSG_TYPE_NONCOMPATIBLE_STATE        |  |  |
| 393315     | QCMAP_VCER_3GPP_UNKNOWN_INFO_ELEMENT                |  |  |
| 393316     | QCMAP_VCER_3GPP_CONDITIONAL_IE_ERROR                |  |  |
| 393317     | QCMAP_VCER_3GPP_MSG_AND_PROTOCOL_STATE_UNCOMPATIBLE |  |  |
| 393327     | QCMAP_VCER_3GPP_PROTOCOL_ERROR                      |  |  |
| 393328     | QCMAP_VCER_3GPP_APN_TYPE_CONFLICT                   |  |  |

## Table A-2 Verbose call end reasons (cont.)

| Value        | Name  |  |
|--------------|---|--|
| Point-to-Poi | Point-to-Point Protocol                               |  |
| 458753       | QCMAP_VCER_PPP_TIMEOUT                                |  |
| 458754       | QCMAP_VCER_PPP_AUTH_FAILURE                           |  |
| 458755       | QCMAP_VCER_PPP_OPTION_MISMATCH                        |  |
| 458783       | QCMAP_VCER_PPP_PAP_FAILURE                            |  |
| 458784       | QCMAP_VCER_PPP_CHAP_FAILURE                           |  |
| 524287       | QCMAP_VCER_PPP_UNKNOWN                                |  |
| eHRPD        |   |  |
| 524289       | QCMAP_VCER_EHRPD_SUBS_LIMITED_TO_V4                   |  |
| 524290       | QCMAP_VCER_EHRPD_SUBS_LIMITED_TO_V6                   |  |
| 524292       | QCMAP_VCER_EHRPD_VSNCP_TIMEOUT                        |  |
| 524293       | QCMAP_VCER_EHRPD_VSNCP_FAILURE                        |  |
| 524294       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_GEN_ERROR               |  |
| 524295       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_UNAUTH_APN              |  |
| 524296       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_PDN_LIMIT_EXCEED        |  |
| 524297       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_NO_PDN_GW               |  |
| 524298       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_PDN_GW_UNREACH          |  |
| 524299       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_PDN_GW_REJ              |  |
| 524300       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_INSUFF_PARAM            |  |
| 524301       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_RESOURCE_UNAVAIL        |  |
| 524302       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_ADMIN_PROHIBIT          |  |
| 524303       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_PDN_ID_IN_USE           |  |
| 524304       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_SUBSCR_LIMITATION       |  |
| 524305       | QCMAP_VCER_EHRPD_VSNCP_3GPP2I_PDN_EXISTS_FOR_THIS_APN |  |
| IPv6         | £196 1:10 @   |  |
| 589825       | QCMAP_VCER_IPV6_PREFIX_UNAVAILABLE                    |  |