
CO3053 – Embedded Systems

1. What is Embedded System?





Contents

Definition and Concept

Characteristic


Design Challenge

Design Metric



What is Embedded System?

- An embedded system is
 - A computer system that is embedded into another larger system.
 - Example: Cars, airplane, weapon, ...
- An embedded system is designed to perform a/some dedicated task(s)
 - Lighting control
 - Camera control





Embedded System Applications

- Require very high performance
 - Communications
 - Multimedia
 - Graphics





- Must also meet strict design goals
 - Real-time performance
 - Power/energy consumption
 - Cost










Example – Automotive


Car as an integrated control, communication and information system.





Example – Consumer Electronics

MP3 audio, digital camera, home electronics






Example – Information Systems

Wireless communication (mobile phone, wireless LAN, etc), end-user

equipment, router.






Common Characteristics of Embedded Systems

- Single-functioned
 - Executes a single program, repeatedly
- Tightly-constrained
 - Low cost, low power, small, fast, etc.

- Reactive and real-time
 - Continually reacts to changes in the system's environment
 - Must compute certain results in real-time without delay



An Embedded System Example



- Single-functioned -- always a digital camera
- Tightly-constrained -- low cost, low power, small, fast
- Reactive and real-time -- only to a small extent



Embedded Systems – Design Challenge

- Obvious design goal
 - Construct an implementation with desired functionality
- Key design challenge:
 - Simultaneously optimize numerous design metrics

- Design metric
 - A measurable feature of a system's implementation
 - Optimizing design metrics is a key challenge



Embedded Systems – Common Design Metrics

Unit cost

- The monetary cost of manufacturing each copy of the system, excluding NRE cost
- NRE cost (Non-Recurring Engineering cost)
 - The one-time monetary cost of designing the system
- Size
 - The physical space required by the system
- Performance
 - The execution time or throughput of the system
- Power
 - The amount of power consumed by the system
- Flexibility
 - The ability to change the functionality of the system without incurring heavy NRE cost





Embedded Systems – Common Design Metrics

- Time-to-prototype
 - The time needed to build a working version of the system
- Time-to-market
 - The time required to develop a system to the point that it can be released and sold to customers
- Maintainability
 - The ability to modify the system after its initial release
- Correctness, Safety, CPU Technologies, Integration Level, Form Factor,
 Application Specific Hardware, User Interface, Connectivity, Security



Embedded Systems – Other Design Metrics

- CPU Technologies
- Integration Level
- Form Factor
- Application Specific Hardware
- User Interface
- Connectivity
- Security



The CPU

General purpose

- 32-bit, 64-bit long time ago.
- Clock-rate reach several GHz.
- Included Floating Point Unit (FPU) and/or Graphic Processing Unit (GPU) with parallel processing capability.


Embedded System

- Large range of compute capability.
- Still many 8-bit and 16-bit in small ES (PIC, AVR,...).
- Now, many systems requires 32-bit, 64-bit CPU (ARM, ATOM,...)



Integration Level

- Early Embedded Systems
 - Separate CPU + Peripherals + ...
 - Cost highly



- SoC (System on a Chip)
 - Many ICs are integrated into a single Chip
 - □ High-density → Low-cost
 - CPU + Memory + IO or CPU + Memory + ADC
 - Many levels of integration



Power Consumption

- Many ES rely on battery
 - Power consumption is very important

- Apply power optimization technique
 - Sleep mode
- Heat is also very important
 - Heat sink must be efficient
 - E.g. Cell phone







Form Factor & Expansion

Size, pin-out, connector.




 Define some standard (Ex COM) help software development, hardware expansion

 Sometime for expansion, resources are reserved (DRAM, Flash). But these have trade-off and need to be consider carefully.



Application Specific Hardware

- Can any SoC suit the user requirements?
- Adding other ASIC or FPGA: trade-off
 - ASIC can show better performance
 - But FPGA can show the flexibility
- Future ES: SoC + FPGA



- Many parts of ES need certification
 - E.g. radio frequency need to be licensed (US, Japan,...)
- Consider to use pre-certified module



User Interface

- Many ES is interactive
 - Headed provide the display
 - E.g. touch screen. The appearance of application
 - Headless: no display.
 - Use console, key/button, or via web page








Connectivity and Security

- For current and future ES, connectivity is very important
 - Wifi, Xbee, Bluetooth, LoRa
 - 3G/4G/5G
 - **-**
- **Ubiquitous**: every device can connect each other
- When the connectivity is easy, the security become critical





Further Reading

- Audio Lecture
 - https://lectures.tik.ee.ethz.ch/es/recordings/ES_I/ES_I.html

