Memory Subsystem of Microprocessors



Chun-Jen Tsai NYCU 11/04/2022

SRAM: On- Chip memory, use transistors. Now denoted

Bottleneck of a Computer pram: Use in Man May., use capacitous, high days is

process of: discharge (peacl) -> charge (write b-clc). DRAM has a wrebule oven then no access due

Today the hottleneck of a computer is often in the main

- □ Today, the bottleneck of a computer is often in the main memory (DRAM) subsystem
 - CPUs do parallel ops (by multi-hart[†], multi-core, or superscalar)
 - DRAM devices usually handle one transaction at a time
 - CPU clocks often more than 4× faster than DRAM clocks
- Most importantly, CPU&DRAM communicate differently
 - CPU word-based read/write instructions
 - DRAM block-based data transactions
 - A memory controller sits between the CPU and DRAM as a mediator to alleviate the problem, but it is still a bottleneck

> process in memory: SamSung


2/42



[†] Hart stands for "hardware thread." Also known as Hyper-thread or Simultaneous multi-thread.

Memory Hierarchy of Computers

- □ A computer has several levels of memory hierarchy
 - L1, L2, and L3 caches
 - Scratchpad has lower delays than L1\$, and much cheaper
 - Main memory usually DRAM
- □ Coherency among different memory blocks is a critical issue (regardless of the # of cores) linker scripe (on contro) whether



TCM V.S Cache SRAM

SRAM.

3/42

Memory-Centric Applications

- Many computers run memory-centric applications:
 - Big-data analysis
 - Deep-learning
 - Network applications
 - Multimedia applications
- □ The memory behaviors of a RISC, a Digital Signal Processor (DSP), and a hard-wired logic are quite different

Memory-Centric Processing (1/3)

- □ Assuming two functional units (FUs) of computations:
 - FU#1

```
for (idx = 0; idx < N; idx++) for (jdx = 0; jdx < N; jdx++)
{
    C[idx][jdx] = A[idx][jdx] + B[idx][jdx];
}</pre>
```


■ FU#2


```
for (idx = 0; idx < N; idx++) for (jdx = 0; jdx < N; jdx++)
{
    row = scan_row[idx], col = scan_col[jdx];
    C2[idx][jdx] = C[row][col];
}</pre>
```

FUHI, FUHZ one common in video codec 1-D briestrem


Memory-Centric Processing (2/3)

□ System blocks:





Memory-Centric Processing (3/3)



Memory Model of a Processor

- ☐ The memory model specifies multiple harts (HW threads) data R/W behavior w.r.t. shared memory
 - For a single thread or multiple threads without shared data, nothing needs to be worried about as long as the data dependency order has been followed strictly

```
int A = 0;
int B = 0;
```

```
Thread_1()
{
   register int C1;
   A = 1;
   C1 = B;
}
```

```
Thread_2()
{
   register int C2;
   B = 1;
   C2 = A;
}
```

Can we have C1 = 0 and C2 = 0 at the end of both threads?

Processor/Compiler Tricks on L/S

- □ A memory model defines the degree of flexibility a processor (or compiler) can have in re-ordering and elimination of the load-store instructions
 - Under a memory model, a programmer must take into account possible re-ordering done by the processor/compiler
- □ When compiler optimization is on, some memory operations may be removed
 - Compilers may not see all threads with a shared variable!
 - "volatile" keywords in C/C++ is used by a programmer to tell the compiler not to play smart

Example of Volatile Usage

☐ Use volatile to avoid optimization errors:

```
int C;
Thread()
{
  int A = 0;

  C = 1;
  while (C) /* busy waiting */;

  (A = 1;)
}
```

The thread can never reach here!

```
volatile int C;

Thread()
{
  int A = 0;

  C = 1;
  while (C) /* busy waiting */;

  (A = 1;)
}
```

The thread can reach here!

Is Memory Model Necessary?

- \Box Since the main memory are much slower than the μ P, memory accesses are cached, buffered, and pipelined
- ☐ The memory model defines how read/write requests can be serialized to maintain "program correctness" while achieving high bandwidth and low latency[†]

Sequential Consistency Model


- □ The Sequential Consistency (SC) model assumes that each thread executes only in program order, and all threads share a single-port main memory
 - When interleaving instructions from all threads, the instruction order of each thread are preserved. From page 8 example:

```
A = 1;
                 A = 1;
                          B = 1;
                                   B = 1;
                                            B = 1;
A = 1;
C1 = B; B = 1; B = 1; C2 = A; A = 1;
                                           A = 1;
                          A = 1;
B = 1; C1 = B; C2 = A;
                                   C2 = A;
                                            C1 = B;
C2 = A;
       C2 = A;
                 C1 = B;
                          C1 = B;
                                   C1 = B;
                                            C2 = A;
```

- SC model means that each read operation (C1 or C2 in the example) from all threads on a variable sees the last write operation on that variable
 - Implies full coherency across all layers of the memory subsystem

Total Store Order (TSO) Model

- □ TSO model only requires preserving the store order of each thread (without violation of data dependency)
- ☐ If write buffers are used in the processors, different harts may see different values of the same variable
 - Under TSO model, previous example can have c1 = c2 = 0:



fence (barrier) instructions must be used here to ensure the consistency of the memory subsystem.

Data Race Issue

- □ A data race condition happens when
 - Concurrent accesses to a shared variable includes a write plus one or more read/write operations
 - Instructions from all harts are not just interleaved, but also executed during the same cycles → a multi-cycle operation can be preempted
- □ For race-free programs, compilers often offer a sequential consistency guarantee
 - Fence instructions will be inserted to preserve the appearance of sequential consistency

Weak Memory Model

- Modern superscalars usually adopt a weak memory model that allows aggressive reordering of the instructions for ultimate performance
- ☐ The consistency among threads must be explicitly enforced by the programmers/compilers using fence, barrier, or atomic instructions
- \Box A μ P with a weak memory model may have better multi-thread performance than a μ P with a TSO model

Non-Idempotent Memory

- □ For memory-mapped I/O addresses, memory cells may not behave in conventional ways
 - Writing to an address may store a different value in the cell
 - Writing to address A may change the content of address B
- Example: in the I/O addresses of Aquila, the content of *uart_status changes due to writing of *uart_txfifo:

```
#define uart_rxfifo ((unsigned int volatile *) 0xC0000000)
#define uart_txfifo ((unsigned int volatile *) 0xC0000004)
#define uart_status ((unsigned int volatile *) 0xC0000008)
```


```
while (*uart_status & TX_FIFO_FULL) /* wait */;
    *uart_txfifo = (unsigned char) '\r';
```

Cache Memory

- □ A cache is a high-speed memory that sits between the processor core and the slow main memory
 - Stores most frequently accessed data
- □ Three types of caches in a CPU core:
 - Instruction cache stores read-only instructions
 - Data cache stores read/write data and possibly instructions
 - TLB cache stores virtual memory table entries
- □ A cache memory is essentially an extremely simple type of associative memory

Associative Memory

- □ Associative memory can be used to retrieve a stored data by a "bit pattern" instead of an address
 - Tagged memory is a special type of associative memory




- □ Examples of associative memory usage:
 - Human brains
 - Artificial neural networks
 - Network filters/routers




Caches Design Principle

- Data exchange between physical memory and cache operates at large blocks called a cache line
 - Typical cache line size: 8 to 64 bytes
- □ Each cache line contains a "tag" that indicate which main memory cache line the data come from




N-Way Cache Memory

- □ For n-way cache, we need to determine which "way" contains the target data using associative memory
 - A 1-way cache is also called a direct-mapping cache
 - Cache memory is also called tagged memory



Tagged Memory Structure

- □ Tagged memory has a two-dimensional structure:
 - A 32-bit address is decomposed into three parts:



21/42

Cache Structure of Aquila

- □ For Aquila on Arty, the cache parameters are:
 - 4-way set associative
 - 128-bit cache line
 - Adjustable cache size
- □ If the cache size is 4KB, a 32-bit address is factored into 22-bit tag, 6-bit line index, and 4-bit byte offset
 - When cache size increases, the tag bits will drop and the line bits will increase
 - If the cache way increases (and cache size fixed), the line index bits drop, and the tag bits and offset bits do not change

Cache Design Parameters (1/2)

- □ Cache line size (aka. cache block size)
 - Cache exchange data with DRAM one line at a time
 - Cache line size does not have to match the DRAM block size, but integer ratios between these two are preferred usually limited to the memory controller.
- □ Cache write policy: when to write cache lines to DRAM
 - Write through (flush every time)
 - Write a block back upon any write request. Simplify data coherency issues. Less performance.
 - Writeback
 - Write back only when necessary. Better performance.
 - Write allocate
 - Write upon cache-miss, read the cache line and write to cache


Cache Design Parameters (2/2)

- □ Cache replacement policy:
 - When all the cache ways are full, the cache line in which cache way should be replaced by the new incoming data?
 - Popular policies are first-in-first-out (FIFO) and least-recently used (LRU)
- Cache associativity
 - Direct-mapping (no associative memory) |- way cache
 - *n*-way set associative
- Cache prefetching
 - Do we prefetch data ahead of time?

Uncached Memory Accesses

- μP also needs a way to bypass cache controller to access memory directly
 - I/O addresses space should not be cached since they are nonidempotent memory cells
- □ There are different schemes to do this
 - Some μPs use system registers to define non-cacheable memory blocks
 - Some μ Ps use MMU to define non-cacheable memory pages
 - Some μ Ps divide the memory address space into cacheable and uncacheable addresses (see next sldie)

Illustration of Uncached Accesses



Snooping-Based Coherent Cache

- Goals of memory coherency
 - Strong any read of an address must returns the most recent write to that address → performance may suffer
 - Weaker any write to an address will be seen by a read after some delay (i.e. writes to the same address must be serialized)
- Snooping-based cache coherence protocols
 - Each cache line records its usage states (shared/valid)
 - Write operation from a μ P will broadcast either the shared write data or an invalidate message to all caches
 - Each cache will snoop its cache lines and update their content or states accordingly

 Cache: promiess power consuming

TCM: need programmer allocate dota in TCM.

MSI Protocol (1/2)

Another is called MESI

- □ Each cache line can be in one of three states
 - Modified (M): data is dirty, no other cache has a copy
 - Shared (S): data is clean, other cache may have a copy
 - Invalid (I): data not in cache or invalidated by other controllers
- □ Cache line tag augmented with state information
- ☐ Given a pair of caches, the possible states of the same cache line:

	M	S	I
M	×	*	✓
S	*	✓	✓
I	✓	✓	✓


Caele 1

MSI Protocol (2/2)

- MSI read/write behavior depends on the state of the target cache line
- □ For read requests:
 - M- or S-states: the cache supplies the data.
 - I-state: verify that the line is not in the M-state in other cache
- □ For write requests:
 - M-state: the cache modifies the data locally
 - S-state: the cache must notify other caches that contain the line in the S-state to evict the line
 - I-state, the cache must notify other caches that contain the line in the S- or M-states to evict the line, before fetching it

FSM of MSI Protocols

- ☐ The FSM of cache block states:
 - Black requests are sent from the owner μ P
 - Blue requests are sent from other cache controllers



MSEI Protocol

- ☐ The MESI is an invalidate-based protocol, and is one of the most common protocols for write-back caches
 - Cache controller invalidates its own copy when it snoops a modification to a cached line
 - Less memory traffic than the MSI protocol
- □ Each cache line is in one of four states:
 - Modified (M): data is dirty, no other cache has a copy
 - → Exclusive (E): data is clean , no other cache has a copy
 - Shared (S): data is clean, other cache may have a copy
 - Invalid (I): data not in cache



Data Sharing thru Multi-Port Memory


- □ A multi-port on-chip memory block for data sharing is more efficient, but a lot more expensive
 - The complexity of the address decoding logic grows as the memory size increases:
 - − n-bit decoder requires 2ⁿ n-input AND gates
 - Coincident decoding reduces the complexity, but still expensive
 - Each port needs its own address decoder
 - Data racing results are implementation dependent
- ☐ To reduce cost, a multi-port memory can be synthesized using single- or two-port memory blocks

JEAM

L3/L2 Cache

Data Sharing with 4-Port OCM

 □ A multi-port scratchpad allows concurrent memory operations and data-sharing for multi-thread systems



Multi-Port Memory for FPGA


- □ Synthesis of a multi-port memory requires design trade-off between access delay and logic usage
 - If LUTs are used to directly synthesize a 4-port memory, the memory size cannot be too large
- □ BRAMs shall be used for multi-port memory synthesis:
 - You can use some decoding logic to arbitrate four concurrent accesses through the port(s) to a two-port BRAM
 - Alternatively, you can use more advanced techniques to design a multi-port memory that allows true simultaneous memory accesses†

URAM: 2-port, lorger in Size

[†] C. E. Laforest et al., "Composing Multi-Ported Memories on FPGAs," *ACM Trans. on Reconfigurable Technology and Systems*, Vol. 7, No. 3, Article 16, August 2014.


Direct Multi-Port Memory Synthesis

 \square A multi-ported memory implemented using logic cells, having D single-word storage (S), m write (W) ports, n read (R) ports, and n output registers r is as follows:



More Ports, Less Logic Cells

- □ Three conventional techniques for providing more R/W ports given 1W/1R memory blocks:
 - Note that each memory block in the following diagrams has the same size as the desired multi-port memory




The Live Value Table (LVT) Approach

- □ The LVT approach is based on memory banking
- □ LVT uses multiplexers and a table to steer reads to the most recently updated bank for each memory address
 - Improves significantly on the area and speed of comparable designs built using only logic cells
 - Can implement multi-ported memories with bidirectional ports

LVT-based mW/nR Memory Design

□ LVT records the most-recent write bank for each write addresses:




The XOR-Based Approach

- □ The XOR approach is also based on memory banking
 - Using the property of \oplus operation that $(A \oplus B) \oplus B = A$
- □ The design removes the need for a Live Value Table and thus avoids output multiplexing → usually uses less logic but require more BRAMs
- ☐ Under some configurations, the XOR design is faster and consumes less total area than the LVT designs

XOR-based 2W/1R Design

- □ Constructing a 2W/1R memory using 1W/1R memory:
 - The row # matches the # of write ports
 - The column # matches #W–1 plus #R



XOR-based mW/nR Design

- □ For mW/nR XOR-based multiport memory, we need:
 - A 2D BRAM array of m×(m–1), each row of BRAMs feeds old values to the other m–1 write ports
 - For each read port, we need an extra 1-D BRAMs array of m×1, which total to a 2D read array of m×n
- ☐ There is no need for multiplexors, only BRAM blocks and m-input XOR logic gates

Discussions

- □ Today, the bottleneck of high performance processors are often in the memory subsystem
 - Fast local memory can improve performance at low device cost, but programming effort can be high
 - Cache memory are easy for programmers, but suffers high overhead as the # of threads increases
- □ We pretty much ran out of ideas for general-purpose design tricks of memory subsystem
 - Application-specific optimization is the key to faster systems