

Mechatronic Modeling and Design with Applications in Robotics

Basic Model Elements


Mechatronic Systems

The field of mechatronics primarily concerns the integration of mechanics and electronics.

(e.g., mechanical, fluid, thermal and electrical/electronic systems)


They can serve functions of

- > Structural support
- ➤ Load bearing
- ➤ Mobility
- Transmission of motion and energy
- > Actuation
- ➤ Manipulation
- > Sensing
- > Control




https://en.wikipedia.org/wiki/Mechatronics

Electromechanical System



An electromechanical system / mechatronic system

Distinction Between Mechanical and Electronic Components



- Energy (or Power)
- ❖ Bandwidth (e.g., Speed and Time Constant)

Basic Electrical Components

Required and needed in this course:

- ➤ Mechanical Components
- > Electrical Elements

Should understand:

- > Fluid Elements
- > Thermal Elements

Across and Through Variables


Across Variable: Varies Across Element (e.g., Velocity, Voltage, Temperature, Pressure)


Through Variable: Remains Unchanged Through Element (e.g., Force, Current, Heat Transfer Rate, Fluid Flow Rate)


Mass

Spring

Damper







Sources: Velocity and force/torque

Variables: Velocity (across variable) and force (through variable)

Mechanical Element: Mass (Inertia)

Mass (Inertia) Element (A-Type Element)

Constitutive Equation (Newton's 2nd Law):


$$f = m \frac{dv}{dt}$$

where m = mass(inertia)

Power = fv = rate of change of energy \rightarrow

$$E = \int f v dt = \int m \frac{dv}{dt} v dt = \int m v dv$$

$$ightharpoonup$$
 Energy $E = \frac{1}{2}mv^2$ (Kinetic Energy) $ightharpoonup$ Energy storage element



Observations: Mass (Inertia)

- An inertia is an energy storage element (kinetic energy).
- ➤ Velocity (across variable) represents the state of an inertia element → "A-Type Element"

Note: 1. Velocity at any t is completely determined from initial velocity and the applied force; 2. Energy of inertia element is represented by v along.


- Hence, *v* is a natural output (or response) variable for an inertia element, which can represent its dynamic state (i.e., state variable), and *f* is a natural input variable for an inertia element.
- ➤ Velocity across an inertia element cannot change instantaneously unless an infinite force is applied to it.

Mechanical Element: Spring (Stiffness)

Spring (Stiffness) Element (T-Type Element)

Constitutive Equation (Hooke's Law):

$$\frac{df}{dt} = k\iota$$



where *k*=stiffness

Note: Differentiated version of familiar force-deflection Hooke's law in order to use velocity (as for inertia element)

$$E = \int f v dt = \int f \frac{1}{k} df$$


- → Energy $E = \frac{1}{2} \frac{f^2}{k}$ (Elastic potential energy)
- → Energy storage element

Observations: Spring (Stiffness)

- A spring (stiffness element) is an energy storage element (elastic potential energy).
- Force (through variable) represents state of spring element \rightarrow "T-Type Element". Note: 1. Spring force of a spring at time t is completely determined from initial force and applied velocity; 2. Spring energy is represented by f alone.
- Force *f* is a natural output (response) variable, and *v* is a natural input variable for a stiffness element.
- Force through a stiffness element cannot change instantaneously unless an infinite velocity is applied to it.

Mechanical Element: Damping (Dissipation)

Damping (Dissipation) Element (D-Type Element)



Constitutive Equation: f = bv

where b=damping constant (damping coefficient); for viscous damping

The power dissipated depending on the velocity v:

$$P = bv^2$$

Observations: Damping (Dissipation)

- \triangleright Mechanical damper is an energy dissipating element (D-Type Element).
- \triangleright Either force f or velocity v may represent its state.
- No new state variable is defined by this element.

Rotational Elements

Rotational Mass:

$$E = \frac{1}{2}I\omega^2$$

Torsional Spring:

$$E = \frac{1}{2} \frac{T^2}{k}$$


Rotary Damper:

$$P = c\omega^2$$


Electrical Elements

Capacitor

Inductor



Resistor



Sources: Voltage and current

Variables: Voltage (across variable) and current (through variable)

Electrical Element: Capacitor

Variables: Voltage (across variable) and the current (through variable)

Constitutive Equation:
$$C \frac{dv}{dt} = i$$
 where $C =$ capacitance

Power =
$$iv \rightarrow$$
 Energy $E = \int ivdt = \int C \frac{dv}{dt} vdt = \int Cvdv \rightarrow$

Energy
$$E = \frac{1}{2}Cv^2$$
 (electrostatic energy) \rightarrow Energy storage element

Observations: Capacitor

➤ Voltage (across variable) is state variable for a capacitor → "A-Type Element".

➤ Voltage is a natural output variable and current is a natural input variable for a capacitor.


➤ Voltage across a capacitor cannot change instantaneously unless an infinite current is applied.

Electrical Element: Inductor

Inductor Element (T-Type Element)

Constitutive Equation:
$$L \frac{di}{dt} = v$$
 where $L = \text{inductance}$

Energy
$$E = \frac{1}{2}Li^2$$
 (Electromagnetic energy)



Observations: Inductor

> Current (through variable) is state variable for an inductor > "T-Type Element".


Current is a natural output variable and voltage is a natural input variable for an inductor.

Current through an inductor cannot change instantaneously unless an infinite voltage is applied.

Electrical Element: Resistor (Dissipation)

Resistor Element (D-Type Element)

Constitutive Equation: v = Ri (Ohm's law) where R = resistance



Observations:

- 1. This is an energy dissipating element (**D-Type Element**)
- 2. Either i or v may represent the state
- 3. No new state variable is defined by this element.

Components	Constitutive Equation	Energy Stored or Power Dissipated
Capacitor	$i = C \frac{dv}{dt}$	$E = \frac{1}{2}Cv^2$
Inductor	$v = L \frac{di}{dt}$	$E = \frac{1}{2}Li^2$
Resistor	v = iR	$P = \frac{v^2}{R} \text{ or } P = I^2 R$

Note:

- Voltage is a natural output variable and current is a natural input variable for a capacitor.
- Current is a natural output variable; voltage is a natural input variable and voltage is a natural state variable for an inductor.

Mechanical-Electrical Analogy

System Type System-Variables:	Mechanical	Electrical
Through-Variables	Force f	Current i
Across- Variables	Velocity v	Voltage v
System	m	C
Parameters	k	1/L
	b	1/R

Variables: Across variable temperature (T) and through variable heat transfer rate (Q).


Thermal Capacitor (A-Type Element)

Consider control volume V of fluid with, density ρ , and specific heat c.

Constitutive Equation: Net heat transfer rate into the control volume $Q = \rho V c \frac{dT}{dt}$ è

$$C_t \frac{dT}{dt} = Q$$

$$C_t = \rho vc = \text{thermal capacitance of control volume}$$



Observations:

Temperature T is state variable for thermal capacitor (from usual argument) $\grave{\mathbf{e}}$ "A-Type Element"

Heat transfer rate Q is natural input and temperature T is natural output for this element. This is a storage element (stores thermal energy)

Note There is no thermal "inductor" like storage element with state variable Q.

Thermal Elements (cont'd)

Thermal Resistance (D-Type Element)

Three basic processes of heat transfer **è** three different types of thermal resistance

Constitutive Relations

Conduction:
$$Q = \frac{kA}{\Delta x}T$$

k = conductivity; A = area of cross section of the heat conduction element; $\Delta x = \text{length of heat conduction that has a temperature drop of } T$.

è Conductive resistance $R_k = \frac{\Delta x}{kA}$

Convection: $Q = h_c AT$

 h_c = convection heat transfer coefficient; A = area of heat convection surface with temperature drop T

è Conductive resistance $R_c = \frac{1}{h_c A}$

Radiation: $Q = \sigma F_E F_A A (T_1^4 - T_2^4)$ è a nonlinear thermal resistor

 σ = Stefan-Boltzman constant

 F_E = effective emmissivity of the radiation source (of temperature T_i)

 F_A = shape factor of the radiation receiver (of temperature T_2)

A = effective surface area of the receiver.


Variables: Pressure (across variable) P and volume flow rate (through variable) Q


Fluid Capacitor (A-Type Element)

Constitutive Equation: $C_f \frac{dP}{dt} = Q$

Note 1: Stores potential energy (a "fluid spring")

Note 2: Pressure (across variable) is state variable for fluid capacitor è "A-Type Element"





Three Types: Fluid compression; Flexible container; Gravity head

1a. For liquid control volume V of bulk modulus β : $C_{bulk} = \frac{V}{\beta}$

1b. For isothermal (constant temperature, slow-process) gas of volume V and pressure:

$$C_{comp} = \frac{V}{P}$$


1. For adiabatic (zero heat transfer, fast-process) gas: $C_{comp} = \frac{V}{kP}$

 $k = \frac{c_p}{c_v}$ = ratio of specific heats at constant pressure and constant volume

2. For incompressible fluid in a flexible vessel of area A and stiffness k: $C_{elastic} = \frac{A}{k}$

Note: For a fluid with bulk modulus, the equivalent capacitance = $C_{bulk} + C_{elastic}$.

3. For incompressible fluid column of area of cross-section A and density ρ : $C_{grav} = \frac{A}{\rho g}$



Fluid Elements (cont'd)

Fluid Inertor (T-Type Element)

Constitutive Equation: $I_f \frac{dQ}{dt} = P$

Note 1: Volume flow rate *Q* (through variable) is state variable for fluid inertor è "T-type Element"

Note 2: It stores kinetic energy, unlike the mechanical *T*-type element (spring), which stores potential energy.

which $P = I_f \frac{dQ}{dt}$

With uniform velocity distribution across A over length segment Δx :

Fluid inertance
$$I_f = \rho \frac{\Delta x}{A}$$


For a non-uniform velocity distribution:

Fluid inertance
$$I_f = \alpha \rho \frac{\Delta x}{A}$$
 (correction factor α)

For a pipe of circular cross-section with a parabolic velocity distribution, $\alpha = 2.0$

Fluid Resistor (D-Type Element)


Constitutive Equation (Linear): $P = R_f Q$



For Viscous Flow Through a Uniform Pipe:

- (a) With circular cross-section of diameter d: $R_f = 128 \mu \frac{\Delta x}{\pi d^4}$
- (b) With rectangular cross-section of height $b \ll width w$: $R_f = 12\mu \frac{\Delta x}{wb^3}$

Note: μ = absolute viscosity (or, dynamic viscosity); ν = kinematic viscosity with $\mu = \nu \rho$



$$P = R_f Q$$

Analogies and Constitutive Relations


	Constitutive Relation for			
System Type	Energy Storage Elements		Energy Dissipating Elements	
	A-Type (Across) Element	T-Type (Through) Element	D-Type (Dissipative) Element	
Translatory- Mechanical $v = \text{velocity}$ $f = \text{force}$	Mass (Newton's 2^{nd} Law) $m = mass$	Spring (Hooke's Law) k = stiffness	Viscous Damper $b = \text{damping constant}$	
Electrical $v = \text{voltage}$ $i = \text{current}$	Capacitor $C = $ capacitance	Inductor $L = inductance$	Resistor R = resistance	
Thermal $T = \text{temperature}$ difference $Q = \text{heat transfer rate}$	Thermal Capacitor C_t = thermal capacitance	None	Thermal Resistor R_t = thermal resistance	
Fluid P = pressure difference Q = volume flow rate	Fluid Capacitor $C_f = \text{fluid}$ capacitance	Fluid Inertor I_f = inertance	Fluid Resistor R_f = fluid resistance	


Through and Across Variables

System Type	Through Variable	Across Variable
Hydraulic/Pneumatic	Flow Rate	Pressure
Electrical	Current	Voltage
Mechanical	Force	Velocity
Thermal	Heat Transfer	Temperature

Building Up Mechanical Systems


Suspension of a car






Building Up Electrical Systems

Electrical Circuit







Building Up Mechatronic Systems

DC Motor (will discuss it in detail in later chapter)







The End!!