C66x KeyStone Training HyperLink


Agenda

- 1. HyperLink Overview
- 2. Address Translation
- 3. Configuration
- 4. Example and Demo

Agenda

- 1. HyperLink Overview
- 2. Address Translation
- 3. Configuration
- 4. Example and Demo

HyperLink Bus



CorePac & Memory Subsystem

Memory Expansion

Multicore Navigator

Network Coprocessor

External Interfaces


TeraNet Switch Fabric

Diagnostic Enhancements

HyperLink Bus


- Provides the capability to expand the C66x to include hardware acceleration or other auxiliary processors
- Four lanes with up to 12.5
 Gbaud per lane

HyperLink in KeyStone




HyperLink Advantages

- Expands internal bus across chip boundaries
 - Fast (50 Gbaud)
 - Low power (50+% saving compared to other serial interfaces)
 - Low latency
 - Industry standard SerDes
 - Future support for FPGA
- Many use cases
 - Remote access of accelerators
 - Expand processing capability by adding 4 or 8 cores
 - Reduce system power by disabling I/O, accelerators on remote device



HyperLink External Interfaces




Sideband:

- LVCMOS signal for control
- Dedicated control for each direction
- Flow Control (FL) and Power Management (PM)

Data:

- SerDes: 1 or 4 lanes
- Supports up to 12.5 GBaud per lane

HyperLink External Interfaces



Sideband:

- LVCMOS signal for control
- Dedicated control for each direction
- Flow Control (FL) and Power Management (PM)

Data:

- SerDes: 1 or 4 lanes
- Supports up to 12.5 GBaud per lane

NOTE: The PM and FL are transparent to the user after setting the registers.

Packet-Based Transfer Protocol


- Four read/write transactions
 - Write Request / Data Packet
 - Optional Write Response Packet
 - Read Request Packet
 - Read Response Data Packet
- Interrupt Request Packet passes event to remote side
- Multiple outstanding transactions
- 8 byte packet header (currently up to 64 bytes)
- 8b/9b error correction

HyperLink Functionality


From the user point of view:

- Access remote device memory
 - Ability to write to remote device memory
 - Ability to read from remote device memory
- Ability to generate event / interrupt in the remote device

Example HyperLink **Use Case**



HyperLink Model



Device B (local/Tx) can see up to 256MB of Device A (remote/Rx) memory:

- Available memory can be divided up to 64 distinct segments.
- All segments are the same size (local perspective).
- Segment size range is 256B to 256MB.
- All segments are aligned to 128KB boundaries.

Agenda

- 1. HyperLink Overview
- 2. Address Translation
- 3. Configuration
- 4. Example and Demo

Segmentation

- The total visible window is 256MB.
- The application can define up to 64 segments.
- The segment size on the remote side is 256B to 256MB.
- All segments are aligned on 17 bits alignment.
- On the local side, the HyperLink memory is between 0x4000_0000 to 0x4FFF_FFFF.
- On the remote side, the HyperLink memory address range is device dependent, but is typically 0x0000_0000 to 0xFFFF FFFF.

How is the local address (0x4XXX XXXX) translated to the remote address?

Offset Into a Segment

Largest Segment Size in Bytes (Power of 2)	Number of Bits For Offset	Maximum Number of Segments	Number of Bits Needed to Choose Segment				
256M	28	1	0				
128M	27	2	1				
8M	23	32	5				
4M	22	22 64 6					
2M	21	64	6				
16K	14	64	6				

What Does Translation Involve?

Translation process inputs on the local/transmit side:

- 1. 28 bits of remote address (the upper 4 bits are 0x4)
- 2. Privilege ID

Process information sent from the local to the remote/receive side:

- Lower portion of the remote address offset into the segment
- 2. Segment Index
- 3. Privilege ID

Translation process outputs on the remote/receive side:

- 1. Complete remote address
- 2. Privilege ID

Segment Lookup Table (Rx)

- The Segment Lookup Table is internal to the HyperLink and is not memory mapped.
- Each segment has a row:
 - o 64 rows
 - 21 information bits in each line
 - 16 bits are the MSB Segment Base Address
 - 5 bits are the Remote Segment Size
- The application loads the table row-by-row (segment-by-segment):
 - First, the Segment Base Address and segment size is written to register Rx Address Segment Value (base address + 0x3c) hyplnkRXSegldxReg_s
 - Then the Segment Number is written to register Rx Address Segment Index (base + 0x38) hypInkRXSegValReg_s
- During the translation process, the Segment Index is extracted from the upper bits of the local HyperLink address.

Low Level Driver Data Structures

Here are the data structures with brief descriptions:

hyplnkChipVerReg s Specification of the Chip Version Register Specification of the HyperLink Control Register hyplnkControlReg s hypInkECCErrorsReg s Specification of the ECC Error Counters Register hyplnkGenSoftIntReg s Specification of the HyperLink Generate Soft Interrupt Value Register hyplnkIntCtrlIdxReg s Specification of the Interupt Control Index Register hypInkIntCtrlValReg s Specification of the Interrupt Control Value Register hypInkIntPendSetReg s Specification of the HyperLink Interrupt Pending/Set Register hyplnkIntPriVecReg s Specification of the HyperLink Interrupt Priority Vector Status/Clear Register hyplnkIntPtrldxReg s Specification of the Interupt Control Index Register hyplnkIntPtrValReg s Specification of the Interrupt Control Value Register hypInkIntStatusClrReg s Specification of the HyperLink Interrupt Status/Clear Register Specification of the Lane Power Management Control Register hyplnkLanePwrMgmtReg s hyplnkLinkStatusReg s Specification of the Link Status Register hyplnkRegisters s Specification all registers Specification of the HyperLink Revision Register hyplnkRevReg s hyplnkRXAddrSelReg s Specification of the Rx Address Selector Control Register hyplnkRXPrivIDIdxReg s Specification of the Rx Address PrivID Index Register hyplnkRXPrivIDValReg s Specification of the Rx Address PrivID Value Register hyplnkRXSegIdxReg s Specification of the Rx Address Segment Index Register hyplnkRXSegValReg s Specification of the Rx Address Segment Value Register hyplnkSERDESControl1Reg s Specification of the SerDes Control And Status 1 Register hyplnkSERDESControl2Reg s Specification of the SerDes Control And Status 2 Register hyplnkSERDESControl3Reg s Specification of the SerDes Control And Status 3 Register hyplnkSERDESControl4Reg s Specification of the SerDes Control And Status 4 Register hyplnkStatusReg s Specification of the HyperLink Status Register hypInkTXAddrOvlyReg s Specification of the Tx Address Overlay Control Register

Example LLD: Write Multiple Registers

```
hypinkRet e Hypink writeRegs (Hypink Handle
                                                  handle,
                               hypinkLocation e
                                                  location.
                               hypinkRegisters t* writeRegs
```

Performs a configuration write.

Writes one or more of the device registers

It is the users responsibility to ensure that no other tasks or cores will modify the registers while they are read, or betwen the time the registers are read and they are later written back.

The user will typically use Hypink readRegs to read the current values in the registers, modify them in the local copies, then write back using HypInk writeRegs.

It is guaranteed that all registers can be written together. The actual ordering will, for example, write index registers before the associated value registers

On exit, the actual written values are returned in each register's reg->raw.

Since the peripheral is shared across the device, and even between peripherals, it is not expected to be dynamically reprogramed (such as between thread or task switches). It should only be reprogrammed at startup or when changing applications. Therefore, there is a single-entry API instead of a set of inlines since it is not time-critical code.

Return values:

hypinkRet e status

Parameters:

```
[in] The HYPLNK LLD instance identifier
handle
```

[in] Local or remote peripheral location writeRegs [in] List of registers to write

Building the Segment Lookup Table

"Build on the receive side for the transmit side specifications"

Here is one simple procedure for building the Segment Lookup Table:

- 1. Determine the maximum segment size that can be used (Power of 2), where N = The number of bits needed to address into the segment.
- 2. Calculate the number of bits needed for the segments (but no more than 6).
- 3. For each segment, load the base address and the remote segment size into the appropriate row of the table.
 - The base address is chosen so that N LSB are all zeros.
 - Only the upper 16 bits are written into the table.
- 4. If the number of segments is not Power of 2, add rows to complete to Power of 2 with empty segments (Size 0).

Show the remote DDR addresses between 0x8000_0000 and 0x8FFF_FFFF (addressed in one consecutive 256MB segment):

28-bit offset

0x8000

- 0 bits for choosing the segment (only one segment)
- One row in Segment Lookup Table

```
Table 3-14 Rx Address Segment Value Register Field Descriptions
If rxlen val = 16, the segment size is 0x0000 20000
If rxlen val = 17, the segment size is 0x0000 40000
If rxlen val = 18, the segment size is 0x0000 80000
If rxlen val = 19, the segment size is 0x0001 00000
If rxlen val = 20, the segment size is 0x0002 00000
If rxlen val = 21, the segment size is 0x0004 00000
If rxlen val = 22, the segment size is 0x0008 00000
If rxlen val = 23, the segment size is 0x0010 00000
If rxlen val = 24, the segment size is 0x0020 00000
If rxlen val = 25, the segment size is 0x0040 00000
If rxlen val = 26, the segment size is 0x0080 00000
If rxlen val = 27, the segment size is 0x0100 00000
```

Size 27 (size 0x0100 0000 = 256MB)

- 8 segments
- Each segment of size 0x0100_0000 (16MB)
- Addresses start at 0x8000_0000, 0x8200_0000, 0x8400_0000, and continue up to 0x8E00_0000
- The maximum size is 16MB. That is, 24 bits.
- 3 bits to choose the segment (8 segments).

Row 0	0x8000_0000	Size 23
Row 1	0x8200_0000	Size 23
Row 2	0x8400_0000	Size 23
Row 3	0x8600_0000	Size 23
Row 4	0x8800_0000	Size 23
Row 5	0000_00A8x0	Size 23
Row 6	0x8C00_0000	Size 23
Row 7	0x8E00_0000	Size 23

Size 23 = 0x00100000 = 16MB

- 8 segments
- 7 each of size 0x0100_0000 (16MB)
- Addresses start at 0x8000_0000, 0x8100_0000, 0x8200_0000, and continue up to 0x8600_0000.
- The last segment is 32MB starting at address 0x8700_0000.
- The maximum size is 32MB. That is, 25 bits.
- 3 bits to choose the segment (8 segments)

Row 0	0x8000_0000	Size 23
Row 1	0x8100_0000	Size 23
Row 2	0x8200_0000	Size 23
Row 3	0x8300_0000	Size 23
Row 4	0x8400_0000	Size 23
Row 5	0x8500_0000	Size 23
Row 6	0x8600_0000	Size 23
Row 7	0x8700 _0000	Size 24

- 9 segments
 - The first segment is the MSMC (4MB = 22 bits).
 - The next 8 segments are L2 memory of each core (512KB = 19 bits).
- The maximum size is 4MB. That is, 22 bits.
- 6 bits to choose the segment (64 segments)

Row 0	0x0C00_0000	Size 21 (4MB)
Row 1	0x1080_0000	Size 18 (512KB)
Row 2	0x1180_0000	Size 18
Row 3	0x1280_0000	Size 18
Row 4	0x1380_0000	Size 18
Row 5	0x1480_0000	Size 18
Row 6	0x1580_0000	Size 18
Row 7	0x1680_0000	Size 18
Row 8	0x1780_0000	Size 18
Row 9	0x0000_0000	Size 0 (0)
Row 10	0x0000_0000	Size 0

... and so on to Row 15.

- 64 segments
- Addresses start at 0x8000_0000, 0x8080_0000, 0x8100_0000, etc.
- The maximum size is 4MB. That is, 22 bits.
- 6 bits to choose the segment (64 segments)


```
Size 21 (4M)
Row 0
           0x8000 0000
Row 1
           0x8080_0000
                         Size 21
Row 2
           0x8100_0000
                         Size 21
Row 3
           0x8180 0000 Size 21
           0x8200_0000
                         Size 21
Row 4
Row 5
           0x8280 0000
                         Size 21
```

On the Local/Transmit Side

- Information included in the Address Word:
 - Offset into Segment
 - Segment Index
 - Privilege ID Value
- Tx Address Overlay Control Register (base + 0x1c) controls the overlay of the Privilege ID.
- The Privilege ID lookup Table has 16 rows and is loaded using two registers:
 - Rx address PrivID Index -> base + 0x30 hypInkRXPrivIDIdxReg_s
 - Rx Address PrivID Value -> base + 0x34 hyplnkRXPrivIDValReg s

Local/Tx Side: Example

- The Tx Address Overlay Control Register (base + 0x1c) controls the overlay of the Privilege ID index. hyplnkTXAddrOvlyReg_s
- Agreed values for the HyperLink Privilege Index:
 - 13 (0xD) if the request comes from a core
 - 14 (0xE) if the request initiated from another master
 - Tx Address information bits 0 to 27
 - Privilege Index bits 28-31
 - txigmask = depends on the maximum segment size:
 - 11 \rightarrow mask 0x0FFF_FFFF (1 segment), 10 \rightarrow 0x07FF_FFFF (2 segments),
 - $8 \rightarrow 0x01FF_FFFF$ (8 segments), $0 \rightarrow 0x0001_FFFFF$ (16 segments)
 - Tx Address Overlay Control Register is shown below.



For other possible configurations, refer to the HyperLink User Guide.

On the Remote/Receive Side

Five registers control the behavior of the remote/receive side:

- Rx Address Selector Control (base + 0x2c) controls how the address word is decoded; hyplnkRXAddrSelReg_s
- 2. Rx Address PrivID Index (base + 0x30) is used to build the Privilege Lookup Table; hypInkRXPrivIDIdxReg_s
- 3. Rx Address PrivID Value (base + 0x34) is used to build the Privilege Lookup Table; hypInkRXPrivIDValReg_s
- 4. Rx Address Segment Index (base + 0x38) is used to build the Segment Lookup Table; hypInkRXSegIdxReg_s
- 5. Rx Address Segment Value (base + 0x3c) is used to build the Segment Lookup Table; hyplnkRXSegValReg_s

Remote/Rx Side: Example

- Rx Address Selector Control (base + 0x2c; hyplnkRXAddrSelReg_s) controls how the receiver decodes:
 - Location in the address word and value of security bit (not used)
 - Location in the address word of Privilege Index.
 - Location in the address word of the index into segment lookup table
 - The mask that is used for extracting the offset
 - rxprividsel = 12 (bits 28-31)
 - rxsegsel depends on the maximum segment size:
 - 12 \rightarrow mask 0x0FFF_FFFF (1 segment), 10 \rightarrow 0x03FF_FFFF (4 segments),
 - $8 \rightarrow 0x00FF_FFFF$ (15 segments), $1 \rightarrow 0x0001_FFFF$ (16 segments)
- The Rx Address Selector Control register is shown below.

 31 2	26	25	24	23	20	19	16	15	12	11	8	7	4	3	0
Reserved	t	rxsechi	rxseclo	Rese	rved	rxsec	csel	Rese	rved	rxpriv	vidsel	Res	erved	r	ksegsel
R		R/W	R/W	F	3	R/\	Ν	F	3	R/	W		R		R/W

For other possible configurations, refer to the HyperLink User Guide.

Remote (Rx) Address Examples

Building upon each of the prior examples, this section demonstrates how to calculate the address value that is sent to the remote/receive side.

- The local address is 0x4567_89a0
- Assume Privilege ID 0xD (request from a core) was loaded to Index
 5 (0101) in the PrivID table.
- The address sent to the other side is 0x5567_89a0.

What address is accessed in the remote side?

Show the remote DDR addresses between 0x8000_0000 and 0x8FFF_FFFF (addressed in one consecutive 256MB segment):

- 28-bit offset
- 0 bits for choosing the segment (only one segment)
- One row in Segment Lookup Table


```
0x8000 Size 27 (size 0x0100_{-}0000 = 256MB)
```

Remote (Rx) Address: Example 1

Show the remote DDR addresses between 0x8000_0000 and 0x8FFF_FFFF (addressed in one consecutive 256MB Segment):

- 28 bit offset 0x0567 89a0
- Bits 28-31 0x0101 = 5
- txigmask = 11 mask 0x0FFF_FFFF
- txsegsel = 12 mask 0x0FFF_FFFF (no bit for segment select)
- Address sent to the receive/remote side = 0x5567_89a0

On the receive side, the address is $0x8000_0000 + 0x0567_89a0 = 0x8567_89a0$



- 8 segments
- Each segment of size 0x0100_0000 (16MB)
- Addresses start at 0x8000_0000, 0x8200_0000, 0x8400_0000, and continue up to 0x8E00_0000
- The maximum size is 16MB. That is, 24 bits.
- 3 bits to choose the segment (8 segments).

Row 0	0x8000_0000	Size 23
Row 1	0x8200_0000	Size 23
Row 2	0x8400_0000	Size 23
Row 3	0x8600_0000	Size 23
Row 4	0x8800_0000	Size 23
Row 5	0000_00A8x0	Size 23
Row 6	0x8C00_0000	Size 23
Row 7	0x8E00_0000	Size 23


Size 23 = 0x00100000 = 16MB

Remote (Rx) Address: Example 2

- 8 segments, each segment of size 0x0100_0000 (16M)
- Addresses start at 0x8000_0000, 0x8200_0000, 0x8400_0000, to 0x8E00_0000
- txigmask = 7 mask 0x00FF FFFF
- rxsegsel = 8 mask 0x00FF FFFF
- 24 bits offset 0x067 89a0
- Segment number 0101 = 5

Row 5 0x8A00_0000 Size 23

On the receive side, the address is $0x8A00_0000 + 0x0067_89A0 = 0x8A67_89A0$



- 8 segments
- 7 each of size 0x0100_0000 (16MB)
- Addresses start at 0x8000_0000, 0x8100_0000, 0x8200_0000, and continue up to 0x8600_0000.
- The last segment is 32MB starting at address 0x8700_0000.
- The maximum size is 32MB. That is, 25 bits.
- 3 bits to choose the segment (8 segments)


Row 0	0x8000_0000	Size 23
Row 1	0x8100_0000	Size 23
Row 2	0x8200_0000	Size 23
Row 3	0x8300_0000	Size 23
Row 4	0x8400_0000	Size 23
Row 5	0x8500_0000	Size 23
Row 6	0x8600_0000	Size 23
Row 7	0x8700 _0000	Size 24

Remote (Rx) Address: Example 3

- 8 segments, 7 each of size 0x0100_0000 (16M)
- Addresses start at 0x8000_0000, 0x8100_0000, 0x8200_0000, to 0x8600_0000.
- Txigmask = 8 mask 0x01FF_FFFF Rxsegsel = 9 mask 0x01FF_FFFF
- For 8 segments, the maximum size is 32M. That is, 25 bits.
- 25 bits offset segment number 010 = 2

Row 2 0x8200 0000 Size 23

On the receive side, the address is $0x8200_0000 + 0x0067_89A0 = 0x8267_89A0$



Segment Lookup Table: Example 4

- 9 segments
 - The first segment is the MSMC (4MB = 22 bits).
 - The next 8 segments are L2 memory of each core (512KB = 19 bits).
- The maximum size is 4MB. That is, 22 bits.
- 6 bits to choose the segment (64 segments)

Row 0	0x0C00_0000	Size 21 (4MB)
Row 1	0x1080_0000	Size 18 (512KB)
Row 2	0x1180_0000	Size 18
Row 3	0x1280_0000	Size 18
Row 4	0x1380_0000	Size 18
Row 5	0x1480_0000	Size 18
Row 6	0x1580_0000	Size 18
Row 7	0x1680_0000	Size 18
Row 8	0x1780_0000	Size 18
Row 9	0x0000_0000	Size 0 (0)
Row 10	0x0000_0000	Size 0

... and so on to Row 15.

Remote (Rx) Address: Example 4


- 9 segments
 - The first 8 segments are L2 memory of each core (512K = 19 bits).
 - The 9th segment is the MSMC (4M = 22 bits).
- The maximum size is 4M. That is, 22 bits.
- 6 bits to choose the segment (64 segments)
- Txigmask = 5 mask 0x003f ffff
- Rxsegsel = 6 mask 0x003f ffff
- 22 bits offset Segment number 010101 = 21

Row 5

0x1480 0000

Size 18

On the receive side, the address is $0x1480\ 0000 + 0x0007\ 89a0 = 0x1487\ 89a0$ (L2 memory of Core 4)



Segment Lookup Table: Example 5

- 64 segments
- Addresses start at 0x8000_0000, 0x8080_0000, 0x8100_0000, etc.
- The maximum size is 4MB. That is, 22 bits.
- 6 bits to choose the segment (64 segments)


```
Size 21 (4M)
Row 0
           0x8000 0000
Row 1
           0x8080_0000
                         Size 21
Row 2
           0x8100_0000
                         Size 21
Row 3
           0x8180 0000 Size 21
           0x8200_0000
                         Size 21
Row 4
Row 5
           0x8280 0000
                         Size 21
```

Remote (Rx) Address: Example 5

- 64 segments
- Addresses start at 0x8000_0000, 0x8080_0000, 0x8100_0000, etc.
- The maximum size is 4M. That is, 22 bits.
- 6 bits to choose the segment (64 segments)
- Txigmask = 5 mask 0x003F FFFF
- Rxsegsel = 6 mask 0x003F_FFFF
- 0x5567 89A0 offset 0x0027 89A0
- Segment number is 21 (010101)

Row 21 0x8A80 0000 Size 21

On the receive side, the address is $0x8a80_0000 + 0x0027_89a0 = 0x8AA7_89a0$



Agenda

- 1. HyperLink Overview
- 2. Address Translation
- 3. Configuration
- 4. Examples and Demo

Chip Level Configuration

1. Enable power domain for peripherals using CSL routines.

Enabling power to peripherals involves the following four functions:

```
CSL_PSC_enablePowerDomain()
CSL_PSC_setMosuleNextState()
CSL_PSC_startStateTransition()
CSL_PSC_isStateTransitionDone()
```

Reset the HyperLink and load the boot code for the PLL.

```
Write 1 to the reset field of control register (address base + 0x04)
CSL_BootCfgUnlockKicker();
CSL_BootCfgSetVUSRConfigPLL ()
```

3. Configure the SERDES.

```
CSL_BootCfgVUSRRxConfig()
CSL_BootCfgVUSRTxConfig()
```

Platform Level Configuration

- 1. HyperLink Control registers
- 2. Interrupt registers
- 3. Lane Power Management registers
- 4. Error Detection registers
- SerDes operation configuration
- 6. Address Translation registers

Basic HyperLink LLD Functions

<u>hyplnkRet_e_Hyplnk_open</u> (int portNum, <u>Hyplnk_Handle</u> *pHandle)

Hyplnk_open creates/opens a HyperLink instance.

<u>hyplnkRet e Hyplnk close (Hyplnk Handle</u> *pHandle)

Hyplnk_close Closes (frees) the driver handle.

<u>hyplnkRet e Hyplnk readRegs</u> (<u>Hyplnk Handle</u> handle, <u>hyplnkLocation e</u> location, <u>hyplnkRegisters t</u> *readRegs)

Performs a configuration read.

<u>hyplnkRet e Hyplnk writeRegs</u> (<u>Hyplnk Handle</u> handle, <u>hyplnkLocation e</u> location, <u>hyplnkRegisters t</u> *writeRegs)

Performs a configuration write.

<u>hyplnkRet e Hyplnk getWindow</u> (<u>Hyplnk Handle</u> handle, void **base, uint32_t *size)

Hyplnk_getWindow returns the address and size of the local memory window.

uint32_t HypInk_getVersion returns the HYPLNK LLD version information.

const char * <u>Hyplnk getVersionStr</u> (void) Hyplnk_getVersionStr returns the HYPLNK LLD version string.

Configuration Functions

 Configuration functions are part of the HyperLink example in the PDK release and can be used "as is" or be modified by users.

PDK_INSTALL_PATH\ti\drv\hyplnk\example\common\hyplnkLLDIFace.c

- Some of the configuration functions are:
 - hyplnkRet_e hyplnkExampleAssertReset (int val)
 - Void hypInkExampleSerdesCfg (uint32_t rx, uint32_t tx)
 - hyplnkRet e hyplnkExampleSysSetup (void)
 - Void hyplnkExampleEQLaneAnalysis (uint32 t lane, uint32 t status)
 - hyplnkRet_e hyplnkExamplePeriphSetup (void)

Example: Configuration Function

```
/********************
******
 * Sets the SERDES configuration registers
***********************
************
void hyplnkExampleSerdesCfg (uint32 t rx, uint32 t tx)
 CSL BootCfgUnlockKicker();
 CSL BootCfqSetVUSRRxConfig (0, rx);
 CSL BootCfgSetVUSRRxConfig (1, rx);
 CSL BootCfgSetVUSRRxConfig (2, rx);
 CSL BootCfgSetVUSRRxConfig (3, rx);
 CSL BootCfqSetVUSRTxConfig (0, tx);
 CSL BootCfgSetVUSRTxConfig (1, tx);
 CSL BootCfqSetVUSRTxConfig (2, tx);
 CSL BootCfgSetVUSRTxConfig (3, tx);
} /* hyplnkExampleSerdesCfg */
```

Agenda

- 1. HyperLink Overview
- 2. Address Translation
- 3. Configuration
- 4. Example and Demo

Example and Demo

- Included in the PDK (Platform Development Kit) release are a set of examples for each of the peripherals.
- For HyperLink, there is one example that can be configured either as a single-EVM loopback or between two C66x EVM boards.
- Location of the example:

pdk_C6678_1_0_0_18\packages\ti\drv\exampleProjects\hyplnk_exampleProject

The loopback flag is in the file hyplnkLLDCfg.h

For More Information

- For more information, refer to the KeyStone Architecture HyperLink User Guide http://www.ti.com/lit/SPRUGW8
- For questions regarding topics covered in this training, visit the support forums at the TI E2E Community website.