## **Monitor Help**



Monitor is designed to realize the four-remote function.


### **Product Coverage:**

- ACB
- MCCB

\*All product should have communication function(Modbus 485).

### **IOS requirement:**

- Windows XP with Microsoft .NET Framework 4
- Windows 7 or higher



# **Home Page**

Display all devices' running status.

- Alarm, Normal or Non-signal
- Open or Close



# **Devices Page**

- Make sure devices' config is right the first time you use Monitor .
- [Type] and [Address] must correspond to the device, you can give every device an intuitive [Name].
- Delete a device.[M-1] as an example:



• Add a device.[M-1] as an example:



**Important:** 

After the new device has been deployed ,such as [Type:MCCB,Name:M-1,Address:4],you must Press Enter to add a null row or make the cursor leave the editing row. Then you can save the new config and see the changes on Home Page.



**Link Page** 


Just a page to display the system organization.



**Device Page** 


### 1.Monitor

On Home Page, press [Name] button to enter Device Page. On Device Page, press [Back] button to return Home Page.




#### 2.Params


- When the [Mode] is <u>Local</u>,[Monitor] switch is disable. You can't change device's params through Monitor.
- When the [Mode] is Remote, [Monitor] switch is able. Here is an example:



①.[Mode] is Remote,[Monitor] switch is able



- ②.[Monitor] button switches to [Set], background color will change as below; Change Params:
  - 1. [Short] switch from **On** to **Off**;
  - 2. [Ir] commobox from **0.6** to **1**.




③.[Set] button switch to [Monitor], wait a secend, you will see the changes.

#### 3.Remote

When the [Mode] is Remote, you can use the switch to Remote Open or Close.





Get more help? Email:haisheng.xu@xseec.cn