PART 1: LOW-RISE BUILDINGS

30.4 BUILDING TYPES

The provisions of Section 30.4 are applicable to an enclosed and partially enclosed:

- Low-rise building (see definition in Section 26.2)
- Building with $h \le 60$ ft (18.3 m)

The building has a flat roof, gable roof, multispan gable roof, hip roof, monoslope roof, stepped roof, or sawtooth roof. The steps required for the determination of wind loads on components and cladding for these building types are shown in Table 30.4-1.

30.4.1 Conditions

For the determination of the design wind pressures on the components and claddings using the provisions of Section 30.4.2 the conditions indicated on the selected figure(s) shall be applicable to the building under consideration.

30.4.2 Design Wind Pressures

Design wind pressures on component and cladding elements of low-rise buildings and buildings with $h \le 60$ ft (18.3 m) shall be determined from the following equation:

$$p = q_h[(GC_p) - (GC_{pi})] \text{ (lb/ft}^2) \text{ (N/m}^2)$$
 (30.4-1)

where

 q_h = velocity pressure evaluated at mean roof height h as defined in Section 30.3

 (GC_p) = external pressure coefficients given in:

- Figure 30.4-1 (walls)
- Figures. 30.4-2A to 30.4-2C (flat roofs, gable roofs, and hip roofs)
- Figure 30.4-3 (stepped roofs)
- Figure 30.4-4 (multispan gable roofs)
- Figures. 30.4-5A and 30.4-5B (monoslope roofs)
- Figure 30.4-6 (sawtooth roofs)
- Fig. 30.4-7 (domed roofs)
- Fig. 27.4-3, footnote 4 (arched roofs)
- (GC_{pi}) = internal pressure coefficient given in Table 26.11-1

User Note: Use Part 1 of Chapter 30 to determine wind pressures on C&C of *enclosed and partially enclosed low-rise buildings* having roof shapes as specified in the applicable figures. The provisions in Part 1 are based on the Envelope Procedure with *wind pressures calculated using the specified equation* as applicable to each building surface. For buildings for which these provisions are applicable this method generally yields the lowest wind pressures of all analytical methods contained in this standard.

Table 30.4-1 Steps to Determine C&C Wind Loads Enclosed and Partially Enclosed Low-rise Buildings

- Step 1: Determine risk category, see Table 1.5-1
- **Step 2:** Determine the basic wind speed, *V*, for applicable risk category, see Fig. 26.5-1A, B or C
- **Step 3:** Determine wind load parameters:
 - ▶ Wind directionality factor, K_d , see Section 26.6 and Table 26.6-1
 - ➤ Exposure category B, C or D, see Section 26.7
 - Topographic factor, K_{zt} , see Section 26.8 and Fig. 26.8-1
 - ➤ Enclosure classification, see Section 26.10
 - ➤ Internal pressure coefficient, (GC_{pi}) , see Section 26.11 and Table 26.11-1
- **Step 4:** Determine velocity pressure exposure coefficient, K_z or K_h , see Table 30.3-1
- Step 5: Determine velocity pressure, q_h, Eq. 30.3-1
- **Step 6:** Determine external pressure coefficient, (GC_p)
 - ➤ Walls, see Fig. 30.4-1
 - ➤ Flat roofs, gable roofs, hip roofs, see Fig. 30.4-2
 - > Stepped roofs, see Fig. 30.4-3
 - ➤ Multispan gable roofs, see Fig. 30.4-4
 - ➤ Monoslope roofs, see Fig. 30.4-5
 - > Sawtooth roofs, see Fig. 30.4-6
 - ➤ Domed roofs, see Fig. 30.4-7
 - > Arched roofs, see Fig. 27.4-3 footnote 4
- **Step 7:** Calculate wind pressure, p, Eq. 30.4-1