		respectively. The first two layers of wallboard are attached as described immediately above. A layer of $0.035''$ thick (No. 20 B.W. gage) $1''$ hexagonal galvanized wire mesh is applied under the soffit of the middle layer and up the sides approximately $2''$. The mesh is held in position with the No. $6 1^{5}/8''$ -long screws installed in the vertical leg of the bottom corner angles. The outer layer of wallboard is attached with No. $6 2^{1}/4''$ -long screws spaced $8''$ on center. One screw is also installed at the mid-depth of the bracket in each layer. Bottom corners are finished as described above.				
3. Bonded		Carbonate, lightweight, sand-lightweight and siliceous aggregate concrete	4 ^g	3 ^g	$2^{1}/_{2}$	$1^{1}/_{2}$
pretensioned reinforcement in	3-1.1	Beams or girders				
prestressed concrete ^e		Solid slabs ^h		2	$1^{1}/_{2}$	1
4. Bonded or unbonded post- tensioned tendons in prestressed concrete ^{e, i}	4-1.1	Carbonate, lightweight, sand-lightweight and siliceous aggregate concrete				
		Unrestrained members:		_	.1.	
		Solid slabs ^h	-	2	$1^{1}/_{2}$	-
		Beams and girders ^j				
		8" wide		$4^{1}/_{2}$	$2^{1}/_{2}$	$1^{3}/_{4}$
		greater than 12" wide	3	$2^{1}/_{2}$	2	$1^{1}/_{2}$
		Carbonate, lightweight, sand-lightweight and siliceous aggregate				
		Restrained members: ^k				
		Solid slabs ^h	$1^{1}/_{4}$	1	3/4	-
	4-1.2	Beams and girders ^j				
		8" wide	$2^{1}/_{2}$	2	$1^{3}/_{4}$	-
		greater than 12" wide	2	$1^{3}/_{4}$	$1^{1}/_{2}$	-

(continued)