BERN STAPLES

ON AUTODESK REVIT

NORTHLAKE CHRISTIAN SCHOOL

Copyright © 2016 Bern Staples

PUBLISHED BY NORTHLAKE CHRISTIAN SCHOOL

HTTP://WWW.NORTHLAKECHRISTIAN.ORG

SPECIAL THANKS TO THOMAS MORTON

This information is free; you can redistribute it and/or modify it under the terms of the GNU General Public License as published by the Free Software Foundation; either version 2 of the License, or (at your option) any later version.

This work is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU General Public License for more details.

The source code of this document may be found under a public GIT repository here: http://www.github.com/hendenburg/onautodeskrevit

You should have received a copy of the GNU General Public License along with this work; if not, write to the Free Software Foundation, Inc., 51 Franklin Street, Fifth Floor, Boston, MA 02110-1301, USA.

THIS DOCUMENT UTILIZES the Tufte-Style Book formating method. It utilizes formating and functions of this template. The Template may be found at http://www.LaTeXTemplates.com and the template is under an individual CC BY-NC-SA 3.0 license.

First printing, October 2016

Contents

Introduction 7	
Chapter 1 - Creating Your House 13	
Chapter 2 - Creating the Base of the House 17	
Chapter 3 - Creating the Terrain 21	
Chapter 4 - Creating Exterior Walls, Floors, and Roofs	25
Bibliography 29	

List of Figures

1	The revit start page 8
2	A revit New file popup 8
3	A template file list 9
4	A revit default workspace 9
5	The revit top bar 10
6	The annotation bar 10
7	The massing and site bar 10
8	The view bar 11
9	The modify bar 11
10	The revit side bar 13
11	The revit elevations list 13
12	Clicked elevation lines 13
13	The revit options bar 14
14	Shortened elevation lines 14
15	The names of elevation lines 14
16	Revit object types 17
17	The foundation walls 18
18	Revit foundation and retaining walls 19
19	Initial topographic points 21
20	Second set of topographic points 22
21	Third topographic points 22
22	Building Pad Lines 23
23	Revit 3D Maneuvering Square 23
24	Revit 3D view after Topographic Creation 22
25	
26	Lower Level Walls 26
27	Exterior walls 3D view 27

28 Revit Roof Intersection

Introduction

The following guide and user manual utilizes Autodesk Revit, a BMI program which is used to create Architectural Visualizations ¹. The guide is based on Autodesk's own guide ²

Starting Revit

To start Revit, either find the program via its icon, or by searching for Revit by bringing up the search menu with the Windows Key

Getting adjusted to Revit

The Figure 1 represents an accurate representation of a Revit opening screen. When opening a Revit project file this screen is circumvented.

Starting your first project, and an introduction to Revit's interface

Let's antiquate ourselves with the introduction page. The introduction page is made up of two primary sections: Projects and Families. For the time being you can ignore the Families section, and focus only on the former.

- ¹ Autodesk. Revit. http://www. autodesk.com/products/revit-family/ overview, 2016. Computer Software
- ² Autodesk. *Getting Started with Autodesk Revit Building*. Autodesk, 2006




Figure 1: This figure shows the opening page when you open up the Revit Application.

There are three major parts to the Revit Application Main Page.

AMONG THE LINKS are: Open... which opens an already existing project, and New... which presents to you the process to create a new project, and various templates. The images and captions within the project section are existing projects that have been opened recently.

We are going to start a new project. If you click on New... you should have a popup window like in Figure 2.

Once you click Browse... you should be taken to another popup. The popup, which is shown in figure 3 has a list of templates used in Revit Projects. The template you will want to you is called default. Once the template is selected click Ok and be off onto the project.



Figure 2: This is new file popup, you see this whenever you wish to create a new project. You will always be creating a Project, not a Project Template.

You will not be creating any files with the Construction Template

if you can't find it, the file path is: ProgramData Autodesk PRVT 2016 > Templates > US Imperial > default




Figure 3: A list of the templates that will popup on your screen




Figure 4: A full screen example of the Revit workspace. Composed of multiple ribbon banners, and views. The large whitespace is the plane on which you have your building

Elements of the Revit Interface



In the figure 5 you can see what we will refer to as the Top Bar, this will be the location where all the tools of this program are located.

You can see icons for each tool, and above those is a line of tabs, called Ribbons, starting with Architecture, then Structure, Systems, etc. When you click one of the ribbon labels you are taken to a new section of tools.

As you create the house below, you will become familiar with all these tools; each tool is essential in the creation of a functioning model.

THE ARCHITECTURE TAB, which is show in Figure 5, contains the tools to create the basic formation of a house: the foundation, the floors, the walls, and the windows.

THE ANNOTATE TAB which is shown in the figure 6 contains the tools which you use to markup the project. These tools document your creation, while also making presentation easier. They can be used to determine the size of your model, the angels of you walls, the width of you house for a variety of reasons.

Figure 5: The revit top bar, at it's base.

You won't be using the majority of these tabs, but it's smart to know what they do, along with the tools inside. See the Menu Tools sections reference for more. For the majority of this tutorial the only tabs will be:

Architecture | Annotate | Massing & Site |
| View | and | Modify |

Beware: overuse of the

Massing & Site Toposurface, and the

Massing & Site Site Component tools can
lead to your computer becoming slow
and sluggish.



Figure 6: A picture of the Annotation bar in revit.

THE MASSING & SITE TAB, in figure 7 is used to model and map the terrain of your model.



Figure 7: A picture of the Massing & site bar in revit.

THE VIEW TAB, shown in figure 8, contains essential tools for viewing and presenting your project. The View 3d View tool will become vital for visualizing your house in the future.



Figure 8: A picture of the View bar in revit.

THE MODIFY TAB, in figure 9, is different from the others. While the previous tabs were meant to interact with the building, this tab is primarily focused on interacting with the objects that make the building up. For instance, splitting a singular wall is done inside the modify tab.



Figure 9: A picture of the Modify bar in revit.

Chapter 1 - Creating Your House

Figure ?? is a picture of what your house will look like.

On the right in figure 10, you can see the Revit Sidebar. This sidebar, which should be on the left hand of your revit window, is the detail window for everything you do. in the Revit Sidebar Properties you can see the type of object, and the specifications for it. in the Revit Sidebar Project Browser you can see a list of all the views and documents associated with your project.

Selecting and Creating Elevations

The following guide's purpose is to establish an understanding of altitudes and elevations in 3d architecture.

- 1. Within Sidebar Project Browser Elevations is the elevations list.
- 2. Refer to figure 11 and click on the Sidebar Project Browser Elevations

 South button
- 3. You should see elevation lines in the main workspace. if you click along the line once, it will become like figure 12, you should click and drag the leftmost circle to the right until the line becomes shorter.
- Each elevation has two main elements, the name and the altitude. Generally your foundation should be several feet under the ground.
- 5. You have two elevations currently: Level 1 and Level 2
- 6. You can either use your scroll wheel too zoom into the elevations, or you can use the keybinding: Ctrl + Z + F
- 7. If you click on the text of Level 1 where it says 0'-0" it will allow the input of a new altitude
- 8. Click on the altitude of both Level 1 and Level 2 and change their altitudes




Figure 11: A view of the elevations: East, North, South, and West




Figure 12: Elevation lines that have been clicked once

- For Level 1 where the altitude should be -14'0"
- for Level 0 where the altitude should be 10'0"

[-4'0"] generally is a good altitude to keep your foundation base, Level 1 is the foundation for this house, for instance.

Creating additional elevations


9. If you right click on the uppermost elevation, Level 2, you should get a context menu, it should include the option: Create Similar. If you click on that option it should select the Architecture Level tool which creates an annotation, but it also has the same selected options as the elevation you selected.


A context menu is what happens when you right click, the first option should be cancel, in this case, the option you're looking for should be the 10th down

10. If you look at Figure 13 you should see what is called the Options Bar, on it you can see multiple options: Make Plan View and Offset: which equals 0'0"

offsets

11. To create an elevation that is 10' above Level 1 Change the Option Bar Offset: to equal 10'0" while Create Similar is selected, and click from the leftmost point of Level 2 and drag to the rightmost point. Reference figure 14





Make sure that your elevations look similar to this figure

- 12. Use the same procedure as used to create Level 3 to create another elevation at 10'0". To do this, make sure your Options Bar Offset: is set to 10' and create a similar elevation above Level 3
- 13. Similar in method to changing a elevation's altitude is changing an elevation's name. For instance, click on Level 1 where it says 'Level 1', so that it becomes a text box like when changing the altitude. Enter the following name: 00 Foundation
 - Name the Level 1 this: 00 Foundation
 - Name the Level 2 this: 01 Lower Level




Figure 15: Make sure that your final elevations are named likewise


- Name the Level 3 this: 02 Entry Level
- name the Level 4 this: 03 Roof Level

Chapter 2 - Creating the Base of the House

The purpose of this guide is to instruct in the method of creating the foundation for the project.

Creating the Retaining Walls

- 1. Select this view Sidebar Project Browser Floor Plans 00 Foundation
- 2. Zoom into the lower right quadrant of the workspace
- 3. From there, select the following tool: Architecture Wall Tool. When you click on the screen with this tool selected you create points, just like on a graph you click or drag another point out to create a line, or a wall in this case.
- 4. If you remember the Sidebar for the interface explanation, there was Sidebar Properties, inside this is the options for the wall.




- 5. Click to create a base point, a line should begin to follow your cursor. You can easily create a wall by pointing your cursor in a direction, and typing in the distance.
- 6. create a base point and move your cursor to the left: type 40'
- 7. If chain was selected in Option Bar Chain: then, you should just be able to move the cursor up and type in 22, otherwise click on your last created point and repeat the aforementioned steps
- 8. Repeat the same steps, moving your cursor right and typing: 40'


This is why we named our elevations the way we did in the previous chapter. Our floor plans are listed alphabetically in the Project Browser so when we have the numbers preceding the name, they are both descriptive, and correctly ordered

It's good to make sure that your walls have the correct base and height. If the program does not let you select the correct height, while not perfect, another option is to choose unconnected for the Sidebar Properties Top Constraint and then select the altitude for the elevation point, for instance, the offset would be 10'0" for 02 Roof Level



Figure 16: When selecting an object in Revit. There is, of course, different object types. The image in this figure is the Object Selector. For walls specifically, there are multiple types that we use. When referenced, the Object type can be explained as Sidebar Properties Object Selector Basic Wall Retaining - 12" Concrete or plainly as Basic Wall Retaining - 12" Concrete






[Revit retaining walls] This is what your walls should look like

Creating your Foundation Walls

9. Select your retaining walls with the following options

Settings	Basic Wall Foundation - 12" Concrete
Location Line	Wall Centerline
Base Constraint	00 Foundation
Base Offset	0'0"
Top Constraint	Up to 01 Lower Level
Top Offset	0'0"

- 10. Create the walls on the outside
 - (a) select the rightmost edge of the bottommost wall with the wall tool selected
 - (b) Move the cursor to the right: type 6'6"
 - (c) Move the cursor up: type 5'
 - (d) move the cursor right: type 10'6"
 - (e) meet the intersect where the topmost point of your wall becomes directly right of the rightmost point of the top wall.
 - (f) Complete the walls by moving to the left until you hit the top wall.
- 11. Figure 18 should be the final product of this level



Make sure your walls look like this

Figure 18: The final foundation walls

Chapter 3 - Creating the Terrain

The purpose of this guide is to introduce the basics of terrain creation in Revit. This should explain the basics of pads and terrain.

Adding a Toposurface

- 1. Go to the following view: Sidebar Project Browser Floor Plans Site
- 2. Select the following tool: Massing & Site > Toposurface
- 3. Select the following options for Options Bar Elevation: to -0'6"
- 4. Add points to the left side of the building, like the figure 19




Figure 19: Initial topographic points

Work to make sure yours looks similar, not exact

- 5. Select the following options for Options Bar Elevation: to -10'
- 6. Select the points as in the figure 20
- 7. Select the following options for Options Bar Elevation: to -11'
- 8. Select the points as in the figure 21





Figure 20: Second set of topographic points

Work to make sure yours looks similar, not exact



Work to make sure yours looks similar, not exact

Figure 21: Third topographic points

Setting up a Building Pad

- 9. Having finished the terrain surface by clicking the big green checkmark.
- 10. To create a building pad click on each of the walls with the Massing & Site >> Building Pad tool.
- 11. Click each wall, finally click the purple line with three parallel lines attached: click it until the purples lines are only on the exterior of the walls. Reference figure 22

Make sure your pad looks like this, it's not essential but recommended

Remember that it's best to avoid adding excessive amounts of topographic points, which may slow your computer.

Figure 22: When building a pad, it's essential that it covers the buildings base, but doesn't extend past it. The pads purpose it to place a solid foundation base, while making sure that the terrain does not enter the floors of your building, so it removes any terrain where it's at.

Creating a 3D view

- 12. Click on the tool View 3d View, it will create a new view called | Sidebar | Project Browser | 3d Views | 43D} | right click on this view to rename it to something, I recommend To Building
- 13. select your renamed 3d View and use the 3D maneuvering square to change the view. Reference Figure 23



Figure 23: Use the 3d viewcube to move around the 3D environment. If you grip the sides and corners with your mouse, you can drag it to change your view.

The proficient use of this is essential, so make sure you focus on it in later projects.




Figure 24: It's Important that everything looks realistic. When presenting your building, you want to an accurate representation of what it would look like. If you wish for further information, either ask your teacher, or reference any information on rendering

Make sure your 3D view looks rather similar to this, but it will vary from person to person

Chapter 4 - Creating Exterior Walls, Floors, and Roofs

The purpose of this guide is to continue on the education of wall creation. This also touches on the creation of wall retained floors, and non retained floors.


Creating Exterior walls

Add walls to the entry level

- 1. go to the following view: Sidebar Project Browser Floor Plans 00 Entry Level
- 2. Create the following walls with these options:

Settings	Generic - 6"
Location Line	Core Face Interior
Base Constraint	02 Entry Level
Base Offset	0'0"
Top Constraint	Up to 03 Roof Level
Top Offset	0'0"

3. beginning at the bottom right, trace the interior of the three existing retaining walls, the three rightmost walls, by selecting endpoints. Reference figure 25.



Make sure your walls look like this, annotations excluded

If you are having issues with seeing objects below the current view level, then change the following settings. While you have the view selected in the Sidebar Properties there is an option called View Range, if you go into that setting and change the View Depth Level: option to the appropriate level you wish to have your view depth to.

Figure 25: The walls along the retaining walls which reach the exterior walls are meant to border the interior of the retaining walls. By selecting

Core Face Interior the walls are more easily alinged with the interior face of the walls.

Add walls to the Lower level

- 4. Open up the following: Sidebar Project Browser Floor Plans 01 Lower Level
- 5. Use the following settings:

Settings	Generic - 6"
Location Line	Core Face Interior
Base Constraint	01 Lower Level Level
Base Offset	0'0"
Top Constraint	Up to 03 Roof Level
Top Offset	0'0"

6. Trace the interior of the Foundation walls, the 5 leftmost walls. Reference figure 26





Figure 26: Lower Level Walls Make sure your walls look like this, annotations excluded



Your 3D view should now look rather similar to this

Creating a Roof

- 7. Go to the following view: Sidebar Project Browser Floor Plans 03 Roof Level
- 8. the tool you should use is called: Architecture Build Roof

Draw a roof line

- 9. When you select the roof tool, you are brought to the modify tab, you will want to select the line tool, which is under you to create a roof in the same was as a wall, except to create a roof, you must create a closed perimeter with your lines to define the roof.
- 10. Make sure the option: Options Bar Chain: is not checkmarked, this means that when you click to create two points, it automatically starts to make the next points.
- 11. Trace the southernmost walls past the end, where it becomes parallel with the endpoints of the rightmost wall. The intersection should look like Figure 28

Figure 27: This is the 3D view of the outer walls. If one of your walls is taller or shorter than the other, make sure that you have the correct height selected in your wall options.




Figure 28: when you push a line past a walls end, it will give you guides in relation to other objects in the project. So for this one, you will want to click only when it gives you guide lines that reach to the leftmost wall.

Bibliography

Autodesk. Getting Started with Autodesk Revit Building. Autodesk, 2006.

Autodesk. Revit. http://www.autodesk.com/products/revit-family/overview, 2016. Computer Software.