# **Orbital Contact Analyzer — User Manual**

#### Version:v1.0.0

**Scope:** Single-file, offline HTML app for simulating two Earth satellites and a ground station. The application uses a J2 perturbation model, renders 2D/3D views, visualizes sensor footprints and local horizons, and computes both satellite-to-satellite line-of-sight (LOS) and satellite-to-ground-station access intervals.

# 1) Overview

This app propagates two satellites using a model that includes J2 secular perturbations, converts positions between ECI and ECEF frames, and visualizes:

- **2D Map** (equirectangular) with ground tracks, current markers, optional sensor footprints (FOV), optional local horizons, and communication links.
- **3D Globe** (WebGL) with full camera control, physically correct inertial and Earth-fixed views, a full-screen "Focus Mode", and an optional Head-Up Display (HUD) showing live orbital elements.
- **Data Tables** for both Inter-Satellite LOS and Ground Station Access intervals, with a single-click CSV export for all contact data.

#### **Key design choices:**

- **J2 Perturbed propagation:** Includes secular effects on RAAN ( $\Omega$ ) and Argument of Perigee ( $\omega$ ).
- Spherical Earth model: Used for all ground geometry, occlusion checks, and footprint calculations.
- **Physically Correct Inertial View:** In 3D, enabling "Inertial View" fixes the orbital planes in space and shows the entire Earth system (globe, terminator, footprints, station) rotating correctly underneath.
- Global Epoch: The simulation timeline is anchored to a single, user-defined UTC epoch.

### 2) System Requirements

- A modern desktop browser with WebGL enabled (Chrome, Edge, Firefox, Safari).
- 8+ GB RAM recommended for long timelines or small time steps.
- Runs fully offline; no external network access is required.

# 3) Concepts in Brief

- Orbital Elements (per satellite):
  - a (km), e, i (deg),  $\Omega$  RAAN (deg),  $\omega$  argp (deg),  $v_0$  (deg) (true anomaly at the global epoch), and Min. elevation  $\varepsilon$  (deg) to define the sensor footprint.
- Ground Station: A point on the Earth's surface defined by Latitude, Longitude, and a Min. Elevation
   Mask (deg) used to calculate access.
- **J2 Perturbations:** The application models the primary secular (long-term) effects of Earth's equatorial bulge, which causes the orbital plane ( $\Omega$ ) and the orbit's orientation within that plane ( $\omega$ ) to precess over time.

- Frames:
  - **ECI** (Earth-Centered Inertial) for orbital dynamics; **ECEF** (Earth-Centered Earth-Fixed) for longitudes/latitudes and surface overlays.
- **Sensor Footprint (FOV):** The circular area on the Earth's surface visible to a satellite, defined by the minimum elevation angle (ε) from the ground to the satellite.
- **Local Horizon:** The physical limit of visibility from the satellite to the Earth's limb (a 0° elevation angle), appearing as a solid circle on the map/globe.
- **Inter-Satellite LOS:** A direct line-of-sight exists if the straight line connecting the two satellites is not obstructed by the spherical Earth.
- **Ground Station Access:** Access occurs when the elevation angle from the ground station up to a satellite is greater than the station's specified minimum elevation mask.

### 4) Quick Start

- 1. Open the HTML file in your browser.
- 2. In Simulation Controls, set the Epoch (UTC, ISO-8601), Step  $\Delta t$  (s), and Duration (min).
- 3. Configure orbital elements for **Satellite 1** and **Satellite 2**. Set the **Min. elevation \varepsilon (deg)** to define the sensor footprint (FOV).
- 4. Configure the **Ground Station** by setting its Latitude, Longitude, and Min. Elevation Mask.
- 5. Click **Recompute tracks**. Then click ► **Run** to animate.
- 6. Use the **Projection** dropdown to toggle between the 2D Map and 3D Globe.
- 7. For a larger view, click the **Focus Mode (`\mathscr{?}\)** button on the top-right of the map.
- 8. Observe the **Line-of-Sight** and **Ground Station Access** tables. Click **Export Contact Times (CSV)** to save all data.

**Tip:** If nothing moves, verify the **epoch** format, ensure **duration** > 0, and click **Recompute tracks** again.

### 5) Controls Reference

#### 5.1 Simulation Controls (top-left)

- **Epoch (UTC, ISO-8601):** Global start; valid ISO string like YYYY-MM-DDThh:mm:ssZ.
- Step Δt (s): Simulation step. Smaller is more precise but computationally slower.
- **Duration (min):** Total span simulated from the epoch.
- Playback speed: Visual playback rate when running.
- Buttons:
  - ▶ Run / Pause: Start/stop time stepping.
  - U **Reset:** Rewind to the epoch (keeps current inputs).
  - **Recompute tracks:** Re-runs the simulation with the current inputs.
  - Export Contact Times (CSV): Saves a CSV file with all computed LOS and GS Access intervals.

### **5.2 Satellite Panels**

#### Satellite 1 (blue) and Satellite 2 (orange) each include:

- a, e, i,  $\Omega$ ,  $\omega$ ,  $v_0$ : Standard classical orbital elements.  $v_0$  is the true anomaly at the global epoch.
- **Min. elevation ε (deg):** The elevation angle from the edge of the ground footprint up to the satellite. This defines the size of the dashed FOV circle.
- **Visibility Toggles:** Independent controls to show/hide the Satellite marker, its Track, its FOV circle, and its Horizon circle.

#### 5.3 Ground Station Panel

- Show Ground Station: Toggles visibility of the station and enables access calculations.
- Latitude (°): Station latitude (-90 to 90).
- Longitude (°): Station longitude (-180 to 180).
- Min Elev. Mask (°): The minimum elevation angle required for a satellite to be considered "in view" of the station.

#### 5.4 View Controls (right-side card)

#### 5.4.1 View Header

- Projection: Toggles between 2D Map and 3D Globe visualizations.
- Focus Mode (`↗`): Click to expand the view to fill the entire browser window for immersive analysis
  or presentations. The button icon changes to `∠`; click again to exit.

#### 5.4.2 3D Globe Controls

- Reset camera: Re-centers and re-zooms the globe to frame the orbits.
- Focus: None | Sat 1 | Sat 2. Automatically follows the selected satellite. Disables free-look mouse rotation.
- Show terminator: Toggles the day/night shading on the globe.
- Show link on LOS: Toggles the visibility of the green line connecting satellites when they have line-of-sight.
- Inertial view:
  - **ON:** A physically correct inertial view. Orbital tracks are fixed in space while the Earth and all surface overlays (terminator, footprints, ground station) rotate underneath.
  - **OFF:** A standard Earth-fixed (ECEF) view where the camera rotates with the Earth.
- Show Elements: Toggles the visibility of a Head-Up Display (HUD) in the top corners of the view. The HUD displays key orbital elements for each satellite. The values for a, e, and i are static, while  $\Omega$  (RAAN) and  $\omega$  (ArgP) are updated in real-time to show the live effects of J2 perturbations.
- **Trail (min):** Limits the length of the orbital trail drawn behind each satellite to the specified number of past minutes.

#### 5.4.3 Data Tables

Two tables are populated after clicking **Recompute tracks**:

- Line-of-Sight Intervals: Lists all time windows where the two satellites have a direct, unobstructed line of sight.
- Ground Station Access Intervals: Lists all time windows where a satellite is above the ground station's minimum elevation mask.

# 6) How The Physics Works (succinct)

- **Orbit propagation:** Two-body Keplerian motion with J2 secular perturbations applied to RAAN ( $\Omega$ ) and Argument of Perigee ( $\omega$ ) at each time step.
- ECI→ECEF: Standard transformation using Greenwich Mean Sidereal Time (GMST) for Earth's rotation.
- Footprint (FOV): The user's Min. elevation ε is converted to a sensor half-angle (η) via the sine rule: η
   = arcsin((R\_E \* cos(ε)) / (R\_E + h)). This angle defines the cone that creates the footprint circle on the
   surface.

- **Horizon:** Calculated as the physical limit of sight, where the elevation angle  $\varepsilon$  is 0°. The angular radius is  $\eta = \arccos(R_E / (R_E + h))$ .
- LOS test: Checks if the straight-line segment between the satellites' ECI positions intersects the Earth's spherical body.
- GS Access test: Calculates the elevation angle of the satellite relative to the ground station's local horizon. Access is true if this angle exceeds the station's Min. Elevation Mask.

**Constants:** Earth ( $\mu$  = 398600.4418 km<sup>3</sup>/s<sup>2</sup>); Earth radius (R\_E = 6378.137 km); J2 = 1.0826267e-3.

### 7) Typical Workflows

### A) Visualize a Sun-Synchronous Orbit

- 1. Set elements for a typical SSO (e.g., a=7078 km, e=0.001, i=98 deg).
- 2. Set a long **Duration** (e.g., 1440 min for one day). **Recompute tracks**.
- 3. Switch to **3D Globe** and enable **Inertial view**. In the 3D controls, check **Show Elements**.
- 4. Scrub the timeline and observe that the orbital plane maintains its orientation relative to the Sun. Notice in the HUD that the value for  $\Omega$  (RAAN) precesses slowly while other elements remain relatively stable, numerically confirming the SSO behavior.

### B) Follow one satellite in inertial space

- 1. Switch Projection=3D Globe; enable Inertial view.
- 2. Set Focus=Sat 1.
- 3. The camera will now "chase" Sat 1's ECI position, keeping it centered while the Earth rotates underneath.

### C) Extract all contact times

- 1. Configure both satellites and the ground station. Recompute tracks.
- 2. The **Line-of-Sight** and **Ground Station Access** tables will populate.
- 3. Click **Export Contact Times (CSV)** to save a single file containing both data sets, distinguished by a "type" column.

#### D) Conduct a presentation

- 1. Set up the desired scenario and click **Recompute tracks**.
- 2. Click the **Focus Mode** (`¬`) button to expand the visualization to full screen.
- 3. Use the scrub bar and playback controls to narrate the simulation. Click `∠` to exit.

#### 7.1 Suggested Time Steps

- **LEO**:  $\Delta t = 1-10 \text{ s}$ , Duration = **60-120 min**
- MEO: ∆t = 10-30 s, Duration = 1-6 h
- **GEO:** ∆t = **30-60 s**, Duration = **12-24 h**

Large  $\Delta t$  can visually alias fast motion; reduce  $\Delta t$  for close inspection.

# 8) Simulation Fidelity & Limitations

This application is designed as an educational tool, a demonstration platform, and for first-order analysis. It prioritizes interactivity, speed, and the clear visualization of core orbital mechanics concepts. To achieve this, several simplifying assumptions are made. For mission-critical analysis, always use a high-fidelity, validated simulation suite.

#### 8.1 J2 Dynamics Model

The J2 model is a significant improvement over simple two-body physics, as it correctly models the long-term precession of the orbit due to Earth's equatorial bulge. However, it does **not** include other major orbital perturbations, such as:

- Atmospheric Drag: Orbits will not decay; altitude and eccentricity remain constant. This is the largest source of error for LEO satellites.
- Solar Radiation Pressure (SRP): The small force exerted by sunlight is not modeled.
- Third-Body Gravity: Gravitational effects from the Moon, Sun, and other planets are ignored.
- **Higher-Order Gravity Fields:** Does not account for Earth's non-uniform mass distribution beyond the J2 term (e.g., tesseral harmonics).

#### 8.2 Spherical Ground Model

All calculations involving the Earth's surface assume a perfect sphere. This simplification has the following consequences:

- No Earth Oblateness: The model does not use a standard ellipsoid (like WGS-84). This can introduce small errors in ground track position and access calculations. Geodetic vs. geocentric latitudes are not distinguished.
- **No Terrain:** Ground station access calculations do not account for local terrain (mountains, valleys) that could block visibility in the real world.

### 9) Troubleshooting

- Can't rotate the globe? Check if Focus is set to Sat 1 or Sat 2. Set it to None to enable free-look camera controls.
- Nothing moves / index stuck at 0: Verify Epoch format; ensure Duration > 0; click Recompute tracks.
- Blank screen when switching views: This can happen during rapid layout changes. Try toggling Focus Mode again or resizing the browser window to force a redraw.
- **No footprints:** Ensure **Show FOV=Yes**. At very high altitudes, the sensor cone may not intersect the Earth.

# 10) Release Notes (Frame Edition Draft)

This version represents a major upgrade from a simple two-body visualizer to a more capable analysis tool. Key highlights include:

- **J2 Dynamics:** The propagator now includes J2 secular perturbations for more realistic long-term orbital precession.
- Ground Station: A fully configurable ground station has been added, with calculations and data export for satellite access times.
- **Physically Correct 3D View:** The "Inertial View" has been completely overhauled to correctly show the Earth rotating underneath fixed ECI orbits. All coordinate frames are now handled correctly in all

views.

- **"Focus Mode" UI:** The new `¬` button expands the visualization to fill the entire browser window for immersive analysis and presentations.
- Live Elements HUD: A new Head-Up Display can be toggled in the 3D view to show live, propagated orbital elements ( $\Omega$  and  $\omega$ ), making the effects of perturbations easy to see numerically.

Copyright © 2025 Paul Henkiel. All rights reserved.