Chapter 3

Governing Equations

3.1 Introduction

The governing equations are basically a set of equations which model a physical phenomena. In our context, they will be a set of partial differential equations (PDEs), also called system of PDEs. These equations define how different properties of interest vary within space and time. The properties of interest are called the dependent variables; and the space and time are called independent variables. The space is spanned by three mutually perpendicular axis denoted by the variables x, y, z and the variable for time is t. Choosing an origin point in space time and arbitrary values for variables x, y, z and t, the complete three dimensional space and time can be spanned. When we talk about solving the governing equations we need to restrict ourselves within a well defined bounded region in space and time. This is called the solution space. At the boundary of solution space we have to define additional conditions to obtain unique solutions.

The dependent variables are properties like pressure, density, temperature, velocity etc. The distribution of these properties is the solution that we are interested in for, say, designing a product or understanding the physics. The system of PDEs is said to be closed when the number of dependent variables are equal to the number of equations. In many cases, the number of equations are lesser than the number of dependent variables. We have to then use models relating different properties, thus adding more equations, to close the system of governing equations. These models are mostly based on empirical relations or simplified assumptions.

3.2 Generic form of system of PDEs

The governing PDEs used for simulation of various physical processes can be cast into a generic form given by,

$$\frac{\partial W}{\partial t} + \frac{\partial F_C}{\partial x} + \frac{\partial G_C}{\partial y} + \frac{\partial H_C}{\partial z} = \frac{\partial F_D}{\partial x} + \frac{\partial G_D}{\partial y} + \frac{\partial H_D}{\partial z} + S \ .$$

Here, W is known as the "conservative vector". It is named so because the variables in this vector are an outcome of application of conservation laws. The vectors F_C , G_C and H_C are called the "convective flux vectors". They are named so because they contain the product of velocity with terms from conservative vector. Therefore capturing the phenomena of translation of conserved quantities due to convection currents. Most importantly, the convective flux vector does not contain any terms with space derivatives and is purely a function of the conservative vector. The vectors F_D , G_D and H_D are called the "diffusion flux vectors". All the terms with space derivatives are placed in these vectors. The diffusion flux vector is called so due to the fact that the spatial derivatives will result in spreading (diffusion) of the quantities, even when the bulk fluid velocity is zero. The vector S is called the "source vector". All the remaining terms in the governing equation, which can be integrated over finite control spatial volume, are clubbed together in this vector. Take a look at the example PDEs in section 3.5 to have a better understanding of these terms.

In many practical applications the solution at the steady state is sought, which makes the time derivative term tend to zero. In such applications, solving time accurate PDEs is unnecessary and probably inefficient. We may therefore, include an additional artificial time derivative term which can be tweaked for efficient computations. The governing equations therefore becomes,

$$\frac{\partial U}{\partial \tau} + \frac{\partial W}{\partial t} + \frac{\partial F_C}{\partial x} + \frac{\partial G_C}{\partial y} + \frac{\partial H_C}{\partial z} = \frac{\partial F_D}{\partial x} + \frac{\partial G_D}{\partial y} + \frac{\partial H_D}{\partial z} + S \ .$$

Here, τ is called the artificial or pseudo time variable and t is the real time variable. The vector U is called the artificial or pseudo conservative vector and to distinguish from this vector, W is now onwards called the real conservative vector. The units of U and W are the same, however the actual terms may be completely different. It is a common practice to write U = PW, where P is a pre conditioner introduced to make the numerical calculations efficient and accurate. The flux and source vectors are functions of the artificial conservative vector. For steady state simulations the term $\partial W/\partial t = 0$ and for unsteady simulations $\partial W/\partial t \neq 0$. In both the cases (steady and unsteady simulations), the term $\partial U/\partial \tau$ must tend to zero for accepting the computational result.

The advantage of writing the governing equations in a generic form is that now it is possible to discuss the various CFD techniques in a well defined setting. Also, this approach makes it possible to derive efficient computational models and write computer programs which cater to a wide variety of applications.

3.3 Different types of variables

TODO

Conservative variables (artificial, real) Primitive variables Characteristic variables

3.4 Representation of governing equations in code

TODO

Variable conversions Convective flux Diffusive flux Source term

3.5 Few common governing equations

TODO

Navier Stokes
Euler
Stokes
shallow water
Axi symmetric flow
1D area varying nozzle
artificial compressibility
Incompressible with and without heat transfer
multiphase flow
Turbulence
Chemical reaction
Road traffic
Electromagnetism

3.6 Important properties of physical PDEs

TODO

Rotational invariance of system of PDEs Homogeneity of flux function Physical bounds on solutions