

Interrupts and Concurrency





Blocking I/O

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```

scan code arrives

Problem!

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```

scan code arrives

Interrupts, Redux


Cause processor to pause what it's doing and immediately execute interrupt code, returning to original code when done

- External events (reset, timer, GPIO)
- Internal events (bad memory access, bad instruction)
 - Sometimes called "exceptions;" different in that they imply code has to do something about the instruction that was interrupted

Concurrency

```
when a scan code arrives {
   add_scan_code_to_buffer();
}

while (1) {
   while (read_chars_from_buffer()) {}
   update_screen();
}
```



Last Lecture

Processor support for interrupts

- Registers to configure and enable/disable interrupts
- Interrupt mode with private sp, Ir, and CPSR registers
- 8 different interrupt cases (we only care about one)
- Processor expects table of instruction (one per interrupt) starting at address 0x0

When an interrupt is raised

- Processor switches to interrupt mode (Ir remembers where your program was interrupted)
- Processor jumps to one of 8 instruction in the table at address 0x0
- At that point, everything is software's responsibility

Interrupts are extremely valuable and seem simple, but getting them right requires using everything you've learned: assembly, linking, C, memory

Challenge

Processor specifies location (0x0) where it expects table of instructions, one per interrupt

- When an interrupt occurs, processor jumps to the corresponding instruction
- At that point, everything is software's responsibility

Writing code that can be safely copied to this location requires very careful assembly

 Have to make sure addresses are all absolute, and you know where they are stored code/vectors

Explicitly Embedded Absolute Addresses

```
.globl vectors
.globl vectors
vectors:
                                         vectors:
ldr pc, =abort asm
                                         ldr pc, = abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
ldr pc, =abort_asm
                                         ldr pc, = abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
ldr pc, =abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
                                         ldr pc, = abort asm
ldr pc, =interrupt asm
                                         ldr pc, = interrupt asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
                                         abort asm:
                                                             .word abort asm
                                         interrupt asm:
                                                             .word interrupt asm
```

Now we know the constants will follow the code. This works!!!

Explicitly Embedded Absolute Addresses

```
8 instructions starting
                                           .globl vectors
at 0x0
                                           vectors:
                                           ldr pc, = abort asm
CPU jumps to instr[6]
                                           ldr pc, = abort asm
                                           ldr pc, = abort asm
on a peripheral
                                           ldr pc, = abort asm
                                           ldr pc, = abort asm
                                           ldr pc, = abort asm
interrupt
                                           ldr pc, = interrupt asm
                                           ldr pc, = abort asm
                                           abort asm:
                                                              .word abort asm
                                           interrupt asm:
                                                              .word interrupt asm
```

Now we know the constants will follow the code. This works!!!

C Code

```
#define RPI_VECTOR_START 0x0
   int* vectorsdst = (int*)RPI VECTOR START;
   int* vectors = & vectors;
   int* vectors_end = &_vectors_end;
   while (vectors < vectors end)</pre>
      *vectorsdst++ = *vectors++;
0000807c < vectors>:
   807c:
              e59ff018
                              ldr
                                     pc, [pc, #24]
                                                    ; 809c <abort addr>
   8080:
              e59ff014
                              ldr
                                     pc, [pc, #20]
                                                    ; 809c <abort addr>
   8084:
              e59ff010
                             ldr
                                     pc, [pc, #16]
                                                    ; 809c <abort addr>
   8088:
              e59ff00c
                             ldr
                                     pc, [pc, #12]
                                                    ; 809c <abort addr>
                                                    ; 809c <abort addr>
   808c:
              e59ff008
                             ldr
                                     pc, [pc, #8]
   8090:
              e59ff004
                             ldr
                                     pc, [pc, #4]
                                                    ; 809c <abort addr>
   8094:
                             ldr
                                                    ; 80a0 <interrupt addr>
              e59ff004
                                     pc, [pc, #4]
   8098:
              e51ff004
                              ldr
                                     pc, [pc, \#-4]
                                                    ; 809c <abort addr>
   809c:
              000080a4
                              .word
                                     0x000080a4
                                     0x000080a8
   80a0:
              000080a8
                              .word
```

```
00000000 < vectors>:
    0000:
                 e59ff018
                                 ldr
                                          pc, [pc, #24]
                                                           ; 809c <abort addr>
                                 ldr
                                                           ; 809c <abort addr>
    0004:
                 e59ff014
                                          pc, [pc, #20]
    0008:
                e59ff010
                                 ldr
                                          pc, [pc, #16]
                                                           ; 809c <abort addr>
    000c:
                e59ff00c
                                 ldr
                                          pc, [pc, #12]
                                                           ; 809c <abort addr>
    0010:
                e59ff008
                                 ldr
                                                           ; 809c <abort addr>
                                          pc, [pc, #8]
    0014:
                                 ldr
                                                           ; 809c <abort addr>
                e59ff004
                                          pc, [pc, #4]
    0018:
                e59ff004
                                 ldr
                                          pc, [pc, #4]
                                                           ; 80a0 <interrupt addr>
    001c:
                e51ff004
                                 ldr
                                          pc, [pc, #-4]
                                                           ; 809c <abort addr>
    0020:
                 000080a4
                                          0x000080a4
                                  .word
    0024:
                 000080a8
                                          0x000080a8
                                  .word
```

interrupts_asm.s

```
interrupt_asm:
    mov    sp, #0x8000
    sub    lr, lr, #4
    push    {r0-r12, lr}
    mov    r0, lr
    bl    interrupt_dispatch
    ldm    sp!, {r0-r12, pc}^
```

Today

- 1. Set up the interrupt stack.
- 2. Install interrupt handler code.
- 3. Tell CPU when to trigger interrupts.
 - When PS/2 clock line has a falling edge
- 4. Enable interrupts!
- 5. Writing safe interrupt handlers.
 - How do you share state that can be modified at any time?

Three Layers


- I. Enable/disable a specific interrupt source
 - For example, when we detect a falling clock edge on GPIO_PIN23 (PS/2 CLK)
- 2. Enable/disable type of interrupts
 - E.g., GPIO interrupts
- 3. Global interrupt enable/disable

Interrupt fires if and only all three are enabled

Forgetting to enable one is a common bug

GPIO Events

Peripheral Registers



See gpioextra.h and gpioextra.c

GPIO Interrupts (pg. 96-98)

Goal: Trigger interrupt on falling edge of clock, read data line in interrupt handler.

Falling edge detect enable register (GPFENn)

• Lots of other options! High level, low level, rising edge, etc.

Event detect status register (GPEDSn)

- Bit is set when an event on the given pin occurs
- Clear event by writing I to position, or will re-trigger an interrupt!

Interrupt sources



BCM2835 ARM Peripherals


ARM peripherals interrupts table.

#	IRQ 0-15	#	IRQ 16-31	#	IRQ 32-47	#	IRQ 48-63
0		16		32		48	smi
1		17		33		49	gpio_int[0]
2		18		34		50	gpio_int[1]
3		19		35		51	gpio_int[2]
4		20		36		52	gpio_int[3]
5		21		37		53	i2c_int
6		22		38		54	spi_int
7	Docum	en	tation is s	bar	se	55	pcm_int
8		24		40		56	
9		25		41		57	uart_int
10		26		42		58	
11		27		43	i2c_spi_slv_int	59	
12		28		44		60	
13		29	Aux int	45	pwa0	61	
14		30		46	pwa1	62	
15		31		47		63	

what we want

The table above has many empty entries. These should not be enabled as they will interfere with the GPU operation.

Enabling Global Interrupts



```
.global interrupts_global_enable
interrupts_global_enable:
    mrs r0,cpsr
    bic r0,r0,#0x80
    // I=0 enables interrupts
    msr cpsr_c,r0
    bx lr
```

```
.global interrupts_global_disable
interrupts_global_disable:
    mrs r0,cpsr
    orr r0,r0,#0x80
    // I=1 disables interrupts
    msr cpsr_c,r0
    bx lr
```

code/button-interrupts

We're done!

We now can write correct and safe interrupt code

- Assembly to save all registers
- Call into C code
- Assembly to restore registers, return to interrupted code

We can install the interrupt code table to 0x0

- Embed addresses of assembly routines so jumps are absolute
- Copy interrupt table to 0x0 in cstart

Enable and disable interrupts

• Specific interrupts, per-peripheral interrupts, global interrupts

Not Quite

Need to be able to specify what code to run

- Interrupts are bottom-up
- The library implements the calling function: we implement the handlers that should run on different interrupts
- Need API to be able to do this

Need to write code that can be safely interrupted

- Interrupt handler may put a PS/2 scan code in a buffer
- Could do so at any time: in the middle of when main() code is trying to pull a scan code out of the buffer
- Need to make sure the interrupt doesn't corrupt the buffer

Interrupt API Goals

Speed!

 Minimize number of cycles spent in library: imagine if the handler is just a few instructions because we want to be able to run it very often

Avoid runtime failures (i.e., debugging)

 You should always be able to register one handler for each interrupt: whether you can register it should be independent of how many modules there are

Flexible


Allow you to easily add new modules that handle interrupts

Basic API

```
bool interrupts enable source(unsigned int source);
bool interrupts disable source(unsigned int source);
typedef bool (*handler fn t)(unsigned int);
handler fn t interrupts register handler (unsigned int source, handler fn t fn);
enum interrupt source {
  INTERRUPTS SHARED START = 29,
  INTERRUPTS AUX = 29,
  INTERRUPTS I2CSPISLV = 43,
  INTERRUPTS GPIO0 = 49,
  INTERRUPTS GPIO1 = 50,
  INTERRUPTS GPIO2 = 51,
  INTERRUPTS GPIO3 = 52,
  INTERRUPTS VC I2C = 53,
  INTERRUPTS VC SPI = 54,
  INTERRUPTS VC I2SPCM = 55,
  INTERRUPTS VC UART = 57,
};
```

Implementation

Array of function pointers, mirrors structure of interrupts



Not Quite

Need to be able to specify what code to run

- Interrupts are bottom-up
- The library implements the calling function: we implement the handlers that should run on different interrupts
- Need API to be able to do this

Need to write code that can be safely interrupted

- Interrupt handler may put a PS/2 scan code in a buffer
- Could do so at any time: in the middle of when main() code is trying to pull a scan code out of the buffer
- Need to make sure the interrupt doesn't corrupt the buffer

code/race

```
main code interrupt
extern int a; extern int a;
a = a + 1;
a = a - 1;
```

interrupt

extern int a;

8054: 00010070 .word 0x00010070

main code

8028: 00010070

extern int a;

```
a = a + 1;
                                         a = a - 1;
                                 <dec>:
<inc>:
8000: e52db004 push {fp}
                                 802c: e52db004 push {fp}
8004: e28db000 add fp, sp, #0
                                8030: e28db000 add fp, sp, #0
              ldr r3, [pc, #24] 8034: e59f3018 ldr r3, [pc, #24]
8008: e59f3018
800c: e5933000 ldr r3, [r3]
                         8038: e5933000 ldr r3, [r3]
             add r2, r3, #1 803c: e2432001 sub r2, r3, #1
8010: e2832001
              ldr r3, [pc, #12] 8040: e59f300c ldr r3, [pc, #12]
8014: e59f300c
              str r2, [r3]
                               8044: e5832000 str r2, [r3]
8018: e5832000
              sub sp, fp, #0 8048: e24bd000 sub sp, fp, #0
801c: e24bd000
              pop {fp}
                                               pop {fp}
8020: e49db004
                          804c: e49db004
8024: e12fff1e
              bx lr
                               8050: e12fff1e bx lr
```

word 0x00010070

interrupt

main code

```
extern int a;
                                          extern int a;
        a = a + 1;
                                            a = a - 1;
                                   <dec>:
<inc>:
8000: e52db004 push {fp}
                                   802c: e52db004 push {fp}
8004: e28db000 add fp, sp, #0 8030: e28db000 add fp, sp, #0
              ldr r3, [pc, #24] 8034: e59f3018 ldr r3, [pc, #24]
8008: e59f3018
              ldr r3, [r3] 8038: e5933000 ldr r3, [r3]
800c: e5933000
              add r2, r3, #1 803c: e2432001 sub r2, r3, #1
8010: e2832001
              ldr r3, [pc, #12] 8040: e59f300c ldr r3, [pc, #12]
8014: e59f300c
                          8044: e5832000
              str r2, [r3]
                                                  str r2, [r3]
8018: e5832000
              sub sp, fp, #0
pop {fp}

8048: e24bd000 sub sp, fp, #0
804c: e49db004 pop {fp}
801c: e24bd000
8020: e49db004
                                   8050: e12fff1e bx lr
8024: e12fff1e
              bx lr
8028: 00010070
              .word 0x00010070
                                   8054: 00010070 .word 0x00010070
```

Why will a decrement be lost if interrupt occurs here?

```
main code
                                 interrupt
       extern int a;
                                           extern int a;
        a = a + 1;
                                             a = a - 1;
                                    <dec>:
<inc>:
8000: e52db004 push {fp}
                                    802c: e52db004 push {fp}
8004: e28db000 add fp, sp, #0
                                    8030: e28db000 add fp, sp, #0
               ldr r3, [pc, #24]
8008: e59f3018
                                  code uses copy of a in r3, not
              ldr r3, [r3]_____
800c: e5933000
               add r2, r3, #1
8010: e2832001
                                  a; decrement is lost
               ldr r3, [pc, #12]
8014: e59f300c
                                                      10, [PC, "IL]
                                    8044: e5832000 str r2, [r3]
               str r2, [r3]
8018: e5832000
               sub sp, fp, #0
                                   8048: e24bd000 sub sp, fp, #0
801c: e24bd000
               pop {fp}
                                 804c: e49db004 pop {fp}
8020: e49db004
8024: e12fff1e
               bx lr
                                   8050: e12fff1e bx lr
8028: 00010070
               .word 0x00010070
                                    8054: 00010070 .word 0x00010070
```

Will volatile solve this?

Disabling Interrupts

main

interrupt handler

```
interrupts_global_disable();
a++;
b++;;
interrupts_global_enable();
```

Preemption and Safety

Very hard, lots of bugs.

You'll learn more in CS110/CS140.


Two simple answers

- I. Use simple, safe data structures
 - write once, but not always possible
- 2. Otherwise, temporarily disable interrupts
 - always works, but easy to forge
 - hard to compose (calling functions)

Concurrency

```
when a scan code arrives {
   add_scan_code_to_buffer();
}

while (1) {
   while (read_chars_from_buffer()) {}
   update_screen();
}
```



Safe Ring Buffer

```
bool rb enqueue(rb t *rb, int elem) {
    if (rb full(rb)) {
        return false;
    } else {
      rb->entries[rb->tail] = elem;
      rb->tail = (rb->tail + 1) % LENGTH; // only writes tail
      return true;
                                                               tail
}
ringbuffer
bool rb_dequeue (rb_t *rb, int *elem) {
                                                   head
    if (rb_empty(rb)) {
        return false;
    *elem = rb->entries[rb->head];
    rb->head = (rb->head + 1) % LENGTH; // only writes head
    return true;
}
```

This Lecture

Writing the code that runs in interrupts

- Assembly code needed to change to processor models and special registers
- Interrupt table copied to 0x0 in cstart.c

Setting up the CPU to issue interrupts

• 3 levels: cause, type, global

Writing code that can be safely interrupted

Race conditions though interrupt-safe ring buffer

Summary

Interrupts allow external events to preempt what's executing and run code immediately

- Needed for responsiveness, e.g., do not missing PS/2 scan codes from keyboard when drawing
- Without interrupts, most computers do nothing: they deliver keystrokes, network packets, disk reads, timers, etc.

Simple goal, but working correctly is very tricky!

Deals with many of the hardest issues in systems

Assignment 7: update keyboard to use interrupts