
Interrupts



Pardon the Interruption

Admin

Your system nearing completion -- exciting!

Interrupts

Today

Exceptional control flow

Suspend, jump to different code, then resume

How to do this safely and correctly

Focus on low-level mechanisms today

Friday

Using interrupts

Sharing data safely with interrupt code



```
while (1) {
   char ch = keyboard_read_next();
   update_screen();
}
```

How long does it take to send a scan code?

I I bits, clock rate I5kHz

How long does it take to update the screen?

What could go wrong?

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```

char arrives

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```

char arrives

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```

code/button-blocking

The Problem

Need long-running computations (graphics, computations, applications, etc.).

Need to respond to external events quickly.

How could we change this code?

```
while (1) {
   read_char_to_screen();
   update_screen();
}
```


Concurrency

```
when a scan code arrives {
  add scan code to buffer();
while (1) {
  // Doesn't block
  while (read chars to screen()) {}
  update screen();
}
                                l·····• time
  update_screen
                         proc
```

Hardware can help

```
bool uart_haschar(void)
{
    return (uart->lsr & MINI_UART_LSR_RX_READY);
}
unsigned char uart_recv(void)
{
    while (!uart_haschar());
    return uart->data & 0xFF;
}

void uart_send(unsigned char byte)
{
    while (!(uart->lsr & MINI_UART_LSR_TX_EMPTY));
    uart->data = byte & 0xFF;
}
```



Blocking I/O (HW help)

```
while (1) {
  while (read_chars_to_screen()) {}
  update_screen();
}
```

chars arrive, buffered in HW




Blocking I/O (HW help)

```
while (1) {
  while (read_chars_to_screen()) {}
  update_screen();
}
```

Can we still lose characters?

chars arrive, buffered in HW



Blocking I/O (HW help)

```
while (1) {
   while (read_chars_to_screen()) {}
   update_screen();
}
```

Yes! Chars overflow FIFO, dropped.



Interrupts to the rescue!

Cause processor to pause what it's doing and immediately execute interrupt code

- External events (peripherals, timer)
- Internal events (bad memory access, software trigger)

Critical for responsive systems, hosted OS

Interrupts are essential and powerful, but getting them right requires using everything you've learned: architecture, assembly, linking, memory, C, peripherals, ...

code/button-interrupt

interrupts_asm.s

```
interrupt_asm:
    mov    sp, #0x8000
    sub    lr, lr, #4
    push    {r0-r12, lr}
    mov    r0, lr
    bl    interrupt_dispatch
    ldm    sp!, {r0-r12, pc}^
```

What is happening in interrupt_asm? What happens to the stack pointer? Why do we save all of the registers?

Problem #1

```
Disassembly of section .text:
00008000 <_start>:
   8000: e3a0d902
                           mov sp, #32768 ; 0x8000
                                  8010 < cstart>
   8004: eb000001
                           bl
00008008 <hang>:
   8008: eb000039
                           bl
                                  80f4 < led_on>
   800c: eafffffe
                                  800c < hang + 0x4 >
00008010 <_cstart>:
                                  {fp, lr} Interrupt!
                           push
        e92d4800
   8010:
```

Need to know what instruction to return to after interrupt.

Where can we store that information?

We Need To

- I. Set up the interrupt stack.
- 2. Install interrupt handler code.
- 3. Tell CPU when to trigger interrupts.
 - When PS/2 clock line has a falling edge
- 4. Enable interrupts!
- 5. Writing safe interrupt handlers.
 - How do you share state that can be modified at any time?

Processor Modes


Dogiston	au pomicor	intorrupt	
Register	supervisor	interrupt	
R0	R0	R0	
RI	RI	RI	
R2	R2	R2	
R3	R3	R3	
R4	R4	R4	
R5	R5	R5	
R6	R6	R6	
R7	R7	R7	
R8	R8	R8	
R9	R9	R9	
RI0	RIO	RIO	
fp	RII	RII	
ip	R12	RI2	
sp	R13_svc	R13_irq	
Ir	R14_svc	R14_irq	
рс	R15	RI5	
CPSR	CPSR	CPSR	
SPSR	SPSR	SPSR	

Modes									
	•	Privileged modes							
	Exception modes								
User	System	Supervisor	Abort	Undefined	Interrupt	Fast interrup			
R0	R0	R0	R0	R0	R0	R0			
R1	R1	R1	R1	R1	R1	R1			
R2	R2	R2	R2	R2	R2	R2			
R3	R3	R3	R3	R3	R3	R3			
R4	R4	R4	R4	R4	R4	R4			
R5	R5	R5	R5	R5	R5	R5			
R6	R6	R6	R6	R6	R6	R6			
R7	R7	R7	R7	R7	R7	R7			
R8	R8	R8	R8	R8	R8	R8_fiq			
R9	R9	R9	R9	R9	R9	R9_fiq			
R10	R10	R10	R10	R10	R10	R10_fiq			
R11	R11	R11	R11	R11	R11	R11_fiq			
R12	R12	R12	R12	R12	R12	R12_fiq			
R13	R13	R13_svc	R13_abt	R13_und	R13_irq	R13_fiq			
R14	R14	R14_svc	R14_abt	R14_und	R14_irq	R14_fiq			
PC	PC	PC	PC	PC	PC	PC			
CPSR	CPSR	CPSR	CPSR	CPSR	CPSR	CPSR			
		SPSR_svc	SPSR_abt	SPSR_und	SPSR_im	SPSR_fig			

indicates that the normal register used by User or System mode has been replaced by an alternative register specific to the exception mode

Figure A2-1 Register organization

Processor Modes, Cont'd



interrupts_asm.s


```
interrupt_asm:
    mov    sp, #0x8000
    sub    lr, lr, #4
    push    {r0-r12, lr}
    mov    r0, lr
    bl    interrupt_dispatch
    ldm    sp!, {r0-r12, pc}^
```

How does the processor know to call interrupt_asm?

We Need To

- 1. Set up the interrupt stack.
- 2. Install interrupt handler code.
- 3. Tell CPU when to trigger interrupts.
 - When PS/2 clock line has a falling edge
- 4. Enable interrupts!
- 5. Writing safe interrupt handlers.
 - How do you share state that can be modified at any time?

CPU Address Space, Revisited



cstart.c

```
#define RPI_VECTOR_START 0x0
...

int* vectorsdst = (int*)RPI_VECTOR_START;
int* vectors = &_vectors;
int* vectors_end = &_vectors_end;
while (vectors < vectors_end)
   *vectorsdst++ = *vectors++;</pre>
```

Where are vectors and vectors end defined?

code/vectors

Desired Assembly

Generate this assembly code and copy it to exception table location (0x0000000).

```
0: b abort_asm
4: b abort_asm
8: b abort_asm
c: b abort_asm
10: b abort_asm
14: b abort_asm
18: b interrupt_asm
1c: b abort_asm
```

Use Branch Instructions

```
.globl _vectors
_vectors:
    b abort_asm
    b abort_asm
```

```
0000807c < vectors>:
    807c:
                ea000006
                                          809c < vectors end>
                                 b
    8080:
                ea000005
                                 b
                                          809c < vectors end>
    8084:
                ea000004
                                          809c < vectors end>
    8088:
                                 b
                                          809c < vectors end>
                ea000003
    808c:
                ea000002
                                          809c < vectors end>
    8090:
                ea000001
                                          809c < vectors end>
                                          80a0 <interrupt_asm>
    8094:
                ea000001
    8098:
                eaffffff
                                          809c < vectors end>
0000809c < vectors end>:
                eafffffe
                                 b
    809c:
                                         809c < vectors end>
000080a0 <interrupt asm>:
    80a0:
                e3a0d902
                                          sp, #32768
                                                           : 0x8000
                                 mov
```

Use Branch Instructions

```
.globl vectors
vectors:
                                                       These are relative jumps.
    b abort asm
                                                      If we move the code, they
    b abort asm
    b abort asm
                                                      won't jump to the right
    b abort asm
    b abort asm
                                                       address.
    b abort asm
    b interrupt asm
    b abort asm
               0000807c < vectors>:
                   807c:
                              ea000006
                                                     809c < vectors end>
                   8080:
                                                     809c < vectors end>
                              ea000005
                   8084:
                              ea000004
                                                     809c < vectors end>
                   8088:
                                                     809c < vectors end>
                              ea000003
                   808c:
                              ea000002
                                                     809c < vectors end>
                   8090:
                              ea000001
                                                     809c < vectors end>
                   8094:
                              ea000001
                                                     80a0 <interrupt asm>
                   8098:
                              eaffffff
                                                     809c < vectors end>
               0000809c < vectors end>:
                   809c:
                              eafffffe
                                             b
                                                     809c < vectors end>
               000080a0 <interrupt_asm>:
```

mov

sp, #32768

: 0x8000

80a0:

e3a0d902

Load Address Explicitly

```
.globl _vectors
_vectors:
    ldr pc, =abort_asm
    ldr pc, =abort_asm
```

Load Address Explicitly

```
.globl _vectors
_vectors:

ldr pc, =abort_asm
ldr pc, =interrupt_asm
ldr pc, =abort_asm
```

```
0000807c < vectors>:
    807c:
                                        pc, [pc, #52]
                e59ff034
                                ldr
                                                         ; 80b8 <interrupt asm+0x18>
    8080:
                                ldr
                                        pc, [pc, #48]
                                                         ; 80b8 <interrupt asm+0x18>
                e59ff030
                                                         ; 80b8 <interrupt asm+0x18>
    8084:
                e59ff02c
                                ldr
                                        pc, [pc, #44]
                                        pc, [pc, #40]
                                                         ; 80b8 <interrupt asm+0x18>
    8088:
                e59ff028
                                ldr
                                        pc, [pc, #36]
                                                         ; 80b8 <interrupt asm+0x18>
    808c:
                e59ff024
                                ldr
                                        pc, [pc, #32]
                                                         ; 80b8 <interrupt asm+0x18>
    8090:
                e59ff020
                                ldr
    8094:
                e59ff020
                                ldr
                                        pc, [pc, #32]
                                                         ; 80bc <interrupt asm+0x1c>
                                                         ; 80b8 <interrupt asm+0x18>
                                        pc, [pc, #24]
    8098:
                e59ff018
                                ldr
0000809c < vectors end>:
                                         809c < vectors end>
    809c:
                eafffffe
                                b
000080a0 <interrupt asm>:
    80a0:
                e3a0d902
                                         sp, #32768
                                                         ; 0x8000
                                mov
```

Load Address Explicitly

```
.globl _vectors
_vectors:

ldr pc, =abort_asm
```

Also gets turned into a relative load. If we move this code it won't work.

```
0000807c < vectors>:
    807c:
                                         pc, [pc, #52]
                e59ff034
                                 ldr
                                                          ; 80b8 <interrupt asm+0x18>
                                                          ; 80b8 <interrupt asm+0x18>
    8080:
                                 ldr
                                         pc, [pc, #48]
                e59ff030
    8084:
                e59ff02c
                                 ldr
                                                          ; 80b8 <interrupt asm+0x18>
                                         pc, [pc, #44]
    8088:
                e59ff028
                                 ldr
                                         pc, [pc, #40]
                                                         80b8 <interrupt asm+0x18>
                                         pc, [pc, #36]
                                                          ; 80b8 <interrupt_asm+0x18>
    808c:
                e59ff024
                                         pc, [pc, #32]
                                                          ; 80b8 <interrupt asm+0x18>
    8090:
                e59ff020
                                 ldr
    8094:
                e59ff020
                                 ldr
                                         pc, [pc, #32]
                                                          ; 80bc <interrupt asm+0x1c>
                                                          ; 80b8 <interrupt asm+0x18>
                                         pc, [pc, #24]
    8098:
                e59ff018
                                 ldr
0000809c < vectors end>:
    809c:
                eafffffe
                                 b
                                         809c < vectors end>
000080a0 <interrupt asm>:
    80a0:
                e3a0d902
                                         sp, #32768
                                                          ; 0x8000
                                 mov
```

Explicit Address v2

(if functions defined in different file so compiler can't use a relative load since their location is not known)

```
.globl vectors
vectors:
ldr pc, =abort asm
ldr pc, =interrupt asm
ldr pc, =abort asm
       0000807c < vectors>:
                                               pc, [pc, #24]
           807c:
                       e59ff018
                                       ldr
                                                              ; 809c < vectors end>
                                       ldr
                                               pc, [pc, #20]
           8080:
                                                              ; 809c < vectors end>
                       e59ff014
           8084:
                       e59ff010
                                       ldr
                                               pc, [pc, #16]
                                                              ; 809c < vectors end>
           8088:
                       e59ff00c
                                       ldr
                                               pc, [pc, #12]
                                                              : 809c < vectors end>
           808c:
                                                              : 809c < vectors end>
                                               pc, [pc, #8]
                       e59ff008
                                       ldr
                                               pc, [pc, #4]
                                                              ; 809c < vectors end>
           8090:
                       e59ff004
                                       ldr
           8094:
                       e59ff004
                                       ldr
                                               pc, [pc, #4]
                                                              ; 80a0 < vectors end+0x4>
           8098:
                                                               ; 809c < vectors end>
                       e51ff004
                                       ldr
                                               pc, [pc, #-4]
       0000809c <_vectors_end>:
           809c:
                                               0x000080a4
                       000080a4
                                       .word
           80a0:
                       000080a8
                                       .word
                                               0x000080a8
```

Explicit Address v2

(if functions defined in different file so compiler can't use a relative load since their location is not known)

```
.globl vectors
vectors:
                                                          These constants could end
ldr pc, =abort asm
ldr pc, =abort asm
                                                          up anywhere.
ldr pc, =abort asm
ldr pc, =abort asm
ldr pc, =abort asm
ldr pc, =abort asm
ldr pc, =interrupt asm
ldr pc, =abort asm
       0000807c < vectors>:
                                             pc, [pc, #24]
           807c:
                      e59ff018
                                      ldr
                                                             ; 809c < vectors end>
                                      ldr
                                             pc, [pc, #20]
           8080:
                                                             ; 809c < vectors end>
                      e59ff014
           8084:
                      e59ff010
                                      ldr
                                             pc, [pc, #16]
                                                             ; 809c < vectors end>
           8088:
                      e59ff00c
                                      ldr
                                             pc, [pc, #12]
                                                             : 809c < vectors end>
           808c:
                                                             : 809c < vectors end>
                                             pc, [pc, #8]
                      e59ff008
                                      ldr
                                             pc, [pc, #4]
                                                             ; 809c < vectors end>
           8090:
                      e59ff004
                                      ldr
           8094:
                      e59ff004
                                      ldr
                                             pc, [pc, #4]
                                                             ; 80a0 < vectors end+0x4>
                                                             ; 809c < vectors end>
           8098:
                      e51ff004
                                      ldr
                                              pc, [pc, #-4]
       0000809c <_vectors_end>:
           809c:
                       000080a4
                                      .word
                                              0x000080a4
           80a0:
                       000080a8
                                      .word
                                              0x000080a8
```

Explicitly Embedded Absolute Addresses

```
.globl vectors
.globl vectors
vectors:
                                         vectors:
ldr pc, =abort asm
                                         ldr pc, = abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
ldr pc, =abort_asm
                                         ldr pc, = abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
ldr pc, =abort asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
                                         ldr pc, = abort asm
ldr pc, =interrupt asm
                                         ldr pc, = interrupt asm
                                         ldr pc, = abort asm
ldr pc, =abort asm
                                         abort asm:
                                                             .word abort asm
                                         interrupt asm:
                                                             .word interrupt asm
```

Now we know the constants will follow the code. This works!!!

C Code

```
#define RPI_VECTOR_START 0x0
   int* vectorsdst = (int*)RPI VECTOR START;
   int* vectors = & vectors;
   int* vectors_end = &_vectors_end;
   while (vectors < vectors end)</pre>
      *vectorsdst++ = *vectors++;
0000807c < vectors>:
   807c:
              e59ff018
                              ldr
                                     pc, [pc, #24]
                                                    ; 809c <abort addr>
   8080:
              e59ff014
                              ldr
                                     pc, [pc, #20]
                                                    ; 809c <abort addr>
   8084:
              e59ff010
                             ldr
                                     pc, [pc, #16]
                                                    ; 809c <abort addr>
   8088:
              e59ff00c
                             ldr
                                     pc, [pc, #12]
                                                    ; 809c <abort addr>
                                                    ; 809c <abort addr>
   808c:
              e59ff008
                             ldr
                                     pc, [pc, #8]
   8090:
              e59ff004
                             ldr
                                     pc, [pc, #4]
                                                    ; 809c <abort addr>
   8094:
                             ldr
                                                    ; 80a0 <interrupt addr>
              e59ff004
                                     pc, [pc, #4]
   8098:
              e51ff004
                              ldr
                                     pc, [pc, \#-4]
                                                    ; 809c <abort addr>
   809c:
              000080a4
                              .word
                                     0x000080a4
                                     0x000080a8
   80a0:
              000080a8
                              .word
```

```
00000000 < vectors>:
    0000:
                 e59ff018
                                 ldr
                                          pc, [pc, #24]
                                                           ; 809c <abort addr>
                                 ldr
                                                           ; 809c <abort addr>
    0004:
                 e59ff014
                                          pc, [pc, #20]
    0008:
                e59ff010
                                 ldr
                                          pc, [pc, #16]
                                                           ; 809c <abort addr>
    000c:
                e59ff00c
                                 ldr
                                          pc, [pc, #12]
                                                           ; 809c <abort addr>
    0010:
                e59ff008
                                 ldr
                                                           ; 809c <abort addr>
                                          pc, [pc, #8]
    0014:
                                 ldr
                                                           ; 809c <abort addr>
                e59ff004
                                          pc, [pc, #4]
    0018:
                e59ff004
                                 ldr
                                          pc, [pc, #4]
                                                           ; 80a0 <interrupt addr>
    001c:
                e51ff004
                                 ldr
                                          pc, [pc, #-4]
                                                           ; 809c <abort addr>
    0020:
                 000080a4
                                          0x000080a4
                                  .word
    0024:
                 000080a8
                                          0x000080a8
                                  .word
```

Interrupts Review (so far)

Problem: responsive PS2 driver.

Answer: run interrupt code in response to events or inputs, CPU preempts execution, no blocking needed.

Requires setting up CPU to execute code, CPU provides some extra mechanisms and has different execution modes.

Hardware support for interrupts

Processor always executes in a particular "mode"

- Supervisor, interrupt, user, abort, ...
- Reset starts in supervisor mode (that's us!)
- Hardware monitors interrupt sources, when event occurs:

Pause current mode, switch to interrupt mode

CPSR register tracks current mode, processor state

- Special instructions copy val to regular register to read/write

Banked registers

- unique sp and Ir per-mode (sometimes others, too)

Interrupt vector

- fixed location in memory has instruction(s) to execute on interrupt

Installing Interrupt Code

The CPU will jump to specific addresses when an interrupt occurs.

We need to copy the code we want to run to these addresses.

Writing code that can be safely copied there requires a great deal of care, understanding assembly and linking.

Next Lecture

- 1. Set up the interrupt stack.
- 2. Install interrupt handler code.
- 3. Tell CPU when to trigger interrupts.
 - When PS/2 clock line has a falling edge
- 4. Enable interrupts!
- 5. Writing safe interrupt handlers.
 - How do you share state that can be modified at any time?