Cheatsheet for PyMAPDL



/ Launching PyMAPDL

To launch PyMAPDL instance locally and exit it

```
# To launch an instance
from ansys.mapdl.core import launch_mapdl
mapdl=launch_mapdl()
# To exit the instance
mapdl.exit()
```

To specify a jobname, number of processors, and working directory

To create and exit a pool of instances

```
# To create a pool of 10 instances
from ansys.mapdl.core import LocalMapdlPool
pool=mapdl.LocalMapdlPool(10)
# To exit the pool
pool.exit()
```

/ PyMAPDL Language

PyMAPDL commands are Python statements that act as a wrapper for APDL commands. For instance, ESEL, s, type,,1 is translated as

```
mapdl.esel('s','type',vmin=1)
```

Commands that start with * or / have those characters removed.

```
mapdl.get() # /PREP7
mapdl.get() # *GET
```

In cases where removing * or / will cause conflict with other commands, a prefix "slash" or "star" is added.

```
mapdl.solu()  # SOLU
mapdl.slashsolu()  # /SOLU

mapdl.vget()  # VGET
mapdl.starvget()  # *VGET
```

Converting an existing APDL script to PyMAPDL format

```
inputfile='ansys_inputfile.inp'
pyscript='pyscript.py'
mapdl.convert_script(inputfile,pyscript)
```

/ MAPDL Class

Load a table from Python to MAPDL

```
mapdl.load_table(name,array,var1=''', var2=''',
    var3=''', csysid=''')
```

To access from or write parameters to MAPDL database

```
# To save a parameter named 'displ_load' to a
    NumPy array nparray
nparray=mapdl.parameters['displ_load']
# To create a parameter named 'exp_disp' from a
    NumPy array nparray
mapdl.parameters['exp_disp']=nparray
```

To access information using *GET and *VGET directly to NumPy arrays

```
# Runs the *GET command and returns a Python
    value.
mapdl.get_value(entity='', entnum='', item1='',
    it1num='', item2='', it2num='', **kwargs)

# Runs *VGET command and returns a Python array
mapdl.get_array(entity='', entnum='', item1='',
    it1num='', item2='', it2num='', kloop='',
    **kwargs)
```

/ Mesh Class

Store the finite element mesh as a VTK Unstructured Grid data object.

```
grid = mapdl.mesh.grid
```

Save element & node numbers to Python arrays.

```
# Array of nodal coordinates
nodes=mapdl.mesh.nodes

# Save node numbers of selected nodes to array
node_num=mapdl.mesh.nnum

# Save node numbers of selected nodes to array
node_num_all=mapdl.mesh.nnum_all

# Element numbers of currently selected
        elem_num=mapdl.mesh.enum

# Array of all element numbers, even those not
        selected.
elem_num_all=mapdl.mesh.enum_all
```

/ Post-processing Class

To plot results the general form is: mapdl.postprocessing.result_name

```
mapdl.post1()
mapdl.set(1, 2)
# To plot the nodal equivalent stress
mapdl.post_processing.plot_nodal_eqv_stress()
# To save nodal eqv. stresses to a Python array
nod_eqv_stress=mapdl.post_processing.
    nodal_eqv_stress()
# To plot the contour legend or Scalar bar
   using python data structure dictionary
mapdl.allsel()
sbar_kwargs = {"color": "black", "title": "1st,,
    Principal, Stress, (psi)", "vertical": False,
     "n_labels": 6}
mapdl.post_processing.
    plot_nodal_principal_stress('1', cpos='xy',
     background = 'white', edge_color = 'black',
    show_edges=True, scalar bar_args=
    sbar_kwargs, n_colors=9)
```

/ Plotting Class

General PyMAPDL plotter for APDL geometry and meshes is: plotting.general_plotter(meshes, points, labels)

References from PyMAPDL Documentation

- · Getting Started
- MAPDL Commands
- · API Reference