What is a control sequence?

A control sequence is a comprehensive system control algorithm formulated using primarily English with some mathematical expressions.


Example English language specification from ASHRAE's primary system control sequence specification document (RP 1711) with the corresponding CDL implementation:

Hysteresis:

"Control some signal to be:

True if T_out>T_loc

False if T_out<T_loc- 1°F"




Lack of explicit definitions in RP1711 sequences

To implement sequences in CDL sometimes one needs to implement additional calculations. These might need to get specified in the Guideline in the future. Often the reason behind it are ALC EIKON features, such as a hysteresis inbuilt in quantity comparison blocks. Two examples:

• When doing stepwise integration with limiters, an anti-windup needs to be implemented:


"Increase "m" by 0.02 when the economizer is disabled if the economizer remained enabled for less than 30 minutes ...


"m" shall be limited to the range of -0.2 to 0.5."



 When performing quantity comparisons on analogue values (real numbers, for example fan speed), such as greater and smaller than, a hysteresis block needs to be implemented to account for effects such as sensor noise. This is not applicable for time measurement (for example timing delays). <u>Click to see more info from user quide.</u>

"WseTower-MaxSpeed did not decrease below 100% speed"





Example chiller plant

Control intent:

 Supply chilled water to cover cooling demand

Refrigeration cycle and mechanical constraints:

- Minimum lift (controlled on the condenser side)
- Minimum chilled water flow (evaporator side)
- Equipment ramp-up times and system inertia


Efficiency constraint:

Minimize energy use


ASHRAE RP-1711:

Advanced Sequences of Operation for HVAC Systems Phase II - Central Plants and Hydronic Systems

6.5 Chilled Water Plants: Series Chillers with WSE, Variable Primary CHW, Variable CW, Headered Pumps



Overarching approach to device status control




Library package

- OBC **ASHRAE** 36 PR1 PrimarySystem ChillerPlant Economizer Generic HeadPressure MinimumFlowBypass Pumps SetPoints Staging Tower Types
- Package structure

- S ASHRAE 36 PR1 ▼ PrimarySystem ChillerPlant → Conomizer Controller Subsequences ▶ Validation → 🔐 Generic PlantEnable EquipmentRotation ControllerTwo **Subsequences** ▶ Validation ▶ Validation → □ HeadPressure Controller Subsequences ▶ Validation ▼ MinimumFlowBypass Controller Subsequences ▶ Validation → Pumps - ChilledWater Controller Subsequences ▶ Validation ▼ ○ CondenserWater Controller Subsequences Package ▶ Validation ▶ S SetPoints structure ▶ Staging expanded ▶ Se Tower

→ Types

Subpackage architecture



- Subsequences
- ContinuousLeadSwapTwo

RuntimeCounter uDevRol

RuntimeCounter

ControllerTwo

- Scheduler
- Two
 Validation
- ContinuousLeadSwapTwo uDevSta
- **(b)**
 - Scheduler
- ► Two_uRot

 Validation

ControllerTwo


Controller architecture

Master controller

ASHRAE RP-1711:

Advanced Sequences of Operation for HVAC Systems Phase II - Central Plants and Hydronic Systems

6.5 Chilled Water Plants: Series Chillers with WSE, Variable Primary CHW, Variable CW, Headered Pumps




Dedicated controllers

ASHRAE RP-1711:


Advanced Sequences of Operation for HVAC Systems Phase II – Central Plants and Hydronic Systems

6.5 Chilled Water Plants: Series Chillers with WSE, Variable Primary CHW, Variable CW, Headered Pumps




Staging configurator:

Involved usage of arrays



Stage change parameterization: usage of arrays



How you can contribute

- Feedback on controller architecture
- Feedback on usage of arrays
- Sequence implementation review (chiller plant)
- Sequence development
 - Boiler plant
 - Basic blocks such as heat recovery, room thermostat
 - Additional sequences for: radiant heating and cooling, secondary