# Package 'GR2MSemiDistr'

October 18, 2021

	October 16, 2021
Type Package	
Title A package for hydrolog model adaptation in larg	ical modeling with a semi-distribute GR2M ge-sample studies.
Version 4.0.0	
Author Harold Llauca <hlla< th=""><th>uca@senamhi.gob.pe&gt;</th></hlla<>	uca@senamhi.gob.pe>
Maintainer Harold Llauca <	nllauca@senamhi.gob.pe>
	n a semi-distributed GR2M model adaptation us- Accumulation algorithm in TauDEM_537 (required)
License GPL (>= 2)	
Encoding UTF-8	
<b>Depends</b> R (>= $4.0$ ),	
Imports airGR, foreach, hydlubridate, sf, exactextra	roGOF, raster, rgdal, rgeos, rtop, tictoc, ctr, parallel,
LazyData true	
RoxygenNote 7.1.2	
R topics documente	d:
Optim_GR2MSemiI Routing_GR2MSem	uts
Index	
Create_Forcing_Inputs	Extract and prepare model's inputs data in the airGR format (DatesR, P and E) from gridded P and E monthly data.

## Description

Extract and prepare model's inputs data in the airGR format (DatesR, P and E) from gridded P and E monthly data.

#### Usage

```
Create_Forcing_Inputs(
   Subbasins,
   Precip,
   PotEvap,
   Qobs = NULL,
   DateIni,
   DateEnd,
   Save = FALSE,
   Update = FALSE,
   Resolution = 0.01,
   Buffer = 1.1,
   Members = NULL
)
```

#### **Arguments**

Subbasins	Subbasins'	chanefile	Must contain	the following	attributec	'Area'	(in km2)

'Region' (in letters), and 'COMID' (identifier number).

Precip Raster brick of the precipitation data in [mm/month].

PotEvap Raster brick of the evapotranspiration data in [mm/month].

Qobs Observed streamflow data in [m3/s] at the basin outlet. Must have the same

length as P and E data (including NA values). NULL as default.

DateIni Initial date of the database in 'mm/yyyy' format.

DateEnd Ending date of the database in 'mm/yyyy' format.

Save Boolean to save results as a text file in the 'Outputs' location. FALSE as default.

Update Boolean for the updating mode where only the last month's values will be re-

turned. FALSE as default.

Resolution Resampling resolution for improving subbasins' data extraction. 0.01degrees as

default.

Buffer Factor for increase subbasins' limits extents. 1.1 as default.

Members Número de miembros del conjunto modelo. Only for streamflow forecasting

purposes. NULL por defecto.

## Value

Return a dataframe of model's inputs data in the airGR format (DatesR, P, E, Q).

## References

Cesar Aybar, Carlos Fernández, Adrian Huerta, Waldo Lavado, Fiorella Vega & Oscar Felipe-Obando (2020) Construction of a high-resolution gridded rainfall dataset for Peru from 1981 to the present day, Hydrological Sciences Journal, 65:5, 770-785, DOI: 10.1080/02626667.2019.1649411

Llauca H, Lavado-Casimiro W, Montesinos C, Santini W, Rau P. PISCO\_HyM\_GR2M: A Model of Monthly Water Balance in Peru (1981–2020). Water. 2021; 13(8):1048. https://doi.org/10.3390/w13081048

## **Examples**

Optim\_GR2MSemiDistr

Model parameter optimization with the SCE-UA algorithm.

## **Description**

Model parameter optimization with the SCE-UA algorithm.

## Usage

```
Optim_GR2MSemiDistr(
  Data,
  Subbasins,
  RunIni,
  RunEnd,
  WarmUp = NULL,
  Parameters,
  Parameters.Min,
  Parameters.Max,
  Max.Functions = 5000,
  Optimization = "NSE",
  No.Optim = NULL
)
```

## Arguments

Data	Dataframe with model input's data in airGR format from Create_Forcing_Inputs. (DatesR, P_1, P_2,,P_n, E_1, E_2,E_n, Q). If Q is not available please provide only DatesR, P, and E.
Subbasins	Subbasins' shapefile. Must contain the following attributes: 'Area' (in km2), 'Region' (in letters), and 'COMID' (identifier number).
RunIni	Initial date of the model simulation in 'mm/yyyy' format.
RunEnd	Ending date of the model simulation in 'mm/yyyy' format.
WarmUp	Number of months for the warm-up period. NULL as default.

Parameters Vector of initial model parameters (X1 and X2) and correction factors of P (fp) and E (fpe) in the following order: c(X1, X2, fp, fpe). In the case of existing more than one 'Region' (e.g. regions A and B) please provide model parameters in the following order: c(X1\_A, X1\_B, X2\_A, X2\_B, Fp\_a, Fp\_B, Fpe\_A,

Fpe\_B).

Parameters. Min Vector of minimum values of GR2M model parameters and correction factors in

the following order: c(X1\_min, X2\_min, fp\_min, fpe\_min).

Parameters.Max Vector of maximum values of GR2M model parameters and correction factors

in the following order: c(X1\_max, X2\_max, fp\_max, fpe\_max).

Max.Functions Maximum number of function evaluation for optimization. 5000 as default.

Optimization Objective function for optimization (NSE, KGE, or RMSE).

No.Optim Regions not to be optimized. NULL as default.

#### Value

List of optimal GR2M model parameters for each 'Region'.

Param: Best set of GR2M model parameters (sorted by 'Region').

Value: Final value of the objective function.

#### References

Llauca H, Lavado-Casimiro W, Montesinos C, Santini W, Rau P. PISCO\_HyM\_GR2M: A Model of Monthly Water Balance in Peru (1981–2020). Water. 2021; 13(8):1048. https://doi.org/10.3390/w13081048

## **Examples**

Routing\_GR2MSemiDistr Routing discharges for each subbasin.

## Description

Routing discharges for each subbasin.

#### Usage

```
Routing_GR2MSemiDistr(
  Model,
  Subbasins,
  Dem,
  AcumIni = NULL,
  AcumEnd = NULL,
  Save = FALSE,
  Update = FALSE
)
```

#### **Arguments**

Model List of model results from Run\_GR2MSemiDistr.

Subbasins Subbasins' shapefile. Must contain the following attributes: 'Area' (in km2),

'Region' (in letters), and 'COMID' (identifier number).

Dem Digital elevation model raster for the extent of the basin.

AcumIni Initial date of the model routing in 'mm/yyyy' format. NULL as default

AcumEnd Ending date of the model routing in 'mm/yyyy' format. NULL as default

Save Boolean to save results as a text file in the 'Outputs' location. FALSE as default.

Update Boolean for the updating mode where only the last month's values will be re-

turned. FALSE as default.

#### Value

List of model routing outputs.

QR: Routed discharge timeseries for all subbasins in [m3/s].

Dates: Vector of dates of the simulation period.

COMID: Vector of identifier numbers for each subbasin.

## Author(s)

Llauca H, Lavado-Casimiro W, Montesinos C, Santini W, Rau P. PISCO\_HyM\_GR2M: A Model of Monthly Water Balance in Peru (1981–2020). Water. 2021; 13(8):1048. https://doi.org/10.3390/w13081048

## **Examples**

Run\_GR2MSemiDistr

Run the GR2M model for 'n' subbasins.

#### **Description**

Run the GR2M model for 'n' subbasins.

## Usage

```
Run_GR2MSemiDistr(
  Data,
  Subbasins,
  RunIni,
  RunEnd,
  WarmUp = NULL,
  Parameters,
  IniState = NULL,
  Save = FALSE,
  Update = FALSE
)
```

## **Arguments**

Data Dataframe with model input's data in airGR format from Create\_Forcing\_Inputs.

(DatesR, P\_1, P\_2,...,P\_n, E\_1, E\_2, ...E\_n, Q). If Q is not available please pro-

vide only DatesR, P, and E.

Subbasins Subbasins' shapefile. Must contain the following attributes: 'Area' (in km2),

'Region' (in letters), and 'COMID' (identifier number).

RunIni Initial date of the model simulation in 'mm/yyyy' format.

RunEnd Ending date of the model simulation in 'mm/yyyy' format.

WarmUp Number of months for warm-up. NULL as default.

Parameters Vector of model parameters (X1 and X2) and correction factors of P (fp) and

E (fpe) in the following order: c(X1, X2, fp, fpe). In the case of existing more than one 'Region' (e.g. regions A and B) please provide model parameters in the following order: c(X1\_A, X1\_B, X2\_A, X2\_B, Fp\_a, Fp\_B, Fpe\_A, Fpe\_B).

IniState Initial states variables. NULL as default.

Boolean to save results as a text file in the 'Outputs' location. FALSE as default.

Update

Boolean for the updating mode where only the last month's values will be re-

turned. FALSE as default.

#### Value

List of GR2M model outputs.

PR: Precipitation timeseries for all subbasins in [mm/month].

AE: Actual evapotranspiration timeseries for all subbasins in [mm/month].

SM: Soil Moisture timeseries for all subbasins in [mm/month].

RU: Runoff timeseries for all subbasins in [mm/month].

Run\_GR2MSemiDistr 7

QS: Discharge timeseries for all subbasins in [m3/s] (not routed).

Dates: Vector of dates of the simulation period.

COMID: Vector of identifier numbers for each subbasin.

EndState: List of end model states of each subbasin.

SINK: Basin outlet which contains qsim and qobs data time series in [m3/s].

#### References

Llauca H, Lavado-Casimiro W, Montesinos C, Santini W, Rau P. PISCO\_HyM\_GR2M: A Model of Monthly Water Balance in Peru (1981–2020). Water. 2021; 13(8):1048. https://doi.org/10.3390/w13081048

## **Examples**

## Index

```
Create_Forcing_Inputs, 1
Optim_GR2MSemiDistr, 3
Routing_GR2MSemiDistr, 4
Run_GR2MSemiDistr, 6
```