
ARM Addressing Modes

Review of ARM Registers Set

As mentioned in the previous lab, ARM has 16 programmer-visiable registers and a *Current Program Status Register*, CPSR.

Here is a picture to show the **ARM register set**.



```
R0 to R12 are the general-purpose registers.
R13 is reserved for the programmer to use it as the stack pointer.
R14 is the link register which stores a subroutine return address.
R15 contains the program counter and is accessible by the programmer.


Conditonion code flags in CPSR:
N - Negative or less than flag
Z - Zero flag
C - Carry or bowrrow or extendedflag
V - Overflow flag
The least-significant 8-bit of the CPSR are the control bits of the system.
The other bits are reserved.
```

Summary of ARM addressing Modes

There are different ways to specify the address of the operands for any given operations such as load, add or branch. The different ways of determining the address of the operands are called addressing modes. In this lab, we are going to explore different addressing modes of ARM processor and learn how all instructions can fit into a single word (32 bits).

Name	Alternative Name	ARM Examples
Register to register	Register direct	MOV R0, R1
Absolute	Direct	LDR R0, MEM
Literal	Immediate	MOV R0, #15 ADD R1, R2, #12
Indexed, base	Register indirect	LDR R0, [R1]
Pre-indexed, base with displacement	Register indirect with offset	LDR R0, [R1, #4]
Pre-indexed, autoindexing	Register indirect pre-incrementing	LDR R0, [R1, #4]!
Post-indexing, autoindexed	Register indirect post-increment	LDR R0, [R1], #4
Double Reg indirect	Register indirect Register indexed	LDR R0, [R1, R2]
Double Reg indirect with scaling		LDR R0, [R1, r2, LSL #2]
Program counter relative		LDR R0, [PC, #offset]

Literal Addressing



Examples	Meaning
CMP R0, #22	
ADD R1, R2, #18	
MOV R1, #30	
MOV R1, #0×FF	
MOV R2, #0xFF0000FF	
AND R0, R1, #0xFF000000	
CMN R0, #6400 ;	update the N, Z, C and V flags
CMPGT SP, R7, LSL #2 ;	update the N, Z, C and V flags

Register Indirect Addressing

Register indirect addressing means that the location of an operand is held in a register. It is also called indexed addressing or base addressing.

Register indirect addressing mode requires three read operations to access an operand. It is very important because the content of the register containing the pointer to the operand can be modified at runtime. Therefore, the address is a vaiable that allows the access to the data structure like arrays.

- Read the instruction to find the pointer register
- Read the pointer register to find the oprand address
- Read memory at the operand address to find the operand

Some examples of using register indirect addressing mode:

```
LDR R2, [R0] ; Load R2 with the word pointed by R0

STR R2, [R3] ; Store the word in R2 in the location pointed by R3
```

Register Indirect Addressing with an Offset

ARM supports a memory-addressing mode where the effective address of an operand is computed by adding the content of a register and a literal offset coded into load/store instruction. For example,

```
Instruction Effective Address

LDR R0, [R1, #20] R1 + 20 ; loads R0 with the word pointed at by R1+20
```

ARM's Autoindexing Pre-indexed Addressing Mode

This is used to facilitate the reading of sequential data in structures such as arrays, tables, and vectors. A pointer register is used to hold the base address. An offset can be added to achieve the effective address. For example.

```
Instruction Effective Address

LDR R0, [R1, #4]! R1 + 4 ; loads R0 with the word pointed at by R1+4
; then update the pointer by adding 4 to R1
```

ARM's Autoindexing Post-indexing Addressing Mode

This is similar to the above, but it first accesses the operand at the location pointed by the base register, then increments the base register. For example,

```
Instruction Effective Address

LDR R0, [R1], #4 R1 ; loads R0 with the word pointed at by R1
```

```
; then update the pointer by adding 4 to R1
```

Program Counter Relative (PC Relative) Addressing Mode

Register R15 is the program counter. If you use R15 as a pointer register to access operand, the resulting addressing mode is called PC relative addressing. The operand is specified with respect to the current code location. Please look at this example,

```
Instruction Effective Address

LDR R0, [R15, #24] R15 + 24 ; loads R0 with the word pointed at by R1+24
```

ARM's Load and Store Encoding Format


The following picture illustrates the encoding format of the ARM's load and store instructions, which is included in the lab material for your reference. Memory access operations have a conditional execution field in bit 31, 03, 29, and 28. The load and store instructions can be conditionally executed depending on a condition specified in the instruction. Now look at the following examples:

```
CMP R1, R2

LDREQ R3, [R4]

LDRNE R3, [R5]
```

Encoding Format of ARM's load and store instructions



Summary of ARM's Indexed Addessing Modes

Addressing Mode	Assembly Mnemonic	Effective address	FinalValue in R1
Pre-indexed, base unchanged	LDR R0, [R1, #d]	R1 + d	R1
Pre-indexed, base updated	LDR R0, [R1, #d]!	R1 + d	R1 + d
Post-indexed, base updated	LDR R0, [R1], #d	R1	R1 + d

An Example Program of Using Post-indexing Mode

```
;The semicolon is used to lead an inline documentation
;When you write your program, you could have your info at the top document block
;For Example: Your Name, Student Number, what the program is for, and what it does etc.

; This program will find the sum of an array.

;;; Directives
```

```
PRESERVE8
          THUMB
; Vector Table Mapped to Address 0 at Reset
; Linker requires ___Vectors to be exported
                  RESET, DATA, READONLY
          AREA
          EXPORT ___Vectors
 Vectors
          DCD 0x20001000
                              ; stack pointer value when stack is empty
          DCD Reset_Handler ; reset vector
          ALIGN
;Your Data section
        ;AREA DATA
       DCD 0
SUMP
       DCD SUM
       DCD 5
NUM1
       DCD 3, -7, 2, -2, 10
POINTER DCD NUM1
; The program
; Linker requires Reset_Handler
                  MYCODE, CODE, READONLY
          AREA
          ENTRY
          EXPORT Reset_Handler
Reset_Handler
;;;;;;;;User Code Start from the next line;;;;;;;;;;;
        LDR R1, N
        LDR R2, POINTER
        MOV R0, #0
LOOP
        LDR R3, [R2], #4
        ADD R0, R0, R3
        SUBS R1, R1, #1
        BGT LOOP
        LDR R4, SUMP
       STR R0, [R4]
STOP
        B STOP
        END
```

Another Example

```
;The semicolon is used to lead an inline documentation;
```

```
;When you write your program, you could have your info at the top document block
;For Example: Your Name, Student Number, what the program is for, and what it does etc.
       This program will count the length of a string.
;;; Directives
         PRESERVE8
         THUMB
 Vector Table Mapped to Address 0 at Reset
; Linker requires ___Vectors to be exported
                RESET, DATA, READONLY
         AREA
         EXPORT Vectors
 Vectors
         DCD 0x20001000
                           ; stack pointer value when stack is empty
         DCD Reset Handler ; reset vector
         ALIGN
; Character array - string
; This type of format will construct a C string and null terminate.
 This means you can tell when the string ends
string1
       DCB
              "Hello world!",0
; The program
 Linker requires Reset_Handler
              MYCODE, CODE, READONLY
       AREA
       ENTRY
       EXPORT Reset_Handler
Reset Handler
;;;;;;;;User Code Start from the next line;;;;;;;;;;;
       LDR
              R0, = string1
                            ; Load the address of string1 into the register R0
       MOV
              R1, #0
                            ; Initialize the counter counting the length of string1
loopCount
                            ; Load the character from the address R0 contains
       LDRB
              R2, [R0], #1
                            ; and update the pointer R0
                            ; using Post-indexed addressing mode
       CBZ
                            ; If it is zero...remember null terminated...
              R2, countDone
                            ; You are done with the string. The length is in R1.
                            ; Otherwise, increment index to the next character
       ; ADD
              R0, #1;
       ADD
              R1, #1;
                            ; increment the counter for length
       В
              1oopCount
```

```
countDone
        В
                CountDone
        END
                                 ; End of the program
```

Lab Assignment





Copyright: Department of Computer Science, University of Regina.