Hollasynth Scanner Bill of Materials, 12 October 2019

-	Designators	
		All 1%, 250mW.
4	R20,R21,R26,R27	
1		
5	n10,n17,n40,n40,n47	
0	1410	Forrito hood, or amit and use wire link
2	عارد	Ferrite bead, or omit and use wire link
	TD1 TD2 TD4	Pourpo 2262P et do
		Bourns 3362P style
1	IH5	Bourns 3362P style
		Ceramic cap, C0G, 5mm spacing
		Ceramic cap, 5mm spacing. *optional, see notes
2	C2,C4	Electrolytic, 25V or higher rating
14	C1,C3,C5,C6,C9,C10,C11,C12,C13,C14,C20,C21,C22,C23	X7R, 25V or higher
1	U4	
2	U1,U2,U3	
2	U5,U6	
10	D1,D2,D3,D4,D5,D6,D7,D8,D9,D10	
1	U7	
13	Q1,Q2,Q3,Q4,Q5,Q6,Q7,Q8,Q9,Q10,Q11,Q12,Q13	
4	LED1,LED2,LED3,LED4	3mm lead spacing, high brightness
1	SW1	miniature toggle switch. Can use SPDT
14	VR1,VR2,VR3,VR4,VR5,VR6,VR7,VR8,VR9,VR10,VR11,VR12,VR13,VR14	9mm vertical alpha style
9	J1,J2,J3,J4,J5,J6,J7,J8,J9	
5	J10,J11,J12,J13,J14	
1		
1		
1		
1		
1		
1		
3		
	X1	Power input
	2 1 2 4 1 4 5 30 1 8 5 2 4 1 1 8 5 30 1 1 8 5 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	2 R2,R48 1 R6 2 R67,R58 4 R37,R39,R41,R49 1 R9 4 R4,R11,R13,R42 5 R1,R7,R12,R14,R15 30 R3,R8,R18,R22,R23,R24,R25,R28,R30,R31,R32,R33,R34, R35,R36,R38,R40,R43,R50,R51,R52,R53,R54,R55,R56,R59,R61,R63,R65,R101 1 R10 8 R5,R19,R29,R44,R60,R62,R64,R66 5 R16,R17,R45,R46,R47 2 L1,L2 4 TR1,TR2,TR3,TR4 1 TR5 5 C15,C16,C17,C18,C19 3° C7',C8',C24 2 C2,C4 1 C1,C3,C5,C6,C9,C10,C11,C12,C13,C14,C20,C21,C22,C23 1 U4 2 U1,U2,U3 2 U5,U6 10 D1,D2,D3,D4,D5,D6,D7,D8,D9,D10 1 U7 13 Q1,Q2,Q3,Q4,Q5,Q6,Q7,Q8,Q9,Q10,Q11,Q12,Q13 4 LED1,LED2,LED3,LED4 1 SW1 1 VR1,VR2,VR3,VR4,VR5,VR6,VR7,VR8,VR9,VR10,VR11,VR12,VR13,VR14 9 J1,J2,J3,J4,J5,J6,J7,J8,J9 5 J10,J11,J12,J13,J14 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1

Notes

Capacitors C7 and C8 provide a bit of slew / low-pass filtering to the scan CV. They are optional. Use them if you find that applying stepped CV to the scan input results in "popping" on the output. This feedthrough should be minimal if the VCAs are trimmed precisely, though.

I use X7R ceramics for all the 100n capacitors and C0G for the 22pF ones. If I installed C7 and C8 I would probably use C0G there too.

LEDs: it is important to use high brightness LEDs. The maximum current that they will receive is about 0.5mA, and this cannot readily be adjusted because it is also the control current for the LM13700 VCAs. These ones are good: Rapid Truopto 3mm pastel LEDs

Pin headers: it is cheapest to buy long strips of header and cut them to size. The 2x4 header can be made from two single-row 4-position headers.