Kinetis Thread Stack API Reference Manual

KTSAPIRM

Rev. 4 Jan 2018



Contents

Chapter 1 Thread Application Configuration Interface

1.1	Overview
1.2	Macro Definition Documentation
1.2.1	THREAD_USE_SHELL 2
1.2.2	THREAD_USE_THCI 2
1.2.3	THR_MAX_REED_ROUTERS_NEIGHBORS
1.2.4	THR_MAX_SLEEPY_ED_NEIGHBORS
1.2.5	THR_MAX_NEIGHBORS
1.2.6	THR_MAX_DATA_REQS
1.2.7	THR_FAILED_CHILD_TRANSMISSIONS
1.2.8	THR_FAILED_ROUTER_TRANSMISSIONS
1.2.9	DHCP6_SERVER_MAX_INSTANCES
1.2.10	DHCP6_SERVER_MAX_CLIENTS
1.2.11	DHCP6_CLIENT_MAX_INSTANCES
1.2.12	COAP_MAX_SESSIONS
1.2.13	BSDS_MAX_SOCKETS
1.2.14	MAX_UDP_CONNECTIONS
1.2.15	IP_IP6_ROUTING_TBL_SIZE
1.2.16	IP_IP6_FIREWALL_TBL_SIZE
1.2.17	IP_IF_NB
1.2.18	IP_IF_IP6_ADDR_NB
1.2.19	IP_IF_IP6_MULTICAST_ADDR_NB
1.2.20	IP_TRANSPORT_SERVICE_NB
1.2.21	IP_IP_REASSEMBLY_QUEUE_SIZE
1.2.22	IP_IF_IP4_ADDR_NB
1.2.23	MPL_INSTANCE_SET_SIZE
1.2.24	MPL_SEED_SET_SIZE
1.2.25	MPL_BUFFERED_MESSAGE_SET_SIZE
1.2.26	TRICKLE_INSTANCE_SET_SIZE
1.2.27	TRICKLE_LIST_SIZE
1.2.28	SLWPCFG_INSTANCES_NB
1.2.29	SLWPCFG_RFC6282_CONTEXT_TABLE_SIZE
1.2.30	SLWPCFG_UNFRAG_SED_TRACK_NB
1.2.31	SLWPCFG_UNFRAG_SED_TRACK_PKT_NB 6

Section number	Title	Page
1.2.32	SLWPCFG_SED_IND_QUEUE_SIZE	. 6
1.2.33	MAC_FILTERING_ENABLED	. 6
1.2.34	MAC_FILTERING_TABLE_SIZE	. 6
1.2.35	ThrPoolId_d	. 6
1.2.36	THREAD_TASK_MSG_QUEUE_SIZE	. 6
1.2.37	THREAD_TASK_STACK_SIZE	. 7
1.2.38	THR_MAX_INSTANCES	. 7
1.2.39	DEBUG_REED_AUTO_PROMOTE	. 7
1.2.40	THR_SERVER_DATA_PREFIX_TBL_SIZE	. 7
1.2.41	THR_SERVER_DATA_BR_SET_TBL_SIZE	. 7
1.2.42	THR_SERVER_DATA_HAS_ROUTE_TBL_SIZE	. 7
1.2.43	THR_LOCAL_SERVICE_SET_TBL_SIZE	. 7
1.2.44	THR_NWK_DATA_SERVICE_SET_TBL_SIZE	. 7
1.2.45	THR_SLAAC_TEMP_ADDR_TABLE_SIZE	. 7
1.2.46	THR_NWK_DATA_PREFIX_TBL_SIZE	. 8
1.2.47	THR_NWK_DATA_CTX_TBL_SIZE	
1.2.48	THR_NWK_DATA_BR_SET_TBL_SIZE	. 8
1.2.49	THR_NWK_DATA_HAS_ROUTE_TBL_SIZE	
1.2.50	THR_NWK_DATA_MIN_STABLE_LIFETIME_SEC	
1.2.51	THR_LEADER_ID_SEQUENCE_PERIOD_SEC	
1.2.52	THR_CHILD_ADDR_REG_ENTIRES	
1.2.53	THR_CHILD_MCAST_ADDR_REG_ENTIRES	
1.2.54	THR_MAX_LINK_SYNC_NEIGHBORS	
1.2.55	THR_MAX_NWK_ATTACH_PARENT_ENTRIES	
1.2.56	THR_REATTACH_JITTER_MIN_MS	
1.2.57	THR_REATTACH_JITTER_MAX_MS	
1.2.58	THR_LEADER_TIMEOUT_SEC	
1.2.59	THR MAX ROUTERS	
1.2.60	THR_ROUTER_UPGRADE_THRESHOLD	
1.2.61	THR_ROUTER_DOWNGRADE_THRESHOLD	
1.2.62	THR_MIN_DOWNGRADE_NEIGHBORS	
1.2.63	THR_ROUTER_SELECTION_JITTER_SEC	
1.2.64	THR_MAX_DEV_ADDR_QUERY_CACHE_ENTRIES	
1.2.65	THR_ADDRESS_QUERY_TIMEOUT_SEC	
1.2.66	THR_ADDRESS_QUERY_INITIAL_RETRY_DELAY_SEC	
1.2.67	THR_ADDRESS_QUERY_MAX_RETRY_DELAY_SEC	
1.2.68	THR_POWERON_ROUTER_MIN_JITTER_MS	
1.2.69	THR_POWERON_ROUTER_MAX_JITTER_MS	
1.2.70	THR_POWERON_ED_MAX_JITTER_MS	
1.2.71	THR_PARENT_ROUTE_TO_LEADER_TIMEOUT_MS	
1.2.72	THR_CHILD_ED_KEEP_ALIVE_INTERVAL_MIN_MS	
1.2.73	THR_CHILD_ED_KEEP_ALIVE_INTERVAL_MAX_MS	
1.2.74	THR_CONTEXT_REUSE_DELAY_SEC	
1.2.75	THR_DISCOVERY_EXT_ADDR	
1.2.76	THR_DISCOVERY_KEY	
1.2.70	TIM_DISCOTENT_INDI	. 11

Section numb	er Title	Page
1.2.77	THR_DISCOVERY_FRAME_COUNTER	. 11
1.2.78	THR_DISCOVERY_TIME	. 12
1.2.79	THR_DISCOVERY_MAX_JITTER	. 12
	Chapter 2	
	Thread Network Interface	
2.1	Overview	. 13
2.2	Data Structure Documentation	. 15
2.2.1	struct thrDeviceConfig_t	. 15
2.3	Macro Definition Documentation	. 16
2.3.1	THR_NWKCAP_CAN_CREATE_NEW_NETWORK	. 16
2.3.2	THR_NWKCAP_CAN_BECOME_ACTIVE_ROUTER	
2.3.3	THR_NWKCAP_IS_POLLING_END_DEVICE	. 17
2.3.4	THR_NWKCAP_IS_FULL_THREAD_DEVICE	
2.3.5	THR_NWKCAP_BIT_MASK	. 17
2.4	Enumeration Type Documentation	. 17
2.4.1	thrEvCodesNwkScan_t	. 17
2.4.2	thrEvCodesCreate_t	
2.4.3	thrEvCodesJoin_t	
2.4.4	thrEvCodesJoinSelectParent_t	
2.4.5	thrEvCodesGeneral_t	. 18
2.5	Function Documentation	. 19
2.5.1	THR_Task(osaTaskParam_t argument)	. 19
2.5.2	THR_Init(void)	. 19
2.5.3	THR_InitAttributes(instanceId_t thrInstId, stackConfig_t *pStackCfg)	
2.5.4	THR_StartInstance(instanceId_t thrInstId, stackConfig_t *pStackCfg)	. 20
2.5.5	THR_SetDeviceConfig(instanceId_t thrInstId, thrDeviceConfig_t *pThrDevice← Config)	. 20
2.5.6	THR_SetDeviceRole(instanceId_t thrInstID, thrDeviceRole_t thrDeviceRole)	
2.5.7	THR_NwkScanWithBeacon(instanceId_t thrInstId, thrNwkScan_t *pThrNwkScan	
2.5.8	THR_NwkDiscoveryReq(instanceId_t thrInstId, thrNwkDiscoveryReqTxOpt_\Limitstation THR_NwkDiscoveryReqTxOpt_\Limitstation THR_NwkDiscove	1) 21
2.3.0	t *pDiscReqTxOpt, thrDiscoveryRespCb_t pfDiscoveryRespCb)	. 21
2.5.9	THR_NwkDiscoveryStop(instanceId_t thrInstId)	
2.5.10	THR_SearchThreadNwkWithAnnounce(instanceId_t thrInstId, uint32_t scan-	
	ChannelMask, thrAnnounceCb_t pfAnnounceCb)	. 23
2.5.11	THR_SetBorderRouterIf(instanceId_t thrInstId, ipIfUniqueId_t brIfId)	
2.5.12	THR_NwkCreate(instanceId_t thrInstId)	
2.5.13	THR_NwkAttach(instanceId_t thrInstId)	. 24
2.5.14	THR_NwkJoin(instanceId_t thrInstId, thrJoinDiscoveryMethod_t discMethod) .	. 24

Kinetis Thread Stack API Reference Manual

NXP Semiconductors

Section numb	er Title	Page
2.5.15	THR_NwkDetach(instanceId_t thrInstId)	. 25
2.5.16	THR_SoftwareReset(instanceId_t thrInstID, bool_t factoryReset)	. 25
2.5.17	THR_FactoryReset(void)	. 26
2.5.18	THR_TimeoutResetMcu(uint32_t timeoutMs, bool_t resetToFactory)	. 26
2.5.19	THR_GetParent(instanceId_t thrInstID)	. 26
2.5.20	THR_GetNeighborTable(uint32_t iCount)	. 26
2.5.21	THR_NeighborGetByShort(uint16_t shortAddr)	. 27
2.5.22	THR_GetRouterIdSet(instanceId_t thrInstId)	
2.5.23	THR_LeaderRemoveRouterID(instanceId_t thrInstID, uint32_t routerID)	
2.5.24	THR_RouterLinkSync(instanceId_t thrInstID, bool_t bOnReset)	
2.5.25	THR_ChildUpdateToParent(instanceId_t thrInstID)	
2.5.26	THR_SolicitGlobalAddress(instanceId_t thrInstID)	
2.5.27	THR_BrPrefixAttrAddEntry(instanceId_t thrInstID, thrOtaBrPrefixSet_t *pEntry	*
2.5.28	THR_ServiceAttrAddEntry(instanceId_t thrInstID, thrLocalServiceSet_t *pEntry	*
2.5.29	THR_BrPrefixAttrRemoveEntry(instanceId_t thrInstID, uint8_t prefixLength,	
	uint8_t *pPrefixValue)	
2.5.30	THR_BrServiceAttrRemoveEntry(instanceId_t thrInstID, uint8_t *pServiceData,	
	uint8_t serviceDataLen, uint8_t *pServerData, uint8_t serverDataLen)	
2.5.31	THR_BrPrefixAttrGetTable(instanceId_t thrInstID, uint8_t startIndex, uint8_\circ	
2.5.22	t reqNoOfElements, uint8_t *pRspNoOfElements, uint8_t *pOutData)	
2.5.32	THR_BrPrefixAttrRemoveAll(instanceId_t thrInstID)	
2.5.33	THR_BrPrefixAttrSync(instanceId_t thrInstID)	
2.5.34	THR_SendProactiveAddressNotification(instanceId_t thrInstId, ipAddr_t *pe	
2.5.25	DestIpAddr)	
2.5.35	THR_GenerateExtendedAddress(bool_t privacyAddr)	
2.5.36	THR_GetRlocToEidMapByEntry(uint32_t entry)	. 32
2.6	Variable Documentation	. 33
2.6.1	gaThrDeviceConfig	
	Chapter 3	
	Thread Attributes Interface	
2.1	Overview	25
3.1	Overview	. 35
3.2	Data Structure Documentation	. 38
3.2.1	struct thrAttr_t	. 38
3.2.2	struct thrStringAttr_t	. 41
3.2.3	struct thrActiveAttr_t	
3.2.4	struct thrPendingAttr_t	. 42
3.2.5	struct thrOtaBrPrefixSet_t	
3.2.6	struct thrLocalServiceSet_t	. 44
2.2	Enumeration Type Decumentation	4 4
3.3	Enumeration Type Documentation	. 44

NXP Semiconductors

Kinetis Thread Stack API Reference Manual

vi

Section numbe	er Title	Page
3.3.1	thrAttrId_t	. 44
3.4	Function Documentation	. 46
3.4.1	THR_InitAttr(instanceId_t thrInstId, void *pDefaultAttr, void *pDefaultStrAttr, void *pDefaultActiveDataSetAttr)	. 46
3.4.2	THR_GetAttr(instanceId_t thrInstID, thrAttrId_t attrID, uint32_t index, uint32 _ t *pSize, void *pAttrValue)	. 47
3.4.3	THR_SetAttr(instanceId_t thrInstID, thrAttrId_t attrID, uint32_t index, uint32_t size, void *pAttrValue)	
3.5	Variable Documentation	
3.5.1	gpaThrAttr	. 48
3.5.2	gpaThrStringAttr	. 48
3.5.3	gpaThrActiveAttr	. 48
3.5.4	gpaThrPendingAttr	. 48
3.5.5	gaServerDataPrefixTbl	. 48
3.5.6	gLocalServiceSetTblSize	. 48
	Chapter 4 Thread Application Callbacks Interface	
4.1	Overview	. 49
4.2	Macro Definition Documentation	49
4.2.1	THR_MAX_NWK_JOINING_ENTRIES	
4.3	Typedef Documentation	. 50
4.3.1	registerServiceServerAddr_t	. 50
	Function Documentation	
4.4.1	APP_JoinerSelectNwkWithBeaconCb(void *pParam)	. 50
4.4.2	APP_OutOfBandSelectNwkWithBeaconCb(instanceId_t thrInstId, thrBeacon← Info_t *pThrBeacon)	. 50
4.4.3	APP_MeshcopValidateJoinerAddrCb(instanceId_t thrInstId, ipAddr_t *pIpAddr)	
4.4.4	APP_MeshCopValidateJoinFinCb(instanceId_t thrInstId, meshCopJoinFinTlvs- _t *pJoinFinTlvs)	
4.4.5	APP_MeshCopValidateCommissionerCb(instanceId_t thrInstId, meshcop← CommIdTlv_t *pCommIdTlv)	
4.4.6	APP_AddressAssignSlaacCb(instanceId_t thrInstId, ipAddr_t *pPrefix)	
4.4.7	APP_CriticalExitCb(uint32_t location, uint32_t param)	
4.4.7	APP_DiscoveryReqCb(instanceId_t thrInstId, uint16_t tlvsSize, uint8_t *pTlvs)	
4.4.8	APP_JoinerDiscoveryRespCb(instanceId_t thrInstId, thrDiscoveryEvent_t event,	. 32
T.T.7	uint8_t lqi, thrDiscoveryRespInfo_t *pDiscoveryRespInfo, meshcopDiscovery← RespTlvs_t *pDiscoveryRespTlvs)	. 52

Kinetis Thread Stack API Reference Manual

NXP Semiconductors

vii

Section numb	er Title	Page
4.4.10	APP_JoinerSelectNwkWithAnnounceCb(instanceId_t thrInstId, thrAnnounce←	
	Event_t event, uint8_t lqi, uint16_t tlvsSize, uint8_t *pTlvs)	. 53
4.4.11	APP_GenerateMLPrefixCb(instanceId_t thrInstID, thrPrefixAttr_t *pMLprefix)	. 53
4.4.12	APP_EnableDHCP6Cb(void)	. 53
4.4.13	APP_BeaconFillCb(instanceId_t thrInstID)	. 53
	Chapter 5	
	Thread Types Interface	
5.1	Overview	. 55
5.2	Data Structure Documentation	. 59
5.2.1	struct thrOctet16_t	. 59
5.2.2	struct thrOctet32_t	. 59
5.2.3	struct thrOctet64_t	. 60
5.2.4	struct thrPrefixAttr_t	. 61
5.2.5	struct macFilteringNeighborData_t	. 61
5.2.6	struct thrBeaconInfo_t	. 61
5.2.7	struct thrBeaconInfo_t.payload	. 62
5.2.8	struct thrNwkActiveScanEntry_t	. 62
5.2.9	struct thrNwkScan_t	. 62
5.2.10	struct thrNwkScanResults_t	. 63
5.2.11	struct thrNeighbor_t	. 63
5.2.12	struct handleTrackingTable_t	. 64
5.2.13	struct thrIdAssignSet_t	. 64
5.2.14	struct mleOtaTlvLeaderData_t	. 64
5.2.15	struct externalRouteSet_t	. 64
5.2.16	struct borderRouterSet_t	. 65
5.2.17	struct contextIdSet_t	. 65
5.2.18	struct serverTlv_t	. 66
5.2.19	struct serviceSet_t	. 67
5.2.20	struct childVersNbSet_t	. 67
5.2.21	struct serverData_t	. 67
5.2.22	struct nwkDataInterfaceSet_t	. 68
5.2.23	struct thrLqCacheEntry_t	. 69
5.2.24	struct thrAqInterfaceSet_t	. 69
5.2.25	struct thrAddrRegEntry_t	. 69
5.2.26	struct thrChildAddrRegEntry_t	. 69
5.2.27	struct thrChildMcastAddrRegEntry_t	. 70
5.2.28	struct thrLinkSet_t	
5.2.29	struct thrRouteSet_t	
5.2.30	struct thrRouterIdSet_t	
5.2.31	struct thrInterfaceSet_t	. 71

Kinetis Thread Stack API Reference Manual

viii NXP Semiconductors

Section numb	er Title	Page
5.2.32	struct thrMacRcvdDiffKeyIndexInd_t	72
5.2.33	union thrEventData_t	72
5.2.34	struct thrEvmParams_t	73
5.2.35	struct thrPskcInputParams_t	74
5.2.36	struct thrNwkJoiningEntry_t	74
5.2.37	struct thrNwkDiscoveryReqTxOpt_t	
5.3	Macro Definition Documentation	75
5.3.1	THR_PROTOCOL_VERSION	
5.3.2	THREAD_ENTERPRISE_NUMBER	75
5.3.3	THREAD_ENTERPRISE_NUMBER_ARRAY	75
5.3.4	THREAD_DNS_SERVICE_TYPE_ID	
5.3.5	THR_MAX_ROUTER_ID	
5.3.6	THR_MAX_POSSIBLE_ROUTERS	
5.3.7	THR_ROUTER_MASK_BYTES	
5.3.8	THR_MAX_CHILD_IDS	
5.3.9	THR R ID ADDR SHIFT	
5.3.10	THR_GET_MY_PARENT	
5.3.11	THR_IS_MY_CHILD	
5.3.12	THR_R_ID_IS_SET_IN_MASK	
5.3.13	THR_NWK_KEY_SIZE	
5.3.14	THR_BEACON_J_FLAG_MASK	
5.3.15	THR_BEACON_N_FLAG_MASK	
5.3.16	THR_BEACON_VERSION_MASK	
5.3.17	THR_BEACON_J_FLAG_GET	
5.3.18	THR_BEACON_N_FLAG_GET	
5.3.19	THR BEACON VERSION GET	
5.3.20	THR_DISCOVERY_REQ_TLV_J_BIT	
5.3.21	THR_DISCOVERY_RESP_TLV_N_BIT	
5.3.22	THR_DISC_RSP_VER_SHIFT	
5.4	Typedef Documentation	
5.4.1	thrEvCode_t	
5.4.2	thrAnnounceCb_t	78
5.5	Enumeration Type Documentation	78
5.5.1	thrStatus_t	78
5.5.2	thrInternalDeviceRole_t	78
5.5.3	thrDeviceRole_t	78
5.5.4	thrDeviceType_t	79
5.5.5	nwkIPAddrType_t	79
5.5.6	thrRouterState_t	79
5.5.7	thrSlaacPolicy_t	79
5.5.8	thrCommissionerMode_t	80
5.5.9	thrParentPriority_e	80

Section numb	er Title	Page
5.5.10	thrNwkScanType_t	80
5.5.11	resetCpuStatus_t	80
5.5.12	meshcopSteeringMatch_t	80
5.5.13	thrEvSets_t	81
5.5.14	thrJoinDiscoveryMethod_t	81
5.5.15	thrDiscReqTxOptions_t	81
5.5.16	thrAnnounceEvent_t	81
5.5.17	thrInstSearchType_t	81
	Chapter 6	
	Thread Commissioning Interface	
6.1	Overview	83
6.2	Data Structure Documentation	88
6.2.1	struct expectedJoinerEntry_t	
6.2.2	struct meshcopCredentialInput_t	
6.2.3	struct meshCopStateTlv_t	
6.2.4	struct meshCopVendorNameTlv_t	
6.2.5	struct meshCopVendorModelTlv_t	
6.2.6	struct meshCopVendorSwVerTlv_t	
6.2.7	struct meshCopVendorDataTlv_t	
6.2.8	struct meshCopStackVersionTlv_t	
6.2.9	struct meshCopProvUrlTlv_t	
6.2.10	struct meshCopJoinFinTlvs_t	
6.2.11	struct meshCopChannelTlv_t	
6.2.12	struct meshCopChannelMaskTlv_t	
6.2.13	struct meshCopCountTlv_t	
6.2.14	struct meshCopPeriodTlv_t	92
6.2.15	struct meshCopEnergyListTlv_t	
6.2.16	struct meshCopScanDurationTlv_t	92
6.2.17	struct meshCopDiscoveryReqTlv_t	92
6.2.18	struct meshCopDiscoveryRespTlv_t	93
6.2.19	struct meshCopDiscoveryTlv_t	93
6.2.20	struct meshCopNwkChannelTlv_t	93
6.2.21	struct meshCopNwkPanIdTlv_t	93
6.2.22	struct meshCopNwkXPanIdTlv_t	94
6.2.23	struct meshCopNwkNameTlv_t	94
6.2.24	struct meshCopPskcTlv_t	94
6.2.25	struct meshCopNwkMasterKeyTlv_t	
6.2.26	struct meshCopNwkKeySeqTlv_t	
6.2.27	struct meshCopNwkMlUlaTlv_t	
6.2.28	struct meshCopSteeringTlv_t	95

Kinetis Thread Stack API Reference Manual

Section number	Title	Page
6.2.29	struct meshCopBrLocTlv_t	. 95
6.2.30	struct meshcopCommIdTlv_t	. 96
6.2.31	struct meshCopCommSessIdTlv_t	. 96
6.2.32	struct meshCopGetTlv_t	. 96
6.2.33	struct meshCopActiveTimestampTlv_t	. 96
6.2.34	struct meshCopCommissionerUdpPortTlv_t	. 97
6.2.35	struct meshCopJoinerUdpPortTlv_t	. 97
6.2.36	struct meshCopPendingTimestampTlv_t	. 97
6.2.37	struct meshCopSecurityPolicyTlv_t	. 97
6.2.38	$struct\ meshCopMacExtendedAddressTlv_t\ \dots\dots\dots\dots\dots\dots\dots$. 98
6.2.39	struct meshCopDelayTimerTlv_t	. 98
6.2.40	struct meshcopDiscoveryRespTlvs_t	. 98
6.2.41	struct thrDiscoveryRespInfo_t	
6.2.42	struct meshcopHandlers_t	
6.2.43	struct meshcopNwkFormParams_t	
6.2.44	struct meshcopMgmtParams_t	
6.3 T	ypedef Documentation	. 100
6.3.1	meshcopDiagnosticHandlerCb_t	
6.3.2	thrDiscoveryRespCb_t	
6.3.3	meshcopHandlerCb_t	
6.4 E	numeration Type Documentation	. 102
6.4.1	$meshCopTlv_t \dots \dots$	
6.4.2	meshcopEuiMask_t	
6.4.3	thrEvCodesComm_t	
6.4.4	meshcopDiagnosticDir_t	
6.4.5	meshcopDiagnosticType_t	
6.4.6	thrDiscoveryEvent_t	
6.5 F	unction Documentation	. 104
6.5.1	MESHCOP_StartNativeCommissionerScan(instanceId_t thrInstId)	
6.5.2	MESHCOP_StopCommissioner(instanceId_t thrInstId, bool_t updateNwk)	
6.5.3	MESHCOP_AddExpectedJoiner(instanceId_t thrInstId, uint8_t *pEui, uint8_	
	t *pPsk, uint32_t pskLen, bool_t selected)	. 105
6.5.4	MESHCOP_RemoveExpectedJoiner(instanceId_t thrInstId, uint8_t *pHashEui,	
	uint8_t *pEui)	
6.5.5	MESHCOP_RemoveAllExpectedJoiners(instanceId_t thrInstId)	. 106
6.5.6	MESHCOP_SyncSteeringData(instanceId_t thrInstId, meshcopEuiMask_t eui ← Mask)	. 107
6.5.7	MESHCOP_CheckSteeringData(meshCopSteeringTlv_t *pSteeringDataTlv)	
6.5.8	MESHCOP_SetCommissionerCredential(instanceId_t thrInstId, meshcop	
	CredentialInput_t *pParams)	. 107
6.5.9	$MESHCOP_SetDiagHandler(instanceId_t thrInstId, meshcopDiagnostic \leftarrow$	
	HandlerCb_t pfTlvsHandler)	. 108

Kinetis Thread Stack API Reference Manual

Section number	er Title	Page
6.5.10	MESHCOP_AddTlvs(instanceId_t thrInstanceID, uint8_t *pStart, uint64_t *p \leftart	,
	Mask, bool_t usePending, bool_t noSecPolicy)	. 108
6.5.11	MESHCOP_GetTlvsLen(instanceId_t thrInstanceID, uint64_t *pMask, bool_←)
	t usePending, bool_t noSecPolicy)	. 108
6.5.12	MESHCOP_RegisterBrServerAddr6(instanceId_t thrInstId, ipIfUniqueId_t ifId,	,
	ipAddr_t *pAddr)	
6.5.13	MESHCOP_NwkJoinWithCommissioning(instanceId_t thrInstId, thrNwk)
	JoiningEntry_t *pNwkJoiningList, uint32_t nbOfNwkJoiningEntries)	
6.5.14	MESHCOP_Set(instanceId_t thrInstId, uint8_t *pTlvs, uint32_t tlvsLength,	
	meshcopHandlerCb_t pfSetCb)	
6.5.15	MESHCOP_Get(instanceId_t thrInstId, uint8_t *pTlvs, uint32_t tlvsLength,)
	meshcopHandlerCb_t pfGetCb)	
6.5.16	MESHCOP_MgmtSendPanIdQuery(instanceId_t thrInstId, uint32_t channel↔)
	Mask, uint16_t panId, meshcopHandlerCb_t pfHandlerCb, ipAddr_t *pIpAddr)	. 111
6.5.17	MESHCOP_MgmtSendEdScan(instanceId_t thrInstId, uint32_t channelMask,	
	uint32_t count, uint32_t period, uint32_t scanDuration, meshcopHandlerCb_t	
	pfHandlerCb, ipAddr_t *pIpAddr)	. 112
6.5.18	MESHCOP_MgmtSendAnnounceBegin(instanceId_t thrInstId, uint16_←)
	t commissionerSessionId, uint32_t channelMask, uint32_t count, uint16_t period,	,
	ipAddr_t *pIpAddr)	. 112
6.5.19	MESHCOP_MgmtActiveSet(meshcopMgmtParams_t *pParams)	. 113
6.5.20	MESHCOP_MgmtPendingSet(meshcopMgmtParams_t *pParams)	. 113
6.5.21	MESHCOP_MgmtCommGet(meshcopMgmtParams_t *pParams)	. 114
6.5.22	MESHCOP_MgmtActiveGet(meshcopMgmtParams_t *pParams)	. 115
6.5.23	$MESHCOP_MgmtPendingGet(meshcopMgmtParams_t *pParams) \ . \ . \ . \ . \ .$. 115
	Variable Decompostation	115
	Variable Documentation	
6.6.1 6.6.2	gThrExpectedJoinerList	
0.0.2	gMeshcopCommissionerMode	. 113
	Chapter 7	
	Network IP Sockets Interface	
7.1	Overview	117
7.1	Overview	. 117
7.2	Data Structure Documentation	. 119
7.2.1	struct sockaddrIn_t	. 119
7.2.2	struct sockaddrIn6_t	
7.2.3	struct sockaddrStorage_t	
7.2.4	struct timeval	
7.2.5	struct ipMreq_t	. 120
7.2.6	struct socketCallback_t	. 120
7.2.6.1	Field Documentation	
7.2.6.1.1	SocketBind	. 120

xii Kinetis Thread Stack API Reference Manual

NXP Semiconductors

Section number	er Title	Page
7.2.6.1.2	SocketConnect	120
7.2.6.1.3	SocketListen	121
7.2.6.1.4	SocketAccept	121
7.2.6.1.5	SocketRecv	121
7.2.6.1.6	SocketRecvFrom	
7.2.6.1.7	SocketSend	
7.2.6.1.8	SocketSendto	
7.2.7	struct sock_t	
7.3	Macro Definition Documentation	122
7.3.1	BSDS_DATAGRAM_SUPPORT	
7.3.2	BSDS_STREAM_SUPPORT	
7.3.3	BSDS_BLOCKING_SOCKET	
7.3.4	BSDS_SELECT_SUPPORT	
7.3.5	BSDS_OPTIONS_SUPPORT	
7.3.6	BSDS_RECV_EVENT	
7.3.7	BSDS_CANCEL_SELECT_EVENT	
7.3.8	BSDS_CONN_DONE_EVENT	
7.3.9	SOCK_DGRAM	
7.3.10	SOCK_STREAM	
7.3.10	PF INET	
7.3.11	PF_INET6	
7.3.12	MSG_DONTWAIT	
7.3.14	MSG_SEND_WITH_MEMBUFF	
7.3.15	MSG_GET	
7.3.16	IPV6 UNICAST HOPS	
7.3.17	IPV6_MULTICAST_HOPS	
7.3.18	IPV6_ADD_MEMBERSHIP	
7.3.19	IPV6_DROP_MEMBERSHIP	
7.3.20	IPV6_MTU	
7.3.21	IPV6_JOIN_ANYCAST	124
7.3.22	IPV6 TCLASS	
7.3.23	IP_TOS	
7.3.24	IP_TTL	
7.3.25	IP_ADD_MEMBERSHIP	
7.3.26	IP_DROP_MEMBERSHIP	
7.3.27	IP_MULTICAST_IF	
7.3.28	IP_MULTICAST_TTL	
7.3.29	IP_MULTICAST_LOOP	
7.3.30	IPV6_JOIN_GROUP	
7.3.31	IPV6_LEAVE_GROUP	
7.3.32	BSDS_DEFAULT_FLOW_FLAGS	
7.3.33	FD SETSIZE	
1.3.33	Τυ_ουτοικύ	123
7.4	Enumeration Type Documentation	126

NXP Semiconductors xiii

Section number	per Title	Page
7.4.1	sockFuncErr_t	. 126
7.4.2	sockStateErr_t	
7.1.2	bookstateEn_t	. 120
7.5	Function Documentation	. 126
7.5.1	socket(uint8_t domain, uint8_t type, uint8_t protocol)	
7.5.2	shutdown(int32_t sockfd, int how)	
7.5.3	bind(int32_t sockfd, sockaddrStorage_t *pLocalAddr, uint32_t addrlen)	
7.5.4	send(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)	
7.5.5	sendto(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddr←	
1.3.3	Storage_t *pTo, uint32_t toLen)	
7.5.6		
	recv(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)	
7.5.7	recvfrom(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddr St. L.	
5 5 0	Storage_t *from, socklen_t *fromLen)	
7.5.8	connect(int32_t sockfd, sockaddrStorage_t *serv_addr, uint32_t addrLen)	
7.5.9	getsockopt(int32_t sockfd, int32_t level, int32_t optName, void *optVal, int32_t	
	*optLen)	
7.5.10	setsockopt(int32_t sockfd, int32_t level, int32_t optName, void *optVal, int32_t	
	optLen)	
7.5.11	getsockname(int32_t sockfd, sockaddrStorage_t *pAddr, socklen_t *addrlen)	
7.5.12	getsocket(int32_t sockFd)	. 131
	Chapter 8	
	CoAP Interface	
8.1	Overview	. 133
8.2	Data Structure Documentation	
8.2.1	struct coapUriPath_t	. 136
8.2.2	struct coapInstance_t	. 136
8.2.3	struct coapCallbackStruct_t	. 136
8.2.4	struct coapTokenCbStruct_t	. 137
8.2.5	struct coapOptionDetails_t	. 137
8.2.6	struct coapSession_t	
8.2.7	struct coapStartSecParams_t	
8.2.8	struct coapStartUnsecParams_t	
8.2.9	struct coapRegCbParams_t	
0.2.)	struct coupling con that is a second control of the second control	. 137
8.3	Macro Definition Documentation	. 139
8.3.1	COAP ENABLED	
8.3.2	COAP_MAX_URI_PATH_OPT_SIZE	
8.3.3	COAP_MAX_OPTION_VALUE_SIZE	
8.3.4	COAP_MAX_TOKEN_LEN	
8.3.5	COAP_OBSERVE_OPTION	
8.3.6	COAP_DEFAULT_PORT	
0.3.0	COAL_DEFAULT_FORT	. 140

xiv Kinetis Thread Stack API Reference Manual
NXP Semiconductors

Section numb	er Title	Page
8.3.7	COAP_INSTANCES_URI_PATH	. 140
8.3.8	COAP_SetMaxRetransmitCount	. 140
8.3.9	COAP_MAX_CALLBACKS	. 140
8.3.10	COAP_MAX_NON_PIGGYBACKED_RSP	. 140
8.3.11	COAP_MAX_MSG_IDs	. 141
8.3.12	COAP_MAX_OPTIONS	. 141
8.3.13	COAP_TOKEN_LENGTH	. 141
8.4	Typedef Documentation	. 141
8.4.1	coapCallback_t	. 141
8.5	Enumeration Type Documentation	. 141
8.5.1	coapSessionStatus_t	. 141
8.5.2	coapMacSecFlags_t	. 141
8.5.3	coapMsgTypesAndCodes_t	. 142
8.5.4	coapMessageTypes_t	. 142
8.5.5	coapReqRespCodes_t	. 142
8.6	Function Documentation	. 142
8.6.1	COAP_Init(taskMsgQueue_t *pTaskMsgQueue)	. 142
8.6.2	COAP_CreateInstance(coapStartSecParams_t *pCoapStartSecParams, coap←	
	StartUnsecParams_t *pCoapStartUnsecParams, ipIfUniqueId_t ipIfId, coap	
	RegCbParams_t *pCallbacksStruct, uint32_t nbOfCallbacks)	. 142
8.6.3	COAP_CloseInstance(uint8_t coapInstanceId)	
8.6.4	COAP_OpenSession(uint8_t coapInstanceId)	. 143
8.6.5	COAP_CloseSession(coapSession_t *pSession)	. 143
8.6.6	COAP_AddOptionToList(coapSession_t *pSession, uint8_t optName, uint8_	
	t *optValue, uint8_t optValueLen)	. 144
8.6.7	COAP_SetUriPath(coapSession_t *pSess, coapUriPath_t *pUriPath)	. 144
8.6.8	COAP_Send(coapSession_t *pSession, coapMsgTypesAndCodes_t coapMsg↔	
	Type, void *pData, uint32_t payloadLen)	
8.6.9	COAP_SendMsg(coapSession_t *pSession, void *pData, uint32_t payloadLen)	. 145
8.6.10	COAP_RegisterResourceCallback(uint8_t coapInstanceId, coapRegCbParams←	
	_t *pCallbacksStruct, uint32_t nbOfCallbacks)	. 146
8.6.11	$COAP_RegisterTokenCallback(coapSession_t *pSession, coapCallback_t p \leftarrow$	
	Callback)	. 146
8.6.12	$COAP_UnregisterTokenCallback(coapSession_t *pSession, coapCallback_t p \leftarrow$	
	Callback)	. 146
8.6.13	$COAP_UnregisterResourceCallback(uint8_t coapInstanceId, coapRegCb \leftarrow$	
	Params_t *pCallbacksStruct, uint32_t nbOfCallbacks)	. 147
8.6.14	COAP_CloseAnySession(void)	. 147

Section number	Title	Page

Chapter 9 Network IP Interface

9.1	Overview
9.2	Data Structure Documentation
9.2.1	struct ip4IfStruct_t
9.2.2	struct ip6IfStruct_t
9.2.3	struct mediaIfStruct_t
9.2.4	struct ipIfStruct_t
9.2.5	struct ip4IfAddrData_t
9.2.6	struct ip6IfAddrData_t
9.3	Typedef Documentation
9.3.1	ifHandle_t
9.3.2	ip6IfSelThreadMLSrcAddr6_t
9.4	Enumeration Type Documentation
9.4.1	ip6AddrType_t
9.5	Function Documentation
9.5.1	IP_IF_Init(void)
9.5.2	IP_IF_Add(ipIfUniqueId_t ifId, void *driverHandle, mediaIfStruct_t *pIfStruct,
	uint16_t ipVersEnabled)
9.5.3	IP_IF_GetIfHandle(ipIfUniqueId_t ifId)
9.5.4	IP_IF_GetIfIndex(ipIfUniqueId_t ipIfId)
9.5.5	IP_IF_IsMyAddr(ipIfUniqueId_t ipIfId, ipAddr_t *pIpAddr)
9.5.6	IP_IF_Join(ipIfUniqueId_t ipIfId, ipAddr_t *groupIp)
9.5.7	IP_IF_Leave(ipIfUniqueId_t ipIfId, ipAddr_t *groupIp)
9.5.8	IP_IF_GetIfIdByIndex(uint32_t ifIndex)
9.5.9	IP_IF_GetIfByIndex(uint32_t ifIndex)
9.5.10	IP_IF_GetIfByAddr(ipAddr_t *pIpAddr)
9.6	Variable Documentation
9.6.1	scope_id
9.6.2	ppNdCfg
9.6.3	ip6IsAddrOnLink
9.6.4	ip6ResolveUnicastAddr
9.6.5	ip6UpperMgtLayerCb
9.6.6	ip6McastForward
9.6.7	ip6UnicastForward
9.6.8	ifOpen
9.6.9	ifClose
9.6.10	ifSend4

Section number	Title	Page
9.6.11	ifSendArp	. 157
9.6.12	ifSend6	. 157
9.6.13	ifGetIID	. 157
9.6.14	ifJoin	. 158
9.6.15	ifLeave	. 158
9.6.16	ifDriverHandle	. 158
9.6.17	ifFunctions	. 158
9.6.18	ifMtu	. 158
9.6.19	ipVersion4	. 158
9.6.20	ipVersion6	. 158
9.6.21	ifDevAddrTbl	. 158
9.6.22	ifUniqueId	. 159
9.6.23	ifMetric	. 159
9.6.24	ipIfId	. 159
9.6.25	ip4Addr	. 159
9.6.26	ip4SubnetMask	. 159
9.6.27	ip4DefaultGw	. 159
9.6.28	ip6Addr	. 159
9.6.29	ipIfId	. 159
9.6.30	creationTime	. 159
9.6.31	lifetime	. 160
9.6.32	ip6AddrTypeAndState	. 160
9.6.33	dadTransmitCounter	. 160
9.6.34	prefixLength	. 160
9.6.35	macAddrIndex	. 160
	Chapter 10 Thread Network Utilities Interface	
10.1 O	verview	. 161
10.2 D	ata Structure Documentation	. 167
10.2.1	union uuint16_t	
10.2.2	union uuint32_t	
10.2.3	union uuint64_t	
10.2.4	union ipAddr_t	
10.2.5	struct nwkBuffer_t	
10.2.6	struct llAddr_t	
10.2.7	struct ip6Header_t	
10.2.8	struct ipPktOptions_t	
10.2.9	struct recvOptions_t	
10.2.10	struct ipPktInfo_t	
10.2.11	union ipPktInfo_t.prot	

Kinetis Thread Stack API Reference Manual

NXP Semiconductors

xvii

Section number	er Title	Page
10.2.12	struct nwkMsg_t	. 172
10.2.13	struct taskMsgQueue_t	. 172
10.2.14	struct lut8_t	
10.2.15	struct nwkStats_t	. 173
10.2.16	struct ipPrefix_t	
10.2.17	struct pbkdf2Params_t	. 174
10.3	Macro Definition Documentation	. 174
10.3.1	THR_ALL_FFs64	. 174
10.3.2	THR_ALL_FFs32	. 174
10.3.3	THR_ALL_FFs16	. 174
10.3.4	THR_ALL_FFs8	. 175
10.3.5	INET_ADDRSTRLEN	
10.3.6	INET6 ADDRSTRLEN	
10.3.7	INET6_IID_LEN	
10.3.8	IP6_MINIMUM_MTU	
10.3.9	IP6_PSEUDO_HDR_SIZE	
10.3.10	IP4_PSEUDO_HDR_SIZE	
10.3.11	IP4_ADDR_ANY	
10.3.12	IP4_ADDR_LOOPBACK	
10.3.13	IP4_ADDR_ALLHOSTS_GROUP	
10.3.14	IP4_ADDR_ALLROUTERS_GROUP	
10.3.15	IP4_ADDR_RIP_GROUP	
10.3.16	IP4_ADDR_NTP_GROUP	
10.3.17	IP4_ADDR_IGMP_GROUP	
10.3.18	IP4_ADDR_BROADCAST	
10.3.19	INADDR_ANY_INIT	
10.3.20	INADDR_BCAST_INIT	
10.3.21	IP4_ZERONET	
10.3.22	IP4_LOOPBACK	
10.3.23	IP4_MULTICAST	
10.3.24	IP4_LOCAL_MULTICAST	
10.3.25	IP4_EXPERIMENTAL	
10.3.26	IP4_CLASS_A	
10.3.27	IP4_CLASS_A_MASK	
10.3.28	IP4 CLASS B	
10.3.29	IP4_CLASS_B_MASK	
10.3.29	IP4_CLASS_C	
10.3.31	IP4_CLASS_C_MASK	
10.3.32	IN6ADDR_ANY_INIT	
10.3.33		
10.3.34	IN6ADDR_NODELOCAL_ALLNODES_INIT	
10.3.35	IN6ADDR_INTFACELOCAL_ALLNODES_INIT	
10.3.36	IN6ADDR_LINKLOCAL_ALLNODES_INIT	
10.3.37	IN6ADDR_LINKLOCAL_ALLROUTERS_INIT	. 1/8

xviii NXP Semiconductors

Section number	Title	Page
10.3.38	IN6ADDR_LINKLOCAL_ALLV2ROUTERS_INIT	. 178
10.3.39	IN6ADDR_LINKLOCAL_ALL_DHCP_ROUTERS_AND_RELAY_AGENTS	. 179
10.3.40	IN6ADDR_REALMLOCAL_ALL_DHCP_LEASEQUERY_SERVERS	. 179
10.3.41	IN6ADDR_REALMLOCAL_MCAST_3EAD	. 179
10.3.42	IN6ADDR_SITELOCAL_ALLDHCPSERVERS	. 179
10.3.43	IN6ADDR_REALMLOCAL_ALLNODES_INIT	
10.3.44	IN6ADDR_REALMLOCAL_ALLROUTERS_INIT	. 179
10.3.45	IN6ADDR_SITELOCAL_ALLNODES_INIT	
10.3.46	IN6ADDR_SITELOCAL_ALLROUTERS_INIT	
10.3.47	IN6ADDR_LINK_LOCAL_PREFIX_INIT	
10.3.48	IN6ADDR_ALL_FFs	
10.3.49	IP_AddrCopy	
10.3.50	IP4_AddrToUint32	
10.3.51	IP_IsAddrEqual	
10.3.52	IP6_IsUnspecifiedAddr	
10.3.53	IP6_IsLinkLocalAddr	
10.3.54	IP6_IsSiteLocalAddr	
10.3.55	IP6_IsUniqueLocalAddr	
10.3.56	IP6_IsGlobalAddr	
10.3.57	IP6_IsMulticastAddr	
10.3.58	IP6_IsAnycastAddr	
10.3.59	IP6_IsLoopbackAddr	
10.3.60	IP6_IsLocalMulticastAllNodes	
10.3.61	IP6_IsLocalMulticastAllRouters	
10.3.62	IP6_IsMeshMulticastAllNodes	
10.3.63	IP6_IsAddrEui64	
10.3.64	IP_ADDR	
10.3.65	IPV4_Mask32_g	
10.3.66	IP_IsAddrIPv4	
10.3.67	IP4 IsUnspecifiedAddr	
10.3.68	IP_IsAddrIPv6	
10.3.69	NWKU_AppendNwkBuffer	
10.3.70	NWKU IsLlAddrValid	
10.3.71	NWKU_GetLastArrayIndex	
10.3.71	htona24	
10.3.73	ntoha24	
10.3.74	htona48	
10.3.75	ntoha48	
10.3.76		
10.3.77	ntohs	
10.3.78	htons	
10.3.79		
	htonl	
10.3.80 10.3.81	ntohll	
	htonll	
10.3.82	ntohas	. 183

NXP Semiconductors xix

Section number	er Title	Page
10.3.83	htonas	. 183
10.3.84	ntohal	. 184
10.3.85	htonal	. 184
10.3.86	ntohall	. 184
10.3.87	htonall	. 184
10.3.88	AF_UNSPEC	. 184
10.3.89	AF_INET	. 184
10.3.90	AF_INET6	. 184
10.3.91	DEFAULT_LLADDR_IDX	. 184
10.3.92	MIN	. 184
10.3.93	NWKU_GENERIC_MSG_EVENT	. 185
10.3.94	NWKU_MEM_BufferAlloc	. 185
10.3.95	NWKU_MEM_BufferAllocForever	. 185
10.4	Typedef Documentation	. 185
10.4.1	nwkMsgHandler	. 185
10.4.2	tspDataIndCb_t	. 185
10.5	Enumeration Type Documentation	. 185
10.5.1	llAddrSize_t	. 185
10.5.2	ipIfUniqueId_t	. 186
10.5.3	nwkStatus_t	. 186
	Function Documentation	. 186
10.6.1	NWKU_SendMsg(nwkMsgHandler pFunc, void *pPload, taskMsgQueue_	
	t *msgQueue)	
10.6.2	NWKU_RecvMsg(taskMsgQueue_t *pMsgQueue)	
10.6.3	NWKU_MsgHandler(taskMsgQueue_t *pMsgQueue)	
10.6.4	NWKU_CreateIpAddr(void)	
10.6.5	NWKU_ConvertIp4Addr(uint32_t ip4Addr, ipAddr_t *pOutIpAddr)	
10.6.6	IP6_IsRealmLocalAddr(ipAddr_t *pIpAddr)	
10.6.7	NWKU_CreateIpPktInfo(void)	
10.6.8	NWKU_FreeIpPktInfo(ipPktInfo_t **pIpPktInfo)	
10.6.9	NWKU_CreateNwkBuffer(uint32_t dataSize)	
10.6.10	NWKU_FreeAllNwkBuffers(nwkBuffer_t **pNwkBufferStart)	. 190
10.6.11	NWKU_FreeNwkBufferElem(nwkBuffer_t **pNwkBufferStart, nwkBuffer_t *pElem)	. 190
10.6.12	NWKU_NwkBufferTotalSize(nwkBuffer_t *pNwkBufferStart)	
10.6.13	NWKU_MemCopyFromNwkBuffer(nwkBuffer_t **pNwkBuffer, uint8_t **p	
	SrcPtr, uint8_t *pDstPtr, uint32_t size)	. 191
10.6.14	NWKU_NwkBufferAddOffset(nwkBuffer_t **pNwkBuffer, uint8_t **pSrcPtr,	
	uint32_t size)	. 192
10.6.15	NWKU_NwkBufferNumber(nwkBuffer_t *pNwkBufferStart)	
10.6.16	NWKU_NwkBufferToRegularBuffer(nwkBuffer_t *pNwkBufferStart, uint8_	
	t *pRegularBuffer)	. 192

Section number	Title	Page
10.6.17	NWKU_CreatePseudoHeader4(nwkBuffer_t *pNwkBuff, ipAddr_t *pSrcIp, ip -	
	Addr_t *pDstIp, uint32_t length, uint8_t nextHeader)	193
10.6.18	NWKU_CreatePseudoHeader6(nwkBuffer_t *pNwkBuff, ipAddr_t *pSrcIp, ip↔	
	Addr_t *pDstIp, uint32_t length, uint8_t nextHeader)	193
10.6.19	NWKU_CalculateChecksum(nwkBuffer_t *pStart)	
10.6.20	NWKU_CmpAddrPrefix6(uint8_t *addr1, uint8_t *addr2, uint32_t prefixLen)	
10.6.21	NWKU_MemCmpToVal(uint8_t *pAddr, uint8_t val, uint32_t len)	
10.6.22	NWKU_BitCmp(uint8_t *pStr1, uint8_t *pStr2, uint8_t startBit, uint8_t stopBit).	
10.6.23	NWKU_IsLLAddrEqual(uint8_t *pFirstLlAddr, uint32_t firstLlAddrSize,	
	uint8_t *pSecondLlAddr, uint32_t secondLlAddrSize)	196
10.6.24	NWKU_GetCommonPrefixLen6(ipAddr_t *addr1, ipAddr_t *addr2)	
10.6.25	NWKU_TransformArrayToValue(uint8_t *pArray, uint32_t nbOfBytes)	
10.6.26	NWKU_TransformValueToArray(uint64_t value, uint8_t *pArray, uint32_t nb-	,
	OfBytes)	198
10.6.27	NWKU_Revert16(uint16_t value)	
10.6.28	NWKU_Revert32(uint32_t value)	
10.6.29	NWKU_Revert64(uint64_t value)	
10.6.30	NWKU_TransformArrayToUint16(uint8_t *pArray)	
10.6.31	NWKU_TransformArrayToUint32(uint8_t *pArray)	
10.6.32	NWKU_TransformArrayToUint64(uint8_t *pArray)	
10.6.33	NWKU_TransformUint16ToArray(uint8_t *pArray, uint16_t value)	
10.6.34	NWKU_TransformUint32ToArray(uint8_t *pArray, uint32_t value)	
10.6.35	NWKU_TransformUint64ToArray(uint8_t *pArray, uint64_t value)	
10.6.36	NWKU_GetLut8(lut8_t *pLutTable, uint8_t lutTableSize, uint8_t type, uint8_t	. 201
10.0.30	*pEntryIndex)	201
10.6.37	NWKU_atoi(char *pStr)	
10.6.38	NWKU_atol(char *pStr)	
10.6.39	NWKU_PrintDec(uint64_t value, uint8_t *pString, uint32_t nbPrintDigits,	. 202
10.0.39	bool_t bLeadingZeros)	202
10.6.40	pton(uint8_t af, char *pTxt, ipAddr_t *pIpAddr)	
10.6.41	ntop(uint8_t af, ipAddr_t *pIpAddr, char *pStr, uint32_t strLen)	
10.6.42	ptoll(uint8_t *pIn, uint32_t len, llAddr_t *pLlAddr)	
10.6.43	NWKU_AsciiToHex(uint8_t *pString, uint32_t strLen)	
10.6.44		
	NWKU_AsciiToDec(uint8_t *pString, uint32_t strLen)	
10.6.45	NWKU_ByteToDec(uint8_t byte)	
10.6.46	NWKU_NibToAscii(int8_t nib, bool_t useUpperCase)	. 204
10.6.47	NWKU_HexToAscii(uint8_t *pInputBuff, uint32_t inputBuffLen, uint8_t *p OutputPuffer vint32_t autputPuffl on heal two Harry Coss	205
10 (40	OutputBuffer, uint32_t outputBuffLen, bool_t useUpperCase)	
10.6.48	NWKU_TmrRtcGetElapsedTimeInSeconds(uint32_t timestamp)	
10.6.49	NWKU_IsNUmber(char *pString)	
10.6.50	NWKU_GetRandomNoFromInterval(uint32_t startInterval, uint32_t endInterval)	
10.6.51	NWKU_IncrementIp6Addr(ipAddr_t *pIpAddr)	
10.6.52	NWKU_RightRotate(uint32_t val, uint8_t amount)	
10.6.53	NWKU_GetIIDFromLLADDR(llAddr_t *llAddr, uint16_t panId, uint8_t *pIID) .	
10.6.54	NWKU_GetLLAddrFromIID(uint8_t *pIID, llAddr_t *pLlAddr)	. 208

Kinetis Thread Stack API Reference Manual

NXP Semiconductors

xxi

Section number	er Title	Page
10.6.55	NWKU_IsIPAddrBasedOnShort(ipAddr_t *pIpAddr)	. 208
10.6.56	NWKU_GetBit(uint32_t bitNr, uint8_t *pArray)	. 208
10.6.57	NWKU_SetBit(uint32_t bitNr, uint8_t *pArray)	
10.6.58	NWKU_ClearBit(uint32_t bitNr, uint8_t *pArray)	. 210
10.6.59	NWKU_GetFirstBitValueInRange(uint8_t *pArray, uint32_t lowBitNr, uint32_t	
	highBitNr, bool_t bitValue)	. 210
10.6.60	NWKU_GetFirstBitValue(uint8_t *pArray, uint32_t arrayBytes, bool_t bitValue)	. 210
10.6.61	NWKU_GetNumOfBits(uint8_t *pArray, uint32_t arrayBytes, bool_t bitValue)	. 211
10.6.62	NWKU_ReverseBits(uint32_t num)	. 211
10.6.63	NWKU_AddTblEntry(uint32_t entry, uint32_t *pTable, uint32_t tableSize)	. 211
10.6.64	NWKU_GetTblEntry(uint32_t index, uint32_t *pTable, uint32_t tableSize)	
10.6.65	NWKU_SwapArrayBytes(uint8_t *pByte, uint8_t numOfBytes)	. 212
10.6.66	NWKU_GenRand(uint8_t *pRand, uint8_t randLen)	
10.6.67	NWKU_GetTlvLen(uint8_t type, uint8_t *pStart, uint32_t len)	
10.6.68	NWKU_GetTlvValue(uint8_t type, uint8_t *pStart, uint32_t len, uint8_t *pOut)	
10.6.69	NWKU_GetTlv(uint8_t type, uint8_t *pStart, uint32_t len, uint8_t *pOut,	
	uint32_t *pOutLen)	
10.6.70	NWKU_Pbkdf2(pbkdf2Params_t *pInput, uint8_t *pOut, uint32_t outLen)	
10.6.71	NWKU_GetTimestampMs(void)	
10.6.72	NWKU_isArrayGreater(const uint8_t *a, const uint8_t *b, uint8_t length)	
	Variable Documentation	
10.7.1	u16	. 216
10.7.2	u8	. 216
10.7.3	u32	. 216
10.7.4	u16	. 216
10.7.5	u8	. 216
10.7.6	u64	. 216
10.7.7	u32	. 217
10.7.8	u16	. 217
10.7.9	u8	. 217
10.7.10	addr8	. 217
10.7.11	addr16	. 217
10.7.12	addr32	. 217
10.7.13	addr64	. 217
10.7.14	next	. 217
10.7.15	pData	. 217
10.7.16	size	. 218
10.7.17	freeBuffer	
10.7.18	eui	. 218
10.7.19	addrSize	
10.7.20	versionTraficClass	
10.7.21	trafficClassFlowLabel	
10.7.22	flowLabel	
10.7.23	payloadLength	
- 30	L-7	10

Section number	Title	Page
10.7.24	nextHeader	. 218
10.7.25	hopLimit	. 219
10.7.26	srcAddr	. 219
10.7.27	dstAddr	. 219
10.7.28	ifHandle	. 219
10.7.29	ipExtensionHeaderBuffer	. 219
10.7.30	ipReassemblyOptions	
10.7.31	srcLlInfo	
10.7.32	ipHdrOffset	
10.7.33	hopLimit	
10.7.34	security	
10.7.35	lqi	
10.7.36	qos	
10.7.37	isRelay	
10.7.38	macSecKeyIdMode	
10.7.39	channel	
10.7.40	destPanId	
10.7.41	srcPanId	
10.7.42	ipIfId	
10.7.43	hopLimit	
10.7.44	security	
10.7.45	lqi	
10.7.46	isRelay	
10.7.47	channel	
10.7.48	macSecKeyIdMode	
10.7.49	macSrcPanId	
10.7.50	pNwkBuff	
10.7.51	pIpSrcAddr	
10.7.52	pIpDstAddr	
10.7.53	pNextProt	
10.7.54	ipSrcAddr	
10.7.55	ipDstAddr	
10.7.56	nextProtLen	
10.7.57	protocolType	
10.7.58	1 *1	
10.7.59	prot	
10.7.60	srcPort	
10.7.61		
10.7.62	ipPktOptions	
	pFunc	
10.7.63	pPload	
10.7.64	msgQueue	
10.7.65	taskId	
10.7.66	taskEventId	
10.7.67	type	
10.7.68	idx	. 223

NXP Semiconductors xxiii

Section number	Title	Page
10.7.69	ipktUsed	. 223
10.7.70	ipktMax	. 224
10.7.71	nwkBuffUsed	. 224
10.7.72	nwkBuffMax	. 224
10.7.73	prefixLen	. 224
10.7.74	aPrefix	. 224
10.7.75	pPass	. 224
10.7.76	passLen	. 224
10.7.77	pSalt	. 224
10.7.78	saltLen	. 224
10.7.79	rounds	. 225

Chapter 1 Thread Application Configuration Interface

Overview 1.1

Files

- file app stack config.h
- file app_thread_config.h
- file thread_cfg.h

Macros

- #define THREAD_USE_SHELL
- #define THREAD_USE_THCI
- #define THR MAX REED ROUTERS NEIGHBORS
- #define THR_MAX_SLEEPY_ED_NEIGHBORS#define THR_MAX_NEIGHBORS
- #define THR_MAX_DATA_REQS
- #define THR FAILED CHILD TRANSMISSIONS
- #define THR_FAILED_ROUTER_TRANSMISSIONS
- #define DHCP6_SERVER_MAX_INSTANCES
- #define DHCP6_SERVER_MAX_CLIENTS
- #define DHCP6_CLIENT_MAX_INSTANCES
- #define COAP_MAX_SESSIONS
- #define BSDS_MAX_SOCKETS
- #define MAX_UDP_CONNECTIONS
- #define IP_IP6_ROUTING_TBL_SIZE
- #define IP_IP6_FIREWALL_TBL_SIZE
- #define IP_IF_NB
- #define IP IF IP6 ADDR NB
- #define IP_IF_IP6_MULTICAST_ADDR_NB
- #define IP_TRANSPORT_SERVICE_NB
- #define IP_IP_REASSEMBLY_QUEUE_SIZE#define IP_IF_IP4_ADDR_NB
- #define MPL_INSTANCE_SET_SIZE
- #define MPL_SEED_SET_SIZE
- #define MPL_BUFFERED_MESSAGE_SET_SIZE
- #define TRICKLE_INSTANCE_SET_SIZE
- #define TRICKLE_LIST_SIZE#define SLWPCFG_INSTANCES_NB
- #define SLWPCFG_RFC6282_CONTEXT_TABLE_SIZE
- #define SLWPCFG_UNFRAG_SED_TRACK_NB
- #define SLWPCFG_UNFRAG_SED_TRACK_PKT_NB
- #define SLWPCFG_SED_IND_QUEUE_SIZE
- #define MAC_FILTERING_ENABLED#define MAC_FILTERING_TABLE_SIZE
- #define ThrPoolId_d
- #define THREAD_TASK_MSG_QUEUE_SIZE

Macro Definition Documentation

- #define THREAD TASK STACK SIZE
- #define THR MAX INSTANCES
- #define DEBUG_REED_AUTO_PROMOTE
- #define THR SERVER DATA PREFIX TBL SIZE
- #define THR_SERVER_DATA_BR_SET_TBL_SIZE
- #define THR_SERVER_DATA_HAS_ROUTE_TBL_SIZE
- #define THR_LOCAL_SERVICE_SET_TBL_SIZE#define THR_NWK_DATA_SERVICE_SET_TBL_SIZE
- #define THR_SLAAC_TEMP_ADDR_TABLE_SIZE
- #define THR_NWK_DATA_PREFIX_TBL_SIZE
- #define THR_NWK_DATA_CTX_TBL_SIZE
- #define THR NWK DATA BR SET TBL SIZE
- #define THR NWK DATA HAS ROUTE TBL SIZE
- #define THR_NWK_DATA_MIN_STABLE_LIFETIME_SEC
- #define THR LEADER ID SEQUENCE PERIOD SEC
- #define THR CHILD ADDR REG ENTIRES
- #define THR_CHILD_MCAST_ADDR_REG_ENTIRES
- #define THR_MAX_LINK_SYNC_NEIGHBORS
- #define THR_MAX_NWK_ATTACH_PARENT_ENTRIES
- #define THR_REATTACH_JITTER_MIN_MS
- #define THR_REATTACH_JITTER_MAX_MS
- #define THR_LEADER_TIMEOUT_SEC
- #define THR_MAX_ROUTERS
- #define THR ROUTER UPGRADE THRESHOLD
- #define THR_ROUTER_DOWNGRADE_THRESHOLD
- #define THR MIN DOWNGRADE NEIGHBORS
- #define THR ROUTER SELECTION JITTER SEC
- #define THR MAX DEV ADDR QUERY CACHE ENTRIES
- #define THR_ADDRESS_QUERY_TIMEOUT_SEC
- #define THR_ADDRESS_QUERY_INITIAL_RETRY_DELAY_SEC#define THR_ADDRESS_QUERY_MAX_RETRY_DELAY_SEC
- #define THR_POWERON_ROUTER_MIN_JITTER_MS
- #define THR_POWERON_ROUTER_MAX_JITTER_MS
- #define THR POWERON ED MAX JITTER MS
- #define THR_PARENT_ROUTE_TO_LEADER_TIMEOUT_MS
- #define THR_CHILD_ED_KEEP_ALIVE_INTERVAL_MIN_MS#define THR_CHILD_ED_KEEP_ALIVE_INTERVAL_MAX_MS
- #define THR CONTEXT REUSE DELAY SEC
- #define THR DISCOVERY EXT ADDR
- #define THR_DISCOVERY_KEY
- #define THR_DISCOVERY_FRAME_COUNTER
- #define THR_DISCOVERY_TIME
- #define THR_DISCOVERY_MAX_JITTER

1.2 **Macro Definition Documentation**

1.2.1 #define THREAD USE SHELL

Thread APP uses SHELL commands.

1.2.2 #define THREAD USE THCI

Thread APP uses FCSI commands.

1.2.3 #define THR MAX REED ROUTERS NEIGHBORS

The maximum number of Thread Router / REED (Router Eligible Devices) radio range neighbors.

1.2.4 #define THR MAX SLEEPY ED NEIGHBORS

The maximum number of Thread Sleepy End Device radio range neighbors.

1.2.5 #define THR_MAX_NEIGHBORS

The maximum number of radio range neighbors with which the Thread device can communicate.

1.2.6 #define THR_MAX_DATA_REQS

The maximum number of simultaneous 802.15.4 transmissions.

1.2.7 #define THR_FAILED_CHILD_TRANSMISSIONS

Number of consecutive failed 802.15.4 transmissions for a link to be considered down and a child device to reattach.

1.2.8 #define THR FAILED ROUTER TRANSMISSIONS

Number of consecutive failed 802.15.4 transmissions for a Router-to-Router link to be considered broken.

1.2.9 #define DHCP6_SERVER_MAX_INSTANCES

The maximum number of DHCPv6 servers that can be started on the device.

1.2.10 #define DHCP6 SERVER MAX CLIENTS

The maximum number of DHCPv6 clients that the device can service as a DHCPv6 server.

1.2.11 #define DHCP6_CLIENT_MAX_INSTANCES

The maximum number of DHCPv6 clients that can be started on the device.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

1.2.12 #define COAP_MAX_SESSIONS

The maximum number of COAP sessions that can be established at one time.

1.2.13 #define BSDS_MAX_SOCKETS

The maximum number of sockets that can be opened at one time.

MUST be correlated to MAX_UDP_CONNECTIONS

1.2.14 #define MAX UDP CONNECTIONS

The maximum number of UDP connections that can be opened at one time.

MUST not be greater than BSDS_MAX_SOCKETS

1.2.15 #define IP_IP6_ROUTING_TBL_SIZE

The maximum number of IP route entries.

1.2.16 #define IP IP6 FIREWALL TBL SIZE

The maximum number of dynamic firewall entries.

1.2.17 #define IP_IF_NB

The maximum supported number of IP interfaces.

1.2.18 #define IP IF IP6 ADDR NB

The maximum number of IPv6 addresses.

This is regardless of how many interfaces are available

1.2.19 #define IP IF IP6 MULTICAST ADDR NB

The maximum number of supported multicast addresses.

1.2.20 #define IP_TRANSPORT_SERVICE_NB

The maximum number of IP transport services that can be supported.

Ex. UDP, TCP.

1.2.21 #define IP_IP_REASSEMBLY_QUEUE_SIZE

Number representing how many IP packet fragments can be stored at one time.

1.2.22 #define IP_IF_IP4_ADDR_NB

The maximum number of IPv4 addresses.

This is regardless of how many interfaces are available

1.2.23 #define MPL INSTANCE SET SIZE

The maximum number of MPL instances.

This must be correlated to IP_IF_NB.

1.2.24 #define MPL SEED SET SIZE

The maximum number of seeds the MPL module can store at one time.

1.2.25 #define MPL_BUFFERED_MESSAGE_SET_SIZE

The maximum number of MPL transmitted messages that can be buffered at one time.

1.2.26 #define TRICKLE INSTANCE SET SIZE

The maximum number of TRICKLE instances.

This must be correlated to IP_IF_NB

1.2.27 #define TRICKLE_LIST_SIZE

The maximum number of Trickle events.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

1.2.28 #define SLWPCFG_INSTANCES_NB

The maximum number of 6LoWPAN instances.

MUST not be greater than IP_IF_NB

1.2.29 #define SLWPCFG_RFC6282_CONTEXT_TABLE_SIZE

The maximum number of 6LoWPAN contexts that can be stored.

1.2.30 #define SLWPCFG_UNFRAG_SED_TRACK_NB

The number of SED devices a router can handle for unfragmented packets.

1.2.31 #define SLWPCFG_UNFRAG_SED_TRACK_PKT_NB

The number of unfragmented packets a parent can hold for a SED.

1.2.32 #define SLWPCFG_SED_IND_QUEUE_SIZE

The number of SED fragmented packets a parent can hold for transmission.

1.2.33 #define MAC FILTERING ENABLED

Enables/Disables the MAC Filtering.

1.2.34 #define MAC_FILTERING_TABLE_SIZE

The maximum number of entries in the MAC filtering table.

1.2.35 #define ThrPoolId_d

The message pool ID used for thread stack.

1.2.36 #define THREAD_TASK_MSG_QUEUE_SIZE

The size of the massage queue used by Thread task.

1.2.37 #define THREAD_TASK_STACK_SIZE

The stack size of Thread task.

1.2.38 #define THR_MAX_INSTANCES

The maximum number of Thread Interfaces.

MUST not be greater that IP_IF_NB

1.2.39 #define DEBUG REED AUTO PROMOTE

Debug flag for auto promote.

1.2.40 #define THR SERVER DATA PREFIX TBL SIZE

The size of the Server Data prefix table.

1.2.41 #define THR_SERVER_DATA_BR_SET_TBL_SIZE

The size of Border Route table for local Server Data.

1.2.42 #define THR_SERVER_DATA_HAS_ROUTE_TBL_SIZE

The size of Has Route table for local Server Data.

1.2.43 #define THR_LOCAL_SERVICE_SET_TBL_SIZE

The size of local BR service set.

1.2.44 #define THR NWK DATA SERVICE SET TBL SIZE

The size of Nwk Data Service Set table.

1.2.45 #define THR_SLAAC_TEMP_ADDR_TABLE_SIZE

The size of Thread Slaac temporary address table - stored in NVM (NotMirroredInRam)

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

1.2.46 #define THR_NWK_DATA_PREFIX_TBL_SIZE

The size of NWK Data prefix table.

1.2.47 #define THR_NWK_DATA_CTX_TBL_SIZE

The size of NWK Data context table.

1.2.48 #define THR_NWK_DATA_BR_SET_TBL_SIZE

The size of NWK Data Border Set table.

1.2.49 #define THR_NWK_DATA_HAS_ROUTE_TBL_SIZE

The size of NWK Data Has Route table.

1.2.50 #define THR_NWK_DATA_MIN_STABLE_LIFETIME_SEC

The lifetime for stable NWK Data.

1.2.51 #define THR_LEADER_ID_SEQUENCE_PERIOD_SEC

The maximum interval between increments of ID_sequence_number by the Leader.

1.2.52 #define THR_CHILD_ADDR_REG_ENTIRES

The number of entries in the Address registration table per RFD child.

1.2.53 #define THR_CHILD_MCAST_ADDR_REG_ENTIRES

The number of entries in the Multicast Address registration table per RFD child.

1.2.54 #define THR MAX LINK SYNC NEIGHBORS

The max number of neighbors to do a link sync.

1.2.55 #define THR_MAX_NWK_ATTACH_PARENT_ENTRIES

The maximum number of parents selected to attach with.

1.2.56 #define THR_REATTACH_JITTER_MIN_MS

The minimum jitter time for generating the random period used at re-attaching the device.

1.2.57 #define THR_REATTACH_JITTER_MAX_MS

The maximum jitter time for generating the random period used at re-attaching the device.

1.2.58 #define THR_LEADER_TIMEOUT_SEC

The maximum number of seconds for a Router to get disconnected from the Leader if no ID_sequence_
number is received from a neighbor.

If a Router goes for THR_LEADER_TIMEOUT_SEC seconds without receiving a new ID_sequence_
number from a neighbor, it MUST consider itself disconnected from the Leader and stop using its current
Router ID

1.2.59 #define THR MAX ROUTERS

The maximum number of allowed Routers in the Thread network.

Maximum value can be 32

1.2.60 #define THR_ROUTER_UPGRADE_THRESHOLD

The number of active Routers on the Thread Network below which a REED may decide to become a Router.

1.2.61 #define THR_ROUTER_DOWNGRADE_THRESHOLD

The number of active Routers on the Thread Network above which an active Router may decide to become a Child.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

1.2.62 #define THR_MIN_DOWNGRADE_NEIGHBORS

The minimum number of neighbors with link quality 2 or better that a Router must have to downgrade to a REED.

It should be less than 32

1.2.63 #define THR ROUTER SELECTION JITTER SEC

The maximum jitter time when soliciting a router ID.

1.2.64 #define THR MAX DEV ADDR QUERY CACHE ENTRIES

The max number of cache entries for address query.

1.2.65 #define THR_ADDRESS_QUERY_TIMEOUT_SEC

The time needed for an address query to complete.

1.2.66 #define THR ADDRESS QUERY INITIAL RETRY DELAY SEC

The minimum delay between 2 address queries.

1.2.67 #define THR_ADDRESS_QUERY_MAX_RETRY_DELAY_SEC

The maximum delay betwenn 2 address queries.

1.2.68 #define THR POWERON ROUTER MIN JITTER MS

On power on, during the network start with NVM, a router will perform a Link Sync after a random period between [THR_POWERON_ROUTER_MIN_JITTER_MS, THR_POWERON_ROUTER_MA \(X_JITTER_MS \)].

1.2.69 #define THR POWERON ROUTER MAX JITTER MS

On power on, during the network start with NVM, a router will perform a Link Sync after a random period between [THR_POWERON_ROUTER_MIN_JITTER_MS, THR_POWERON_ROUTER_MA \(\times \) X JITTER MS].

Kinetis Thread Stack API Reference Manual

1.2.70 #define THR_POWERON_ED_MAX_JITTER_MS

On power on, during the network start with NVM, an end device will perform a Child Update after a random period between [gThrPowerOnRouterMaxJitterMs, gThrPowerOnRouterMaxJitterMs+gThrPower← OnEDMaxJitterMs].

1.2.71 #define THR_PARENT_ROUTE_TO_LEADER_TIMEOUT_MS

The number of seconds a Child waits prior to reattaching in the event its Parent advertises an infinite cost to the Leader.

1.2.72 #define THR CHILD ED KEEP ALIVE INTERVAL MIN MS

The default periodic interval for REED or End DeviceRxOn to send ChildUpdateRequest. These values should be less than THR_CHILD_ED_TIMEOUT_PERIOD_SEC

1.2.73 #define THR_CHILD_ED_KEEP_ALIVE_INTERVAL_MAX_MS

The default periodic interval for REED or End DeviceRxOn to send ChildUpdateRequest.

These values should be less than THR_CHILD_ED_TIMEOUT_PERIOD_SEC

1.2.74 #define THR_CONTEXT_REUSE_DELAY_SEC

Network Data Context ID reuse delay.

1.2.75 #define THR_DISCOVERY_EXT_ADDR

The extended address used for discovery.

1.2.76 #define THR_DISCOVERY_KEY

The key used for discovery.

1.2.77 #define THR_DISCOVERY_FRAME_COUNTER

The frame counter used for discovery.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

1.2.78 #define THR_DISCOVERY_TIME

Time an originator of a Discovery Request should wait for incoming Discovery Responses on a channel.

1.2.79 #define THR_DISCOVERY_MAX_JITTER

Maximum jitter time used to delay generation of Discovery Responses.

Chapter 2 Thread Network Interface

2.1 Overview

Files

• file thread network.h

Data Structures

struct thrDeviceConfig_t

Macros

- #define THR_NWKCAP_CAN_CREATE_NEW_NETWORK
- #define THR_NWKCAP_CAN_BECOME_ACTIVE_ROUTER
- #define THR_NWKCAP_IS_POLLING_END_DEVICE
- #define THR_NWKCAP_IS_FULL_THREAD_DEVICE
- #define THR NWKCAP BIT MASK

Enumerations

```
    enum thrEvCodesNwkScan_t { gThrEv_NwkScanCnf_Results_c }
    enum thrEvCodesCreate_t { gThrEv_NwkCreateCnf_Success_c, gThrEv_NwkCreateCnf_Failed_c, gThrEv_NwkCreateInd_SelectBestChannel_c, gThrEv_NwkCreateInd_GeneratePSKc_c }
    enum thrEvCodesJoin_t { gThrEv_NwkJoinInd_Attaching_c, gThrEv_NwkJoinCnf_Success_c, gThrEv_NwkJoinCnf_Failed_c }
    enum thrEvCodesJoinSelectParent_t { gThrEv_NwkSelectParentsInd_ScanStarted_c, gThrEv_NwkSelectParentsInd_RcvBeacon_c, gThrEv_NwkSelectParentsInd_ScanEnded_c }
    enum thrEvCodesGeneral_t {
```

Overview

```
gThrEv GeneralInd Disconnected c.
gThrEv_GeneralInd_Connected_c,
gThrEv GeneralInd ResetToFactoryDefault c.
gThrEv_GeneralInd_InstanceRestoreStarted_c,
gThrEv GeneralInd RouterSynced c,
gThrEv GeneralInd EndDeviceSynced c,
gThrEv_GeneralInd_ConnectingStarted_c,
gThrEv_GeneralInd_ConnectingFailed_c,
gThrEv GeneralInd ConnectingDeffered c,
gThrEv_GeneralInd_DeviceIsLeader_c,
gThrEv_GeneralInd_DeviceIsRouter_c,
gThrEv GeneralInd DevIsREED c,
gThrEv GeneralInd DevIsFED c,
gThrEv GeneralInd DevIsSED c.
gThrEv_GeneralInd_RequestGlobalAddr_c,
gThrEv GeneralInd GlobalAddrAssigned c,
gThrEv GeneralInd RequestRouterId c,
gThrEv_GeneralInd_RouterIdAssigned_c,
gThrEv_GeneralInd_RouterIdAssignedFailed_c,
gThrEv GeneralInd AllowDeviceToSleep c,
gThrEv_GeneralInd_DisallowDeviceToSleep_c,
gThrEv GeneralInd ChildIdAssigned c.
gThrEv_GeneralInd_DevIsMED_c,
gThrEv GeneralInd ResetMcuTimeout c }
```

Functions

- void THR Task (osaTaskParam t argument)
- void THR_Init (void)
- thrStatus_t THR_InitAttributes (instanceId_t thrInstId, stackConfig_t *pStackCfg)
- thrStatus_t THR_StartInstance (instanceId_t thrInstId, stackConfig_t *pStackCfg)
- thrStatus_t THR_SetDeviceConfig (instanceId_t thrInstId, thrDeviceConfig_t *pThrDeviceConfig)
- thrStatus_t THR_SetDeviceRole (instanceId_t thrInstID, thrDeviceRole_t thrDeviceRole)
- thrStatus t THR NwkScanWithBeacon (instanceId t thrInstId, thrNwkScan t *pThrNwkScan)
- thrStatus_t THR_NwkDiscoveryReq (instanceId_t thrInstId, thrNwkDiscoveryReqTxOpt_t *p↔ DiscReqTxOpt, thrDiscoveryRespCb_t pfDiscoveryRespCb)
- thrStatus_t THR_NwkDiscoveryStop (instanceId_t thrInstId)
- thrStatus_t THR_SearchThreadNwkWithAnnounce (instanceId_t thrInstId, uint32_t scanChannel← Mask, thrAnnounceCb t pfAnnounceCb)
- thrStatus_t THR_SetBorderRouterIf (instanceId_t thrInstId, ipIfUniqueId_t brIfId)
- thrStatus_t THR_NwkCreate (instanceId_t thrInstId)
- thrStatus t THR NwkAttach (instanceId t thrInstId)
- thrStatus_t THR_NwkJoin (instanceId_t thrInstId, thrJoinDiscoveryMethod_t discMethod)
- thrStatus_t THR_NwkDetach (instanceId_t thrInstId)
- thrStatus_t THR_SoftwareReset (instanceId_t thrInstID, bool_t factoryReset)
- void THR_FactoryReset (void)
- void THR_TimeoutResetMcu (uint32_t timeoutMs, bool_t resetToFactory)
- thrNeighbor_t * THR_GetParent (instanceId_t thrInstID)
- thrNeighbor t * THR GetNeighborTable (uint32 t iCount)

15

- uint16_t **THR_NeighborGetShortByExtAddr** (uint64_t *pEui)
- thrNeighbor_t * THR_NeighborGetByShort (uint16_t shortAddr)
- thrRouterIdSet_t * THR_GetRouterIdSet (instanceId_t thrInstId)
- thrStatus_t THR_LeaderRemoveRouterID (instanceId_t thrInstID, uint32_t routerID)
- thrStatus_t THR_RouterLinkSync (instanceId_t thrInstID, bool_t bOnReset)
- thrStatus_t THR_ChildUpdateToParent (instanceId_t thrInstID)
- thrStatus_t THR_SolicitGlobalAddress (instanceId_t thrInstID)
- thrStatus_t THR_BrPrefixAttrAddEntry (instanceId_t thrInstID, thrOtaBrPrefixSet_t *pEntry)
- thrStatus_t THR_ServiceAttrAddEntry (instanceId_t thrInstID, thrLocalServiceSet_t *pEntry)
- thrStatus_t THR_BrPrefixAttrRemoveEntry (instanceId_t thrInstID, uint8_t prefixLength, uint8_t *pPrefixValue)
- thrStatus_t THR_BrServiceAttrRemoveEntry (instanceId_t thrInstID, uint8_t *pServiceData, uint8_t serviceDataLen, uint8_t *pServerData, uint8_t serverDataLen)
- void THR_BrPrefixAttrGetTable (instanceId_t thrInstID, uint8_t startIndex, uint8_t reqNoOf← Elements, uint8_t *pRspNoOfElements, uint8_t *pOutData)
- thrStatus t THR BrPrefixAttrRemoveAll (instanceId t thrInstID)
- thrStatus_t THR_BrPrefixAttrSync (instanceId_t thrInstID)
- thrStatus_t THR_SendProactiveAddressNotification (instanceId_t thrInstId, ipAddr_t *pDestIp← Addr)
- uint64_t THR_GenerateExtendedAddress (bool_t privacyAddr)
- thrLqCacheEntry_t * THR_GetRlocToEidMapByEntry (uint32_t entry)

Variables

• thrDeviceConfig_t gaThrDeviceConfig []

2.2 Data Structure Documentation

2.2.1 struct thrDeviceConfig_t

thread device configuration

Data Fields

bool_t	outOfBand←	If TRUE than the device is out-of-band configured.
	Configured	 On network creation, it is not used.
		• On joining, if it is set TRUE the THR_NwkJoin() will per-
		form only the attaching procedure; otherwise it will perform
		the joining with Commissioner procedure (mesh-cop join-
		ing).
		-

Macro Definition Documentation

uint8_t	outOfBand← Channel	Network creation channel. If different form 0, On network creation (THR_NwkCreate()), will OVERRIDE the SCAN channel and only use this channel. Range: 0, 11-26
uint16_t	panId	• On network creation (THR_NwkCreate()), the configured value will be used or if it is set to 0xffff then the device will generate a random pan ID .
	scanChannels	The channel mask used for scanning for networks and to discover network parameters (panId, channel, xpan, network name)
uint8_t	xPanId[8]	 On network creation (THR_NwkCreate()), the configured value will be used or if all bytes are 0xff then the device will generate a random extended pan ID. On joining using out-of-band configuration (outOfBand← Configured = TRUE), if all bytes are 0xff then the device won't filter after the extended pan ID; otherwise it uses this extended pan id for filtering.
uint8_t	masterKey[16]	 On network creation (THR_NwkCreate()), the configured value will be used or if all bytes are 0xff then the device will generate a random master key. On joining using out-of-band configuration (outOfBand← Configured = TRUE), the device uses the configured key for communication.
thrOctet16_t		On joining with the out-of-band configuration (outOfBand Configured = TRUE), if (outOfBandChannel == 0) and nwk Name.length!= 0, the device will filter after network name to find the pan id and channel.
thrPrefixAttr↔ _t	MLprefix	• On network creation (THR_NwkCreate()), the configured value will be used or if all bytes are 0xff then the device will generate a random mesh local prefix.

2.3 Macro Definition Documentation

2.3.1 #define THR_NWKCAP_CAN_CREATE_NEW_NETWORK

Thread Device Capabilities.

The node can create a new network

2.3.2 #define THR NWKCAP CAN BECOME ACTIVE ROUTER

The node can become an active router.

2.3.3 #define THR NWKCAP IS POLLING END DEVICE

The node is a polling end device (sleepy end device)

2.3.4 #define THR_NWKCAP_IS_FULL_THREAD_DEVICE

The node is a full Thread device (FTD)

2.3.5 #define THR_NWKCAP_BIT_MASK

Thread Device Capabilities bit mask.

2.4 Enumeration Type Documentation

2.4.1 enum thrEvCodesNwkScan_t

Network scan events.

Enumerator

gThrEv_NwkScanCnf_Results_c nwk scan confirm - results

2.4.2 enum thrEvCodesCreate_t

Network Create Events.

Enumerator

```
gThrEv_NwkCreateCnf_Success_c nwk create confirm - success
gThrEv_NwkCreateCnf_Failed_c nwk create confirm - failed
gThrEv_NwkCreateInd_SelectBestChannel_c nwk create indication - select best channel
gThrEv_NwkCreateInd_GeneratePSKc_c nwk create indication - generate PSKc
```

Enumeration Type Documentation

2.4.3 enum thrEvCodesJoin_t

Network Join Events.

Enumerator

```
gThrEv_NwkJoinInd_Attaching_c nwk join indication - attaching gThrEv_NwkJoinCnf_Success_c nwk join confirm - success gThrEv_NwkJoinCnf_Failed_c nwk join confirm - failed
```

2.4.4 enum thrEvCodesJoinSelectParent_t

Network Select Parent when joining with Commissioner.

Enumerator

```
gThrEv_NwkSelectParentsInd_ScanStarted_c network select parent indication - scan started gThrEv_NwkSelectParentsInd_RcvBeacon_c network select parent indication - received beacon gThrEv_NwkSelectParentsInd_ScanEnded_c network select parent indication - scan ended
```

2.4.5 enum thrEvCodesGeneral t

Network General Events - warning the order of events impacts the THCI event monitor.

Enumerator

```
gThrEv_GeneralInd_Disconnected_c general event indication - disconnected
gThrEv_GeneralInd_Connected_c general event indication - connected
gThrEv_GeneralInd_ResetToFactoryDefault_c general event indication - device started with factory defaults
```

- gThrEv_GeneralInd_InstanceRestoreStarted_c general event indication start restore from reset
 gThrEv_GeneralInd_RouterSynced_c general event indication restored from reset with success
 for router
- gThrEv_GeneralInd_EndDeviceSynced_c general event indication restored from reset with success for end device
- gThrEv_GeneralInd_ConnectingStarted_c general event indication trying to connect to the network
- gThrEv_GeneralInd_ConnectingFailed_c general event indication failed to connect to the network
- gThrEv_GeneralInd_ConnectingDeffered_c general event indication app must initiate connect action
- gThrEv_GeneralInd_DeviceIsLeader_c general event indication device has leader role

Kinetis Thread Stack API Reference Manual

```
gThrEv_GeneralInd_DeviceIsRouter_c general event indication - device has router role
gThrEv_GeneralInd_DevIsREED_c general event indication - device has REED role
gThrEv_GeneralInd_DevIsFED_c general event indication - device has RX on when idle end device role
```

gThrEv_GeneralInd_DevIsSED_c general event indication - device has sleepy end device role
gThrEv_GeneralInd_RequestGlobalAddr_c general event indication - request global address
gThrEv_GeneralInd_GlobalAddrAssigned_c general event indication - global address assigned
gThrEv_GeneralInd_RequestRouterId_c general event indication - request router short address
gThrEv_GeneralInd_RouterIdAssigned_c general event indication - router short address assigned
gThrEv_GeneralInd_RouterIdAssignedFailed_c general event indication - failed to received router
short address

gThrEv_GeneralInd_AllowDeviceToSleep_c general event indication - allow device to sleep gThrEv_GeneralInd_DisallowDeviceToSleep_c general event indication - disallow device to sleep gThrEv_GeneralInd_ChildIdAssigned_c general event indication - child short address assigned gThrEv_GeneralInd_DevIsMED_c general event indication - device has minimal end device role gThrEv_GeneralInd_ResetMcuTimeout_c general event indication - reset mcu timeout

2.5 Function Documentation

2.5.1 void THR_Task (osaTaskParam_t argument)

Thread application task.

Parameters

in	argument	Task private data

Returns

NONE

2.5.2 void THR_Init (void)

Initialize Thread module.

Returns

NONE

2.5.3 thrStatus_t THR_InitAttributes (instanceId_t thrInstId, stackConfig_t * pStackCfg)

Function that initializes with factory defaults or restores from NVM the Thread Attributes.

Kinetis Thread Stack API Reference Manual

Parameters

in	thrInstId	Thread instance Id
in	pStackCfg	Pointer to stack configuration

Returns

thrStatus_t Result of the operation

2.5.4 thrStatus_t THR_StartInstance (instanceId_t thrInstId, stackConfig_t * pStackCfg)

Function that starts the Thread instance.

Parameters

in	thrInstID	Thread instance ID
in	pStackCfg	Pointer to stack configuration

Returns

thrStatus_t Result of the operation

2.5.5 thrStatus_t THR_SetDeviceConfig (instanceld_t thrInstId, thrDeviceConfig_t * pThrDeviceConfig)

This function is used to set device configuration. This function overwrites the default settings (see app← _thread_config.h) with a minimum set of attributes needed to start a node. The application may not call this function if it wants to use the default settings.

Parameters

in	thrInstID	Thread instance Id
in	pThrDevice↔	Pointer to device configuration
	Config	

Returns

thrStatus_t Status

2.5.6 thrStatus_t THR_SetDeviceRole (instanceId_t thrInstID, thrDeviceRole_t thrDeviceRole)

This is a public function used to set the network capabilities for a Thread device.

Kinetis Thread Stack API Reference Manual

Parameters

in	thrInstID	Thread instance ID
in	thrDeviceRole	Thread desired device role.

Returns

thrStatus_t Status

2.5.7 thrStatus_t THR_NwkScanWithBeacon (instanceId_t thrInstId, thrNwkScan_t * pThrNwkScan)

This function is used to start a network scan using beacon messages. A callback function must be registered (using EVM_RegisterStatic() function) with the gThrEvSet_NwkScan_c set to receive the scan results (see thrNwkScanResults_t message).

Parameters

in	thrInstID	Thread instance Id
in	pThrNwkScan	Network scan parameters

Returns

thrStatus t Status

2.5.8 thrStatus_t THR_NwkDiscoveryReq (instanceId_t thrInstId, thrNwkDiscoveryReqTxOpt_t * pDiscReqTxOpt, thrDiscoveryRespCb_t pfDiscoveryRespCb)

This function starts the Thread Discovery Procedure. A callback function must be registered (pf← DiscoveryRespCb) to receive the Discovery Responses.

Parameters

in	thrInstID	Thread instance Id
in	pDiscReqTx↔	Pointer to Discovery Request Tx options
	Opt	
in	pfDiscovery⇔	Pointer to a callback to receive the Discovery Responses
	RespCb	

Returns

thrStatus_t Status

Kinetis Thread Stack API Reference Manual

2.5.9 thrStatus_t THR_NwkDiscoveryStop (instanceId_t thrInstId)

This function stops the discovery process before timing out.

23

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus t Status

2.5.10 thrStatus_t THR_SearchThreadNwkWithAnnounce (instanceId_t thrInstId, uint32_t scanChannelMask, thrAnnounceCb_t pfAnnounceCb)

The device has the Nwk key and searches the thread network using the announcement messages. Only Thread networks that have the same Nwk key will respond. This function could be used to discover the channel and panId of a Thread network, so that to start the attachment process (to perform the out-of-band joining procedure).

Parameters

in	thrInstID	Thread instance Id
in	scanChannel←	Channel mask to scan
	Mask	
in	pfAnnounceCb	Pointer to a callback that handles the received announcement messages.

Returns

thrStatus_t Status

2.5.11 thrStatus_t THR_SetBorderRouterIf (instanceId_t thrInstID, ipIfUniqueId_t brIfId)

This function is used for configuring a device as a Thread Border Router by providing the external interface to use for routing outbound packets

Parameters

in	thrInstID	Thread instance Id.
in	brIfId	Border router external interface Unique ID

Returns

thrStatus_t status

2.5.12 thrStatus_t THR_NwkCreate (instanceId_t thrInstId)

This function is used to create a Thread network (start the device as a leader node). If the PAN ID and channel attributes are configured (panid != 0xFFFF and channel != 0), the function will start the leader using these attributes. Otherwise, the scanChannelMask attribute is used to select the best channel and panID. A callback function is registered (see thread_app_callbacks.h and app_thread_callbacks.c) with the gThrEvSet_NwkCreate_c event set to receive the network creation events(see APP_NwkCreateCb callback). Note that THR_NWKCAP_CAN_CREATE_NEW_NETWORK bit must be set in the network capabilities.

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus_t Status

2.5.13 thrStatus_t THR_NwkAttach (instanceId_t thrInstId)

This function is used to perform the attachment procedure using the configured attributes: channel, panId, network key. NOTE:

- It can be used for out-of-band joining.
- A callback function must be registered (using EVM_RegisterStatic() function) with the gThrEvc—Set_NwkJoin_c event set to receive the network join events.

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus_t Status

2.5.14 thrStatus_t THR_NwkJoin (instanceld_t thrInstld, thrJoinDiscovery ← Method_t discMethod)

This function is used to join a device to a thread network and is using all the above functionality. Depending on attributes configuration, it can perform the following actions:

1. join as an end node using commissioning (calling MESHCOP_NwkJoinWithCommissioning()). In this case, the device is NOT out-of-band configured; this means the devIsCommissioned attribute shall be set to FALSE. Depending on discovery method parameter (discMethod), the device will search the panId and channel using Beacon or Thread Discovery messages.

Kinetis Thread Stack API Reference Manual

2. attach to a thread network (calling THR NwkAttach()). In this case, the device must be out-of-band configured; this means the devIsCommissioned attribute shall be set to TRUE. Depending on discovery method parameter (discMethod), the device will search the panId and channel using Beacon or Announcement messages (see THR_SearchThreadNwkWithAnnounce()). A callback function must be registered (using EVM_RegisterStatic() function) with the gThrEvSet_NwkJoin_c event set to receive the network join events.

Parameters

in	thrInstID	Thread instance Id
in	discMethod	The discovery method (see thrJoinDiscoveryMethod_t)

Returns

thrStatus t Status

2.5.15 thrStatus_t THR_NwkDetach (instanceId_t thrInstId)

This function is used to detach a joined device. The device will keep the network settings but will disconnect itself from the network.

Parameters

in	thrInstID	Thread instance Id

Returns

thrStatus t Status

thrStatus_t THR SoftwareReset (instanceld t thrInstID, bool t 2.5.16 factoryReset)

This function is used to do a thread software reset.

Parameters

in	thrInstID	Thread instance Id
in	factoryReset	If TRUE, the device will be reseted to factory

Returns

thrStatus_t Status

Kinetis Thread Stack API Reference Manual NXP Semiconductors 25

2.5.17 void THR_FactoryReset (void)

This function is used to reset device to factory default settings.

Returns

NONE

2.5.18 void THR_TimeoutResetMcu (uint32_t timeoutMs, bool_t resetToFactory)

This function is used to reset the device after a specific timeout.

Parameters

in	timeoutMs	Time expressed in milliseconds units. [in] resetToFactory If TRUE, the
		device will be reseted to factory

Returns

NONE

2.5.19 thrNeighbor_t * THR_GetParent (instanceId_t thrInstID)

This is a public function used to get information about parent when node is an end device and REED or about the attaching parent in case of a router. For a leader it will return NULL.

Parameters

in	thrInstID	Thread instance ID
----	-----------	--------------------

Returns

thrNeighbor_t* Pointer to neighbor structure.

2.5.20 thrNeighbor_t * THR_GetNeighborTable (uint32_t iCount)

This function is used to get the neighbor from a given index from the neighbor table.

Parameters

in	iCount	Entry in neighbor table
----	--------	-------------------------

Returns

thrNeighbor_t * Pointer to neighbor structure.

2.5.21 thrNeighbor_t * THR NeighborGetByShort (uint16 t shortAddr)

This function is used to get a neighbor's information by its short address.

Parameters

in	shortAddr	Neighbor's short address
----	-----------	--------------------------

Returns

thrNeighbor_t Neighbor info

2.5.22 thrRouterIdSet_t * THR GetRouterIdSet (instanceld t thrInstId)

This function is used to get the thread router ID set.

Parameters

in	thrInstId	Thread instance id	
----	-----------	--------------------	--

Returns

thrRouterIdSet_t* Pointer to router ID set structure

2.5.23 thrStatus_t THR_LeaderRemoveRouterID (instanceId_t thrInstID, uint32_t routerID)

This function is used to remove a router from network. It should be called only on the leader node.

Parameters

Kinetis Thread Stack API Reference Manual

in	thrInstID	Thread instance ID
in	routerID	The ID of the router to be removed

Returns

thrStatus_t Status

2.5.24 thrStatus_t THR_RouterLinkSync (instanceld_t thrInstID, bool_t bOnReset)

This function will perform the "link synchronization after reset" or "initial link synchronization" procedure. Must be called only on a router node.

Parameters

in	thrInstID	Thread instance Id
in	bOnReset	Specify if the router should do the "Router synchronization after reset"
		procedure or the "Initial Router synchronization" procedure.

Returns

thrStatus_t Status

2.5.25 thrStatus_t THR_ChildUpdateToParent (instanceId_t thrInstID)

This function is used to send a ChildUpdate.Request to synchronize the parent with the updated attributes (timeout period, node mode flags TLV).

Parameters

	I	
in	thrInstID	Thread instance Id

Returns

thrStatus_t Status

2.5.26 thrStatus_t THR_SolicitGlobalAddress (instanceId_t thrInstID)

This function solicits a global address from a DHCPv6 server.

Kinetis Thread Stack API Reference Manual

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus t Status

2.5.27 thrStatus_t THR_BrPrefixAttrAddEntry (instanceId_t thrInstID, thrOtaBrPrefixSet_t * pEntry)

Add a Border router prefix attribute entry.

Parameters

in	thrInstID	Thread instance Id
in	pEntry	Border router nwk data entry

Returns

thrStatus_t Status

2.5.28 thrStatus_t THR_ServiceAttrAddEntry (instanceId_t thrInstID, thrLocalServiceSet_t * pEntry)

Add a Border router service attribute entry.

Parameters

in	thrInstID	Thread instance Id
in	pEntry	Border router service set entry

Returns

thrStatus_t Status

2.5.29 thrStatus_t THR_BrPrefixAttrRemoveEntry (instanceId_t thrInstID, uint8_t prefixLength, uint8_t * pPrefixValue)

Remove Border Router prefix attribute entry.

Kinetis Thread Stack API Reference Manual

Parameters

in	thrInstID	Thread instance Id
in	prefixLength	Prefix size
in	pPrefixValue	Prefix value

Returns

thrStatus_t Status

2.5.30 thrStatus_t THR_BrServiceAttrRemoveEntry (instanceId_t thrInstID, uint8_t * pServiceData, uint8_t * pServerData, uint8_t * pServerData, uint8_t * pServerDataLen)

Remove Service attribute entry.

Parameters

in	thrInstID	Thread instance Id
in	pServiceData	Pointer to service data
in	serviceData⇔	Service data size
	Len	
in	pServerData	Pointer to server data
in	D I	Server data size

Returns

thrStatus t Status

2.5.31 void THR_BrPrefixAttrGetTable (instanceId_t thrInstID, uint8_t startIndex, uint8_t reqNoOfElements, uint8_t * pRspNoOfElements, uint8_t * pOutData)

Get the BR table, from startIndex to a maximum of reqNoOfElements.

Parameters

in	thrInstID	Thread instance Id
in	startIndex	Start to search from this index
in	reqNoOf⇔	Try to retrieve this many elements
	Elements	
out	pRspNoOf⇔	Actual number of elements retrieved
	Elements	
out	pOutData	Data buffer to store the information

Kinetis Thread Stack API Reference Manual

2.5.32 thrStatus_t THR_BrPrefixAttrRemoveAll (instanceId_t thrInstID)

Remove all Border router prefix attribute entries.

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus t Status

2.5.33 thrStatus_t THR_BrPrefixAttrSync (instanceId_t thrInstID)

This function is used to synchronize the Border Router prefixes with the over-the-air network data information. After adding or removing more BR prefixes, this function shall be called to propagate the global network data.

Parameters

in	thrInstID	Thread instance Id
----	-----------	--------------------

Returns

thrStatus_t Status

2.5.34 thrStatus_t THR_SendProactiveAddressNotification (instanceId_t thrInstId, ipAddr_t * pDestIpAddr)

This function is used to send ADDR_NTF.ntf - Proactive Address Notification. This is useful if the device has changed short address and knows there are devices that likely maintain an address cache of that short address.

Parameters

in	thrInstId	Thread instance ID
in	pDestIpAddr	Destination address: unicast or multicast

Returns

thrStatus_t Status

2.5.35 uint64_t THR_GenerateExtendedAddress (bool_t privacyAddr)

This function generates a random extended mac address

Kinetis Thread Stack API Reference Manual

Parameters

in	privacyAddr	TRUE if the address should be a privacy address
D . 1		
Return value	es .	
	uint64_t e	extended mac address

2.5.36 thrLqCacheEntry_t * THR_GetRlocToEidMapByEntry (uint32_t entry)

This function is used to get a specific entry from eid to rloc mapping cache table.

Parameters

in	entry	Entry table number.
		· J ···· · · · · · · · · · · · · · · ·

Returns

thrLqCacheEntry_t* Pointer to value of the entry, NULL if entry number is not valid

2.6 Variable Documentation

2.6.1 thrDeviceConfig_t gaThrDeviceConfig[]

Thread device configuration.

Variable Documentation

Chapter 3 **Thread Attributes Interface**

3.1 **Overview**

Files

• file thread attributes.h

Data Structures

- struct thrAttr t
- struct thrStringAttr_t
- struct thrActiveAttr_t
- struct thrPendingAttr_t
- struct thrOtaBrPrefixSet_t
- struct thrLocalServiceSet_t

Macros

- #define THR_BR_PREFIX_FLAGS_P_PREFERENCE_MASK
- #define THR_BR_PREFIX_FLAGS_P_PREFERRED_MASK
- #define THR_BR_PREFIX_FLAGS_P_SLAAC_MASK
- #define THR_BR_PREFIX_FLAGS_P_DHCP_MASK
- #define THR_BR_PREFIX_FLAGS_P_CONFIGURE_MASK
- #define THR_BR_PREFIX_FLAGS_P_DEFAULT_MASK

- #define THR_BR_PREFIX_FLAGS_P_ON_MESH_MASK
 #define THR_BR_PREFIX_FLAGS_P_ND_DNS_MASK
 #define THR_BR_PREFIX_FLAGS_P_PREFERENCE_OFFSET
- #define THR_BR_PREFIX_FLAGS_P_PREFERRED_OFFSET
- #define THR BR PREFIX FLAGS P SLAAC OFFSET
- #define THR_BR_PREFIX_FLAGS_P_DHCP_OFFSET
- #define THR BR PREFIX FLAGS P CONFIGURE OFFSET
- #define THR_BR_PREFIX_FLAGS_P_DEFAULT_OFFSET
- #define THR_BR_PREFIX_FLAGS_P_ON_MESH_OFFSET
- #define THR_BR_PREFIX_FLAGS_P_ND_DNS_OFFSET
- #define THR BR EXT ROUTE FLAGS R PREF MASK
- #define THR_BR_EXT_ROUTE_FLAGS_R_PREF_OFFSET
- #define THR_BR_FLAGS_SET(flag, value, mask, offset)
 #define THR_BR_FLAGS_GET(value, mask, offset)
- #define THR_FLAGS_PREFERENCE_MEDIUM
- #define THR_FLAGS_PREFERENCE_HIGH
- #define THR FLAGS PREFERENCE RESERVED
- #define THR FLAGS PREFERENCE LOW
- #define gNwkAttrId Undefined c
- #define **THR_GetAttr_Channel**(thrInstId)
- #define **THR_GetAttr_PanId**(thrInstId)
- #define **THR GetAttr ShortAddr**(thrInstId)

Overview

- #define THR GetAttr IsDevConnected(thrInstId)
- #define **THR_GetAttr_PartionId**(thrInstId)
- #define THR_GetAttr_NwkCapabilities(thrInstId)
- #define THR_GetAttr_IsDevCommissioned(thrInstId)
- #define THR_GetAttr_DeviceRole(thrInstId)
- #define THR_GetAttr_DeviceType(thrInstId)
- #define THR_GetAttr_CommissionerMode(thrInstId)
- #define THR_GetAttr_SelBestChEDThreshold(thrInstId)
- #define **THR_GetAttr_JoinLqiThreshold**(thrInstId)
- #define **THR GetAttr PermitJoin**(thrInstId)
- #define THR_GetAttr_BrDefaultRoute(thrInstId)
- #define THR GetAttr BrExternalIfPrefix(thrInstId)
- #define THR GetAttr BrGlobalOnMeshPrefix(thrInstId)
- #define THR_GetAttr_ScanChannelMask(thrInstId)
- #define THR GetAttr SedFastPollInterval(thrInstId)
- #define THR GetAttr SedPollInterval(thrInstId)
- #define **THR_GetAttr_SedFastPoll**(thrInstId)
- #define THR_GetAttr_DoNotGeneratePartId(thrInstId)
- #define THR_GetAttr_NwkKeySeq(thrInstId)
- #define THR_GetAttr_NvmRestore(thrInstId)
- #define THR_GetAttr_NvmAutostart(thrInstId)
- #define THR_GetAttr_ChildAddrMask(thrInstId)
- #define THR_GetAttr_ScanDuration(thrInstId)
- #define THR_GetAttr_DiscReqMacTxOptions(thrInstId)
- #define THR GetAttr RandExtAddr(thrInstId)
- #define THR_GetAttr_ShaHashAddr(thrInstId)
- #define THR_GetAttr_RxOnWhenIdle(thrInstId)
- #define **THR_GetAttr_Weighting**(thrInstId)
- #define THR_GetAttr_ChildReqFullNwkData(thrInstId)
- #define THR GetAttr ParentHoldTime(thrInstId)
- #define THR_GetAttr_KeySwitchGuardTime(thrInstId)
- #define THR_GetAttr_JoinerUdpPort(thrInstId)
- #define THR_GetAttr_MinDelayTimer(thrInstId)
- #define THR GetAttr CommissionerUpdPort(thrInstId)
- #define **THR_GetAttr_SedTimeoutPeriod**(thrInstId)
- #define THR_GetAttr_EdTimeoutPeriod(thrInstId)
- #define **THR GetAttr SlaacPolicy**(thrInstId)

Enumerations

```
• enum thrAttrId t {
  gNwkAttrId_RandExtAddr_c,
 gNwkAttrId_ShortAddr_c,
 gNwkAttrId ScanChannelMask c,
  gNwkAttrId_ScanDuration_c,
  gNwkAttrId_Channel_c,
 gNwkAttrId_PanId_c,
 gNwkAttrId ExtendedPanId c,
  gNwkAttrId_PermitJoin_c,
 gNwkAttrId RxOnIdle c.
 gNwkAttrId_SEDPollInterval_c,
 gNwkAttrId UniqueExtAddr c,
  gNwkAttrId_VendorName_c,
 gNwkAttrId_ModelName_c,
 gNwkAttrId_SWVersion_c,
 gNwkAttrId StackVersion c,
  gNwkAttrId_ThreadNwkCapabilites_c,
 gNwkAttrId NwkName c.
 gNwkAttrId DeviceType c,
 gNwkAttrId IsDevConnected c,
  gNwkAttrId_IsDevCommissioned_c,
 gNwkAttrId_PartitionId_c,
 gNwkAttrId DeviceRole c,
  gNwkAttrId_NwkMasterKey_c,
  gNwkAttrId_NwkKeySeq_c,
 gNwkAttrId_PSKc_c,
 gNwkAttrId_PSKd_c,
  gNwkAttrId_VendorData_c,
 gNwkAttrId_EDTimeoutPeriod_c,
 gNwkAttrId_MLPrefix_c,
 gNwkAttrId WhiteListEntry c,
  gNwkAttrId_KeyRotationInterval_c,
 gNwkAttrId ChildAddrMask c.
 gNwkAttrId_SEDTimeoutPeriod_c,
 gNwkAttrId ChildEDReqFullNwkData c,
 gNwkAttrId_IsFastPollEnabled_c,
 gNwkAttrId_SEDFastPollInterval_c,
 gNwkAttrId_JoinLqiThreshold_c,
 gNwkAttrId ProvisioningURL c,
 gNwkAttrId_SelectBestChEDThreshold_c,
 gNwkAttrId_SteeringData_c,
 gNwkAttrId KeySwitchGuardTime c,
  gNwkAttrId_ParentHoldTime_c,
  gNwkAttrId_SecurityPolicy_c,
 gNwkAttrId_NvmRestoreAutoStart_c,
 gNwkAttrId_NvmRestKinetis Thread Stack API Reference Manual
```

```
gNwkAttr MinDelayTime }
```

Functions

- thrStatus t THR InitAttr (instanceId t thrInstId, void *pDefaultAttr, void *pDefaultStrAttr, void *pDefaultActiveDataSetAttr)
- thrStatus_t THR_GetAttr (instanceId_t thrInstID, thrAttrId_t attrID, uint32_t index, uint32_t *pe Size, void *pAttrValue)
- thrStatus t THR SetAttr (instanceId t thrInstID, thrAttrId t attrID, uint32 t index, uint32 t size, void *pAttrValue)

Variables

- thrAttr_t * gpaThrAttr []
- thrStringAttr_t * gpaThrStringAttr []
- thrActiveAttr_t * gpaThrActiveAttr []
- thrPendingAttr_t * gpaThrPendingAttr []
 ipAddr_t gaServerDataPrefixTbl []
- uint8_t gaServerDataPrefixLenTbl []
- borderRouterSet_t gaThrServerDataBrSetTbl []
- externalRouteSet_t gaServerDataExtRouteTbl []
- thrLocalServiceSet t * gpaLocalServiceSetTbl []
- const uint8 t gLocalServiceSetTblSize

3.2 **Data Structure Documentation**

3.2.1 struct thrAttr t

Thread network information base (Thread Nibs) structure:

- 802.15.4 attributes
- thread specific attributes

Data Fields

uint64_t	ieeeAddr	The MAC extended address, also called IEEE address, long address or 64-bit MAC address.
uint64_t	shaHashAddr	MAC address used for commissioning generated from SHA256 hash on the ieeeAddr.
uint64_t	randExtAddr	The random MAC extended address, used for communication in-
		side the network after commissioning.
uint8_t	scanDuration	The scan duration time. This is an exponential scale, as seen in the 802.15.4 specification. Range: 0 - 14. Values greater than 14 will be set to 14, as described in Thread Specification chapter 8.10.2.
		10. The user can take into account that the total scanning time also depends on the number of channels scanned. Ex.: for a scanmask
		of 16 channels, maximum value of scanDuration is 8, meaning 3.75 seconds/channel.
uint16_t	shortAddr	The short address.
bool_t		Permit Join(Router devices only). True = Device is allowing the
0001_t	permison	child to join the network, False = Device is not allowing any child to join the network
bool_t	rxOnWhenIdle	The receiver is ON when the device is in idle state. Set RxOn← WhenIdle TRUE for mains-powered (non-sleeping) end-devices. Set this FALSE for sleeping end-devices. When FALSE, end-devices will poll their parent for messages. See sedPollInterval for the polling timeout.
uint32_t	sedPollInterval	The poll interval in milliseconds. This attribute is used only for sleepy end devices
uint32 t	sedFastPoll←	The fast poll interval in milliseconds. This attribute is used only
umt32_t	Interval	for sleepy end devices during the joining procedure
bool_t	isFastPoll← Enabled	Specify if the fast polling is enabled.
bool_t	uniqueExtAddr	If is set to TRUE, the device is automatically generated a random extended address.
bool_t	devIs← Connected	Specifies if the device is connected or not.
bool_t		If TRUE than the device is commissioned. • On joining calling THR_NwkJoin() with devIs← Commissioned == TRUE, the device will perform the attaching procedure using the commissioning settings. Note that a network active scan is performed before attaching. • On joining calling THR_NwkJoin() with devIs← Commissioned == FALSE, the device will perform the joining with Commissioner procedure (mesh-cop joining).

Kinetis Thread Stack API Reference Manual

uint32_t	sedTimeout←	The Timeout period used by the parent to consider a sleepy end
	Period	device (SED) disconnected.
uint32_t	edTimeout←	The Timeout period used by the parent to consider an end device
	Period	(ED) disconnected.
bool_t	childEDReq←	If it is set TRUE, the end device is requesting the full network
	FullNwkData	data(stable and temporary nwk data). If it is set FALSE, the end
		device is requesting only the unstable (temporary) network data.
thrDevice←	deviceType	The device type: 0x00 -EndNode, 0x01 - Combo Node.
Type_t		
thrInternal←	devRole	The device role: 0x01 - SED, 0x02 - MED, 0x03 - FED,0x04 -
DeviceRole_t		REED, 0x05 - Router, 0x06 - Leader.
uint8_t	thrNwk⊷	A bitmap that specify network capabilities of this device.
	Capabilities←	
	BitMap	
uint32_t	nwkKeySeq	The current network key sequence number.
uint32_t	childAddr↔	The child address mask.
	Mask[THR_←	
	MAX_CHIL←	
	D_IDS]	
uint32_t	partitionId	The current partition identifier.
uint8_t	weighting	Leader weight.
bool_t	doNot⊷	Avoid random generation of partition ID.
	Generate←	
	PartitionId	
uint8_t	joinLqi⊷	The joining LQI threshold used to select a potential parent.
	Threshold	
uint8_t	selBest←	The energy channel threshold to select the best channel when more
	ChannelED←	channels are scan (energy detect scan) to form the network. Note
	Threshold	that this is used only if the scanChannelMask attribute includes
		more than one channel.
		Joiner UDP port.
uint16_t		Commissioner UDP port.
	UdpPort	
uint32_t	keySwitch←	The thread Key switch guard time to prevent inadvertent key
	GuardTime	switching.
uint16_t	*	Thread hold time in seconds used by the parent to hold the packets
	Time	for SED devices.
uint8_t	slaacPolicy	Used SLAAC policy (see thrSlaacPolicy_t)
bool_t	nvmRestore←	Stack starts automatically with NVM restore after reset.
	AutoStart	

Kinetis Thread Stack API Reference Manual

bool_t	nvmRestore	Restore from NVM.
thrPrefixAttr←	brGlobalOn⊷	Global /64 on-Mesh Prefix on Border Router.
_t	MeshPrefix	
bool_t	brDefaultRoute	Default Route of the /64 on-mesh prefix.
thrPrefixAttr←	brExternalIf←	Global /64 external interface prefix.
_t	Prefix	
uint8_t	discoveryReq←	The default discovery request Mac Tx options (see thrDiscReq←
	MacTxOptions	TxOptions_t)
uint32_t	minDelay←	The minimum accepted time before a Pending Dataset can be
	Timer	installed[s].

3.2.2 struct thrStringAttr_t

Thread network information base (Thread Nibs) structure:

• thread specific string attributes

Data Fields

thrOctet32_t	vendorName	Vendor name.
thrOctet16_t	modelName	Model Name.
thrOctet16_t	swVersion	Software version.
thrOctet64_t	provisioning←	Provisioning URL.
	URL	
thrOctet16_t	steeringData	Steering data.
thrOctet32_t	pskD	The passphrase used in authentication procedure - a new Joiner
		device is the correct one.
uint8_t	stackVersion[6]	Stack version - ReadOnly.
thrOctet64_t	vendorData	Vendor data.
thrOctet64_t	commissioner←	Commissioner ID.
	Id	

3.2.3 struct thrActiveAttr_t

Data Fields

uint8_t	channel	The current channel.
uint32_t	scanChannel←	The channels mask used when a network scanning is performed
		(energy scan, active scan or both); 0x07FFF800 means all 16 channels are used (from 11 to 26).

Kinetis Thread Stack API Reference Manual

uint16_t	panId	The PAN identifier (ID). • On network creation (calling THR_NwkCreate()), if it is set 0xffff then the device will generate a random pan ID.
uint8_t	xPanId[8]	 The extended PAN ID. On network creation (calling THR_NwkCreate()), if all bytes are 0xff's then the device will generate a random extended pan ID. On joining using out-of-band configuration (calling THR←_NwkJoin() when devIsCommissioned = TRUE), if xPanId! = all ff's the device is using this extended pan id to find the pan ID and channel; otherwise no filter is apply
thrPrefixAttr← t	MLprefix	
uint8_t	nwkMaster↔ Key[16]	The network master key.
thrOctet16_t	nwkName	Network Name. • On joining calling THR_NwkJoin() with devIs← Commissioned == TRUE, if nwkName.length != 0, the device will filter after network name to find the network parameters.
uint8_t	pskC[16]	The Pre-Shared Key (PSKc) derived from Commissioning Credential (network password)
uint8_t	securityPolicy	O and N bits without rotation time.
uint32_t	nwkKey← Rotation← Interval	The current key rotation interval in minutes.
uint8_t	timestamp[8]	First 6 bytes: seconds, last 2 bytes: ticks.

3.2.4 struct thrPendingAttr_t

Data Fields

ſ	uint16_t	channel	Pending channel.
	uint32_t	scanChannel←	Pending Channel Mask.
		Mask	

Kinetis Thread Stack API Reference Manual

uint16_t	panId	Pending Pan ID.
uint8_t	xPanId[8]	Pending Extended PanId.
thrPrefixAttr←	mlPrefix	Pending MeshLocal prefix.
_t		
uint8_t	nwkMaster⊷	Pending Master Key.
	Key[16]	
thrOctet16_t	nwkName	Pending Network Name.
uint8_t	pskC[16]	Pending PSKc.
uint8_t	securityPolicy	Pending Security Policy bits.
uint32_t	nwkKey⊷	Pending Key Rotation Interval[sec].
	Rotation←	
	Interval	
uint8_t	active	Pending Active Timestamp.
	Timestamp[8]	
uint8_t	timestamp[8]	Pending Timestamp.
uint32_t	delayTimer	Pending Delay Timer[msec].

3.2.5 struct thrOtaBrPrefixSet_t

border router network data attributes - ota format Data Fields

uint8_t	thrBrPrefix←	Prefix length in bits.
	Length	
uint8_t	thrBrPrefix←	Prefix value.
	Value[16]	
uint8_t	thrBrPrefix←	Flags data - Border Router TLV of the Thread Network Data: byte0
	Flags[2]	- reserved, byte1 - border router flags (see above BR prefix flags)
uint8_t	thrBrPrefix←	Prefix Data Lifetime (seconds)
	Lifetime[4]	
bool_t	thrBrPrefix←	Flag that indicates whether a Border Router TLV SHALL be ad-
	Advertised	vertised for prefix in the Network Data.
uint8_t	thrBrExt←	Flags data - Has Route TLV of the Thread Network Data (see above
	RouteFlags	BR external route flags)
uint8_t	thrBrExt←	External Route Data Lifetime (seconds)
	Route←	
	Lifetime[4]	

Enumeration Type Documentation

bool_t	thrBrExt←	Flag that indicates whether a Has Route TLV SHALL be advertised
	Route⊷	for prefix in the Network Data.
	Advertised	

3.2.6 struct thrLocalServiceSet_t

Data Fields

uint8_t	thr⊷	Senterprise number.
	Senterprise←	
	Number[4]	
uint8_t	thrSservice←	Size of the Sservice data.
	DataLen	
uint8_t	thrSservice←	Sservice data eg "dnsserver".
	Data[THR_S←	
	ERVICE_DA←	
	TA_MAX_L	
	EN]	
uint8_t	thrSserver16←	Sserver address.
	Addr[2]	
uint8_t	thrSserver←	Size of sserver data (16)
	DataLen	
uint8_t	thrSserver←	Sserver data.
	Data[THR_S←	
	ERVER_DA⊷	
	TA_MAX_L ←	
	EN]	
uint8_t	thrSserviceId	Sservice id.
bool_t	thrSstable	Sstable mode.

3.3 Enumeration Type Documentation

3.3.1 enum thrAttrId_t

Thread network information base (Thread Nibs) Ids:

- 802.15.4 attributes
- thread specific attributes

Enumerator

```
    gNwkAttrId_RandExtAddr_c Random extended address.
    gNwkAttrId_ShortAddr_c Short address.
    gNwkAttrId_ScanChannelMask_c Scan channel mask.
    gNwkAttrId_ScanDuration_c Scan duration.
```

Kinetis Thread Stack API Reference Manual

Enumeration Type Documentation

```
gNwkAttrId Channel c Channel.
gNwkAttrId_PanId_c Pan id.
gNwkAttrId_ExtendedPanId_c Extended pan id.
gNwkAttrId_PermitJoin_c Permit join.
gNwkAttrId_RxOnIdle_c Rx on when idle.
gNwkAttrId SEDPollInterval c Poll interval.
gNwkAttrId_UniqueExtAddr_c Unique extended address (test only)
gNwkAttrId_VendorName_c Vendor name.
gNwkAttrId ModelName c Model name.
gNwkAttrId_SWVersion_c Software version.
gNwkAttrId_StackVersion_c Stack version.
gNwkAttrId ThreadNwkCapabilities c Nwk capabilities.
gNwkAttrId_NwkName_c Nwk name.
gNwkAttrId DeviceType c Device type.
gNwkAttrId_IsDevConnected_c Is device connected.
gNwkAttrId_IsDevCommissioned_c Is device out-of band preconfigured.
gNwkAttrId PartitionId c Partition id of the network.
gNwkAttrId_DeviceRole_c Device role.
gNwkAttrId_NwkMasterKey_c Nwk master key.
gNwkAttrId NwkKeySeq c Nwk key sequence.
gNwkAttrId_PSKc_c Network credential.
gNwkAttrId PSKd c Device password.
gNwkAttrId_VendorData_c Vendor data.
gNwkAttrId_EDTimeoutPeriod_c The timeout period included in the Child ID Request sent to the
     parent.
gNwkAttrId_MLPrefix_c Mesh local prefix.
gNwkAttrId_WhiteListEntry_c White list entry.
gNwkAttrId KeyRotationInterval c Key rotation interval.
gNwkAttrId_ChildAddrMask_c Child address mask.
gNwkAttrId_SEDTimeoutPeriod_c The timeout period included in the Child ID Request sent to the
gNwkAttrId_ChildEDReqFullNwkData_c If it is set TRUE The child End device should request
     the Full network data.
gNwkAttrId_IsFastPollEnabled_c Is fast poll enabled.
gNwkAttrId SEDFastPollInterval c Fast poll interval.
gNwkAttrId JoinLqiThreshold c Join lqi threshold.
gNwkAttrId_ProvisioningURL_c A URL for the Joiner to communicate to the user which Commis-
     sioning application is best to use to properly provision it to the appropriate service.
gNwkAttrId_SelectBestChEDThreshold_c The energy channel threshold to select the best channel
     when more channels are scan to form the network.
gNwkAttrId SteeringData c Steering data.
```

Kinetis Thread Stack API Reference Manual

switching.

packets for SED devices.

NXP Semiconductors 45

gNwkAttrId_KeySwitchGuardTime_c The thread Key switch guard time to prevent inadvertent key

gNwkAttrId ParentHoldTime c The hold time period in seconds used by the parent to hold the

```
gNwkAttrId_SecurityPolicy_c O and N bits without the rotation time.
gNwkAttrId_NvmRestoreAutoStart_c Stack starts automatically with NVM restore after reset.
gNwkAttrId NvmRestore c Restore from NVM.
gNwkAttrId_SlaacPolicy_c Specifies the policy for generating the IID of an address configured us-
    ing SLAAC.
gNwkAttrId IeeeAddr c MAC IEE Extended address used for SHA256 address generation.
gNwkAttrId_LeaderWeight_c Leader Weight, an 8-bit unsigned integer.
gNwkAttrId_HashIeeeAddr_c SHA256 generated MAC address used during commissioning phase.
gNwkAttrId_DoNotGeneratePartitionId_c Avoid random generation of partition ID.
gNwkAttrId_BrGlobalOnMeshPrefix_c Global /64 on-Mesh Prefix on Border Router.
gNwkAttrId BrDefaultRouteOnMeshPrefix c Default Route of the /64 on-mesh prefix.
gNwkAttrId_BrExternalIfPrefix_c Global /64 external interface prefix.
gNwkAttrId_MeshCop_ActiveTimestamp_c Active timestamp.
gNwkAttrId_MeshCop_PendingChannel_c Pending channel.
gNwkAttrId_MeshCop_PendingChannelMask_c Pending Channel Mask.
gNwkAttrId MeshCop PendingXpanId c Pending Extended PanId.
gNwkAttrId_MeshCop_PendingMLprefix_c Pending MeshLocal prefix.
gNwkAttrId_MeshCop_PendingNwkMasterKey_c Pending Master Key.
gNwkAttrId MeshCop PendingNwkName c Pending Network Name.
gNwkAttrId_MeshCop_PendingPanId_c Pending Pan ID.
gNwkAttrId MeshCop PendingPSK c Pending PSKc.
gNwkAttrId_MeshCop_PendingSecurityPolicy Pending Security Policy bits.
gNwkAttrId MeshCop PendingNwkKeyRotationInterval c Pending Key Rotation Interval[sec].
gNwkAttrId MeshCop PendingDelayTimer c Pending Delay Timer[msec].
gNwkAttrId_MeshCop_PendingActiveTimestamp_c Pending Active Timestamp.
gNwkAttrId_MeshCop_PendingTimestamp_c Pending Timestamp.
gNwkAttrId MeshCop CommissionerId c Commissioner string.
gNwkAttr_JoinerUdpPort_c Joiner UDP port.
gNwkAttr CommissionerUdpPort c Commissioner UDP port.
gNwkAttr_DiscoveryReqMacTxOptions_c The default discovery request Mac Tx options (see thr←
    DiscReqTxOptions t)
gNwkAttr MinDelayTime The minimum accepted time before a Pending Dataset can be installed[s].
```

3.4 Function Documentation

3.4.1 thrStatus_t THR_InitAttr (instanceId_t thrInstId, void * pDefaultAttr, void * pDefaultStrAttr, void * pDefaultActiveDataSetAttr)

Initialize the attributes.

Parameters

in	thrInstID	Thread instance Id
in	pDefaultAttr	Pointer to the default attributes
in	pDefaultStrAttr	Pointer to the default string attributes
in	pDefault⇔	Pointer to the default active data set attributes
	ActiveData⇔	
	SetAttr	

Returns

thrStatus_t Thread status - Succes/Fail

3.4.2 thrStatus_t THR_GetAttr (instanceId_t thrInstID, thrAttrId_t attrID, uint32_t index, uint32 t * pSize, void * pAttrValue)

Get thread attribute value.

Parameters

in	thrInstID	Thread instance Id
in	attrID	Attribute Id
in	index	Index (use zero if it is a scalar attribute)
out	pSize	Attribute size
out	pAttrValue	Pointer to Attribute Value

Returns

thrStatus_t Thread status - Succes/Fail

3.4.3 thrStatus_t THR_SetAttr (instanceld_t thrInstID, thrAttrId_t attrID, uint32_t index, uint32 t size, void * pAttrValue)

Set thread attribute value.

Parameters

in	thrInstID	Thread instance Id
in	attrID	Attribute Id

AVD 0

Kinetis Thread Stack API Reference Manual

Variable Documentation

in	index	Index
in	size	Attribute size
in	pAttrValue	Pointer to Attribute Value

Returns

thrStatus_t Thread status - Succes/Fail

3.5 Variable Documentation

3.5.1 thrAttr_t* gpaThrAttr[]

Thread attributes:

• saved using NVNG

3.5.2 thrStringAttr_t* gpaThrStringAttr[]

Thread string attributes:

• saved using NVNG

3.5.3 thrActiveAttr_t* gpaThrActiveAttr[]

Thread active data set attributes:

• saved using NVNG

3.5.4 thrPendingAttr_t* gpaThrPendingAttr[]

Thread pending data set attributes:

• saved using NVNG

3.5.5 ipAddr_t gaServerDataPrefixTbl[]

Border router network data attributes.

• saved using NVNG

3.5.6 const uint8_t gLocalServiceSetTblSize

Size of the border router service set table.

Chapter 4 **Thread Application Callbacks Interface**

Overview 4.1

Files

• file thread_app_callbacks.h

Macros

#define THR_MAX_NWK_JOINING_ENTRIES

Typedefs

typedef void(* registerServiceServerAddr_t) (ipAddr_t *pIpAddr)

Functions

- void APP_JoinerSelectNwkWithBeaconCb (void *pParam)
- bool tAPP OutOfBandSelectNwkWithBeaconCb (instanceId tthrInstId, thrBeaconInfo t*pThr← Beacon)
- bool t APP MeshcopValidateJoinerAddrCb (instanceId t thrInstId, ipAddr t *pIpAddr)
- bool t APP MeshCopValidateJoinFinCb (instanceId t thrInstId, meshCopJoinFinTlys t *pJoin←
- bool_t APP_MeshCopValidateCommissionerCb (instanceId_t thrInstId, meshcopCommIdTlv_ t *pCommIdTlv)
- bool_t APP_AddressAssignSlaacCb (instanceId_t thrInstId, ipAddr_t *pPrefix)
- bool_t APP_ServiceServerDataCb (serviceSet_t serviceSet, bool_t bAddService)
- void APP_CriticalExitCb (uint32_t location, uint32_t param)
 bool_t APP_DiscoveryReqCb (instanceId_t thrInstId, uint16_t tlvsSize, uint8_t *pTlvs)
- void APP Joiner Discovery RespCb (instanceId t thr InstId, thr Discovery Event t event, uint8 t lqi, thrDiscoveryRespInfo_t *pDiscoveryRespInfo, meshcopDiscoveryRespTlvs_t *pDiscoveryResp←
- void APP JoinerSelectNwkWithAnnounceCb (instanceId t thrInstId, thrAnnounceEvent t event, uint8_t lqi, uint16_t tlvsSize, uint8_t *pTlvs)
- void APP_GenerateMLPrefixCb (instanceId_t thrInstID, thrPrefixAttr_t *pMLprefix)
- void APP EnableDHCP6Cb (void)
- void APP BeaconFillCb (instanceId t thrInstID)

4.2 **Macro Definition Documentation**

#define THR MAX_NWK_JOINING_ENTRIES 4.2.1

Maximum number of networks to perform the joining procedure.

Function Documentation

4.3 Typedef Documentation

4.3.1 typedef void(* registerServiceServerAddr_t) (ipAddr_t *plpAddr)

< Structure for holding pointer to the IPv6 address of a server service advertised in network data

4.4 Function Documentation

4.4.1 void APP_JoinerSelectNwkWithBeaconCb (void * pParam)

This function is used to handle the network events during the meshcop joining. This is the callback function used to select the potential network to join when THR_NwkJoin() is called.

Parameters

in	pParam	- pointer to event messages (thrEvmParams_t *)
----	--------	--

4.4.2 bool_t APP_OutOfBandSelectNwkWithBeaconCb (instanceId_t *thrInstId*, thrBeaconInfo_t * *pThrBeacon*)

This is the callback function used to select a thread network (find the panId, channel etc.) when the device in out-of-band configured and THR_NwkJoin(thrInst, gUseMACBeacon_c) is called. This function should filter the received beacons and select a thread network to start the attachment process.

Parameters

ſ	in	thrInstId	The thread instance ID
Ī	in	pThrBeacon	Pointer to received Beacon

Returns

TRUE A network has been selected FALSE No network has been selected

4.4.3 bool_t APP_MeshcopValidateJoinerAddrCb (instanceId_t *thrInstId*, ipAddr_t * *plpAddr*)

This is the callback function used to check if a Joiner will be accepted by our DTLS server.

Parameters

Kinetis Thread Stack API Reference Manual

in	thrInstId	The thread instance ID
in	pIpAddr	Pointer to client IP address

Returns

TRUE The Joiner is known FALSE The Joiner is unknown

4.4.4 bool_t APP_MeshCopValidateJoinFinCb (instanceld_t *thrInstld*, meshCopJoinFinTlvs_t * *pJoinFinTlvs*)

Function used to check the TLVs given by the Joiner in the Join Finalization step.

Parameters

in	thrInstId	Thread instance ID
in	pJoinFinTlvs	Join Finalization TLVs

Returns

TRUE Continue joining FALSE Otherwise

4.4.5 bool_t APP_MeshCopValidateCommissionerCb (instanceId_t *thrInstId*, meshcopCommIdTlv_t * *pCommIdTlv*)

Function used to check the Commissioner ID. It can be accepted or rejected.

Parameters

in	thrInstId	Thread instance ID
in	<i>pCommIdTlv</i>	Pointer to the Commissioner ID TLV

Returns

TRUE Allow this Commissioner FALSE Reject this Commissioner

4.4.6 bool_t APP_AddressAssignSlaacCb (instanceId_t thrInstId, ipAddr_t * pPrefix)

If slaacPolicy attribute is configured to gThrSlaacManual_c this function serves as a callback to the application to decide if it wants to bind an address with the prefix or not and if so, the application can choose the IID to use with the provided prefix.

Kinetis Thread Stack API Reference Manual

Function Documentation

Parameters

in	thrInstId	Thread instance ID
	[in/out]	pPrefix Pointer to ip prefix and output to store the IID

Returns

TRUE If the address generated with the prefix and IID should be used by the stack FALSE If the application does not want to use this prefix and the stack should ignore it

4.4.7 void APP_CriticalExitCb (uint32_t location, uint32_t param)

If the stack is in a deadlock situation, it calls APP_CriticalExitCb.

Parameters

in	location	Address where the Panic occurred
in	param	Parameter with extra debug information

4.4.8 APP_DiscoveryReqCb (instanceId_t thrInstId, uint16_t tIvsSize, uint8_t * pTIvs)

This is a callback used by the Application to accept or deny the Discovery Requests. The Discovery Request messages could contain some application specific TLVs, and the APP could have filters based on these TLVs.

Parameters

in	thrInstId	Thread instance ID
in	tlvsSize	Discovery request TLVs size
in	pTlvs	Pointer to Discovery Request TLVs

Returns

TRUE Send the Discovery Response FALSE Otherwise

4.4.9 void APP_JoinerDiscoveryRespCb (instanceld_t thrInstId, thrDiscovery Event_t event, uint8_t lqi, thrDiscoveryRespInfo_t * pDiscoveryRespInfo, meshcopDiscoveryRespTlvs_t * pDiscoveryRespTlvs)

This callback can be used by the application to handle and filter the Discovery Response messages. This function is application specific and could build a list of Joiner Routers to start the Meshcop joining process.

Kinetis Thread Stack API Reference Manual

53

Parameters

in	thrInstId	Thread instance ID
in	event	Discovery event
in	lqi	Discovery response packet lqi
in	pDiscovery⇔	Discovery Response pan information
	RespInfo	
in	pDiscovery⇔	Pointer to Discovery Response TLVs
	RespTlvs	

This callback handles the announcement messages to select a Thread Network (channel and panId) and start the attachment process.

Parameters

in	thrInstId	Thread instance
in	event	Announcement events (see thrAnnounceEvent_t)
in	lqi	Received packet lqi
in	tlvsSize	The size of the received Announce TLVs
in	pTlvs	Pointer to Announce TLVs

4.4.11 void APP_GenerateMLPrefixCb (instanceId_t thrInstID, thrPrefixAttr_t * pMLprefix)

This callback is called by Thread Stack to generate the MLprefix

Parameters

in	thrInstID	Thread instance ID
out	pMLprefix	ML prefix

4.4.12 void APP_EnableDHCP6Cb (void)

This callback can be used by the application to initialize the callbacks for DHCPv6 module.

4.4.13 void APP_BeaconFillCb (instanceId_t thrInstID)

This callback can be used by the application to set the beacon payload.

NXP Semiconductors

Kinetis Thread Stack API Reference Manual

Function Documentation

Parameters

in	thrInstID	Thread instance ID
----	-----------	--------------------

Chapter 5 Thread Types Interface

5.1 Overview

Files

• file thread_types.h

Data Structures

- struct thrOctet16_t
- struct thrOctet32 t
- struct thrOctet64_t
- struct thrPrefixAttr_t
- struct macFilteringNeighborData_t
- struct thrBeaconInfo t
- struct thrBeaconInfo_t.payload
- struct thrNwkActiveScanEntry_t
- struct thrNwkScan_t
- struct thrNwkScanResults_t
- struct thrNeighbor_t
- struct handleTrackingTable_t
- struct thrIdAssignSet_t
- struct mleOtaTlvLeaderData_t
- struct externalRouteSet t
- struct borderRouterSet_t
- struct contextIdSet_t
- struct serverTlv t
- struct serviceSet_t
- struct childVersNbSet t
- struct serverData t
- struct nwkDataInterfaceSet_t
- struct thrLqCacheEntry_t
- struct thrAqInterfaceSet_t
- struct thrAddrRegEntry_t
- struct thrChildAddrRegEntry_t
- struct thrChildMcastAddrRegEntry_t
- struct thrLinkSet_t
- struct thrRouteSet_t
- struct thrRouterIdSet_t
- struct thrInterfaceSet t
- struct thrMacRcvdDiffKeyIndexInd_t
- union thrEventData t
- struct thrEvmParams_t
- struct thrPskcInputParams_t
- struct thrNwkJoiningEntry_t
- struct thrNwkDiscoveryReqTxOpt_t

Overview

Macros

- #define THR_PROTOCOL_VERSION
- #define THREAD ENTERPRISE NUMBER
- #define THREAD_ENTERPRISE_NUMBER_ARRAY
- #define THREAD_DNS_SERVICE_TYPE_ID
- #define THREAD_OTA_SERVICE_TYPE_ID
- #define THR MAX ROUTER ID
- #define THR ROUTER BITS SIZE
- #define THR_CHILD_BITS_SIZE
- #define THR_RSV_BITS_SIZE#define THR_MAX_ADV_ROUTE_COST
- #define THR MAX POSSIBLE ROUTERS
- #define THR ROUTER MASK BYTES
- #define THR MAX CHILD IDS
- #define THR_R_ID_ADDR_SHIFT
- #define THR_R_ID_TO_SHORT_ADDR(x)
- #define THR SHORT ADDR TO R ID(x)
- #define ROUTER ID MASK BYTE
- #define ROUTER ID MASK
- #define CHILD_ID_MASK
- #define THR_GET_MY_PARENT(chidShortAddr)
- #define **THR_IS_ROUTER**(x)
- #define THR_IS_END_DEVICE(x)
- #define THR IS MY CHILD(childShortAddr, parentShortAddr)
- #define THR_IS_MY_PARENT(childShortAddr, parentShortAddr)
- #define THR_R_ID_IS_SET_IN_MASK(mask, rId)
- #define THR_NWK_KEY_SIZE
- #define THR_BEACON_XPAN_DEFAULT_VALUE
- #define THR BEACON J FLAG MASK
- #define THR_BEACON_J_FLAG_OFFSET
- #define THR_BEACON_N_FLAG_MASK
- #define THR_BEACON_N_FLAG_OFFSET
- #define THR_BEACON_VERSION_MASK
 #define THR_BEACON_VERSION_OFFSET
- #define THR BEACON J FLAG GET(byte)
- #define THR BEACON J FLAG SET(byte, flag)
- #define THR_BEACON_N_FLAG_GET(byte)
- #define THR_BEACON_N_FLAG_SET(byte, flag)
- #define THR_BEACON_VERSION_GET(byte)
 #define THR_BEACON_VERSION_SET(byte, flag)
- #define THR_DISCOVERY_REQ_TLV_J_BIT
- #define THR DISCOVERY RESP TLV N BIT
- #define THR DISC RSP VER SHIFT
- #define THR_DISC_RSP_VER_SET(byte, ver)
 #define THR_DISC_RSP_VER_GET(byte)
 #define THR_DISC_RSP_N_SHIFT

- #define THR DISC RSP N SET(byte, val)
- #define **THR DISC RSP N GET**(byte)
- #define THR_DISC_REQ_VER_SHIFT
- #define THR_DISC_REQ_VER_SET(byte, ver)
 #define THR_DISC_REQ_VER_GET(byte)
- #define THR_DISC_REQ_J_SHIFT
- #define **THR DISC_REQ_J_SET**(byte, val)
- #define THR DISC REQ J GET(byte)
- #define THR SERVICE DATA MAX LEN

- #define THR_SERVER_DATA_MAX_LEN
- #define THR_MAX_PSKC_LEN
- #define THR_PARENT_PRIORITY_OFFSET
- #define THR_ML_PREFIX_LEN_BITS
- #define **gUnusedValue** c

Typedefs

- typedef uint32_t thrEvCode_t
- typedef void(* thrAnnounceCb_t) (instanceId_t thrInstId, thrAnnounceEvent_t event, uint8_t lqi, uint16 t tlvsSize, uint8 t *pTlvs)

Enumerations

```
• enum thrStatus t {
  gThrStatus_Success_c,
 gThrStatus_Failed_c,
 gThrStatus InvalidInstance c,
 gThrStatus_InvalidParam_c,
 gThrStatus_NotPermitted_c,
 gThrStatus NotStarted c.
 gThrStatus_NoMem_c,
 gThrStatus UnsupportedAttr c,
  gThrStatus_EmptyEntry_c,
 gThrStatus_InvalidValue_c,
 gThrStatus AlreadyConnected c,
 gThrStatus_AlreadyCreated_c,
 gThrStatus_NoTimers_c,
 gThrStatus EntryNotFound c }

    enum thrInternalDeviceRole t {

  gThrDevRole_Disconnected,
  gThrDevRole_SED_c,
  gThrDevRole_MED_c,
  gThrDevRole_FED_c,
  gThrDevRole_REED_c,
  gThrDevRole_Router_c,
  gThrDevRole_Leader_c }
enum thrDeviceRole_t {
  gThrDeviceRole_SED_c,
  gThrDeviceRole_MED_c,
  gThrDeviceRole_FED_c,
  gThrDeviceRole_REED c }
enum thrDeviceType_t {
  gThrDevType_EndNode_c,
  gThrDevType ComboNode c }
enum nwkIPAddrType_t {
```

Overview

```
gLL64Addr c,
 gMLEIDAddr_c,
 gRLOCAddr_c,
  gGUAAddr_c,
 gAnycastAddr_c,
 gAnyIpv6_c,
 gAllThreadNodes_c }
enum thrRouterState_t {
 gThrReedIdle_c,
 gThrReedReqRouterId_c,
 gThrReedReatachJitter_c,
 gThrReedReqRouterIdJitter c,
 gThrRouterIdle c,
 gThrRouterDownGrdIdJitter_c,
 gThrRouterDownGrd_c }
enum thrSlaacPolicy_t {
  gThrSlaacRandom c,
  gThrSlaacManual_c,
  gThrSlaacMlIid_c }
enum thrCommissionerMode_t {
  gThrCommissionerModeDisabled c,
  gThrCommissionerModeNative_c,
  gThrCommissionerModeEthernet_c,
  gThrCommissionerModeOnMesh_c,
 gThrCommissionerModeClosing c }
enum thrParentPriority_e {
 gThrRouterPriorityMed_c,
 gThrRouterPriorityHigh_c,
 gThrRouterPriorityRsvd_c,
 gThrRouterPriorityLow c c }
enum thrNwkScanType_t {
  gThrNwkScan_EnergyDetect_c,
  gThrNwkScan_ActiveScan_c,
  gThrNwkScan BothScans c }
enum resetCpuStatus_t {
  gResetCpuSuccess_c,
 gResetCpuPending_c }
enum meshcopSteeringMatch_t {
  gMeshcopSteeringMatchNA c,
  gMeshcopSteeringMatchNone_c,
 gMeshcopSteeringMatchFfs_c,
  gMeshcopSteeringMatchSpecific_c }
• enum thrEvSets t {
```

```
gThrEvSet_NwkScan_c,
 gThrEvSet_NwkCreate_c,
 gThrEvSet_NwkJoin_c,
 gThrEvSet_NwkSelectParents_c,
 gThrEvSet_NwkGeneral_c,
 gThrEvSet NwkCommissioning c }
enum thrJoinDiscoveryMethod_t {
 gUseMACBeacon_c,
 gUseThreadDiscovery c }
enum thrDiscReqTxOptions_t {
 gThrNoSecurityAtMacLevel_c,
 gThrEncryptedAtMacLevel c }
• enum thrÄnnounceEvent t {
 gThrSearchThreadNwkStarted_c,
 gThrAnnounceRespRcv_c,
 gThrSearchThreadNwkStopped_c }
enum thrInstSearchType_t {
 gThrIfUniqueIdSearch_c,
 gThrSlwpInstSearch_c,
 gThrMacInstIdSearch_c,
 gThrInstSearch_c,
 gThrIfHandleSearch_c }
```

5.2 **Data Structure Documentation**

struct thrOctet16 t 5.2.1

Specific octet string type, 16 bytes.

Data Fields

uint8_t	length	
uint8_t	aStr[16]	

5.2.2 struct thrOctet32_t

Specific octet string type, 32 bytes.

Data Fields

uint8_t	length	
uint8_t	aStr[32]	

5.2.3 struct thrOctet64_t

Specific octet string type, 64 bytes.

61

Data Fields

uint8_t	length	
uint8_t	aStr[64]	

5.2.4 struct thrPrefixAttr_t

ML prefix.

Data Fields

ipAddr_t	prefix	
uint8_t	prefixLenBits	

5.2.5 struct macFilteringNeighborData_t

Mac filtering neighbor data.

Data Fields

uint64_t	extended←	
	Address	
uint16_t	shortAddress	
uint8_t	linkIndicator	
bool_t	blockNeighbor	

5.2.6 struct thrBeaconInfo_t

Thread Beacon Info.

Data Fields

uint64_t	address	MAC extended address.
uint16_t	panid	PAN ID.
macAbsAddr⊷	addrType	MAC address type: short or long (usually long)
ModeType_t		
uint8_t	channel	received on channel
uint8_t	lqi	received Lqi
uint8_t	unused	
instanceId_t	slwpInstId	6lowpan instanec ID

uint32_t	payloadSize	beacon payload size
struct thr←	payload	
BeaconInfo_t		

5.2.7 struct thrBeaconInfo_t.payload

Data Fields

uint8_t	protocolId	thread protocol ID
uint8_t	flags	the beacon flags
uint8_t	nwkName[16]	network name
uint8_t	xpanId[8]	extended PAN ID
uint8_t	aTlvs[]	where beacon tlv starts

5.2.8 struct thrNwkActiveScanEntry_t

Network Discovery Entry - Each entry represents a Thread network.

Data Fields

uint16_t	numOfRcvd↔	number of received beacons on that channel
	Beacons	
uint16_t	panid	PAN ID.
uint8_t	channel	received channel
uint8_t	lqi	link quality indicator

5.2.9 struct thrNwkScan_t

This structure is used to perform a network scan.

Data Fields

uint32_t	scanChannels←	What channels to scan; 0x07FFF800 means all 16 channels are
	Mask	used (from 11 to 26)
thrNwkScan←	scanType	what scan should be performed: energy, active or both
Type_t		
uint8_t	scanDuration	This is an exponential scale, as seen in the 802.15.4 specification
		(Range:1 - 14)

uint16_t	maxThrNwk←	
	ToDisc	

5.2.10 struct thrNwkScanResults_t

The Network scan results.

Data Fields

thrNwkScan_t	scanInfo	
uint8_t	numOf⊷	
	EnergyDetect←	
	Entries	
uint8_t *	pEnergy⊷	One byte for each channel. Only the channels from scanInfo. ←
	DetectList	scanChannelsMask should be handled; the rest of the channels are
		zeros
uint8_t	numOfNwk↔	Number of discovered network performing an active scan.
	ScanEntries	
thrNwk↔	nwkScanList[]	
ActiveScan←		
Entry_t		

5.2.11 struct thrNeighbor_t

Thread Neighbor.

Data Fields

uint64_t	extended←	Extended Address.
	Address	
uint32_t	timestamp	Last Time of Communication.
uint32_t	timeoutSec	Device Timeout value.
uint16_t	shortAddress	Short Address.
uint8_t	inLinkMargin	Link Margin of incoming frames from neighbor.
uint8_t	outLinkQuality	Link Quality of sent frames to neighbor.
uint8_t	mode	Device mode.
uint8_t	state	Device state.
uint8_t	txFailure	Number of consecutive transmission failures.
uint8_t	mleReqCount	Number of consecutive MLE Req trans sent.

5.2.12 struct handleTrackingTable_t

Handle Tracking Table Entry.

Data Fields

uint64_t	destAddr	link layer address destination
uint8_t	msduHandle	message handle
macAbsAddr↔	destAddrMode	link layer address mode
ModeType_t		

5.2.13 struct thrldAssignSet_t

Thread ID Assignment set.

Data Fields

uint32_t	thrReuseTime	time interval after which the ID can be reused
uint8_t	thrOwner⊷	link layer address of the ID owner
	Eui[gLlayer←	
	AddrEui64_c]	

5.2.14 struct mleOtaTlvLeaderData_t

Leader Data TLV - Over the Air mapping structure.

Data Fields

uint8_t	type	TLV Type.
uint8_t	length	Length of Leader Data TLV.
uint8_t	partitionId[4]	Network Segment Identifier.
uint8_t	weighting	Weighting value for the network fragment.
uint8_t	dataVersion	Version of the Network Data.
uint8_t	stableData←	Stable Version of the Network Data.
	Version	
uint8_t	leaderId	Network Leader Router ID.

5.2.15 struct externalRouteSet_t

External Route Set.

65

Data Fields

uint16_t	brShortAddr	Border Router short address.
uint8_t	hasRouteFlags	Border Router external route flags (Value of R_preference)
uint8_t	brPrefixIndex	Border Route prefix index.
uint8_t	brDomainId	Domain ID.
uint8_t	brLifetime[4]	Entry lifetime.
bool_t	isStable	TRUE - if prefix is valid more than THR_NWK_DATA_MIN_S←
		TABLE_LIFETIME_SEC FALSE - otherwise.
bool_t	bAdvertised	TRUE - Prefix was advertised in the Thread network, FALSE -
		otherwise.

5.2.16 struct borderRouterSet_t

Border router (BR) Set.

Data Fields

uint16_t	brShortAddr	Border Router short address.
uint8_t	brPrefix⊷	Byte 0: BR Flags; Byte 1: Bits 0-6 Reserved, 7 ND_DNS bit;.
	Flags[2]	
uint8_t	brPrefixIndex	Border Route prefix index.
uint8_t	brDomainId	Domain ID.
uint8_t	brLifetime[4]	Entry lifetime.
bool_t	bIsStable	TRUE - if prefix is valid more than THR_NWK_DATA_MIN_S↔
		TABLE_LIFETIME_SEC, FALSE - otherwise.
bool_t	bAdvertised	TRUE - Prefix was advertised in the Thread network, FALSE -
		otherwise.

5.2.17 struct contextIdSet_t

Context Id Set.

Data Fields

uint8_t	contextFlags	
uint8_t	contextLength	Length of context address.
uint8_t	contextPrefix←	Prefix index corresponding to context.
	Index	

bool_t	isStable	TRUE - if prefix is valid more than THR_NWK_DATA_MIN_S↔
		TABLE_LIFETIME_SEC, FALSE - otherwise.
uint32_t	removeTstamp	Timestamp after which context can be used only for decompres-
		sion.

5.2.18 struct serverTlv_t

Data Fields

uint8_t	sServer16[2]	Server's short address.
uint8_t	sDataLen	Length of service data.
uint8_t	sServer←	
	Data[THR_S←	
	ERVER_DA⇔	
	TA_MAX_L↔	
	EN]	

5.2.19 struct serviceSet_t

Data Fields

uint8_t	sFlags	Service flags.
uint8_t	sEntNb[4]	Enterprise number.
uint8_t	sDataLen	Service Data length.
uint8_t	sData[THR_←	Service data.
	SERVICE_D←	
	ATA_MAX_←	
	LEN]	
serverTlv_t	sServer	Server TLV.
bool_t	bLocalService	Whether the service is advertised by us.
bool_t	bIsStable	Whether the service is stable.

5.2.20 struct childVersNbSet_t

Child Version Number Set.

Data Fields

uint16_t	childShortAddr	Child short address.
bool_t	childStable←	TRUE - Child requires only stable data, FALSE - otherwise.
	Only	
uint8_t	childVersion	Child's version of network data.
uint32_t	childRet←	Child's retry timestamp.
	Tstamp	

5.2.21 struct serverData_t

Server Data.

Data Fields

ipAddr_t *	pPrefixTbl	Pointer to Prefix in Prefix Table.
uint8_t *	pPrefixLenTbl	Pointer to Prefix length.
external←	pExtRouteTbl	Pointer to External Route.
RouteSet_t		
*		
borderRouter←	pBRSetTbl	Pointer to External Route Set.
Set_t		
*		

5.2.22 struct nwkDataInterfaceSet_t

Thread Network Data Structure.

Kinetis Thread Stack API Reference Manual

Data Fields

ipAddr_t *	pPrefixTbl	Pointer to Prefix Table.
uint8_t *	pPrefixLenTbl	Pointer to Prefix Length Table.
childVersNb↔	pChildVers←	Pointer to Children Version Number Set.
Set_t	NbSet	
*		
borderRouter←	pBRSetTbl	Pointer to Valid Prefix (Border Router) Set.
Set_t		
*		
external←	pExtRouteTbl	Pointer to External Route Set.
RouteSet_t		
*		
contextIdSet_t	pContextTbl	Pointer to 6LoWPAN Context ID Set.
*		
serviceSet_t *	pServiceSetTbl	Pointer to Service Set.
serverData_t	serverData	Server Data.
mleOtaTlv←	leaderData	Leader Data TLV.
LeaderData_t		

5.2.23 struct thrLqCacheEntry_t

Data Fields

ipAddr_t	eid	IP Address.
uint16_t	address16	Short address.
uint8_t	discovery←	The time remaining for waiting for responses to an Address Query,
	Timeout	or zero if there is no outstanding Address Query.
uint8_t	discoveryFail	The number of consecutive Address Query messages for which no
		corresponding response was received before discoveryTimeout ex-
		pires.
uint32_t	retryTimeout	The time a device must wait before sending another Address Query
		message.
uint32_t	ageSec	Last usage of cache entry.

5.2.24 struct thrAqInterfaceSet_t

Data Fields

ipPktInfo_t *	pIpPktInfo↔	Pointer to the outstanding IP packet.
	Buffer	
tmrTimerID_t	addrDiscTimer	Timer ID for address discovery.
uint32_t	minClient←	Last transaction time.
	LastTransa←	
	Time	
uint8_t	mAddrNotify↔	Mesh Local EID.
	MlEid[8]	

5.2.25 struct thrAddrRegEntry_t

Thread sleepy child ID table entry.

Data Fields

uint8_t addrIid[8]	Interface identifier.
uint8_t contextId	Context ID.

5.2.26 struct thrChildAddrRegEntry_t

Thread RFD child address registration table.

Data Fields

uint8_t	neighborIdx	Entry in neighbor table.
thrAddrReg←	childAddr⊷	Registered IID.
Entry_t	Entry[THR_←	
	CHILD_AD←	
	DR_REG_E↔	
	NTIRES]	

5.2.27 struct thrChildMcastAddrRegEntry_t

Thread RFD child Multicast address registration table.

Data Fields

uint8_t	neighborIdx	Entry in neighbor table.
ipAddr_t	multicast←	
	Addr[THR_C↔	
	HILD_MCA⊷	
	ST_ADDR_←	
	REG_ENTIR←	
	ES]	

5.2.28 struct thrLinkSet_t

Thread routing Link set.

Data Fields

uint32_t	thrLinkAge	
uint16_t	thrShortAddr	
uint8_t	thrLinkMargin	
uint8_t	thrOutgoing←	
	Qual	

5.2.29 struct thrRouteSet_t

Thread routing Route set.

Data Fields

uint16_t	thrMultiHop←	
	RouterId	
uint16_t	thrNextHop←	
	RouterId	
uint8_t	thrMultihop←	
	RouteCost	
uint8_t	thrRouteStatus	

5.2.30 struct thrRouterIdSet_t

Thread routing Router ID set.

71

Data Fields

uint8_t	thrIdSeqNb	Sequence number.
uint8_t	thrIdSet[THR←	Router ID Set.
	ROUTER←	
	$MASK_BYT {\hookleftarrow}$	
	ES]	

5.2.31 struct thrInterfaceSet_t

Structure with all Thread routing parameters for an interface.

Data Fields

thrRouteSet_t *	pThread←	Pointer to Routing Table.
	RoutingTbl	
thrLinkSet_t *	pThreadLink↔	Pointer to link set.
	Set	
uint32_t	dgradeTstamp	Timestamp for when downgrading to REED.
uint16_t	deviceShort←	Device's short address.
	Addr	
tmrTimerID_t	singleShot←	Timer id for single shot operations.
	TmrId	
tmrTimerID_t	periodicTmrId	Timer id for periodic operations.
uint8_t	thrRouterCount	Number of routers in network.
bool_t	bIsLeader	TRUE - if device is Leader, FALSE - otherwise.
bool_t	bIsInit	TRUE - if is initialized, FALSE - otherwise.
thrRouter←	devState	Device's state.
State_t		
uint8_t	leaderCost	Route cost to Leader.
thrRouterId←	threadRouter←	Router ID Set.
Set_t	IdSet	

${\bf 5.2.32 \quad struct \ thr MacRcvdDiff KeyIndexInd_t}$

Mac Key Index.

Data Fields

instanceId_t	macInstId	MAC instance ID.
uint8_t	keyIdMode	Key ID mode.
uint8_t	keyIndex	Key index.

Kinetis Thread Stack API Reference Manual

5.2.33 union thrEventData_t

Thread event data.

Data Fields

thrNwkS	can⊷	nwkScanCnf	network scan confirm - result
Res	ults_t		
thrMacR	.cvd←	thrMacRcvd←	the MAC received a different key index data
DiffKeyIn	dex⊷	DiffKeyIndex←	
	Ind_t	Ind	
thrBea	.con←	nwkSelect←	network select parents indication
I	[nfo_t	ParentsInd	

5.2.34 struct thrEvmParams_t

Thread event parameters header.

Data Fields

thrEvCode_t	code	Event Code.
uint32_t	thrInstId	Instance Id.
uint16_t	eventDataSize	Event Data Size.
uint16_t	reserved	Reserved for future use.
thrEventData←	pEventData	pointer to event data
_t		
*		

5.2.35 struct thrPskcInputParams_t

Structure used to specify input parameters for PSKc generation.

Data Fields

uint8_t *	pPskcStr	PSKc string.
uint32_t	pskcStrLen	PSKc string length.
uint8_t *	pXpanId	Extended PAN ID.
uint8_t *	pNwkName	Network name.
uint32_t	nwkNameLen	Network name length.
uint8_t *	pPskcOut	PSKc.

5.2.36 struct thrNwkJoiningEntry_t

Macro Definition Documentation

Data Fields

uint8_t	euiAddr[8]	Link layer address.
uint8_t	aXpanId[8]	Extended PAN ID.
uint8_t	channel	Channel.
meshcop←	steeringMatch	Steering Data match.
Steering←		
Match_t		
uint16_t	panId	PAN ID.
uint16_t	joinerUDPPort	if not used, it will be set to 0x0000
uint16_t	commissioner←	if not used, it will be set to 0x0000
	UDPPort	

5.2.37 struct thrNwkDiscoveryReqTxOpt_t

Discovery Request TX parameters.

Data Fields

thrDiscReq←	discReqTxOpt	
TxOptions_t		
uint32_t	scanChannel←	the scan channel mask (0x07FFF800 means all 16 channels are
	Mask	used).
uint16_t	destPanId	destination PAN ID (it can be 0xFFFF or a specific PAN ID)
uint8_t	flags	flags from Discovery Request TLV: THR_DISCOVERY_REQ_
		TLV_J_BIT or zero. Note that the Protocol Version will be always
		added
uint8_t	extraTlvs⊷	extra TLV length. More TLVs can be added in the payload (eg
	Length	extended pan ID, application specific TLVs). Maximum 70 bytes.
uint8_t *	pExtraTlvs	pointer to extra TLV

5.3 Macro Definition Documentation

5.3.1 #define THR_PROTOCOL_VERSION

The Thread protocol version.

5.3.2 #define THREAD_ENTERPRISE_NUMBER

Thread Enterprise number.

5.3.3 #define THREAD_ENTERPRISE_NUMBER_ARRAY

Thread Enterprise number.

5.3.4 #define THREAD_DNS_SERVICE_TYPE_ID

Supported Service Type IDs.

5.3.5 #define THR_MAX_ROUTER_ID

Maximum Router ID.

5.3.6 #define THR_MAX_POSSIBLE_ROUTERS

Maximum number of thread routers.

5.3.7 #define THR_ROUTER_MASK_BYTES

The maximum bytes of the router mask.

5.3.8 #define THR MAX CHILD IDS

The maximum child ID.

5.3.9 #define THR R ID ADDR SHIFT

Thread Router Id <-> Short address conversion.

5.3.10 #define THR_GET_MY_PARENT(chidShortAddr)

Macro for determining the address of a parent based on the child short.

Input: child short address (uin16_t)

5.3.11 #define THR_IS_MY_CHILD(childShortAddr, parentShortAddr)

Macro for determining if an node is the devices child.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

Input: node short address (uin16_t) parent short address (uint16_t)

5.3.12 #define THR R ID IS SET IN MASK(mask, rld)

Check if the router ID is set in the mask.

5.3.13 #define THR_NWK_KEY_SIZE

The Network key size.

5.3.14 #define THR BEACON J FLAG MASK

Permit join flag mask and offset.

5.3.15 #define THR BEACON N FLAG MASK

Native commissioner flag mask and offset.

5.3.16 #define THR BEACON VERSION MASK

Beacon Version mask and offset.

5.3.17 #define THR_BEACON_J_FLAG_GET(byte)

Thread Beacon Permit Join Flag Macros.

5.3.18 #define THR BEACON N FLAG GET(byte)

Thread Beacon Native Commissioner Flag Macros.

5.3.19 #define THR BEACON VERSION GET(byte)

Thread Beacon Permit Join Flag Macros.

5.3.20 #define THR_DISCOVERY_REQ_TLV_J_BIT

Thread Discovery Request/Response TLV bits.

Joiner Flag bit in the byte

5.3.21 #define THR_DISCOVERY_RESP_TLV_N_BIT

Native Commissioner bit in the byte.

5.3.22 #define THR DISC RSP VER SHIFT

Thread Discovery Request/Response bits and version.

5.4 Typedef Documentation

5.4.1 typedef uint32_t thrEvCode_t

Thread event code.

5.4.2 typedef void(* thrAnnounceCb_t) (instanceId_t thrInstId, thrAnnounceEvent_t event, uint8_t lqi, uint16_t tlvsSize, uint8_t *pTlvs)

The announcement callback.

5.5 Enumeration Type Documentation

5.5.1 enum thrStatus_t

Thread status.

5.5.2 enum thrInternalDeviceRole_t

Device roles.

Enumerator

```
gThrDevRole_Disconnected Device is disconnected.
gThrDevRole_SED_c Sleepy End Device, no routing capability.
gThrDevRole_MED_c Minimal End Device, no routing capability.
gThrDevRole_FED_c Full End Device, address discovery and no routing capability.
gThrDevRole_REED_c Router eligible end device (REED)
```

Kinetis Thread Stack API Reference Manual

```
gThrDevRole_Router_c Router device.
gThrDevRole_Leader_c Leader device.
```

5.5.3 enum thrDeviceRole_t

Device roles.

Enumerator

```
gThrDeviceRole_SED_c Sleepy End Device, no routing capability. gThrDeviceRole_MED_c Minimal End Device, no routing capability. gThrDeviceRole_FED_c Full End Device, has routing capability. gThrDeviceRole_REED_c Router eligible end device (REED)
```

5.5.4 enum thrDeviceType_t

Device types.

Enumerator

```
gThrDevType_EndNode_c The node can be sleepy or non-sleepy end device (no routing capability
)
gThrDevType_ComboNode_c The node can have any device role above.
```

5.5.5 enum nwkIPAddrType_t

IP Address Types.

Enumerator

```
gLL64Addr_c Link-Local 64 address (the IID is MAC Extended address Which is not the factory-assigned IEEE EUI-64,)
gMLEIDAddr_c Mesh-Local Endpoint Identifier address (the IID is randmon)
gRLOCAddr_c Routing Locator address (the IID encodes the Router and Child IDs.)
gGUAAddr_c Global Unicast Address.
gAnycastAddr_c Anycast IPv6 addresses.
gAnyIpv6_c All IPv6 address.
gAllThreadNodes_c All Thread nodes address.
```

5.5.6 enum thrRouterState_t

REED and route states.

5.5.7 enum thrSlaacPolicy_t

The Stateless Address Autoconfiguration (SLAAC) policy.

Enumerator

```
gThrSlaacRandom_c the addresses is randomly generate
gThrSlaacManual_c it is provided by the application
gThrSlaacMIIid_c use ML-EID address
```

5.5.8 enum thrCommissionerMode_t

Thread Commissioner mode.

Enumerator

```
    gThrCommissionerModeDisabled_c Commissioner disabled (normal thread node)
    gThrCommissionerModeNative_c Native (802.15.4) commissioner.
    gThrCommissionerModeEthernet_c Ethernet commissioner.
    gThrCommissionerModeOnMesh_c The commissioner is on mesh network. A thread node can become a commissioner at run time
    gThrCommissionerModeClosing_c The Commissioner is in closing mode.
```

5.5.9 enum thrParentPriority_e

parent priority

5.5.10 enum thrNwkScanType_t

Scan type structure.

Enumerator

```
gThrNwkScan_EnergyDetect_c Energy Detect only.
gThrNwkScan_ActiveScan_c Beacon request only.
gThrNwkScan BothScans c Energy detect and beacon request.
```

Kinetis Thread Stack API Reference Manual

5.5.11 enum resetCpuStatus_t

reset CPU status enum

5.5.12 enum meshcopSteeringMatch_t

Enumerator

```
gMeshcopSteeringMatchNA_c Matching not performed.
gMeshcopSteeringMatchNone_c No matching.
gMeshcopSteeringMatchFfs_c Matched a 0xFF mask.
gMeshcopSteeringMatchSpecific_c Matched specific bits.
```

5.5.13 enum thrEvSets_t

Thread Event Sets.

Enumerator

```
gThrEvSet_NwkScan_c network scan event set
gThrEvSet_NwkCreate_c network create event set
gThrEvSet_NwkJoin_c network join event set
gThrEvSet_NwkSelectParents_c network select parent event set
gThrEvSet_NwkGeneral_c network general event set
gThrEvSet_NwkCommissioning c network commissioning event set
```

5.5.14 enum thrJoinDiscoveryMethod_t

Thread Discovery method.

Enumerator

```
gUseMACBeacon_c use MAC beacons for discovery
gUseThreadDiscovery_c use Thread Discovery request
```

5.5.15 enum thrDiscReqTxOptions_t

Discovery Request TX options.

Enumerator

gThrNoSecurityAtMacLevel_c no security is used at Mac level gThrEncryptedAtMacLevel_c encrypted with the well-known key and Extended Address at Mac level

5.5.16 enum thrAnnounceEvent_t

The announce events used by the thrAnnounceCb_t callback.

5.5.17 enum thrInstSearchType_t

Thread Instance search type.

Kinetis Thread Stack API Reference Manual

Chapter 6 **Thread Commissioning Interface**

6.1 **Overview**

Files

file thread_meshcop_mgmt.h

Data Structures

- struct expectedJoinerEntry_t
- struct meshcopCredentialInput_t
- struct meshCopStateTlv_t
- struct meshCopVendorNameTlv_t
- struct meshCopVendorModelTlv_tstruct meshCopVendorSwVerTlv_t
- struct meshCopVendorDataTlv_t
- struct meshCopStackVersionTlv_t
- struct meshCopProvUrlTlv_t
- struct meshCopJoinFinTlvs_t
- struct meshCopChannelTlv_t
- struct meshCopChannelMaskTlv_t
- struct meshCopCountTlv_t
- struct meshCopPeriodTlv_t
- struct meshCopEnergyListTlv_t
- struct meshCopScanDurationTlv_t
- struct meshCopDiscoveryReqTlv_t
- struct meshCopDiscoveryRespTlv_t
- struct meshCopDiscoveryTlv_t
- struct meshCopNwkChannelTlv_t
- struct meshCopNwkPanIdTlv_t
- struct meshCopNwkXPanIdTlv_t
- struct meshCopNwkNameTlv_t
- struct meshCopPskcTlv_t
- struct meshCopNwkMasterKeyTlv_t
- struct meshCopNwkKeySeqTlv_t
- struct meshCopNwkMlUlaTlv_t
- struct meshCopSteeringTlv_t
- struct meshCopBrLocTlv_t
- struct meshcopCommIdTlv_t
- struct meshCopCommSessIdTlv_t
- struct meshCopGetTlv_t
- struct meshCopActiveTimestampTlv_t
- struct meshCopCommissionerUdpPortTlv_t
- struct meshCopJoinerUdpPortTlv_t
- struct meshCopPendingTimestampTlv_t
- struct meshCopSecurityPolicyTlv_t
- struct meshCopMacExtendedAddressTlv_t

Overview

- struct meshCopDelayTimerTlv t
- struct meshcopDiscoveryRespTlvs t
- struct thrDiscoveryRespInfo_t
- struct meshcopHandlers t
- struct meshcopNwkFormParams_t
- struct meshcopMgmtParams_t

Macros

- #define MESHCOP ENABLED
- #define MESHCOP_O_MASK#define MESHCOP_N_MASK
- #define MESHCOP_R_MASK
- #define MESHCOP C MASK
- #define MESHCOP B MASK
- #define MESHCOP STATE ACCEPT
- #define MESHCOP_STATE_REJECT#define MESHCOP_STATE_PENDING
- #define TLV TYPE LEN
- #define MESHCOP MAX PSK LEN
- #define TLV_NETWORK_PANID_LEN
- #define TLV NETWORK XPANID LEN
- #define TLV_NETWORK_KEY_LEN
 #define TLV_NETWORK_KEY_SEQ_LEN
- #define TLV_NETWORK_ML_ULA_LEN
- #define MESHCOP MAX COMM ID LEN
- #define MESHCOP NETWORK NAME MAX LEN

Typedefs

- typedef void(* meshcopDiagnosticHandlerCb_t) (meshcopDiagnosticType_t meshcopDiagType, meshcopDiagnosticDir_t dir, uint8_t *pEui, uint8_t *pTlvs, uint32_t tlvsLen)
- typedef void(* thrDiscoveryRespCb_t) (instanceId_t thrInstId, thrDiscoveryEvent_t event, uint8_ t lqi, thrDiscoveryRespInfo_t *pDiscoveryRespInfo, meshcopDiscoveryRespTlvs_t *pDiscovery←
- typedef void(* meshcopHandlerCb t) (meshcopHandlers t *pIdHandlerEntry, uint8 t *pTlvs, uint32 t tlvsLen)

Enumerations

```
enum meshCopTlv_t {
 gMeshCopTlvChannel c,
 gMeshCopTlvPanID c,
 gMeshCopTlvXpanID_c,
 gMeshCopTlvNwkName c,
 gMeshCopTlvPskc c,
 gMeshCopTlvNwkMasterKey_c,
 gMeshCopTlvNwkKevSeq c.
 gMeshCopTlvNwkMlUla c,
 gMeshCopTlvSteeringData c,
 gMeshCopTlvBorderRouterLoc c.
 gMeshCopTlvCommID_c,
 gMeshCopTlvCommSessId c,
 gMeshCopTlvSecPolicy_c,
 gMeshCopTlvGet c.
 gMeshCopTlvActiveTimestamp c.
 gMeshCopTlvCommissionerUdpPort c,
 gMeshCopTlvState c,
 gMeshCopTlv.JoinerDtlsEnc c.
 gMeshCopTlvJoinerUdpPort_c,
 gMeshCopTlvJoinerAddr c,
 gMeshCopTlvJoinerRouterLoc_c,
 gMeshCopTlv.JoinerRouterKEK c.
 gMeshCopTlvProvisioningUrl_c,
 gMeshCopTlvVendorName c,
 gMeshCopTlvVendorModel c,
 gMeshCopTlvVendorSwVer c.
 gMeshCopTlvVendorData c,
 gMeshCopTlvVendorStackVer c,
 gMeshCopTlvPendingTimestamp_c,
 gMeshCopTlvDelayTimer_c,
 gMeshCopTlvChannelMask c,
 gMeshCopTlvCount_c,
 gMeshCopTlvPeriod c.
 gMeshCopTlvScanDuration c.
 gMeshCopTlvEnergyList c,
 gMeshCopTlvChannelPages c,
 gMeshCopTlvDiscoveryReq_c,
 gMeshCopTlvDiscoveryResp_c,
 gMeshCopTlvMacExtAddress c,
 gMeshCopTlvFuture c }
enum meshcopEuiMask_t {
```

Kinetis Thread Stack API Reference Manual

Overview

```
gMeshcopEuiMaskAllZeroes c,
 gMeshcopEuiMaskAllFFs c,
  gMeshcopEuiMaskExpectedJoinerList c }
enum thrEvCodesComm_t {
  gThrEv MeshCop JoinerDiscoveryStarted c,
  gThrEv_MeshCop_JoinerDiscoveryFailed_c,
  gThrEv_MeshCop_JoinerDiscoveryFailedFiltered_c,
  gThrEv_MeshCop_JoinerDiscoverySuccess_c,
  gThrEv_MeshCop_JoinerDtlsSessionStarted_c,
  gThrEv_MeshCop_JoinerDtlsError_c,
 gThrEv_MeshCop_JoinerError_c,
 gThrEv MeshCop JoinerAccepted c,
  gThrEv_MeshCop_CommissionerPetitionStarted_c,
 gThrEv_MeshCop_CommissionerPetitionAccepted_c,
 gThrEv_MeshCop_CommissionerPetitionRejected_c,
  gThrEv_MeshCop_CommissionerPetitionError_c,
 gThrEv_MeshCop_CommissionerKeepAliveSent_c,
  gThrEv MeshCop CommissionerError c.
 gThrEv_MeshCop_CommissionerJoinerDtlsSessionStarted_c,
  gThrEv MeshCop CommissionerJoinerDtlsError c,
  gThrEv_MeshCop_CommissionerJoinerAccepted_c,
 gThrEv_MeshCop_CommissionerNwkDataSynced_c,
 gThrEv_MeshCop_CommissionerBrDtlsSessionStarted_c,
  gThrEv MeshCop CommissionerBrDtlsError c,
 gThrEv_MeshCop_CommissionerBrError_c,
 gThrEv_MeshCop_CommissionerBrAccepted_c,
 gThrEv_MeshCop_BrCommissionerDtlsSessionStarted_c,
  gThrEv MeshCop BrCommissionerDtlsError c,
  gThrEv MeshCop BrCommissionerAccepted c,
 gThrEv_MeshCop_BrCommissionerDataRelayedInbound_c,
  gThrEv_MeshCop_BrCommissionerDataRelayedOutbound_c,
  gThrEv MeshCop JoinerrouterJoinerDataRelayedInbound c,
 gThrEv_MeshCop_JoinerrouterJoinerDataRelayedOutbound_c,
 gThrEv_MeshCop_JoinerrouterJoinerAccepted_c,
 gThrEv_MeshCop_StartVendorProvisioning_c }
enum meshcopDiagnosticDir_t {
  gMeshcopDiagnosticOut_c,
  gMeshcopDiagnosticIn c }
enum meshcopDiagnosticType_t {
  gMeshcopDiagnosticJoinFinReq_c,
  gMeshcopDiagnosticJoinFinRsp_c,
  gMeshcopDiagnosticJoinEntReq_c,
  gMeshcopDiagnosticJoinEntRsp_c,
 gMeshcopDiagnosticCloseNotify c,
 gMeshcopDiagnosticLog_c }
```

```
• enum thrDiscovervEvent t {
  gThrDiscoveryStarted_c,
  gThrDiscoveryRespRcv c.
  gThrDiscoveryStopped_c }
```

Functions

- thrStatus_t MESHCOP_StartCommissioner (instanceId_t thrInstId)
- thrStatus_t MESHCOP_StartNativeCommissionerScan (instanceId_t thrInstId)
- bool t MESHCOP StopCommissioner (instanceId t thrInstId, bool t updateNwk)
- bool t MESHCOP AddExpectedJoiner (instanceId t thrInstId, uint8 t *pEui, uint8 t *pPsk, uint32_t pskLen, bool_t selected)
- expectedJoinerEntry t * MESHCOP GetExpectedJoiner (instanceId t thrInstId, uint8 t *p↔ HashEui, uint8 t *pEui)
- bool_t MESHCOP_RemoveExpectedJoiner (instanceId_t thrInstId, uint8_t *pHashEui, uint8_t *p↔
- void MESHCOP_RemoveAllExpectedJoiners (instanceId_t thrInstId)
- void MESHCOP SyncSteeringData (instanceId t thrInstId, meshcopEuiMask t euiMask)
- meshcopSteeringMatch_t MESHCOP_CheckSteeringData (meshCopSteeringTlv_t *pSteering→
- void MESHCOP SetCommissionerCredential (instanceId t thrInstId, meshcopCredentialInput \leftarrow t *pParams)
- void MESHCOP SetDiagHandler (instanceId tthrInstId, meshcopDiagnosticHandlerCb tpfTlvs← Handler)
- uint8 t * MESHCOP AddTlvs (instanceId t thrInstanceID, uint8 t *pStart, uint64 t *pMask, bool tusePending, bool t noSecPolicy)
- uint32_t MESHCOP_GetTlvsLen (instanceId_t thrInstanceID, uint64_t *pMask, bool_t use-Pending, bool t noSecPolicy)
- uint8_t MESHCOP_RegisterBrServerAddr6 (instanceId_t thrInstId, ipIfUniqueId_t ifId, ipAddr_t *pAddr)
- void MESHCOP NwkJoinWithCommissioning (instanceId t thrInstId, thrNwkJoiningEntry t *p← NwkJoiningList, uint32_t nbOfNwkJoiningEntries)
- nwkStatus t MESHCOP Set (instanceId t thrInstId, uint8 t *pTlvs, uint32 t tlvsLength, meshcopHandlerCb_t pfSetCb)
- nwkStatus_t MESHCOP_Get (instanceId_t thrInstId, uint8_t *pTlvs, uint32_t tlvsLength, meshcopHandlerCb t pfGetCb)
- nwkStatus_t MESHCOP_SendNetworkForm (meshcopNwkFormParams_t *pNwkFormParams)
- nwkStatus_t MESHCOP_MgmtSendPanIdQuery (instanceId_t thrInstId, uint32_t channelMask, uint16 t panId, meshcopHandlerCb_t pfHandlerCb, ipAddr_t *pIpAddr)
- nwkStatus t MESHCOP MgmtSendEdScan (instanceId t thrInstId, uint32 t channelMask, uint32 t count, uint32 t period, uint32 t scanDuration, meshcopHandlerCb t pfHandlerCb, ip← Addr t*pIpAddr)
- nwkStatus t MESHCOP MgmtSendAnnounceBegin (instanceId tthrInstId, uint16 t commissioner ← SessionId, uint32 t channelMask, uint32 t count, uint16 t period, ipAddr t *pIpAddr)
- nwkStatus_t MESHCOP_MgmtCommSet (meshcopMgmtParams_t *pParams)
- nwkStatus_t MESHCOP_MgmtActiveSet (meshcopMgmtParams_t *pParams)
- nwkStatus_t MESHCOP_MgmtPendingSet (meshcopMgmtParams_t *pParams)

- nwkStatus_t MESHCOP_MgmtCommGet (meshcopMgmtParams_t *pParams)
 nwkStatus_t MESHCOP_MgmtActiveGet (meshcopMgmtParams_t *pParams)
 nwkStatus_t MESHCOP_MgmtPendingGet (meshcopMgmtParams_t *pParams)
- nwkStatus t MESHCOP SendUdpRxNtf (ipAddr t *pSrcIpAddr, uint16 t pktLength, uint16 t

srcPort, uint16_t dstPort, void *pPayload)
 nwkStatus_t MESHCOP_SendUdpTxNtf (ipAddr_t *pDstIpAddr, uint16_t pktLength, uint16_t srcPort, uint16_t dstPort, void *pPayload)

Variables

- list_t gThrExpectedJoinerList
- thrCommissionerMode_t gMeshcopCommissionerMode

6.2 Data Structure Documentation

6.2.1 struct expectedJoinerEntry_t

This entry defines a Joiner.

Data Fields

uint8_t	aHashEui[8]	Extended address of the Joiner(hash)
uint8_t	aPsk[32]	Password of the Joiner.
uint8_t	pskLen	Length in byte of the password.
bool_t	selected	This Joiner is used in computing steering or not.
bool_t	ffEntry	This entry represents all addresses.

6.2.2 struct meshcopCredentialInput_t

Structure used to specify input parameters for PSKc generation on commissioner.

Data Fields

uint8_t *	pPskcStr	Pointer to the human readable password.
uint32_t	pskcStrLen	Size of the human readable password.
uint8_t *	pXpanId	Pointer to the extended pan id.
uint8_t *	pNwkName	Pointer to the network name.
uint32_t	nwkNameLen	Size of the network name buffer.

6.2.3 struct meshCopStateTlv_t

State TLV.

Data Fields

uint8_t	type	Tlv type.

uint8_t	len	Tlv length.
uint8_t	state	State value.

6.2.4 struct meshCopVendorNameTlv_t

Vendor name TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	vendorName[]	Vendor name.

6.2.5 struct meshCopVendorModelTlv_t

Vendor model TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	vendorModel[]	Vendor model.

${\bf 6.2.6 \quad struct \ meshCopVendorSwVerTlv_t}$

Vendor software version TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	vendorSwVer[]	Vendor software version.

6.2.7 struct meshCopVendorDataTlv_t

Vendor data TLV.

Data Fields

:40 4	4	TI 4
uinto t	tvne	TIV type.
	J F	JF

uint8_t	len	Tlv length.
uint8_t	vendorData[]	Vendor dame.

6.2.8 struct meshCopStackVersionTlv_t

Vendor stack TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	vendorOui[3]	Organization unique identifier.
uint8_t	majMin	Major and minor version numbers of the Thread Stack.
uint8_t	revBuild[2]	Revision and build numbers of the Thread Stack.

6.2.9 struct meshCopProvUrlTlv_t

Provisioning URL TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	provUrl[]	Provisioning URL.

6.2.10 struct meshCopJoinFinTlvs_t

Joiner Finalization TLVs.

Data Fields

meshCop←	pState	Pointer to the state tlv.
StateTlv_t		
*		
meshCop←	pVendorName	Pointer to the vendor name.
VendorName←		
Tlv_t		
*		

meshCop←	pVendorModel	Pointer to the vendor model.
VendorModel←		
Tlv_t		
*		
meshCop←	pVendorSwVer	Pointer to the vendor software version.
VendorSwVer⊷		
Tlv_t		
*		
meshCop←	pVendorData	Pointer to the vendor data.
VendorData←		
Tlv_t		
*		
meshCop←	pVendor⊷	Pointer to the vendor stack version.
StackVersion ←	StackVer	
Tlv_t		
*		
meshCop←	pProvUrl	Pointer to the provisioning url.
ProvUrlTlv_t		
*		

6.2.11 struct meshCopChannelTlv_t

Channel TLV.

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	channelPage	Channel page.
uint8_t	channel[2]	Channel.

6.2.12 struct meshCopChannelMaskTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	channelPage	Channel page.
uint8_t	maskLength	Channel mask length.

uint8_t channe	
Mask[4	

6.2.13 struct meshCopCountTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	count	Count.

6.2.14 struct meshCopPeriodTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	period[2]	Period between successive scans.

6.2.15 struct meshCopEnergyListTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	aList[]	Energy list start.

6.2.16 struct meshCopScanDurationTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	scan←	The scan duration in MAC units.
	Duration[2]	

6.2.17 struct meshCopDiscoveryReqTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	verFlags	Version flags.
uint8_t	reserved	Reserved.

6.2.18 struct meshCopDiscoveryRespTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	verFlags	Version flags.
uint8_t	reserved	Reserved.

6.2.19 struct meshCopDiscoveryTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	value[]	Start of the discovery tlvs.

6.2.20 struct meshCopNwkChannelTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	channel	Channel.

6.2.21 struct meshCopNwkPanIdTlv_t

Data Fields

_			
	•		
	uint8 t	tuna	Thy type
		LVDC	TIV type.
		. 7 I	· J r · ·
	671110 0_0	t j p c	Tr type.

Kinetis Thread Stack API Reference Manual

uint8_t	len	Tlv length.
uint8_t	panId[TLV_←	Pan id.
	$NETWORK_{\leftarrow}$	
	PANID_LEN]	

6.2.22 struct meshCopNwkXPanIdTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	xPanId[TLV←	Extended pan id.
	_NETWORK↔	
	_XPANID_L↔	
	EN]	

6.2.23 struct meshCopNwkNameTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	nwkName[]	Network name.

6.2.24 struct meshCopPskcTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	pskc[]	Commissioner credential.

6.2.25 struct meshCopNwkMasterKeyTlv_t

Data Fields

_			
	uint8_t	type	Tlv type.

uint8_t	len	Tlv length.
uint8_t	masterKey[T←	Master key.
	LV_NETWO ←	
	RK_KEY_L ←	
	EN]	

6.2.26 struct meshCopNwkKeySeqTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	keySeq[TLV←	Key sequence.
	_NETWORK ←	
	_KEY_SEQ_←	
	LEN]	

6.2.27 struct meshCopNwkMIUIaTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	mlUla[TLV_←	Mesh local prefix.
	NETWORK_←	
	ML_ULA_L	
	EN]	

6.2.28 struct meshCopSteeringTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	filter[]	Filter bytes.

6.2.29 struct meshCopBrLocTlv_t

Kinetis Thread Stack API Reference Manual NXP Semiconductors 95

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	addr[2]	Short address in network order.

6.2.30 struct meshcopCommldTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	commId[]	Commissioner id.

6.2.31 struct meshCopCommSessIdTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	id[2]	Commissioner session id in network order.

6.2.32 struct meshCopGetTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	aIds[]	List of tlv ids.

6.2.33 struct meshCopActiveTimestampTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	seconds[6]	Seconds part.

uint8_t ticks[2]	Ticks part.
--------------------	-------------

6.2.34 struct meshCopCommissionerUdpPortTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	aPort[2]	Port number in network order.

6.2.35 struct meshCopJoinerUdpPortTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	aPort[2]	Port number in network order.

6.2.36 struct meshCopPendingTimestampTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	seconds[6]	Seconds part.
uint8_t	ticks[2]	Ticks part.

6.2.37 struct meshCopSecurityPolicyTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	rotation←	Key rotation interval in network order.
	Interval[2]	

uint8_t policy Policy bits.	
---------------------------------	--

6.2.38 struct meshCopMacExtendedAddressTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	aExtended←	Extended address.
	Address[8]	

6.2.39 struct meshCopDelayTimerTlv_t

Data Fields

uint8_t	type	Tlv type.
uint8_t	len	Tlv length.
uint8_t	time←	Timer value in netowrk byte order[ms].
	Remaining[4]	

6.2.40 struct meshcopDiscoveryRespTlvs_t

Discovery TLVs.

Data Fields

meshCop←	pDiscRespTlv	Pointer to discovery response tlv.
Discovery←		
RespTlv_t		
*		
meshCop←	pXpanIdTlv	Pointer to extended pan id tlv.
NwkXPanId←		
Tlv_t		
*		
meshCop←	pNwkNameTlv	Pointer to network name tlv.
NwkName←		
Tlv_t		
*		

meshCop←	pSteering←	Pointer to steering data tlv.
SteeringTlv_t	DataTlv	
*		
meshCop←	pJoinerUdp←	Pointer to joiner udp port tlv.
JoinerUdp↔	PortTlv	
PortTlv_t		
*		
meshCop←	p⇔	Pointer to Commissioner udp port tlv.
Commissioner←	Commissioner←	
UdpPortTlv_t	UdpPortTlv	
*		

6.2.41 struct thrDiscoveryRespInfo_t

Discovery Response message.

Data Fields

uint32_t	LQI	LQI of the packet.
uint16_t	panId	Pan id from where the discovery response packet came.
uint8_t	aEui[8]	Extended address of the sender of the discovery response packet.
uint8_t	channel	Channel number from where the discovery packet came.

6.2.42 struct meshcopHandlers_t

Structure defining the MESHCOP handler.

Data Fields

uint32_t	id	Callback Id.
uint32_t	secondId	Optional parameter.
void *	pfCallback	Callback used by the application to receive TLVs.
bool_t	keep	Keep or erase handler after the first execution.
bool_t	used	The status of this entry.

6.2.43 struct meshcopNwkFormParams_t

Structure defining the parameters of MESHCOP_SendNetworkForm.

Typedef Documentation

Data Fields

uint8_t	instanceId	Thread instance Id.
uint8_t	network←	Network name length.
	NameSize	
uint8_t	masterKeySize	Master key length.
uint8_t	pskcSize	PSKC length.
uint8_t *	pNwkName	Pointer to network name.
uint8_t *	pMasterKey	Pointer to master key.
uint8_t *	pPskc	Pointer to PSKC.
meshcop←	pfGetCb	Pointer to handler function.
HandlerCb_t		
uint8_t	channel	Channel.

6.2.44 struct meshcopMgmtParams_t

Structure defining the parameters used for management commands.

Data Fields

instanceId_t	thrInstId	Thread instance Id.
uint8_t *	pTlvs	Pointer to the TLVs to be sent.
uint32_t	tlvsLength	Length of the TLVs buffer.
meshcop←	pfCb	Pointer to the callback.
HandlerCb_t		
ipAddr_t *	pDstIpAddr	Pointer to the IP of the destination.

6.3 Typedef Documentation

6.3.1 typedef void(* meshcopDiagnosticHandlerCb_t) (meshcopDiagnosticType_t meshcopDiagType, meshcopDiagnosticDir_t dir, uint8_t *pEui, uint8_t *pTlvs, uint32_t tlvsLen)

Callback used to send meshcop diagnostics

Parameters

in	meshcopDiag↔	Diagnostics type
	Туре	
in	dir	Direction of packet
in	рЕиі	Pointer to eui address

Typedef Documentation

in	pTlvs	Pointer to tlvs
in	tlvsLen	Tlvs length

Returns

NONE

6.3.2 typedef void(* thrDiscoveryRespCb_t) (instanceId_t thrInstId, thrDiscoveryEvent_t event, uint8_t lqi, thrDiscoveryRespInfo_t *pDiscoveryRespInfo, meshcopDiscoveryRespTlvs_t *pDiscoveryRespTlvs)

The Discovery Response Callback used by the application to receive the Discovery Responses received during the Discovery process

Parameters

in	thrInstId	Thread instance ID
in	event	Discovery event type
in	lqi	LQI of the Discovery packet received
in	pDiscovery←	Pointer to a structure containing information about the received Discov-
	RespInfo	ery response packet
in	pDiscovery↔	Pointer to the Discovery response tlvs
	RespTlvs	

Returns

NONE

6.3.3 typedef void(* meshcopHandlerCb_t) (meshcopHandlers_t *pldHandlerEntry, uint8_t *pTlvs, uint32_t tlvsLen)

Callback used by the application to receive TLVs

Parameters

in	pIdHandler⇔	Pointer to MESHCOP handler
	Entry	

Enumeration Type Documentation

in	pTlvs	Pointer to TLVs location
in	tlvsLen	TLVs length

Returns

NONE

6.4 Enumeration Type Documentation

6.4.1 enum meshCopTlv_t

TLV types.

6.4.2 enum meshcopEuiMask_t

Bloom filter mode.

Enumerator

```
gMeshcopEuiMaskAllZeroes_c Don't allow any device.
gMeshcopEuiMaskAllFFs_c Allow all devices.
gMeshcopEuiMaskExpectedJoinerList_c Allow only expected joiners (see expected joiners list)
```

6.4.3 enum thrEvCodesComm_t

Network Commissioner Events.

Enumerator

```
gThrEv_MeshCop_JoinerDiscoveryStarted_c Joiner has started discovery.
gThrEv_MeshCop_JoinerDiscoveryFailed_c No Thread networks/routers found.
gThrEv_MeshCop_JoinerDiscoveryFailedFiltered_c Joiner Routers found, but device is filtered.
gThrEv_MeshCop_JoinerDiscoverySuccess_c Network selected.
gThrEv_MeshCop_JoinerDtlsSessionStarted_c Started DTLS session to commissioner (sent Hello)
gThrEv_MeshCop_JoinerDtlsError_c DTLS session error - all DTLS errors, e.g. : incorrect PSKd
gThrEv_MeshCop_JoinerError_c All other non-DTLS errors (e.g. : Joiner Router failed to send credentials)
gThrEv_MeshCop_JoinerAccepted_c Joiner has received credentials.
gThrEv_MeshCop_CommissionerPetitionStarted_c Petitioning has started.
gThrEv_MeshCop_CommissionerPetitionAccepted_c Petition success.
gThrEv_MeshCop_CommissionerPetitionRejected_c Petition rejected.
```

Enumeration Type Documentation

103

- gThrEv_MeshCop_CommissionerPetitionError_c Other errors in petitioning (did not get PET response)
- gThrEv_MeshCop_CommissionerKeepAliveSent_c Generated after each KA.
- gThrEv_MeshCop_CommissionerError_c Errors during generating KA or other errors on the commissioner session.
- gThrEv_MeshCop_CommissionerJoinerDtlsSessionStarted_c A Joiner sent Hello.
- gThrEv_MeshCop_CommissionerJoinerDtlsError_c DTLS session error all DTLS errors, e.g. : incorrect PSKd
- gThrEv MeshCop CommissionerJoinerAccepted c Joiner accepted.
- gThrEv_MeshCop_CommissionerNwkDataSynced_c generated after the commissioner changes the Nwk data
- gThrEv_MeshCop_CommissionerBrDtlsSessionStarted_c started DTLS session to BR (sent Hello)
- gThrEv_MeshCop_CommissionerBrDtlsError_c DTLS session error all DTLS errors, e.g. : incorrect PSKc
- gThrEv_MeshCop_CommissionerBrError_c All Other errors non-DTLS errors when communicating with the BR.
- gThrEv_MeshCop_CommissionerBrAccepted_c BR session established.
- gThrEv_MeshCop_BrCommissionerDtlsSessionStarted_c Commissioner sent Hello.
- gThrEv_MeshCop_BrCommissionerDtlsError_c DTLS session error all DTLS errors, e.g. : incorrect PSKc
- gThrEv_MeshCop_BrCommissionerAccepted_c BR session established.
- gThrEv_MeshCop_BrCommissionerDataRelayedInbound_c After each relay from BR to Thread.
- gThrEv_MeshCop_BrCommissionerDataRelayedOutbound_c After each relay to BR from Thread.
- gThrEv_MeshCop_JoinerrouterJoinerDataRelayedInbound_c After each relay from Joiner to Commissioner.
- gThrEv_MeshCop_JoinerrouterJoinerDataRelayedOutbound_c After each relay to Joiner from Commissioner.
- gThrEv_MeshCop_JoinerrouterJoinerAccepted_c Before providing the security material to the Joiner.
- gThrEv_MeshCop_StartVendorProvisioning_c Device entered Joiner Provisioning mode.

6.4.4 enum meshcopDiagnosticDir_t

Enumerator

gMeshcopDiagnosticOut_c The packet was sent.gMeshcopDiagnosticIn_c The packet was received.

6.4.5 enum meshcopDiagnosticType_t

Enumerator

```
    gMeshcopDiagnosticJoinFinReq_c
    gMeshcopDiagnosticJoinFinRsp_c
    gMeshcopDiagnosticJoinEntReq_c
    gMeshcopDiagnosticJoinEntRsp_c
    gMeshcopDiagnosticCloseNotify_c
    gMeshcopDiagnosticLog_c
    Logging
    Logging
```

6.4.6 enum thrDiscoveryEvent_t

Discovery event received by the Discovery Response Callback.

Enumerator

```
gThrDiscoveryStarted_c The discovery mechanism has been started.
gThrDiscoveryRespRcv_c Discovery response packet has been received.
gThrDiscoveryStopped_c Discovery mechanism has been completed.
```

6.5 Function Documentation

6.5.1 thrStatus_t MESHCOP_StartNativeCommissionerScan (instanceId_t thrInstId)

This function is used to start the scan process on behalf of the Native Commissioner.

Parameters

in	thrInstId	Thread instance ID
----	-----------	--------------------

Returns

thrStatus t Status

6.5.2 bool_t MESHCOP_StopCommissioner (instanceId_t thrInstId, bool_t updateNwk)

This function is used to stop the Commissioner on this device.

Parameters

in	thrInstId	Thread instance ID
in	updateNwk	Send information into the network

Returns

bool_t TRUE - if the stop operation succeeded FALSE - otherwise

6.5.3 bool t MESHCOP AddExpectedJoiner (instanceld t thrinstid, uint8 t * pEui, uint8 t * pPsk, uint32 t pskLen, bool t selected)

Add a Joiner to the expected joiners list.

Parameters

in	thrInstId	Thread instance ID
in	рЕиі	Pointer to the extended address of the Joiner
in	pPsk	Pointer to given pskc
in	pskLen	Length of given pskc
in	selected	Use this entry or not

Returns

TRUE The Joiner was scanned successfully FALSE The Joiner was not scanned successfully

6.5.4 bool t MESHCOP RemoveExpectedJoiner (instanceld t thrInstId, uint8 t * pHashEui, uint8_t * pEui)

Remove an expected joiner from the gThrExpectedJoinerList list.

Parameters

in	thrInstId	Thread instance ID
in	рНashEui	Pointer to the hash extended address(optional)
in	рЕиі	Pointer to the extended address(optional)

Returns

TRUE Item was found FALSE Item was not found

Kinetis Thread Stack API Reference Manual NXP Semiconductors 105

6.5.5 void MESHCOP_RemoveAllExpectedJoiners (instanceId_t thrInstId)

Remove all expected joiners from the gThrExpectedJoinerList list.

107

Parameters

in	thrInstId	Thread instance ID
----	-----------	--------------------

6.5.6 void MESHCOP_SyncSteeringData (instanceld_t *thrInstld*, meshcopEuiMask_t *euiMask*)

Sync the steering data on the network with our device.

Parameters

in	thrInstId	Thread instance ID
in	euiMask	Specify which devices will be steered

Returns

none

6.5.7 meshcopSteeringMatch_t MESHCOP_CheckSteeringData (meshCopSteeringTlv_t * pSteeringDataTlv)

Check if this device is in the received steering data.

Parameters

in	pSteering⇔	Pointer to the Steering Data TLV
	DataTlv	

Returns

meshcopSteeringMatch_t Matching type

6.5.8 void MESHCOP_SetCommissionerCredential (instanceld_t *thrInstld*, meshcopCredentialInput_t * *pParams*)

Function used to compute and set the PSKc, network name, extended pan Id attributes on the commissioner.

Parameters

in	thrInstId	Thread instance id
in	pParams	Pointer to the input parameters

6.5.9 void MESHCOP_SetDiagHandler (instanceId_t *thrInstId*, meshcopDiagnosticHandlerCb_t *pfTIvsHandler*)

Function used to set the function which will handle tlvs received during the commissioning process.

Parameters

in	thrInstId	Thread instance id
in	pfTlvsHandler	Pointer to the tlvs function handler

6.5.10 uint8_t * MESHCOP_AddTlvs (instanceId_t *thrInstanceID,* uint8_t * *pStart,* uint64_t * *pMask,* bool_t *usePending,* bool_t *noSecPolicy*)

Function used add TLV information into buffer.

Parameters

in	thrInstId	Thread instance id
in	pStart	Pointer to the start of the buffer
in	pMask	Pointer to the mask array
in	usePending	Boolean variable used to request data from pending set
in	noSecPolicy	Internal use: add any TLV w/o taking care of security policy

Returns

uint8_t* Pointer to the buffer after addition

6.5.11 uint32_t MESHCOP_GetTlvsLen (instanceId_t thrInstanceID, uint64_t * pMask, bool_t usePending, bool_t noSecPolicy)

Function used to get the length of the TLVs requested in mask.

Parameters

_			
	in	thrInstId	Thread instance id

Kinetis Thread Stack API Reference Manual

in	pStart	Pointer to the start of the buffer
in	pMask	Pointer to the mask array
in	usePending	Boolean variable used to request data from pending set
in	noSecPolicy	Do not take care of security policy

Returns

uint32_t Length of the TLVs requested in the mask

6.5.12 uint8_t MESHCOP_RegisterBrServerAddr6 (instanceId_t thrInstId, ipIfUniqueId_t ifId, ipAddr_t * pAddr)

Function used to register border router server address.

Parameters

in	thrInstId	Thread instance ID
in	ifId	IP Interface identifier
in	pAddr	Pointer to the IP address

Returns

uint8_t

6.5.13 void MESHCOP_NwkJoinWithCommissioning (instanceld_t *thrInstId*, thrNwkJoiningEntry_t * *pNwkJoiningList*, uint32_t *nbOfNwkJoiningEntries*)

Run through the pNwkJoiningList list and join using the commissioning procedure. NOTE:

- More callback functions must be registered (using EVM_RegisterStatic() function) with the g
 —
 ThrEvSet_NwkJoin_c and gThrEvSet_NwkCommissioning_c event set to receive the network join
 events.
- pNwkJoiningList is a allocated buffer and it will be free by the function

Parameters

in	thrInstID	Thread instance Id
in	pNwkJoining←	Pointer to network joining list
	List	

in	nbOfNwk↔	Size of network joining list
	JoiningEntries	

Returns

thrStatus_t Status

6.5.14 nwkStatus_t MESHCOP_Set (instanceId_t thrInstId, uint8_t * pTlvs, uint32_t tlvsLength, meshcopHandlerCb_t pfSetCb)

Function used to do a ManagementSet.

Parameters

in	thrInstId	Thread instance ID
in	pTlvs	Pointer to the start of the TLVs buffer
in	tlvsLen	Length of the TLVs buffer
in	pfSetCb	Pointer to the function which will be called when the request is com-
		pleted

Returns

 $nwkStatus_t$

6.5.15 nwkStatus_t MESHCOP_Get (instanceId_t thrInstId, uint8_t * pTlvs, uint32_t tlvsLength, meshcopHandlerCb_t pfGetCb)

Function used to do a management get.

Parameters

in	thrInstId	Thread instance ID
in	pTlvs	Pointer to the list of TLV IDs
in	tlvsLen	Length of the TLV IDs list
in	pfGetCb	Pointer to the function which will be called when the request is com-
		pleted
in	pNeighborIp↔	Pointer to the specific neighbor IP address(optional)
	Addr	

Returns

 $nwkStatus_t$

Kinetis Thread Stack API Reference Manual

6.5.16 nwkStatus_t MESHCOP_MgmtSendPanldQuery (instanceld_t thrInstld, uint32_t channelMask, uint16_t panld, meshcopHandlerCb_t pfHandlerCb, ipAddr_t * plpAddr)

Request to search for Pan ID conflict.

Kinetis Thread Stack API Reference Manual

Parameters

in	thrInstId	Thread instance ID
in	channelMask	Mask of channels
in	panId	Pan ID
in	pfHandlerCb	Pointer to the function which will be called when the request is com-
		pleted
in	pIpAddr	Pointer to the IP address of the node which will search for Pan ID con-
		flict

Returns

nwkStatus_t

6.5.17 nwkStatus_t MESHCOP_MgmtSendEdScan (instanceId_t thrInstId, uint32_t channelMask, uint32_t count, uint32_t period, uint32_t scanDuration, meshcopHandlerCb_t pfHandlerCb, ipAddr_t * plpAddr)

Request to do ED scan.

Parameters

in	thrInstId	Thread instance ID
in	channelMask	Mask of channels
in	count	Count
in	period	Period
in	scanDuration	Scan duration
in	pfHandlerCb	Pointer to the function which will be called when the request is com-
		pleted
in	pIpAddr	Pointer to the IP address of the node which will search for Pan ID con-
		flict

Returns

nwkStatus_t

6.5.18 nwkStatus_t MESHCOP_MgmtSendAnnounceBegin (instanceId_t thrInstId, uint16_t commissionerSessionId, uint32_t channelMask, uint32_t count, uint16_t period, ipAddr_t * plpAddr)

Request to send a MGMT_ANNOUNCE_BEGIN.ntf

Kinetis Thread Stack API Reference Manual

113

Parameters

in	thrInstId	Thread instance ID
in	commissioner←	Commissioner Session ID
	SessionId	
in	channelMask	Mask of channels
in	count	Count
in	period	Period
in	pIpAddr	Pointer to the IP address of the node which will begin sending the M←
		GMT_ANNOUNCE.ntf

Returns

 $nwkStatus_t$

6.5.19 nwkStatus_t MESHCOP_MgmtActiveSet (meshcopMgmtParams_t * pParams)

Function used to send a MGMT_ACTIVE_SET packet.

Parameters

in	pParams	Pointer to the input parameters

Returns

nwkStatus_t

6.5.20 nwkStatus_t MESHCOP_MgmtPendingSet ($meshcopMgmtParams_t * pParams$)

Function used to send a MGMT_PENDING_SET packet.

Parameters

in	pParams	Pointer to the input parameters
----	---------	---------------------------------

Returns

nwkStatus_t

NXP Semiconductors

6.5.21 $nwkStatus_t MESHCOP_MgmtCommGet (meshcopMgmtParams_t * pParams)$

Function used to send a MGMT_COMMISSIONER_GET packet.

Parameters

in	pParams	Pointer to the input parameters
----	---------	---------------------------------

Returns

nwkStatus_t

6.5.22 nwkStatus_t MESHCOP_MgmtActiveGet (meshcopMgmtParams_t * pParams)

Function used to send a MGMT_ACTIVE_GET packet.

Parameters

in	pParams Pointer to the	input parameters
----	--------------------------	------------------

Returns

nwkStatus_t

6.5.23 nwkStatus_t MESHCOP_MgmtPendingGet (meshcopMgmtParams_t * pParams)

Function used to send a MGMT_PENDING_GET packet.

Parameters

in	pParams	Pointer to the input parameters
----	---------	---------------------------------

Returns

nwkStatus_t

6.6 Variable Documentation

6.6.1 list_t gThrExpectedJoinerList

List of expected joiners (of type expectedJoinerEntry_t)

6.6.2 thrCommissionerMode_t gMeshcopCommissionerMode

The current commissioner mode.

Kinetis Thread Stack API Reference Manual

Variable Documentation

Chapter 7 **Network IP Sockets Interface**

Overview 7.1

Files

• file sockets.h

Data Structures

- struct sockaddrIn t
- struct sockaddrIn6_t
- struct sockaddrStorage_t
- struct timeval
- struct ipMreq_t
- struct socketCallback_t
- struct sock_t

Macros

- #define BSDS_DATAGRAM_SUPPORT
- #define BSDS_STREAM_SUPPORT
- #define BSDS_BLOCKING_SOCKET
- #define BSDS_SELECT_SUPPORT
- #define BSDS OPTIONS SUPPORT
- #define BSDS RECV EVENT
- #define BSDS_CANCEL_SELECT_EVENT#define BSDS_CONN_DONE_EVENT
- #define SOCK DGRAM
- #define SOCK STREAM
- #define PF_INET
- #define PF_INET6
- #define MSG_DONTWAIT
- #define MSG_SEND_WITH_MEMBUFF
- #define MSG_GET
- #define IPV6_UNICAST_HOPS
- #define IPV6_MULTICAST_HOPS
- #define IPV6_ADD_MEMBERSHIP
- #define IPV6_DROP_MEMBERSHIP
- #define IPV6 MTU
- #define IPV6_JOIN_ANYCAST
- #define IPV6_TCLASS
- #define IP_TOS
- #define IP_TTL#define IP_ADD_MEMBERSHIP
- #define IP_DROP_MEMBERSHIP
- #define IP MULTICAST IF

Overview

```
#define IP_MULTICAST_TTL
#define IP_MULTICAST_LOOP
#define IPV6_JOIN_GROUP
#define IPV6_LEAVE_GROUP
#define BSDS_DEFAULT_FLOW_FLAGS
#define BSDS_SET_TX_SEC_FLAGS(macKeyIdMode, macSecLevel)
#define FD_SETSIZE
```

Typedefs

• typedef uint32_t socklen_t

Enumerations

```
enum sockFuncErr t {
  gBsdsSockSuccess c.
  gBsdsSockUnavailable_c,
 gBsdsSockAdded c,
 gBsdsSockRemoved c,
 gBsdsSockListFull_c,
 gBsdsSockError_g,
 gBsdsSockPortInUse_c,
 gBsdsNoMoreFreePorts c,
 gBsdsSockFound c.
 gBsdsSockInvalid c }
enum sockStateErr_t {
  gBsdsSockUnbound c,
  gBsdsSockBound_c,
 gBsdsSockListening_c,
  gBsdsSockUnConnected c,
 gBsdsSockConnected c }
```

Functions

```
• int32_t socket (uint8_t domain, uint8_t type, uint8_t protocol)
```

- int32_t shutdown (int32_t sockfd, int how)
- int32_t bind (int32_t sockfd, sockaddrStorage_t *pLocalAddr, uint32_t addrlen)
- int32_t send (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)
- int32_t **sendmsg** (int32_t sockfd, ipAddr_t *pSrc, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t *pTo, socklen_t toLen)
- int32_t sendto (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t *p← To, uint32_t toLen)
- int32_t recv (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)
- int32_t recvfrom (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t *from, socklen t *fromLen)
- int32_t connect (int32_t sockfd, sockaddrStorage_t *serv_addr, uint32_t addrLen)
- int32_t getsockopt (int32_t sockfd, int32_t level, int32_t optName, void *optVal, int32_t *optLen)
- int32 t setsockopt (int32 t sockfd, int32 t level, int32 t optName, void *optVal, int32 t optLen)
- int32 t getsockname (int32 t sockfd, sockaddrStorage t *pAddr, socklen t *addrlen)
- sock_t * getsocket (int32_t sockFd)

Variables

- $\bullet \ const \ socket Callback_t \ sock Dgram Callback\\$
- const socketCallback_t sockStreamCallback

7.2 Data Structure Documentation

7.2.1 struct sockaddrln_t

Data Fields

ipAddr_t	sin_addr	Internet address.
uint16_t	sin_family	Address family.
uint16_t	sin_port	Port number.

7.2.2 struct sockaddrln6_t

Data Fields

ipAddr_t	sin6_addr	IPV6 address.
uint16_t	sin6_family	The address family we used when we set up the socket (AF_INE⊷
		T6)
uint16_t	sin6_port	The port number (the transport address)
uint32_t	sin6_flowinfo	IPV6 flow information (LSB= (MAC key id mode) (MAC security
		level))
uint32_t	sin6_scope_id	set of interfaces for a scope (RFC2553) or media interface handle

7.2.3 struct sockaddrStorage_t

Data Fields

ipAddr_t	ss_addr	Internet address.
uint16_t	ss_family	Address family.
uint8_t	_~	Storage large enough and aligned for storing the socket address
	data[sizeof(uint1	data structure of any family.
	_~	
	t)+sizeof(uint32	
	_~	
	t)+sizeof(uint32	
	_t)]	

7.2.4 struct timeval

Structure containing time information.

Kinetis Thread Stack API Reference Manual

Data Fields

uint32_t tv_sec	seconds
uint32_t tv_usec	microseconds

7.2.5 struct ipMreq t

Data Fields

ipAddr_t	imrMultiaddr	IP multicast group address.
ipAddr_t	imrInterface	IP address of local interface.

7.2.6 struct socketCallback t

Data Fields

- int32_t(* SocketBind)(int32_t sockfd, sockaddrStorage_t *pLocalAddr, uint32_t addrlen)
- int32_t(* SocketConnect)(int32_t sockfd, sockaddrStorage_t *serv_addr, int addrLen)
- int32_t(* SocketListen)(int32_t sockfd, uint32_t backlog)
 int32_t(* SocketAccept)(int32_t sockfd, sockaddrStorage_t *addr, int addrLen)
- int32_t(* SocketRecv)(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)
- int32_t(* SocketRecvFrom)(int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage t *from, socklen t fromLen)
- int32 t(* SocketSend)(int32 t sockfd, void *msg, uint32 t msgLen, uint32 t flags)
- int32_t(* SocketSendto)(int32_t sockfd, ipAddr_t *pAddr, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage t *to, socklen t toLen)
- int32 t(* **SocketClose**)(int32 t sockfd, int how)

7.2.6.1 Field Documentation

7.2.6.1.1 int32_t(* socketCallback_t::SocketBind) (int32_t sockfd, sockaddrStorage_t *pLocalAddr, uint32 t addrlen)

< Socket bind callback

Socket connect (TCP) callback

7.2.6.1.2 int32 t(* socketCallback t::SocketConnect) (int32 t sockfd, sockaddrStorage_t *serv addr, int addrLen)

Socket listen (TCP) callback.

7.2.6.1.3 int32 t(* socketCallback t::SocketListen) (int32 t sockfd, uint32 t backlog)

Socket accept (TCP) callback.

7.2.6.1.4 int32_t(* socketCallback_t::SocketAccept) (int32_t sockfd, sockaddrStorage_t *addr, int addrLen)

Socket recv (TCP) callback.

7.2.6.1.5 int32_t(* socketCallback_t::SocketRecv) (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)

Socket recvfrom (UDP) callback.

7.2.6.1.6 int32_t(* socketCallback_t::SocketRecvFrom) (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t *from, socklen_t fromLen)

Socket send (TCP) callback.

7.2.6.1.7 int32_t(* socketCallback_t::SocketSend) (int32_t sockfd, void *msg, uint32_t msgLen, uint32_t flags)

Socket sendto (UDP) callback.

7.2.6.1.8 int32_t(* socketCallback_t::SocketSendto) (int32_t sockfd, ipAddr_t *pAddr, void *msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t *to, socklen_t toLen)

Socket close (UDP/TCP) callback.

7.2.7 struct sock t

Data Fields

uint8_t	addrFam	Address family.
uint8_t	prot	Protocol.
uint8_t	type	Socket type(datagram or stream)
uint8_t	state	Socket status of the connection.

Macro Definition Documentation

uint8_t	flags	Socket flags.
uint8_t	tspConnIndex	Transport connection index.
uint8_t	sockPad	padding
socket←	pCallback	Pointer to socket callbacks.
Callback_t		
*		

7.3 Macro Definition Documentation

7.3.1 #define BSDS_DATAGRAM_SUPPORT

Support datagram sockets(using UDP)

7.3.2 #define BSDS_STREAM_SUPPORT

Support stream sockets(using TCP)

7.3.3 #define BSDS BLOCKING SOCKET

Support blocking sockets.

7.3.4 #define BSDS_SELECT_SUPPORT

Sockets module support select functionality.

7.3.5 #define BSDS OPTIONS SUPPORT

Support socket options.

7.3.6 #define BSDS_RECV_EVENT

Event to be used for Socket receive blocking.

7.3.7 #define BSDS CANCEL SELECT EVENT

Event to be used for Socket select blocking.

7.3.8 #define BSDS_CONN_DONE_EVENT

Event to be used for receiving a connection.

7.3.9 #define SOCK_DGRAM

Datagram socket type.

7.3.10 #define SOCK_STREAM

Stream socket type.

7.3.11 #define PF_INET

IPv4 family.

7.3.12 #define PF INET6

IPv6 family.

7.3.13 #define MSG DONTWAIT

Nonblocking IO.

7.3.14 #define MSG_SEND_WITH_MEMBUFF

socket send app data is located in a memory buffer allocated from memory pools and will be freed by the stack

7.3.15 #define MSG_GET

Message get.

7.3.16 #define IPV6_UNICAST_HOPS

Set the unicast hop limit for the socket.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

7.3.17 #define IPV6_MULTICAST_HOPS

Set the multicast hop limit for the socket.

7.3.18 #define IPV6_ADD_MEMBERSHIP

Joins the IPv6 multicast group specified.

7.3.19 #define IPV6_DROP_MEMBERSHIP

Leaves the IPv6 multicast group specified.

7.3.20 #define IPV6_MTU

Set/Get MTU only for connected socket.

7.3.21 #define IPV6_JOIN_ANYCAST

Joins the anycast group specified.

7.3.22 #define IPV6_TCLASS

Set the traffic class field of IPv6 header.

7.3.23 #define IP TOS

Sets the TOS field from IPv4 header.

7.3.24 #define IP TTL

Sets the Time To Live (TTL) in the IP header for unicast packets.

7.3.25 #define IP ADD MEMBERSHIP

Joins the multicast group specified.

Kinetis Thread Stack API Reference Manual

7.3.26 #define IP DROP MEMBERSHIP

Leaves the multicast group specified.

7.3.27 #define IP_MULTICAST_IF

Sets the interface over which outgoing multicast datagrams are sent.

7.3.28 #define IP_MULTICAST_TTL

Sets the Time To Live (TTL) in the IP header for outgoing multicast datagrams.

7.3.29 #define IP_MULTICAST_LOOP

Specifies whether or not a copy of an outgoing multicast datagram is delivered to the sending host as long as it is a member of the multicast group.

7.3.30 #define IPV6 JOIN GROUP

Joins the IPv6 multicast group specified.

7.3.31 #define IPV6 LEAVE GROUP

Leaves the IPv6 multicast group specified.

Get default socket flow flag

7.3.32 #define BSDS DEFAULT FLOW FLAGS

Set MAC security flags.

7.3.33 #define FD_SETSIZE

File descriptor list size to select/poll on.

Kinetis Thread Stack API Reference Manual

7.4 Enumeration Type Documentation

7.4.1 enum sockFuncErr_t

Enumerator

```
gBsdsSockUnavailable_c Socket to be removed is not available.
gBsdsSockAdded_c Socket was successfully added to list.
gBsdsSockRemoved_c Socket was successfully removed from list.
gBsdsSockListFull_c The sockets list is full.
gBsdsSockError_g Error.
gBsdsSockPortInUse_c Port was already used.
gBsdsNoMoreFreePorts_c There are no more free ports.
gBsdsSockFound_c Socket was found in list.
gBsdsSockInvalid_c Invalid.
```

7.4.2 enum sockStateErr_t

Enumerator

```
gBsdsSockUnbound_c Socket is not in use.
gBsdsSockBound_c Socket is bound to an address/port combination.
gBsdsSockListening_c Socket is in listening state.
gBsdsSockUnConnected_c Socket is not connected.
gBsdsSockConnected_c Socket is connected.
```

7.5 Function Documentation

7.5.1 int32_t socket (uint8_t domain, uint8_t type, uint8_t protocol)

This function creates a socket structure(and initialize its values with default) using a specific domain, type and protocol.

Parameters

in	domain	Domain which can be PF_INET or PF_INET6
in	type	Type of socket(SOCK_DGRAM or SOCK_STREAM)
in	protocol	Transport protocol to be used(IPPROTO_UDP or IPPROTO_TCP)

Returns

int32_t Socket file descriptor or -1 in case of error

7.5.2 int32_t shutdown (int32_t sockfd, int how)

This function close a socket connection.

Parameters

in	sockfd	Socket descriptor
in	how	(UNUSED)parameter which specifies how the socket will be closed

Returns

- 0 On success
- -1 On failure

7.5.3 int32_t bind (int32_t sockfd, sockaddrStorage_t * pAddr, uint32_t addrLen)

Public interface function for Sockets module. This function is used to bind a local IP address and a local port to an existing socket.

Parameters

in	sockfd	Socket descriptor
in	pAddr	Pointer to the socket address structure
in	addrLen	Size of the pAddr structure

Returns

- 0 On success
- -1 On failure

7.5.4 int32 t send (int32 t sockfd, void * msg, uint32 t msgLen, uint32 t flags)

This function is used to send data to a connected socket.

Parameters

in	sockfd	Socket descriptor
in	msg	Pointer to the data which needs to be send
in	msgLen	Length of the data which needs to be send
in	flags	Flags used for sending

Returns

int32_t Length of the data sent, -1 on failure

7.5.5 int32_t sendto (int32_t sockfd, void * msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t * pTo, uint32_t toLen)

This function is used to send data to a specific socket.

Kinetis Thread Stack API Reference Manual

129

Parameters

in	sockfd	Socket descriptor
in	msg	Pointer to the data which needs to be send
in	msgLen	Length of the data which needs to be send
in	flags	Flags used for sending
in	рТо	Pointer to the remote socket address structure
in	toLen	Size of the remote address structure

Returns

int32_t Length of the data sent, -1 on failure

7.5.6 int32_t recv (int32_t sockfd, void * msg, uint32_t msgLen, uint32_t flags)

This function is used to get data from a socket RX queue.

Parameters

in	sockfd	Socket descriptor
out	msg	Pointer to the buffer responsible for holding received data
in	msgLen	Length of the buffer allocated for receiving data
in	flags	Flags used for receiving

Returns

int32_t Length of the data received, -1 on failure

7.5.7 int32_t recvfrom (int32_t sockfd, void * msg, uint32_t msgLen, uint32_t flags, sockaddrStorage_t * from, socklen t * fromLen)

This function is used to get data from a specific socket from the RX queue. The remote information will be placed in the from structure.

Parameters

in	sockfd	Socket descriptor
out	msg	Pointer to the buffer responsible for holding received data
in	msgLen	Length of the buffer allocated for receiving data

in	flags	Flags used for receiving
out	from	Pointer to the remote socket address structure
in	fromLen	Pointer to the size of the remote address structure

Returns

int32_t Length of the data received, -1 on failure

7.5.8 int32_t connect (int32_t sockfd, sockaddrStorage_t * serv_addr, uint32_t addrLen)

This function is used to connect to a remote server.

Parameters

	in	sockfd	Socket descriptor
Ī	in	serv_addr	Address structure for the server to connect to
	in	addrLen	Address structure length

Returns

- 0 On success
- -1 On error

7.5.9 int32_t getsockopt (int32_t sockfd, int32_t level, int32_t optName, void * optVal, int32_t * optLen)

This function retrieves information about a specified socket.

Parameters

in	sockfd	Socket file descriptor
in	level	Layer for operation
in	optName	Option
out	optVal	Pointer to the value for the option
out	optLen	Pointer to the length of the option

Return values

gBsdsSockSuccess_c	If the option was set
gBsdsSockError_g	If the option cannot be set

Kinetis Thread Stack API Reference Manual

7.5.10 int32_t setsockopt (int32_t sockfd, int32_t level, int32_t optName, void * optVal, int32_t optLen)

This function sets information for a specified socket.

Parameters

in	sockfd	Socket file descriptor
in	level	Layer for operation
in	optName	Option
in	optVal	Pointer to the value for the option
in	optLen	The length of the option

Return values

gBsdsSockSuccess_c	If the option was set
gBsdsSockError_g	If the option cannot be set

7.5.11 int32_t getsockname (int32_t sockfd, $sockaddrStorage_t * pAddr$, $socklen_t * addrlen$)

This function retrieves information about the local address and port of a socket.

Parameters

in	sockfd	Socket file descriptor	
out	pAddr	A pointer to a structure containing the local information	
out	addrlen	Pointer to the size of the pAddr structure	

Return values

gBsdsSockSuccess_c	If the name can be retrieved
gBsdsSockError_g	If the name cannot be retrieved

7.5.12 sock_t * getsocket (int32_t sockFd)

This function gets a pointer to the socket structure.

Parameters

in	sockFd So	ocket descriptor	
----	-------------	------------------	--

Returns

sock_t* Pointer to the socket structure or NULL if it doesn't exist

Chapter 8 CoAP Interface

8.1 **Overview**

Files

- file coap.h
- file coap_cfg.h

Data Structures

- struct coapUriPath_t
- struct coapInstance_t
- struct coapCallbackStruct_t
- struct coapTokenCbStruct_t
- struct coapOptionDetails_t
- struct coapSession_t
- struct coapStartSecParams_t
- struct coapStartUnsecParams_t
- struct coapRegCbParams_t

Macros

- #define COAP_ENABLED
- #define COAP_MAX_URI_PATH_OPT_SIZE
- #define COAP_MAX_OPTION_VALUE_SIZE
- #define COAP_MAX_TOKEN_LEN
- #define COAP_OBSERVE_OPTION
- #define COAP_URI_PATH_OPTION
 #define COAP_CONTENT_FORMAT_OPTION
- #define COAP URI QUERY OPTION
- #define COAP ACCEPT OPTION
- #define COAP_TIMER_INTERVAL
- #define COAP DEFAULT PORT
- #define COAP_DEFAULT_SECURED_PORT
- #define COAP_INSTANCES_URI_PATH
- #define COAP_SetMaxRetransmitCount(coapInstanceId, maxRetransmitCount)
- #define COAP_MAX_CALLBACKS
- #define COAP_MAX_NON_PIGGYBACKED_RSP
- #define COAP_MAX_INSTANCES#define COAP_MAX_MSG_IDs
- #define COAP_MAX_OPTIONS
- #define COAP_TOKEN_LENGTH

Typedefs

• typedef void(* coapCallback_t) (coapSessionStatus_t sessionStatus, void *pData, struct coap← Session_tag *pSession, uint32_t dataLen)

Overview

• typedef coapOptionDetails_t coapOption_t

Enumerations

```
enum coapSessionStatus_t {
 gCoapSuccess_c,
 gCoapFailure_c,
 gCoapDuplicate_c }
enum coapMacSecFlags_t {
 gCoapMacSecMode0Level5_c,
 gCoapMacSecMode1Level5_c,
 gCoapMacSecUnsecured_c }
enum coapMsgTypesAndCodes_t {
 gCoapMsgTypeConPost_c,
 gCoapMsgTypeNonPost_c,
 gCoapMsgTypeAckSuccessChanged_c,
 gCoapMsgTypeAckSuccessContent_c,
 gCoapMsgTypeConGet_c,
 gCoapMsgTypeNonGet_c,
 gCoapMsgTypeEmptyAck_c,
 gCoapMsgTypeUseSessionValues_c }
enum coapMessageTypes_t {
 gCoapConfirmable_c,
 gCoapNonConfirmable_c,
 gCoapAcknowledgement_c,
 gCoapReset_c }
enum coapReqRespCodes_t {
```

Kinetis Thread Stack API Reference Manual 134 **NXP Semiconductors**

```
gCoapGET c,
gCoapPOST_c,
gCoapPUT c.
gCoapDELETE_c,
gEmpty_c,
gCreated c,
gDeleted_c,
gValid_c,
gChanged c,
gContent c,
gBadRequest_c,
gUnauthorized c,
gBadOption c,
gForbidden c.
gNotFound_c,
gMethodNotAllowed c,
gNotAcceptable c,
gPreconditionFailed_c,
gRequestEntityTooLarge_c,
gUnsupportedContentFormat c,
gInternalServerError c,
gNotImplemented c.
gBadGateway_c,
gServiceUnavailable c,
gGatewayTimeout c,
gProxyingNotSupported_c }
```

Functions

- void COAP Init (taskMsgQueue t *pTaskMsgQueue)
- uint8_t COAP_CreateInstance (coapStartSecParams_t *pCoapStartSecParams, coapStartUnsec← Params_t *pCoapStartUnsecParams, ipIfUniqueId_t ipIfId, coapRegCbParams_t *pCallbacks← Struct, uint32 t nbOfCallbacks)
- bool_t COAP_CloseInstance (uint8_t coapInstanceId)
- coapSession_t * COAP_OpenSession (uint8_t coapInstanceId)
- void COAP_CloseSession (coapSession_t *pSession)
- void COAP_AddOptionToList (coapSession_t *pSession, uint8_t optName, uint8_t *optValue, uint8 t optValueLen)
- void COAP_SetUriPath (coapSession_t *pSess, coapUriPath_t *pUriPath)
- nwkStatus_t COAP_Send (coapSession_t *pSession, coapMsgTypesAndCodes_t coapMsgType, void *pData, uint32_t payloadLen)
- nwkStatus_t COAP_SendMsg (coapSession_t *pSession, void *pData, uint32_t payloadLen)
- nwkStatus_t COAP_RegisterResourceCallback (uint8_t coapInstanceId, coapRegCbParams_t *p↔ CallbacksStruct, uint32_t nbOfCallbacks)
- void COAP RegisterTokenCallback (coapSession t *pSession, coapCallback t pCallback)
- bool t COAP UnregisterTokenCallback (coapSession t *pSession coapCallback t pCallback)
- bool_t COAP_UnregisterResourceCallback (uint8_t coapInstanceId, coapRegCbParams_t *p↔ CallbacksStruct, uint32_t nbOfCallbacks)

Kinetis Thread Stack API Reference Manual

• void COAP_CloseAnySession (void)

8.2 Data Structure Documentation

8.2.1 struct coapUriPath_t

URI-path structure of a CoAP message.

Data Fields

uint8_t length	sizeof URI-path. e.g. for "/thread/client", uriPathLen = 14
uint8_t * pUriPath	pointer to URI-path. URI-path example: "/thread/client"

8.2.2 struct coapInstance_t

This structure keeps the parameters of a CoAP instance.

Data Fields

void *	pTransport	sockFd or DTLS peer/context(for servers)
list_t	sessionList	list of ongoing CoAP sessions
uint16_t	port	UDP port number.
uint16_t	coapAck←	the minimum spacing before another retransmission in millisec-
	TimeoutMs	onds
ipIfUniqueId←	ipIfId	IP interface unique ID.
_t		
uint8_t	coapMax←	number of retransmissions
	Retransmit	
bool_t	usedEntry	TRUE - if entry is populated, FALSE - entry is free.

8.2.3 struct coapCallbackStruct_t

The URI-path, callback and instance id tuple for associating an incoming message with its callback.

Data Fields

const	pUriPathStruct	pointer to URI-path and its length
coapUriPath_t		
*		

coapCallback←	pCallback	pointer to callback function
_t		
uint8_t	coapInstance←	CoAP instance ID array.
	Id[COAP_IN↔	
	STANCES_←	
	URI_PATH]	

8.2.4 struct coapTokenCbStruct_t

The token, callback, instance id tuple needed for associating a non-piggybacked message with its callback. Data Fields

uint8_t	aToken[COA←	Token of variable length.
	P_MAX_TO↔	
	KEN_LEN]	
coapCallback←	pCallback	pointer to callback function
_t		
uint8_t	coapInstanceId	CoAP instance ID.
uint8_t	tokenLen	The length of the token.

8.2.5 struct coapOptionDetails_t

CoAP option structure.

Data Fields

uint8_t	optName	The ID of the CoAP option.
uint8_t	optValueLen	Length in bytes of the option value.
uint8_t	optValue[CO←	Option value.
	AP_MAX_O↔	
	PTION_VAL↔	
	UE_SIZE]	

8.2.6 struct coapSession_t

A CoAP session keeps all the information necessary for a CoAP message exchange.

Data Fields

Kinetis Thread Stack API Reference Manual

ipAddr_t	remoteAddr	The destination IP address.
ipAddr_t	sourceAddr	The source IP address.
coapOption_t *	pTxOptionList	Options to be included in an outgoing CoAP msg.
coapOption_t *	pRxOptionList	Options received in the incoming CoAP msg.
coapCallback←	pCallback	Pointer to callback function.
_t		
uint8_t	aToken[COA←	Token of variable length.
	P_MAX_TO	
	KEN_LEN]	
coapUriPath_t	pUriPath	Pointer to URI-Path structure.
*		
uint32_t	macTxFlags	Sets the security level and the key ID mode for MAC layer encryp-
		tion. This value is by default set to key ID mode 1 and encryption
		level 5 and should not be modified
uint16_t		Message ID is a random number generated by CoAP module.
uint16_t		Source port.
ipIfUniqueId↔	ipIfId	IP interface id.
_t		
uint8_t	*	CoAP instance ID.
uint8_t		The length of the token.
bool_t	isDtlsSecured	A flag indicating if the message uses a secure connection (DTLS)
	~	or not.
bool_t	autoClose	Set this flag to FALSE if the coap session should not be automati-
		cally closed when receiving the ACK (on the requester) or sending
		the ACK (on the server)
bool_t	bIsSubscribed	On client side keeps record if the server successfully registered the
		client as observer and pass this parameter to application. On server
		side, application checks this parameter to see if the client asked
		for subscription and depending on the server availability responds
: 40	1 0 1	positive or not.
uint8_t	-	Value of the observe option. LSB 24 bits keep the sequence id
coapMessage←	msgType	CoAP message types are: CON, NON, ACK, RESET.
Types_t	4-	Demanding on the masses so true (Demande on Demande)
coapReqResp←	code	Depending on the message type (Request or Response)
Codes_t	lastHop! OI	I OI of lost han if the massage is multi han
uint8_t	lastHopLQI	LQI of last hop, if the message is multi hop.
uint8_t		Hop limt to use when sending a COAP packet.
uint8_t	ipQos	Ip packet Quality of service -> DSCP field.

8.2.7 struct coapStartSecParams_t

Parameters needed for creating a secured CoAP instance over DTLS.

Kinetis Thread Stack API Reference Manual

Data Fields

sockaddr⊷	pServerAddr	DTLS Server's IP address.
Storage_t		
*		
sockaddr↔	pLocalAddr	My local IP address.
Storage_t		
*		
uint32_t	retransmit←	Number of time units to retransmit a packet.
	TimeUnits	
uint8_t	max⇔	Number of message retransmissions.
	RetransmitCnt	

8.2.8 struct coapStartUnsecParams_t

Parameters needed for creating an unsecured CoAP instance over UDP.

Data Fields

uint16_t port	UDP port.
uint8_t addrFamily	address family (AF_INET and AF_INET6 supported)

struct coapRegCbParams_t 8.2.9

The callback, URI-path tuple for associating an incoming message with its callback function.

Data Fields

ſ	$coapCallback \leftarrow$	pCallback	pointer to the callback function
	_t		
	coapUriPath_t	pUriPathStruct	pointer to URI-path and its length
	*		

8.3 **Macro Definition Documentation**

8.3.1 #define COAP_ENABLED

Macro used to disable or enable Coap when compiling the Thread library.

8.3.2 #define COAP_MAX_URI_PATH_OPT_SIZE

The maximum length of URI-path options.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

8.3.3 #define COAP_MAX_OPTION_VALUE_SIZE

Maximum length of one option.

URI-path options are not limited by this value if they are added with COAP_SetUriPath() function

8.3.4 #define COAP_MAX_TOKEN_LEN

Maximum length of token as defined in RFC 7252.

8.3.5 #define COAP OBSERVE OPTION

CoAP Option Names.

8.3.6 #define COAP DEFAULT PORT

CoAP Ports.

8.3.7 #define COAP_INSTANCES_URI_PATH

Number of CoAP instances allowed for one URI-path.

8.3.8 #define COAP_SetMaxRetransmitCount(coapInstanceId, maxRetransmitCount)

Set number of retransmissions for a CON message.

8.3.9 #define COAP_MAX_CALLBACKS

< Maximum number of callbacks

Maximum number of callbacks registered for non-piggybacked responses

8.3.10 #define COAP_MAX_NON_PIGGYBACKED_RSP

Maximum number of active CoAP sessions at a give moment, per one CoAP instance.

Maximum number of CoAP instances

Kinetis Thread Stack API Reference Manual

8.3.11 #define COAP MAX MSG IDs

Used for keeping track of duplicate CoAP messages.

8.3.12 #define COAP MAX OPTIONS

Maximum number of options included in one CoAP message.

Here are not included URI-path options which MAY be added with COAP_SetUriPath() function

8.3.13 #define COAP TOKEN LENGTH

Token length used by default in CoAP messages.

8.4 **Typedef Documentation**

8.4.1 typedef void(* coapCallback t) (coapSessionStatus_t sessionStatus, void *pData, struct coapSession tag *pSession, uint32 t dataLen)

CoAP callback function prototype for receiving a CoAP message.

Enumeration Type Documentation 8.5

8.5.1 enum coapSessionStatus_t

Return status of a CoAP session.

Enumerator

```
gCoapSuccess_c CoAP transaction succeeded.
gCoapFailure c Retransmission timer expired and no reply was received.
gCoapDuplicate_c A message with same message ID was received in the latest gCoapMaxMsgIds
     messages.
```

8.5.2 enum coapMacSecFlags_t

Security at MAC layer for CoAP messages.

By default, all messages use gCoapMacSecMode1Level5_c

NXP Semiconductors

Kinetis Thread Stack API Reference Manual 141

8.5.3 enum coapMsgTypesAndCodes_t

This enum is meant to compress the most used message type and code combinations in one constant.

Enumerator

```
gCoapMsgTypeNonPost_c CON POST message.
gCoapMsgTypeNonPost_c NON POST message.
gCoapMsgTypeAckSuccessChanged_c ACK Success Changed message.
gCoapMsgTypeAckSuccessContent_c ACK Success Content message.
gCoapMsgTypeConGet_c CON GET message.
gCoapMsgTypeNonGet_c NON GET message.
gCoapMsgTypeEmptyAck_c ACK Empty message.
gCoapMsgTypeUseSessionValues_c Use the (msgType, code) values set in the session.
```

8.5.4 enum coapMessageTypes_t

CoAP message types.

8.5.5 enum coapReqRespCodes_t

CoAP Method and Response Codes.

8.6 Function Documentation

8.6.1 void COAP Init (taskMsgQueue t * pTaskMsgQueue)

This function initializes the CoAP module.

Parameters

in	pTaskMsg↔	Pointer to message task queue.
	Queue	

8.6.2 uint8_t COAP_CreateInstance (coapStartSecParams_t * pCoapStart← SecParams, coapStartUnsecParams_t * pCoapStartUnsecParams, ipIfUniqueId_t ipIfId, coapRegCbParams_t * pCallbacksStruct, uint32_t nbOfCallbacks)

This function opens a secure or unsecured Coap instance.

Parameters

in	pCoapStart⇔	Pointer to initialization structure for a secure transmission over DTLS.
	SecParams	
in	pCoapStart←	Pointer to initialization structure for an unsecured transmission over
	UnsecParams	sockets.
in	<i>ipIfUniqueId</i>	ip interface ID.
in	pCallbacks⇔	Pointer to callbacks registered for that instance.
	Struct	
in	nbOfCallbacks	Number of registered callbacks.

Returns

uint8_t CoAP instance id.

8.6.3 bool t COAP CloseInstance (uint8 t coapInstanceId)

This function closes a CoAP instance. Make sure that no other module uses the same instance.

Parameters

in	coapInstanceId	CoAP instance
----	----------------	---------------

Returns

bool_t TRUE - if the closing succeeded FALSE - otherwise

8.6.4 coapSession_t * COAP_OpenSession (uint8_t coapInstanceId)

This function opens a CoAP session for a specific instance. A session is identified by the message ID of the message.

Parameters

2	7 , 71	C-AD:
ın	coapInstanceId	CoAP instance Id.

Returns

coapSession_t* Pointer to CoAP session.

8.6.5 void COAP_CloseSession ($coapSession_t * pSession$)

This function deletes a CoAP session when completed. This function must be called when a response message was received (in the case of the client/initiator), or when a response message is sent (in the case of the server)

Kinetis Thread Stack API Reference Manual

Parameters

in	pSession	Pointer to CoAP session to be deleted.
----	----------	--

8.6.6 void COAP_AddOptionToList (coapSession_t * pSession, uint8_t optName, uint8_t * optValue, uint8_t optValueLen)

This function adds the options named by application to a list.

Parameters

in	pSession	Pointer to CoAP session.
in	optName	The name of the uri-path.
in	optValue	The value of the option.
in	optValueLen	The length of the option value.

8.6.7 void COAP_SetUriPath (coapSession_t * pSess, coapUriPath_t * pUriPath)

This function adds the URI-paths to the option list.

Parameters

in	pSession	Pointer to CoAP session.
in	pUriPath	Pointer to URI-path.

8.6.8 nwkStatus_t COAP_Send (coapSession_t * pSession, coapMsg TypesAndCodes_t coapMsgType, void * pData, uint32_t payloadLen)

This function builds and transmits a CoAP message. This function shall be used when sending one of the predefined messages. For a custom build message please use COAP_SendMsg() function.

Parameters

in	pSession	Pointer to CoAP session.
in	coapMsgType	CoAP message type. Is one from the list coapMsgTypesAndCodes_t.
in	pData	Pointer to data payload.
in	payloadLen	Payload length.

Returns

nwkStatus_t Status of the operation.

Kinetis Thread Stack API Reference Manual

8.6.9 nwkStatus_t COAP_SendMsg (coapSession_t * pSession, void * pData, uint32 t payloadLen)

This function builds and transmits a CoAP message.

Parameters

in	pSession	Pointer to CoAP session.
in	pData	Pointer to data payload.
in	payloadLen	Payload length.

Returns

nwkStatus_t Status of the operation.

8.6.10 nwkStatus_t COAP_RegisterResourceCallback (uint8_t coapInstanceId, coapRegCbParams_t * pCallbacksStruct, uint32_t nbOfCallbacks)

This function registers a callback for a given uri-path name.

Parameters

in	coapInstanceId	CoAP instance.
in	pCallbacks⇔	Pointer to callback functions array.
	Struct	
in	nbOfCallbacks	Number of callbacks.

Returns

nwkStatus_t - Success if registering succeeded

• Fail if table is full

8.6.11 void COAP_RegisterTokenCallback (coapSession_t * pSession, coapCallback_t pCallback_)

This function registers a callback for a given token, for non-piggybacked responses. The client calls this function when it expects another message with the same token.

Parameters

in	pSession	Pointer to CoAP session.
in	pCallback	Pointer to callback function.

8.6.12 bool_t COAP_UnregisterTokenCallback (coapSession_t * pSession, coapCallback_t pCallback_)

This function unregisters a callback for a given token.

Kinetis Thread Stack API Reference Manual

147

Parameters

in	pSession	Pointer to CoAP session.
in	pCallback	Pointer to callback function.

Returns

bool_t TRUE - if the unregister succeeded FALSE - otherwise

8.6.13 bool_t COAP_UnregisterResourceCallback (uint8_t coapInstanceId, coapRegCbParams_t * pCallbacksStruct, uint32_t nbOfCallbacks)

This function unregisters a callback for a given uri-path name.

Parameters

in	coapInstanceId	CoAP instance.
in	pCallback	Pointer to callback functions array.
in	nbOfCallbacks	Number of callbacks.

Returns

bool_t TRUE - if the unregister succeeded FALSE - otherwise

8.6.14 void COAP_CloseAnySession (void)

This function close any sessions for CoAP module.

Chapter 9 **Network IP Interface**

Overview 9.1

Files

• file ip_if_management.h

Data Structures

- struct ip4IfStruct_t
- struct ip6IfStruct_t
- struct mediaIfStruct_t
- struct ipIfStruct_t
- struct ip4IfAddrData_t
- struct ip6IfAddrData_t

Macros

• #define IP_IF_MAC_ADDR_NB

Typedefs

- typedef ipIfStruct_t * ifHandle_t
- typedef void(* ip6IfSelThreadMLSrcAddr6_t) (ipAddr_t *pDestAddr, ipAddr_t **pBestSource Addr)

Enumerations

```
• enum ip6AddrType_t {
  ip6AddrTypeManual_c,
 ip6AddrTypeAutoconfigurable_c,
 ip6AddrTypeAutoconfigurableMac2 c }
```

Functions

- void **IP_IF_Init** (void)
- uint32_t IP_IF_Add (ipIfUniqueId_t ifId, void *driverHandle, mediaIfStruct_t *pIfStruct, uint16_t ipVersEnabled)

- ifHandle_t IP_IF_GetIfHandle (ipIfUniqueId_t ifId)
 int32_t IP_IF_GetIfIndex (ipIfUniqueId_t ipIfId)
 bool_t IP_IF_IsMyAddr (ipIfUniqueId_t ipIfId, ipAddr_t *pIpAddr)
- void IP_IF_Join (ipIfUniqueId_t ipIfId, ipAddr_t *groupIp)
- void IP_IF_Leave (ipIfUniqueId_t ipIfId, ipAddr_t *groupIp)

Kinetis Thread Stack API Reference Manual

- ipIfUniqueId_t IP_IF_GetIfIdByIndex (uint32_t ifIndex)
- ifHandle_t IP_IF_GetIfByIndex (uint32_t ifIndex)
- ifHandle_t IP_IF_GetIfByAddr (ipAddr_t *pIpAddr)

Variables

- void(* ip4IfStruct_t::ip4Forward)(ipPktInfo_t *)
- uint32_t ip6IfStruct_t::scope_id
- void ** ip6IfStruct_t::ppNdCfg
- bool_t(* ip6IfStruct_t::ip6IsAddrOnLink)(ipAddr_t *pIpDestAddr, struct ipIfStruct_tag *instance → Id)
- bool_t(* ip6IfStruct_t::ip6ResolveUnicastAddr)(ipPktInfo_t *pIpDestAddr)
- void(* ip6IfStruct_t::ip6UpperMgtLayerCb)(ipPktInfo_t *pIpDestAddr)
- uint32_t(* ip6IfStruct_t::ip6McastForward)(ipPktInfo_t *, uint8_t, ipAddr_t *)
- ipAddr_t *(* ip6IfStruct_t::ip6UnicastForward)(ipPktInfo_t *, uint8_t)
- uint32_t(* mediaIfStruct_t::ifOpen)(struct ipIfStruct_tag *)
- uint32_t(* mediaIfStruct_t::ifClose)(struct ipIfStruct_tag *)
- uint32_t(* mediaIfStruct_t::ifSend4)(ipPktInfo_t *)
- uint32_t(* mediaIfStruct_t::ifSendArp)(ipPktInfo_t *, llAddr_t *)
- uint32_t(* mediaIfStruct_t::ifSend6)(ipPktInfo_t *)
- uint32_t(* mediaIfStruct_t::ifGetIID)(struct ipIfStruct_tag *, llAddr_t *, ipAddr_t *)
- uint32_t(* mediaIfStruct_t::ifJoin)(struct ipIfStruct_tag *, ipAddr_t *, uint16_t)
- uint32 t(* mediaIfStruct t::ifLeave)(struct ipIfStruct tag *, ipAddr t *, uint16 t)
- void * ipIfStruct_t::ifDriverHandle
- mediaIfStruct_t * ipIfStruct_t::ifFunctions
- uint16_t ipIfStruct_t::ifMtu
- uint8_t ipIfStruct_t::ipVersion4
- uint8_t ipIfStruct_t::ipVersion6
- llAddr_t ipIfStruct_t::ifDevAddrTbl [IP_IF_MAC_ADDR_NB]
- ipIfUniqueId t ipIfStruct t::ifUniqueId
- uint8_t ipIfStruct_t::ifMetric
- ipIfUniqueId_t ip4IfAddrData_t::ipIfId
- uint32_t ip4IfAddrData_t::ip4Addr
- uint32_t ip4IfAddrData_t::ip4SubnetMask
- uint32_t ip4IfAddrData_t::ip4DefaultGw
- ipAddr t ip6IfAddrData t::ip6Addr
- ipIfUniqueId_t ip6IfAddrData_t::ipIfId
- uint32_t ip6IfAddrData_t::creationTime
- uint32_t ip6IfAddrData_t::lifetime
- uint8_t ip6IfAddrData_t::ip6AddrTypeAndState
- uint8 t ip6IfAddrData t::dadTransmitCounter
- uint8_t ip6IfAddrData_t::prefixLength
- uint8_t ip6IfAddrData_t::macAddrIndex

9.2 Data Structure Documentation

9.2.1 struct ip4lfStruct_t

Information about an IPv4 interface.

Data Fields

• void(* ip4Forward)(ipPktInfo t *)

151

9.2.2 struct ip6lfStruct_t

Information about an IPv6 interface.

Data Fields

```
• uint32_t scope_id
```

- void ** ppNdCfg
- bool_t(* ip6IsAddrOnLink)(ipAddr_t *pIpDestAddr, struct ipIfStruct_tag *instanceId)
- bool_t(* ip6ResolveUnicastAddr)(ipPktInfo_t *pIpDestAddr)
- void(* ip6UpperMgtLayerCb)(ipPktInfo_t *pIpDestAddr)
- uint32_t(* ip6McastForward)(ipPktInfo_t *, uint8_t, ipAddr_t *)
- ipAddr_t *(* ip6UnicastForward)(ipPktInfo_t *, uint8_t)

9.2.3 struct medialfStruct_t

Information about a media interface.

Data Fields

```
uint32_t(* ifOpen )(struct ipIfStruct_tag *)
uint32_t(* ifClose )(struct ipIfStruct_tag *)
uint32_t(* ifSend4 )(ipPktInfo_t *)
uint32_t(* ifSendArp )(ipPktInfo_t *, llAddr_t *)
uint32_t(* ifSend6 )(ipPktInfo_t *)
uint32_t(* ifGetIID )(struct ipIfStruct_tag *, llAddr_t *, ipAddr_t *)
uint32_t(* ifJoin )(struct ipIfStruct_tag *, ipAddr_t *, uint16_t)
uint32_t(* ifLeave )(struct ipIfStruct_tag *, ipAddr_t *, uint16_t)
```

9.2.4 struct iplfStruct_t

Information about a network interface (IPv4 or IPv6)

Data Fields

void *	ifDriverHandle	Handle for media link layer module.
mediaIfStruct←	ifFunctions	Pointer to media interface functions.
_t		
*		

uint16_t	ifMtu	Interface maximum transmission unit.
uint8_t	ipVersion4	If ipVersion4 == 1->IPv4 is enabled on this interface.
uint8_t	ipVersion6	If ipVersion6 == 1->IPv6 is enabled on this interface.
llAddr_t	ifDevAddr⊷	Media link layer address.
	Tbl[IP_IF_M↔	
	AC_ADDR_←	
	NB]	
ipIfUniqueId←	ifUniqueId	Interface unique ID.
_t		
uint8_t	ifMetric	Interface metric.

9.2.5 struct ip4lfAddrData_t

Information about the addressing of an IPv4 interface.

Data Fields

ipIfUniqueId←	ipIfId	Interface ID of the interface this IP4 address is binded to.
_t		
uint32_t	ip4Addr	IPv4 address in host byte order.
uint32_t	ip4SubnetMask	IPv4 address subnet mask in host byte order.
uint32_t	ip4DefaultGw	IPv4 default gateway for the interface in host byte order.

9.2.6 struct ip6lfAddrData_t

Information about the addressing of an IPv6 interface.

Data Fields

ipAddr_t	ip6Addr	IPv6 address.
ipIfUniqueId←	ipIfId	Interface ID of the interface this IP6 address is binded to.
_t		
uint32_t	creationTime	Time of entry creation (in seconds)
uint32_t	lifetime	Address lifetime expire timestamp (in seconds). 0xFFFFFFF=
		Infinite Lifetime
uint8_t	ip6AddrType←	Address type (4 bits) and current state (4 bits).
	AndState	
uint8_t	dadTransmit←	Counter used by DAD. Equals to the number of NS transmits till
	Counter	DAD is finished

Kinetis Thread Stack API Reference Manual

NXP Semiconductors

uint8_t	prefixLength	The number of leading bits in the Prefix that are validNot used,
		maybe used for routing
uint8_t	macAddrIndex	Index in the interface MAC address table of the MAC address this
		IP6 address is assigned to.

9.3 Typedef Documentation

9.3.1 typedef ipIfStruct_t* ifHandle_t

Typedef for interface handler.

9.3.2 typedef void(* ip6lfSelThreadMLSrcAddr6_t) (ipAddr_t *pDestAddr, ipAddr_t *pBestSourceAddr)

Typedef needed by the Thread Stack to select the source address when the destination address is a ML16 or ML64.

9.4 Enumeration Type Documentation

9.4.1 enum ip6AddrType_t

IPv6 address types.

Enumerator

```
    ip6AddrTypeManual_c Manual Address.
    ip6AddrTypeAutoconfigurable_c Autoconfigurable address - default MAC address.
    ip6AddrTypeAutoconfigurableMac2_c Autoconfigurable address - second MAC address.
```

9.5 Function Documentation

9.5.1 void IP IF Init (void)

Init the global interface table.

9.5.2 uint32_t IP_IF_Add (ipIfUniqueId_t ifId, void * driverHandle, mediaIfStruct_t * plfStruct, uint16_t ipVersEnabled)

Adds a new interface to the global interface table.

Parameters

in	ifId	Interface unique ID
in	driverHandle	Pointer to the packet driver handle (can be NULL)
in	pIfStruct	Call table for the interface
in	ipVersEnabled	The IP version that wants to be enabled on this interface (gIpProtv4_c,
		gIpProtv6_c or gIpProtv4_c gIpProtv6_c)

Returns

uint32_t Result of the operation

9.5.3 ifHandle_t IP_IF_GetIfHandle (ipIfUniqueId_t ifId)

Returns pointer interface handle structure identified by unique ID.

Parameters

in	ifId	Interface unique ID

Returns

ifHandle_t interface handle

9.5.4 int32_t IP_IF_GetIfIndex ($ipIfUniqueId_t ipIfId$)

Returns the index (from zero) in the interface table of the provided interface.

Parameters

in	ipIfId	IP interface identifier
----	--------	-------------------------

Returns

int32_t Interface index or -1 in case of error

9.5.5 bool_t IP_IF_lsMyAddr ($ipIfUniqueId_t ipIfId$, $ipAddr_t * plpAddr$)

Checks if an unicast address is attached/bound to the interface.

Kinetis Thread Stack API Reference Manual

Parameters

in	ipIfId	IP interface identifier
in	pIpAddr	Pointer to IP address

Returns

bool_t TRUE if the address is attached/bound, FALSE otherwise

9.5.6 void IP IF Join (ipIfUniqueId_t ipIfId, ipAddr_t * groupIp)

Adds a multicast group into the physical interface.

Parameters

in	ipIfId	IP interface identifier
in	groupIp	Pointer to the IP multicast address to join

9.5.7 void IP_IF_Leave (ipIfUniqueId_t ipIfId, ipAddr_t * groupIp)

Removes a multicast group from the physical interface.

Parameters

in	ipIfId	IP interface identifier
in	groupIp	Pointer to the IP multicast group address to leave

9.5.8 ipIfUniqueId_t IP_IF_GetIfIdByIndex (uint32_t ifIndex)

Returns the interface unique ID according to its index (from zero).

Parameters

in	ifIndex	The interface Index
----	---------	---------------------

Returns

ipIfUniqueId_t Interface unique ID

9.5.9 ifHandle_t IP_IF_GetIfByIndex (uint32_t ifIndex)

Returns double pointer to if Number interface according to its index (from zero).

Kinetis Thread Stack API Reference Manual

Variable Documentation

Parameters

in	ifIndex	The interface Index
----	---------	---------------------

Returns

ifHandle_t It returns NULL if there is no interface with the ifNumber index

9.5.10 ifHandle_t IP IF GetIfByAddr (ipAddr_t * plpAddr)

This function returns double pointer to interface which has the provided address.

Parameters

in	pIpAddr	Pointer to the IP address
----	---------	---------------------------

Returns

ifHandle_t * It returns NULL if there is no interface with the address

9.6 Variable Documentation

9.6.1 uint32_t ip6lfStruct_t::scope_id

The scope ID of the interface, useful in link-local communication.

9.6.2 void** ip6lfStruct_t::ppNdCfg

ND configuration.

9.6.3 bool_t(* ip6lfStruct_t::ip6lsAddrOnLink) (ipAddr_t *plpDestAddr, struct iplfStruct_tag *instanceId)

Detects if pIpDestAddr is On-link.

9.6.4 bool_t(* ip6lfStruct_t::ip6ResolveUnicastAddr) (ipPktInfo_t *plpDestAddr)

Selects the unicast address needed to reach pIpDestAddr.

9.6.5 void(* ip6lfStruct_t::ip6UpperMgtLayerCb) (ipPktInfo_t *plpDestAddr)

Callback that allows management layer inspection on received packets.

Kinetis Thread Stack API Reference Manual

9.6.6 uint32_t(* ip6lfStruct_t::ip6McastForward) (ipPktInfo_t *, uint8_t, ipAddr_t *)

IPv6 multicast forwarding callback.

9.6.7 ipAddr_t*(* ip6lfStruct_t::ip6UnicastForward) (ipPktInfo_t *, uint8_t)

IPv6 unicast forwarding callback.

9.6.8 uint32_t(* medialfStruct_t::ifOpen) (struct iplfStruct_tag *)

Open interface function pointer.

9.6.9 uint32_t(* medialfStruct_t::ifClose) (struct iplfStruct_tag *)

Close interface function pointer.

9.6.10 uint32 t(* medialfStruct t::ifSend4) (ipPktInfo_t *)

Send IPv4 packet.

9.6.11 uint32 t(* medialfStruct t::ifSendArp) (ipPktInfo t*, llAddr t*)

Send IPv4 ARP packet.

9.6.12 uint32 t(* medialfStruct t::ifSend6) (ipPktInfo_t *)

Send IPv6 packet.

9.6.13 uint32_t(* medialfStruct_t::ifGetIID) (struct ipIfStruct_tag *, llAddr_t *, ipAddr_t *)

Get the interface identifier.

Variable Documentation

9.6.14 uint32_t(* medialfStruct_t::ifJoin) (struct iplfStruct_tag *, ipAddr_t *, uint16_t)

Join a group on the physical interface.

Leave a group on the physical interface.

9.6.16 void* iplfStruct t::ifDriverHandle

Handle for media link layer module.

9.6.17 mediaIfStruct_t* ipIfStruct_t::ifFunctions

Pointer to media interface functions.

9.6.18 uint16 t iplfStruct t::ifMtu

Interface maximum transmission unit.

9.6.19 uint8_t iplfStruct_t::ipVersion4

If ipVersion4 == 1->IPv4 is enabled on this interface.

9.6.20 uint8 t iplfStruct t::ipVersion6

If ipVersion6 == 1->IPv6 is enabled on this interface.

9.6.21 llAddr_t iplfStruct_t::ifDevAddrTbl[IP_IF_MAC_ADDR_NB]

Media link layer address.

9.6.22 ipIfUniqueId_t ipIfStruct_t::ifUniqueId

Interface unique ID.

9.6.23 uint8_t iplfStruct_t::ifMetric

Interface metric.

9.6.24 ipIfUniqueId_t ip4lfAddrData_t::iplfld

Interface ID of the interface this IP4 address is binded to.

9.6.25 uint32_t ip4lfAddrData_t::ip4Addr

IPv4 address in host byte order.

9.6.26 uint32_t ip4lfAddrData_t::ip4SubnetMask

IPv4 address subnet mask in host byte order.

9.6.27 uint32 t ip4lfAddrData t::ip4DefaultGw

IPv4 default gateway for the interface in host byte order.

9.6.28 ipAddr_t ip6lfAddrData_t::ip6Addr

IPv6 address.

9.6.29 ipIfUniqueId_t ip6lfAddrData_t::iplfld

Interface ID of the interface this IP6 address is binded to.

9.6.30 uint32_t ip6lfAddrData_t::creationTime

Time of entry creation (in seconds)

Kinetis Thread Stack API Reference Manual

Variable Documentation

9.6.31 uint32_t ip6lfAddrData_t::lifetime

Address lifetime expire timestamp (in seconds).

0xFFFFFFFF Infinite Lifetime

9.6.32 uint8_t ip6lfAddrData_t::ip6AddrTypeAndState

Address type (4 bits) and current state (4 bits).

9.6.33 uint8 t ip6lfAddrData t::dadTransmitCounter

Counter used by DAD.

Equals to the number of NS transmits till DAD is finished

9.6.34 uint8_t ip6lfAddrData_t::prefixLength

The number of leading bits in the Prefix that are valid.

-Not used, maybe used for routing

9.6.35 uint8 t ip6lfAddrData t::macAddrIndex

Index in the interface MAC address table of the MAC address this IP6 address is assigned to.

Chapter 10 **Thread Network Utilities Interface**

10.1 **Overview**

Files

file network utils.h

Data Structures

- union uuint16 t
- union uuint32_t
- union uuint64_t
- union ipAddr_t
- struct nwkBuffer_t
- struct llAddr_t
- struct ip6Header_t
- struct ipPktOptions_t
- struct recvOptions_t
- struct ipPktInfo_t
- union ipPktInfo_t.prot
- struct nwkMsg_t
- struct taskMsgQueue_t
- struct lut8_t
- struct nwkStats t
- struct ipPrefix_t
- struct pbkdf2Params_t

Macros

- #define THR_ALL_FFs64
- #define THR_ALL_FFs32#define THR_ALL_FFs16
- #define THR_ALL_FFs8
- #define INET_ADDRSTRLEN
- #define INET6_ADDRSTRLEN
- #define INET6_IID_LEN
- #define IP6_MINIMUM_MTU
- #define IP6_PSEUDO_HDR_SIZE
- #define IP4_PSEUDO_HDR_SIZE
- #define IP4_ADDR_ANY
- #define IP4_ADDR_LOOPBACK
- #define IP4_ADDR_ALLHOSTS_GROUP
- #define IP4_ADDR_ALLROUTERS_GROUP#define IP4_ADDR_RIP_GROUP
- #define IP4_ADDR_NTP_GROUP
- #define IP4_ADDR_IGMP_GROUP

Overview

- #define IP4 ADDR BROADCAST
- #define INADDR_ANY_INIT
- #define INADDR_BCAST_INIT
- #define IP4 ZERONET(a)
- #define IP4 LOOPBACK(a)
- #define IP4_MULTICAST(a)
- #define IP4_LOCAL_MULTICAST(a)
- #define IP4_EXPERIMENTAL(a)
- #define IP4_CLASS_A(a)
- #define IP4 CLASS A MASK
- #define IP4_CLASS_B(a)
- #define IP4 CLASS B MASK
- #define IP4 CLASS C(a)
- #define IP4_CLASS_C_MASK
- #define IN6ADDR ANY INIT
- #define IN6ADDR_LOOPBACK_INIT
- #define IN6ADDR_NODELOCAL_ALLNODES_INIT
- #define IN6ADDR_INTFACELOCAL_ALLNODES_INIT
- #define IN6ADDR_LINKLOCAL_ALLNODES_INIT
- #define IN6ADDR_LINKLOCAL_ALLROUTERS_INIT
- #define IN6ADDR_LINKLOCAL_ALLV2ROUTERS_INIT
- #define IN6ADDR_LINKLOCAL_ALL_DHCP_ROUTERS_AND_RELAY_AGENTS
- #define IN6ADDR_REALMLOCAL_ALL_DHCP_LEASEQUERY_SERVERS
- #define IN6ADDR REALMLOCAL MCAST 3EAD
- #define IN6ADDR_SITELOCAL_ALLDHCPSERVERS
- #define IN6ADDR_REALMLOCAL_ALLNODES_INIT
- #define IN6ADDR_REALMLOCAL_ALLROUTERS_INIT
- #define IN6ADDR_SITELOCAL_ALLNODES_INIT
- #define IN6ADDR_SITELOCAL_ALLROUTERS_INIT
- #define IN6ADDR LINK LOCAL PREFIX INIT
- #define IN6ADDR ALL FFs
- #define IP_AddrCopy(dst, src)
- #define IP4_AddrToUint32(addr)
- #define IP IsAddrEqual(addr1, addr2)
- #define IP6_IsUnspecifiedAddr(addr)
- #define IP6_IsLinkLocalAddr(addr)
- #define IP6 IsSiteLocalAddr(addr)
- #define IP6 IsUniqueLocalAddr(addr)
- #define IP6 IsGlobalAddr(addr)
- #define IP6 IsMulticastAddr(addr)
- #define IP6 IsAnycastAddr(addr)
- #define IP6 IsLoopbackAddr(addr)
- #define IP6_IsLocalMulticastAllNodes(addr)
- #define IP6 IsLocalMulticastAllRouters(addr)
- #define IP6 IsMeshMulticastAllNodes(addr)
- #define IP6_IsAddrEui64(addr)
- #define IP_ADDR(a1, a2, a3, a4, a5, a6, a7, a8, a9, a10, a11, a12, a13, a14, a15, a16)
- #define IPV4 Mask32 g
- #define IP IsAddrIPv4(addr)
- #define IP4_IsUnspecifiedAddr(addr)
- #define IP IsAddrIPv6(addr)
- #define NWKU_AppendNwkBuffer(dst, src)
- #define NWKU IsLlAddrValid(llAddr)
- #define NWKU_GetLastArrayIndex(arraySize)
- #define htona24(p, x)
- #define ntoha24(p)

163

```
• #define htona48(p, x)
• #define ntoha48(p)
• #define ntohs(val)
• #define htons(val)
• #define ntohl(val)
• #define htonl(val)
• #define ntohll(val)
• #define htonll(val)
• #define ntohas(p)
• #define htonas(p, x)
• #define ntohal(p)
• #define htonal(p, x)
• #define ntohall(p)
• #define htonall(p, x)

    #define AF UNSPEC

    #define AF INET

• #define AF_INET6

    #define DEFAULT_LLADDR_IDX

• #define MIN(a, b)

    #define NWKU_GENERIC_MSG_EVENT

• #define NWKU_MEM_BufferAlloc(a)
• #define NWKU_MEM_BufferAllocForever(a)
```

Typedefs

typedef void(* nwkMsgHandler) (void *)
 typedef void(* tspDataIndCb_t) (uint8_t tspConnIndex)

Enumerations

```
enum llAddrSize_t {
  gLlayerAddrNoAddr_c,
  gLlayerAddrReserved_c,
  gLlayerAddrEui16_c,
  gLlayerAddrEui48_c,
  gLlayerAddrEui64 c }
enum ipIfUniqueId_t {
  gIpIfSlp0_c,
  gIpIfSlp1_c,
  gIpIfEth0_c,
  gIpIfEth1_c,
  gIpIfWifi0_c,
  gIpIfWifi1_c,
  gIpIfUsbRndis_c,
  gIpIfSerialTun_c,
  gIpIfBle0_c,
  gIpIfBle1_c,
  gIpIfUndef c }
enum nwkStatus_t {
```

Overview

```
gNwkStatusSuccess c,
gNwkStatusMemAllocErr_c,
gNwkStatusNotAllowed_c,
gNwkStatusFail_c }
```

Functions

- bool_t NWKU_SendMsg (nwkMsgHandler pFunc, void *pPload, taskMsgQueue_t *msgQueue)
- void NWKU_RecvMsg (taskMsgQueue_t *pMsgQueue)
- bool_t NWKU_MsgHandler (taskMsgQueue_t *pMsgQueue)
- ipAddr_t * NWKU_CreateIpAddr (void)
- void NWKU_ConvertIp4Addr (uint32_t ip4Addr, ipAddr_t *pOutIpAddr)
- bool_t IP6_IsRealmLocalAddr (ipAddr_t *pIpAddr)
- ipPktInfo_t * NWKU_CreateIpPktInfo (void)
- void NWKU FreeIpPktInfo (ipPktInfo t **pIpPktInfo)
- nwkBuffer t * NWKU CreateNwkBuffer (uint32 t dataSize)
- void NWKU_FreeAllNwkBuffers (nwkBuffer_t **pNwkBufferStart)
- void NWKU_FreeNwkBufferElem (nwkBuffer_t **pNwkBufferStart, nwkBuffer_t *pElem)
- uint32 t NWKU NwkBufferTotalSize (nwkBuffer t *pNwkBufferStart)
- void NWKU_MemCopyFromNwkBuffer (nwkBuffer_t **pNwkBuffer, uint8_t **pSrcPtr, uint8_t *pDstPtr, uint32 t size)
- void NWKU_NwkBufferAddOffset (nwkBuffer_t **pNwkBuffer, uint8_t **pSrcPtr, uint32_t size)
- uint32 t NWKU NwkBufferNumber (nwkBuffer t *pNwkBufferStart)
- uint8_t * NWKU_NwkBufferToRegularBuffer (nwkBuffer_t *pNwkBufferStart, uint8_t *p← RegularBuffer)
- void NWKU CreatePseudoHeader4 (nwkBuffer t *pNwkBuff, ipAddr t *pSrcIp, ipAddr t *p← DstIp, uint32 t length, uint8 t nextHeader)
- void NWKU_CreatePseudoHeader6 (nwkBuffer_t *pNwkBuff, ipAddr_t *pSrcIp, ipAddr_t *p→ DstIp, uint32_t length, uint8_t nextHeader)
- uint16_t NWKU_CalculateChecksum (nwkBuffer_t *pStart)
- bool_t NWKU_CmpAddrPrefix6 (uint8_t *addr1, uint8_t *addr2, uint32_t prefixLen)
- bool_t NWKU_MemCmpToVal (uint8_t *pAddr, uint8_t val, uint32_t len)
- bool_t NWKU_BitCmp (uint8_t *pStr1, uint8_t *pStr2, uint8_t startBit, uint8_t stopBit)
- bool_t NWKU_IsLLAddrEqual (uint8_t *pFirstLlAddr, uint32_t firstLlAddrSize, uint8_t *p↔ SecondLlAddr, uint32 t secondLlAddrSize)
- uint32_t NWKU_GetCommonPrefixLen6 (ipAddr_t *addr1, ipAddr_t *addr2)
- uint64 t NWKU TransformArrayToValue (uint8 t*pArray, uint32 t nbOfBytes)
- void NWKU_TransformValueToArray (uint64_t value, uint8_t *pArray, uint32_t nbOfBytes)
- uint16_t NWKU_Revert16 (uint16_t value)
- uint32_t NWKU_Revert32 (uint32_t value)
- uint64 t NWKU Revert64 (uint64 t value)
- uint16_t NWKU_TransformArrayToUint16 (uint8_t *pArray)
 uint32_t NWKU_TransformArrayToUint32 (uint8_t *pArray)
 uint64_t NWKU_TransformArrayToUint64 (uint8_t *pArray)

- void NWKU_TransformUint16ToArray (uint8_t *pArray, uint16_t value)
- void NWKU TransformUint32ToArray (uint8 t *pArray, uint32 t value)
- void NWKU_TransformUint64ToArray (uint8_t *pArray, uint64_t value)
- bool_t NWKU_GetLut8 (lut8_t *pLutTable, uint8_t lutTableSize, uint8_t type, uint8_t *pEntry-
- int32_t NWKU_atoi (char *pStr)
- int64_t NWKU_atol (char *pStr)
- void NWKU PrintDec (uint64 t value, uint8 t *pString, uint32 t nbPrintDigits, bool t bLeading Zeros)

- int32 t pton (uint8 t af, char *pTxt, ipAddr t *pIpAddr) • char * ntop (uint8_t af, ipAddr_t *pIpAddr, char *pStr, uint32_t strLen) • bool_t ptoll (uint8_t *pIn, uint32_t len, llAddr_t *pLlAddr) • uint32_t NWKU_AsciiToHex (uint8_t *pString, uint32_t strLen) • uint32_t NWKU_AsciiToDec (uint8_t *pString, uint32_t strLen) • uint8_t NWKU_ByteToDec (uint8_t byte) • uint8_t NWKU_NibToAscii (int8_t nib, bool_t useUpperCase) void NWKU_HexToAscii (uint8_t *pInputBuff, uint32_t inputBuffLen, uint8_t *pOutputBuffer, uint32 t outputBuffLen, bool t useUpperCase) • uint32_t NWKU_TmrRtcGetElapsedTimeInSeconds (uint32_t timestamp) • bool_t NWKU_IsNUmber (char *pString) • uint32 t NWKU GetRandomNoFromInterval (uint32 t startInterval, uint32 t endInterval) void NWKU_IncrementIp6Addr (ipAddr_t *pIpAddr) • uint32_t NWKU_RightRotate (uint32_t val, uint8_t amount) void NWKU_GetIIDFromLLADDR (llAddr_t *llAddr, uint16_t panId, uint8_t *pIID) • void NWKU_GetLLAddrFromIID (uint8_t *pIID, llAddr_t *pLlAddr) bool_t NWKU_IsIPAddrBasedOnShort (ipAddr_t *pIpAddr) • bool_t NWKU_GetBit (uint32_t bitNr, uint8_t *pArray) • void NWKU_SetBit (uint32_t bitNr, uint8_t *pArray) • void NWKU ClearBit (uint32 t bitNr, uint8 t *pArray) uint32 t NWKU GetFirstBitValueInRange (uint8 t *pArray, uint32 t lowBitNr, uint32 t highBit← Nr, bool t bitValue) uint32_t NWKU_GetFirstBitValue (uint8_t *pArray, uint32_t arrayBytes, bool_t bitValue)
 uint32_t NWKU_GetNumOfBits (uint8_t *pArray, uint32_t arrayBytes, bool_t bitValue) • uint32_t NWKU_ReverseBits (uint32_t num) • uint32 t NWKU AddTblEntry (uint32 t entry, uint32 t *pTable, uint32 t tableSize) • uint32_t NWKU_GetTblEntry (uint32_t index, uint32_t *pTable, uint32_t tableSize) • void NWKU_SwapArrayBytes (uint8_t *pByte, uint8_t numOfBytes) • void NWKU_GenRand (uint8_t *pRand, uint8_t randLen) • uint32_t NWKU_GetTlvLen (uint8_t type, uint8_t *pStart, uint32_t len) • uint8_t * NWKU_GetTlvValue (uint8_t type, uint8_t *pStart, uint32_t len, uint8_t *pOut) uint8_t * NWKU_GetTlv (uint8_t type, uint8_t *pStart, uint32_t len, uint8_t *pOut, uint32_t *p←
- bool t NWKU Pbkdf2 (pbkdf2Params t *pInput, uint8 t *pOut, uint32 t outLen)

• uint64 t NWKU GetTimestampMs (void)

int8_t NWKU_isArrayGreater (const uint8_t *a, const uint8_t *b, uint8_t length)

Variables

OutLen)

- uint16 t uuint16 t::u16
- uint8_t uuint16_t::u8 [2]
- uint32_t uuint32_t::u32
- uint16_t uuint32_t::u16 [2]
- uint8_t uuint32_t::u8 [4]
- uint64 t uuint64 t::u64
- uint32_t uuint64_t::u32 [2]
- uint16_t uuint64_t::u16 [4]
- uint8_t uuint64_t::u8 [8]
- uint8_t ipAddr_t::addr8 [16]
- uint16_t ipAddr_t::addr16 [8]
- uint32 t ipAddr t::addr32 [4]
- uint64_t ipAddr_t::addr64 [2]
- struct nwkBuffer_tag * nwkBuffer_t::next
- uint8_t * nwkBuffer_t::pData
- uint32 t nwkBuffer t::size

Kinetis Thread Stack API Reference Manual

Overview

```
• uint8 t nwkBuffer t::freeBuffer
• uint8_t llAddr_t::eui [8]
• llAddrSize_t llAddr_t::addrSize
• uint8_t ip6Header_t::versionTraficClass

    uint8_t ip6Header_t::trafficClassFlowLabel

• uint8_t ip6Header_t::flowLabel [2]

    uint8_t ip6Header_t::payloadLength [2]

• uint8_t ip6Header_t::nextHeader

    uint8_t ip6Header_t::hopLimit

• uint8_t ip6Header_t::srcAddr [16]
• uint8_t ip6Header_t::dstAddr [16]

    void * ipPktOptions t::ifHandle

    nwkBuffer_t * ipPktOptions_t::ipExtensionHeaderBuffer

    void * ipPktOptions_t::ipReassemblyOptions

• llAddr t ipPktOptions t::srcLlInfo

    uint8_t ipPktOptions_t::ipHdrOffset

    uint8_t ipPktOptions_t::hopLimit

    uint8_t ipPktOptions_t::security

uint8_t ipPktOptions_t::lqi
uint8_t ipPktOptions_t::qos
• uint8_t ipPktOptions_t::isRelay

    uint8_t ipPktOptions_t::macSecKeyIdMode

    uint8_t ipPktOptions_t::channel

    uint16 t ipPktOptions t::destPanId

    uint16_t ipPktOptions_t::srcPanId

• ipIfUniqueId t recvOptions t::ipIfId

    uint8 t recvOptions t::hopLimit

uint8_t recvOptions_t::security
uint8_t recvOptions_t::lqi

    uint8_t recvOptions_t::isRelay

uint8_t recvOptions_t::channel

    uint8_t recvOptions_t::macSecKeyIdMode

    uint16_t recvOptions_t::macSrcPanId

nwkBuffer_t * ipPktInfo_t::pNwkBuff

    ipAddr_t * ipPktInfo_t::pIpSrcAddr

    ipAddr_t * ipPktInfo_t::pIpDstAddr

uint8_t * ipPktInfo_t::pNextProt
• ipAddr_t ipPktInfo_t::ipSrcAddr

    ipAddr_t ipPktInfo_t::ipDstAddr

    uint32_t ipPktInfo_t::nextProtLen

    uint32_t ipPktInfo_t::protocolType

 union {
  uint32_t nextProtLen
  uint32_t protocolType
  } ipPktInfo_t::prot
• uint16_t ipPktInfo_t::srcPort
• uint16 t ipPktInfo t::dstPort
• ipPktOptions t ipPktInfo t::ipPktOptions

    nwkMsgHandler nwkMsg_t::pFunc

void * nwkMsg_t::pPload

    msgQueue_t taskMsgQueue_t::msgQueue

    osaTaskId_t taskMsgQueue_t::taskId

    osaEventId_t taskMsgQueue_t::taskEventId
```

• uint8_t lut8_t::type

Kinetis Thread Stack API Reference Manual

- uint8_t lut8_t::idx
- uint8_t nwkStats_t::ipktUsed
- uint8_t nwkStats_t::ipktMax
- uint8 t nwkStats t::nwkBuffUsed
- uint8 t nwkStats t::nwkBuffMax
- uint8_t ipPrefix_t::prefixLen
- uint8_t ipPrefix_t::aPrefix []
- uint8_t * pbkdf2Params_t::pPass
- uint32_t pbkdf2Params_t::passLen
- uint8_t * pbkdf2Params_t::pSalt
- uint32_t pbkdf2Params_t::saltLen
- uint32 t pbkdf2Params t::rounds
- const ipAddr t inaddr any
- const ipAddr_t inaddr_bcast
- const ipAddr_t in6addr_any
- const ipAddr_t in6addr_loopback
- const ipAddr_t in6addr_nodelocal_allnodes
- const ipAddr_t in6addr_linklocal_allnodes
- const ipAddr_t in6addr_linklocal_allrouters
- const ipAddr_t in6addr_linklocal_allv2routers
- const ipAddr_t in6addr_sitelocal_alldhcpservers
- const ipAddr_t in6addr_realmlocal_allnodes
- const ipAddr_t in6addr_realmlocal_allrouters
- const ipAddr_t in6addr_realmlocal_allleasequeryservers
- const ipAddr_t in6addr_realmlocal_mcast_3ead
- const ipAddr_t in6addr_sitelocal_allnodes
- const ipAddr t in6addr sitelocal allrouters
- const ipAddr_t in6addr_link_local_prefix
- ipAddr_t in6addr_linklocal_allthreadnodes
- ipAddr t in6addr realmlocal allthreadnodes
- ipAddr t in6addr realmlocal threadleaderanycast
- const uint8_t gNwkPoolId

10.2 Data Structure Documentation

10.2.1 union uuint16 t

Generic structure for holding uint16 values.

Data Fields

uint16_t	u16	16bit variable
uint8_t	u8[2]	8bit array

10.2.2 union uuint32_t

Generic structure for holding uint32 values.

Data Fields

uint32_t	u32	32bit variable
uint16_t	u16[2]	16bit array
uint8_t	u8[4]	8bit array

10.2.3 union uuint64_t

Generic structure for holding uint64 values.

Data Fields

uint64_t	u64	64bit variable
uint32_t	u32[2]	32bit array
uint16_t	u16[4]	16bit array
uint8_t	u8[8]	8bit array

10.2.4 union ipAddr_t

Generic structure for holding IP address information.

Data Fields

uint8_t	addr8[16]	8bit array
uint16_t	addr16[8]	16bit array
uint32_t	addr32[4]	32bit array
uint64_t	addr64[2]	64bit array

10.2.5 struct nwkBuffer_t

Generic structure for holding buffer information.

Data Fields

struct	next	Pointer to next buffer.
nwkBuffer_tag		
*		
uint8_t *	pData	Pointer to data.
uint32_t	size	Size of data.
uint8_t	freeBuffer	Flag used to notify buffer clearance.

10.2.6 struct IIAddr_t

Generic structure for link layer address.

Kinetis Thread Stack API Reference Manual

Data Fields

uint8_t	eui[8]	Destination address: short/extended.
llAddrSize_t	addrSize	Destination address type: short/extended.

10.2.7 struct ip6Header_t

Generic structure for IPv6 header.

Data Fields

uint8_t	versionTrafic←	Version Traffic Class.
	Class	
uint8_t	trafficClass←	Traffic Class Flow label.
	FlowLabel	
uint8_t	flowLabel[2]	Flow label.
uint8_t	payload←	Payload length.
	Length[2]	
uint8_t	nextHeader	Next header.
uint8_t	hopLimit	Hop limit.
uint8_t	srcAddr[16]	Source Address.
uint8_t	dstAddr[16]	Destination Address.

10.2.8 struct ipPktOptions_t

Generic structure for IP packet options.

Data Fields

void *	ifHandle	Pointer to interface handler.
nwkBuffer_t *	ipExtension←	Pointer to extended options buffer.
	HeaderBuffer	
void *	ip⇔	Pointer to IP reassembly structure.
	Reassembly←	
	Options	
llAddr_t	srcLlInfo	Source Link Layer information.
uint8_t	ipHdrOffset	Offset from beginning of RX data where IP HDR is found.
uint8_t	hopLimit	Hop limit.
uint8_t	security	Security option.
uint8_t	lqi	Packet LQI.

171

	uint8_t	qos	Packet Quality of Service.
ſ	uint8_t	isRelay	Flag to specify if packet is relay.
	uint8_t	macSecKeyId←	MacSec Key ID Mode.
		Mode	
	uint8_t	channel	Packet Channel.
	uint16_t	destPanId	Destination PAN ID.
ſ	uint16_t	srcPanId	Source PAN ID.

10.2.9 struct recvOptions_t

Received packet options structure.

Data Fields

ipIfUniqueId↔	ipIfId	ID of the interface.
_t		
uint8_t	hopLimit	Hop limit.
uint8_t	security	Security option.
uint8_t	lqi	Packet LQI.
uint8_t	isRelay	Flag to specify if packet is relay.
uint8_t	channel	Packet Channel.
uint8_t	macSecKeyId←	MacSec Key ID Mode.
	Mode	
uint16_t	macSrcPanId	MAC Source PAN ID.

10.2.10 struct ipPktInfo_t

Data Fields

nwkBuffer_t *	pNwkBuff	Pointer to network buffer.
ipAddr_t *	pIpSrcAddr	Pointer to source IP address.
ipAddr_t *	pIpDstAddr	Pointer to destination IP address.
uint8_t *	pNextProt	Pointer to the next protocol in pNwkBuff->pData. Do not free this
		one!
ipAddr_t	ipSrcAddr	Source IP address.
ipAddr_t	ipDstAddr	Destination IP address.
union	prot	Protocol information.
ipPktInfo_t		

	uint16_t	srcPort	Source port.
	uint16_t	dstPort	Destination port.
Ī	ipPktOptions←	ipPktOptions	IP packet options.
	_t		

10.2.11 union ipPktInfo_t.prot

Protocol information.

Data Fields

uint32_t nextProtLen	Size of the data of next protocol in pNwkBuff->pData.
uint32_t protocolType	Protocol type.

10.2.12 struct nwkMsg_t

Generic structure for network message.

Data Fields

nwkMsg←	pFunc	Pointer to packet handler.
Handler		
void *	pPload	Pointer to handler payload.

10.2.13 struct taskMsgQueue_t

Task Message Queue structure.

Data Fields

msgQueue_t	msgQueue	Pointer to task message queue.
osaTaskId_t	taskId	Pointer to task ID.
osaEventId_t	taskEventId	Pointer to task event ID.

10.2.14 struct lut8_t

Lookup tables with 8 bits elements.

Data Fields

Macro Definition Documentation

uint8_t	type	Type.
uint8_t	idx	Index.

10.2.15 struct nwkStats_t

Network statistics, for debug.

Data Fields

uint8_t	ipktUsed	IP packets used.
uint8_t	ipktMax	Maximum IP packets.
uint8_t	nwkBuffUsed	Network buffers used.
uint8_t	nwkBuffMax	Maximum network buffers.

10.2.16 struct ipPrefix_t

Structure for holding IP prefix information.

Data Fields

uint8_t 1	prefixLen	Size of the prefix in bits.
uint8_t a	aPrefix[]	Pointer to the start of the prefix.

10.2.17 struct pbkdf2Params_t

Structure used for pbkdf2 generation.

Data Fields

uint8_t *	pPass	Pointer to the password.
uint32_t	passLen	Length of the password.
uint8_t *	pSalt	Pointer to the salt.
uint32_t	saltLen	Length of the salt.
uint32_t	rounds	Number of rounds.

10.3 Macro Definition Documentation

10.3.1 #define THR_ALL_FFs64

Max unsigned 64bit integers value.

NXP Semiconductors 173

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

10.3.2 #define THR ALL FFs32

Max unsigned 32bit integers value.

10.3.3 #define THR ALL FFs16

Max unsigned 16bit integers value.

10.3.4 #define THR_ALL_FFs8

Max unsigned 8bit integers value.

10.3.5 #define INET_ADDRSTRLEN

Length for IP address string size (used to compute size used in ntop). Value for 16 bytes strings

10.3.6 #define INET6_ADDRSTRLEN

Length for IP address string size (used to compute size used in ntop). Value for 46 bytes strings

10.3.7 #define INET6_IID_LEN

Length for IP address string size (used to compute size used in ntop). Value for IID strings

10.3.8 #define IP6 MINIMUM MTU

Minimum MTU value.

10.3.9 #define IP6_PSEUDO_HDR_SIZE

IPv6 Pseudo HDR size.

10.3.10 #define IP4_PSEUDO_HDR_SIZE

IPv4 Pseudo HDR size.

10.3.11 #define IP4 ADDR ANY

IPv4 any address.

10.3.12 #define IP4_ADDR_LOOPBACK

IPv4 loopback address.

10.3.13 #define IP4_ADDR_ALLHOSTS_GROUP

IPv4 all host group address.

10.3.14 #define IP4_ADDR_ALLROUTERS_GROUP

IPv4 all routers group address.

10.3.15 #define IP4 ADDR RIP GROUP

IPv4 RIP group address.

10.3.16 #define IP4_ADDR_NTP_GROUP

IPv4 NTP group address.

10.3.17 #define IP4 ADDR IGMP GROUP

IPv4 IGMP group address.

10.3.18 #define IP4 ADDR BROADCAST

IPv4 all routers group address.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

10.3.19 #define INADDR_ANY_INIT

IPv4 any address mapped to IPv6.

10.3.20 #define INADDR_BCAST_INIT

IPv4 broadcast address mapped to IPv6.

10.3.21 #define IP4_ZERONET(*a*)

Macro to classify IPv4 address to any.

10.3.22 #define IP4_LOOPBACK(a)

Macro to classify IPv4 address to loopback.

10.3.23 #define IP4 MULTICAST(a)

Macro to classify IPv4 address to multicast.

10.3.24 #define IP4 LOCAL MULTICAST(a)

Macro to classify IPv4 address to local multicast.

10.3.25 #define IP4_EXPERIMENTAL(a)

Macro to classify IPv4 address to experimental.

10.3.26 #define IP4 CLASS A(a)

Macro to classify IPv4 address to class A.

10.3.27 #define IP4_CLASS_A_MASK

IPv4 Class A mask.

10.3.28 #define IP4_CLASS_B(a)

Macro to classify IPv4 address to class B.

10.3.29 #define IP4_CLASS_B_MASK

IPv4 Class B mask.

10.3.30 #define IP4_CLASS_C(a)

Macro to classify IPv4 address to class C.

10.3.31 #define IP4_CLASS_C_MASK

IPv4 Class C mask.

10.3.32 #define IN6ADDR ANY INIT

IPV6 any address.

10.3.33 #define IN6ADDR LOOPBACK INIT

IPV6 loopback address.

10.3.34 #define IN6ADDR_NODELOCAL_ALLNODES_INIT

IPV6 node local all nodes address.

10.3.35 #define IN6ADDR INTFACELOCAL ALLNODES INIT

IPV6 interface local all nodes address.

10.3.36 #define IN6ADDR_LINKLOCAL_ALLNODES_INIT

IPV6 link local all nodes address.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

10.3.37 #define IN6ADDR_LINKLOCAL_ALLROUTERS_INIT

IPV6 link local all routers address.

10.3.38 #define IN6ADDR_LINKLOCAL_ALLV2ROUTERS_INIT

IPV6 link local all v2 routers address.

10.3.39 #define IN6ADDR_LINKLOCAL_ALL_DHCP_ROUTERS_AND_RELAY_AG⊷ ENTS

IPV6 link local all DHCP routers and relay agents address.

10.3.40 #define IN6ADDR REALMLOCAL ALL DHCP LEASEQUERY SERVERS

IPV6 realm local all DHCP lease query servers address.

10.3.41 #define IN6ADDR REALMLOCAL MCAST 3EAD

IPV6 realm local multicast 3ead address.

10.3.42 #define IN6ADDR_SITELOCAL_ALLDHCPSERVERS

IPV6 site local all DHCP servers address.

10.3.43 #define IN6ADDR REALMLOCAL ALLNODES INIT

IPV6 realm local all nodes address.

10.3.44 #define IN6ADDR REALMLOCAL ALLROUTERS INIT

IPV6 realm local all routers address.

10.3.45 #define IN6ADDR SITELOCAL ALLNODES INIT

IPV6 site local all nodes address.

Kinetis Thread Stack API Reference Manual

10.3.46 #define IN6ADDR_SITELOCAL_ALLROUTERS_INIT

IPV6 site local all routers address.

10.3.47 #define IN6ADDR_LINK_LOCAL_PREFIX_INIT

IPV6 link local prefix address.

10.3.48 #define IN6ADDR_ALL_FFs

IPV6 all FFs address.

10.3.49 #define IP_AddrCopy(dst, src)

Macro for IP address copy.

10.3.50 #define IP4_AddrToUint32(addr)

Macro for IP address conversion to uint32 t.

10.3.51 #define IP IsAddrEqual(addr1, addr2)

Macro for IPV6 address comparison.

10.3.52 #define IP6_IsUnspecifiedAddr(addr)

Macro for unspecified IPV6 address inquiry.

10.3.53 #define IP6_IsLinkLocalAddr(addr)

Macro for link local IPV6 address inquiry.

10.3.54 #define IP6_IsSiteLocalAddr(addr)

Macro for site local IPV6 address inquiry.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

10.3.55 #define IP6_IsUniqueLocalAddr(addr)

Macro for unique local IPV6 address inquiry.

10.3.56 #define IP6_IsGlobalAddr(addr)

Macro for global IPV6 address inquiry.

10.3.57 #define IP6_IsMulticastAddr(addr)

Macro for multicast IPV6 address inquiry.

10.3.58 #define IP6_IsAnycastAddr(addr)

Macro for anycast IPV6 address inquiry.

10.3.59 #define IP6_IsLoopbackAddr(addr)

Macro for loopback IPV6 address inquiry.

10.3.60 #define IP6 IsLocalMulticastAllNodes(addr)

Macro for local multicast all nodes IPV6 address inquiry.

10.3.61 #define IP6_IsLocalMulticastAllRouters(addr)

Macro for local multicast all routers IPV6 address inquiry.

10.3.62 #define IP6_IsMeshMulticastAllNodes(addr)

Macro for mesh multicast all nodes IPV6 address inquiry.

10.3.63 #define IP6 IsAddrEui64(addr)

Macro for EUI64 IPV6 address inquiry.

10.3.64 #define IP_ADDR(*a1*, *a2*, *a3*, *a4*, *a5*, *a6*, *a7*, *a8*, *a9*, *a10*, *a11*, *a12*, *a13*, *a14*, *a15*, *a16*)

Macro for values to IP address array transformation.

10.3.65 #define IPV4 Mask32 g

Mask for IPV4 address identification(RFC4291: 2.5.5.2)

10.3.66 #define IP_lsAddrlPv4(addr)

Macro for IPV4 in IPv6 address inquiry.

10.3.67 #define IP4 IsUnspecifiedAddr(addr)

Macro for IPV4 unspecified address inquiry.

10.3.68 #define IP IsAddrlPv6(addr)

Macro for IPV6 address inquiry.

10.3.69 #define NWKU_AppendNwkBuffer(dst, src)

Macro for appending network buffer.

10.3.70 #define NWKU IsLIAddrValid(IIAddr)

Macro for link layer address validity inquiry.

10.3.71 #define NWKU_GetLastArrayIndex(arraySize)

Macro for retrieving the last index of an array.

10.3.72 #define https://define.com/define.com/p, x)

Macro for host variable to 24 bit network array conversion.

Kinetis Thread Stack API Reference Manual

Macro Definition Documentation

10.3.73 #define ntoha24(p)

Macro for 24 bit network array to host variable conversion.

10.3.74 #define htona48(p, x)

Macro for host variable to 48 bit network array conversion.

10.3.75 #define ntoha48(*p*)

Macro for 48 bit network array to host variable conversion.

10.3.76 #define ntohs(*val*)

Macro for network to host short conversion.

10.3.77 #define htons(*val*)

Macro for host short to network conversion.

10.3.78 #define ntohl(*val*)

Macro for network to host 32bit conversion.

10.3.79 #define htonl(*val*)

Macro for host 32bit to network conversion.

10.3.80 #define ntohll(val)

Macro for network to host 64bit conversion.

10.3.81 #define htonll(val)

Macro for host 64bit to network conversion.

10.3.82 #define ntohas(p)

Macro for network array to host short conversion.

10.3.83 #define httnas(p, x)

Macro for host short to network array conversion.

10.3.84 #define ntohal(p)

Macro for network array to host 32bit conversion.

10.3.85 #define httonal(p, x)

Macro for host 32bit to network array conversion.

10.3.86 #define ntohall(p)

Macro for network array to host 64bit conversion.

10.3.87 #define httnall(p, x)

Macro for host 64bit to network array conversion.

10.3.88 #define AF_UNSPEC

Unspecified sockets.

10.3.89 #define AF INET

Internet IP Protocol.

10.3.90 #define AF INET6

IP version 6.

Kinetis Thread Stack API Reference Manual

Typedef Documentation

10.3.91 #define DEFAULT_LLADDR_IDX

Default index for link layer address.

10.3.92 #define MIN(a, b)

Macro for obtaining the minimum value variable between two input variables.

10.3.93 #define NWKU_GENERIC_MSG_EVENT

Generic Message Event.

10.3.94 #define NWKU_MEM_BufferAlloc(a)

Macro for memory buffer allocation.

Parameters

in	а	Size of requested memory buffer
----	---	---------------------------------

10.3.95 #define NWKU_MEM_BufferAllocForever(a)

Macro for memory buffer allocation.

The allocated memory buffer will never be freed

Parameters

i	n	а	Size of requested memory buffer

10.4 Typedef Documentation

10.4.1 typedef void(* nwkMsgHandler) (void *)

Callback function for servicing network messages.

10.4.2 typedef void(* tspDataIndCb_t) (uint8_t tspConnIndex)

Callback function for servicing transport packets.

Parameters

in	tspConnIndex	Connection index
----	--------------	------------------

10.5 Enumeration Type Documentation

10.5.1 enum llAddrSize_t

Enumeration for address size.

Enumerator

```
    gLlayerAddrNoAddr_c No address (addressing fields omitted)
    gLlayerAddrReserved_c Reserved value.
    gLlayerAddrEui16_c 16-bit short Link Layer address (size 2 bytes)
    gLlayerAddrEui48_c 48-bit Ethernet MAC Address (size 6 bytes)
    gLlayerAddrEui64_c 64-bit extended Link Layer address (size 8 bytes)
```

10.5.2 enum ipIfUniqueId_t

Unique interface ID enumeration.

Enumerator

```
gIpIfSlp1_c SLWP0 interface.
gIpIfSlp1_c SLWP1 interface.
gIpIfEth0_c ETH0 interface.
gIpIfEth1_c ETH1 interface.
gIpIfWifi0_c WiFi0 interface.
gIpIfWifi1_c WiFi1 interface.
gIpIfUsbRndis_c RNDIS interface.
gIpIfSerialTun_c Serial TUN interface.
gIpIfBle0_c BLE0 interface.
gIpIfBle1_c BLE1 interface.
gIpIfUndef_c Undefined interface.
```

10.5.3 enum nwkStatus_t

Network generic status enumeration.

Enumerator

```
gNwkStatusSuccess_c Network Status: Success.
```

Kinetis Thread Stack API Reference Manual

Function Documentation

gNwkStatusMemAllocErr_c Network Status: Memory allocation error.
 gNwkStatusNotAllowed_c Operation was not allowed.
 gNwkStatusFail_c Network Status: Fail.

10.6 Function Documentation

10.6.1 bool_t NWKU_SendMsg (nwkMsgHandler *pFunc*, void * *pPload*, taskMsgQueue_t * *msgQueue*)

Network Utils module function used to send a message between two tasks.

Parameters

in	pFunc	Pointer to message handler function
in	pPload	Pointer to message data
in	msgQueue	Pointer to structure holding message queue and task id to send message

Returns

TRUE If the message was sent successfully FALSE If not

10.6.2 void NWKU_RecvMsg (taskMsgQueue_t * msgQueue)

Network Utils module function used to receive and handle a message in a task.

Parameters

in	pMsgQueue	Pointer to structure holding message queue and task id to receive mes-]
		sage	

10.6.3 bool_t NWKU_MsgHandler (taskMsgQueue_t * pMsgQueue)

Network Utils module function used to dequeue and handle a task message.

Parameters

in	pMsgQueue	Pointer to structure holding message queue and task id to receive mes-
		sage

Returns

TRUE If there was a message in the queue FALSE Otherwise

Kinetis Thread Stack API Reference Manual

10.6.4 ipAddr_t * NWKU CreatelpAddr (void)

Network Utils module function used to create an ipAddr t structure.

Returns

Pointer to the allocated ipAddr_t structure NULL if memory cannot be allocated

10.6.5 void NWKU_Convertlp4Addr (uint32_t ip4Addr, ipAddr_t * pOutlpAddr)

Network Utils module function used to convert an IPv4 address in uint32_t format to an ipAddr_t type address.

Parameters

in	ip4Addr	IPv4 address
out	pOutIpAddr	Pointer to ipAddr_t to store the converted address

10.6.6 bool t IP6 IsRealmLocalAddr (ipAddr_t * plpAddr)

Network Utils module function used determine if an IPv6 address has realm local scope - valid only in the context of a THREAD stack.

Parameters

in	pIpAddr	IPv6 address
----	---------	--------------

Returns

TRUE If address is realm local FALSE If not or if not supported

10.6.7 ipPktInfo_t * NWKU CreatelpPktInfo (void)

Network Utils module function used to create an ipPktInfo_t structure.

Returns

Pointer to the allocated ipPktInfo_t structure NULL if memory cannot be allocated

Kinetis Thread Stack API Reference Manual NXP Semiconductors 187

Function Documentation

10.6.8 void NWKU_FreelpPktInfo (ipPktInfo_t ** plpPktInfo)

Network Utils module function used to free one ipPktInfo_t structure.

Parameters

in	pIpPktInfo	Double pointer to the ipPktInfo_t structure
----	------------	---

10.6.9 nwkBuffer_t * NWKU CreateNwkBuffer (uint32 t dataSize)

Network Utils module function used to create a nwkBuffer_t structure and allocate memory for data.

Parameters

in	dataSize	Size of the data available in the buffer
----	----------	--

Returns

Pointer to the allocated nwkBuffer_t structure NULL if memory cannot be allocated

10.6.10 void NWKU FreeAllNwkBuffers (nwkBuffer_t ** pNwkBufferStart)

Network Utils module function used to free all nwkBuffer_t structures(starting with pNwkBufferStart) and change the start of the list to NULL.

Parameters

in	pNwkBuffer⇔	Double pointer to the start of data buffer
	Start	

10.6.11 void NWKU FreeNwkBufferElem (nwkBuffer t ** pNwkBufferStart, nwkBuffer_t * *pElem*)

Network Utils module function used to free one nwkBuffer_t element.

Parameters

in	pNwkBuffer⇔	Double pointer to the start of data buffer
	Start	
in	pElem	Pointer to the element to be freed

10.6.12 uint32 t NWKU NwkBufferTotalSize (nwkBuffer_t * pNwkBufferStart)

Network Utils module function used to calculate the total size of a nwkBuffer_t list, starting with pNwk-BufferStart.

Kinetis Thread Stack API Reference Manual NXP Semiconductors 189

Function Documentation

Parameters

in	pNwkBuffer⇔	Pointer to the start of nwkBuffer
	Start	

Returns

Size of the whole list

10.6.13 void NWKU_MemCopyFromNwkBuffer (nwkBuffer_t ** pNwkBuffer, uint8_t ** pSrcPtr, uint8_t * pDstPtr, uint32_t size)

Network Utils module function used to copy from a network fragmented buffer into a regular linear buffer. Parameters

in,out	<i>pNwkBuffer</i>	Pointer to the start network buffer - pointer to end network buffer
in,out	pSrcPtr	Pointer to the source date in the start network buffer - returns last posi-
		tion in the end network buffer
in	pDstPtr	Destination pointer
in	size	Size to copy

10.6.14 void NWKU_NwkBufferAddOffset (nwkBuffer_t ** pNwkBuffer, uint8_t ** pSrcPtr, uint32_t size)

Network Utils module function used to add data into a buffer using an offset.

Parameters

in,out	pNwkBuffer	Pointer to the start network buffer - pointer to end network buffer
in,out	pSrcPtr	Pointer to the source date in the start network buffer - returns last posi-
		tion in the end network buffer
in	size	Size to copy

10.6.15 uint32_t NWKU_NwkBufferNumber (nwkBuffer_t * pNwkBufferStart)

Network Utils module function used to return the number of nwkBuffer_t fragments in the list Parameters

in	pNwkBuffer⇔	Pointer to the start of data buffer
	Start	

Kinetis Thread Stack API Reference Manual

Returns

Number of nwkBuffer_t fragments in the list

10.6.16 uint8_t * NWKU_NwkBufferToRegularBuffer (nwkBuffer_t * pNwkBufferStart, uint8_t * pRegularBuffer)

Network Utils module function used to transform a network fragmented buffer into a regular linear buffer.

Parameters

in	pNwkBuffer⇔	Pointer to the start of network buffer
	Start	
in	pRegularBuffer	Pointer to the provided Buffer, if null then allocate

Returns

Pointer to an allocated regular buffer that gets created NULL if memory cannot be allocated

10.6.17 void NWKU_CreatePseudoHeader4 (nwkBuffer_t * pNwkBuff, ipAddr_t * pSrclp, ipAddr_t * pDstlp, uint32 t length, uint8 t nextHeader)

Network Utils module function used to create the pseudoheader for IPv4 protocols

Parameters

out	pNwkBuff	Pointer to the nwkBuffer_t element containing the pseudoheader
in	pSrcIp	Pointer to the source IP address
in	pDstIp	Pointer to the destination IP address
in	length	Length of the protocol(header + data)
in	nextHeader	Value of the next header

10.6.18 void NWKU_CreatePseudoHeader6 (nwkBuffer_t * pNwkBuff, ipAddr_t * pSrclp, ipAddr_t * pDstlp, uint32_t length, uint8_t nextHeader)

Network Utils module function used to create the pseudoheader for IPv6 protocols

Parameters

out	pNwkBuff	Pointer to the nwkBuffer_t element containing the pseudoheader
in	pSrcIp	Pointer to the source IP address
in	pDstIp	Pointer to the destination IP address
in	length	Length of the protocol(header + data)
in	nextHeader	Value of the next header

Kinetis Thread Stack API Reference Manual

Function Documentation

10.6.19 uint16_t NWKU_CalculateChecksum (nwkBuffer_t * pStart)

Network Utils module function used to calculate the checksum for a nwkBuffer_t list starting with pStart element

Parameters

in	pStart	Pointer to the start of the list
----	--------	----------------------------------

Returns

Checksum for the whole list

10.6.20 bool_t NWKU_CmpAddrPrefix6 (uint8_t * addr1, uint8_t * addr2, uint32_t prefixLen)

Compares first "prefixLen" bits of the ipv6 addresses.

Parameters

in	addr1	First prefix to compare
in	addr2	Second prefix to compare
in	prefixLen	Length in bits to compare

Returns

TRUE If match FALSE Otherwise

10.6.21 bool_t NWKU_MemCmpToVal (uint8_t * pAddr, uint8_t val, uint32_t len)

Compare each octet of a given location to a value.

Parameters

in	pAddr	location to be compared
in	val	reference value
in	len	length of location to be compared

Returns

TRUE If match FALSE Otherwise

Kinetis Thread Stack API Reference Manual

10.6.22 bool_t NWKU_BitCmp (uint8_t * *pStr1*, uint8_t * *pStr2*, uint8_t *startBit*, uint8_t *stopBit*)

Compare two strings bit by bit

Kinetis Thread Stack API Reference Manual

Parameters

in	pStr1	The start address of the first string to be compared
in	pStr2	The start address of the second string to be compared
in	startBit	The start bit number in the 2 strings
in	stopBit	The stop bit number in the 2 strings

Returns

TRUE If the strings match FALSE If the strings don't match

10.6.23 bool_t NWKU_IsLLAddrEqual (uint8_t * pFirstLIAddr, uint32_t firstLIAddrSize, uint8_t * pSecondLIAddr, uint32_t secondLIAddrSize)

Compare two Link Layer addresses

Parameters

in	pFirstLlAddr	The start address of the first address to be compared
in	firstLlAddrSize	The size of the first address to be compared
in	pSecondLlAddr	The start address of the second address to be compared
in	secondLl⇔	The size of the second address to be compared
	AddrSize	

Returns

TRUE If the Link Layer addresses are the same FALSE If the Link Layer addresses are different

10.6.24 uint32_t NWKU_GetCommonPrefixLen6 (ipAddr_t * addr1, ipAddr_t * addr2)

The common prefix length CommonPrefixLen(A, B) of two addresses A and B is the length of the longest prefix (looking at the most significant, or leftmost, bits) that the two addresses have in common.

Parameters

in	addr1	First prefix to compare
in	addr2	Second prefix to compare

Returns

Longest prefix length in bits (0 - 128)

Kinetis Thread Stack API Reference Manual

10.6.25 uint64_t NWKU_TransformArrayToValue (uint8_t * pArray, uint32_t nbOfBytes)

Converts an array to a numeric value.

Kinetis Thread Stack API Reference Manual

Parameters

in	pArray	The start address of the array
in	nbOfBytes	The length of the data to be converted

Returns

The value converted from the array

10.6.26 void NWKU_TransformValueToArray (uint64_t *value*, uint8_t * *pArray*, uint32_t *nbOfBytes*)

Converts a numeric value to array.

Parameters

in	value	The value to be converted
out	pArray	The start address of the array
in	nbOfBytes	The length of the data to be converted

10.6.27 uint16_t NWKU_Revert16 (uint16_t value)

Reverts a 16 bit numeric value.

Parameters

in	value	The value to be converted
----	-------	---------------------------

Returns

The converted value

10.6.28 uint32_t NWKU_Revert32 (uint32_t value)

Reverts a 32 bit numeric value.

Parameters

in	value	The value to be converted
----	-------	---------------------------

Returns

The converted value

Kinetis Thread Stack API Reference Manual

10.6.29 uint64_t NWKU_Revert64 (uint64_t value)

Reverts a 64 bit numeric value.

Parameters

in	value	The value to be converted
----	-------	---------------------------

Returns

The converted value

10.6.30 uint16_t NWKU_TransformArrayToUint16 (uint8_t * pArray)

Converts an big endian array to a 16 bit numeric value.

Parameters

		The stand of the second
I In I	nArray	The start address of the array
	princy	The start address of the array

Returns

The converted value

10.6.31 uint32_t NWKU_TransformArrayToUint32 (uint8_t * pArray)

Converts an big endian array to a 32 bit numeric value.

Parameters

in	pArray	The start address of the array
----	--------	--------------------------------

Returns

The converted value

10.6.32 uint64 t NWKU TransformArrayToUint64 (uint8 t * pArray)

Converts an big endian array to a 64 bit numeric value.

Parameters

in	pArray	The start address of the array
----	--------	--------------------------------

Returns

The converted value

Kinetis Thread Stack API Reference Manual

10.6.33 void NWKU_TransformUint16ToArray (uint8_t * pArray, uint16_t value)

Converts a 16 bit numeric value to array.

Parameters

in	value	The value to be converted
out	pArray	The start address of the array

10.6.34 void NWKU_TransformUint32ToArray (uint8_t * pArray, uint32_t value)

Converts a 32 bit numeric value to array.

Parameters

in	value	The value to be converted
out	pArray	The start address of the array

10.6.35 void NWKU_TransformUint64ToArray (uint8_t * pArray, uint64_t value)

Converts a 64 bit numeric value to array.

Parameters

in	value	The value to be converted
out	pArray	The start address of the array

10.6.36 bool_t NWKU_GetLut8 (lut8_t * pLutTable, uint8_t lutTableSize, uint8_t * pEntryIndex)

Searches an entry in the lookup table indicated by pLutTable.

Parameters

in	pLutTable	Pointer to the lookup table
in	lutTableSize	Lookup table size
in	type	Type to find
out	pEntryIndex	Index of the entry in case the entry is found

Returns

TRUE Returned when the entry is found FALSE Otherwise

10.6.37 int32_t NWKU_atoi (char * str)

Converts a string into an integer.

Kinetis Thread Stack API Reference Manual

Parameters

in	pStr	Pointer to string	
----	------	-------------------	--

Returns

Integer converted from string.

10.6.38 int64_t NWKU_atol (char * *str*)

Converts a string into an long integer.

Parameters

in	pStr	pointer to string	

Return values

int64_t	integer converted from string.
---------	--------------------------------

void NWKU_PrintDec (uint64_t value, uint8_t * pString, uint32_t 10.6.39 nbOfDigits, bool_t bLeadingZeros)

Prints in a string decimal values.

Parameters

in	value	Integer value
	[in/out]	pString Pointer to output location
in	nbPrintDigits	Number of digits to be printed
in	bLeadingZeros	Indicate if leading zeros are put or omitted TRUE - print leading zeros
		FALSE - do not print leading zeros

10.6.40 int32_t pton (uint8_t af, char * pTxt, ipAddr_t * plpAddr)

Converts a string into an ipAddr_t. Presentation to network function.

Parameters

in	af	Address family(AF_INET, AF_INET6)
----	----	-----------------------------------

in	pTxt	Pointer to the start of the string to be parsed
in	pIpAddr	Pointer to the start of the allocated ipAddr_t structure

Returns

- 1 on success
- 0 string address is not valid
- -1 on error

10.6.41 char * ntop (uint8_t af, ipAddr_t * plpAddr, char * pStr, uint32_t strLen)

Converts an ipAddr_t into a string. Network to presentation function.

Parameters

in	af	Address family(AF_INET, AF_INET6)
in	pIpAddr	Pointer to the start of the allocated ipAddr_t structure
out	pStr	Pointer to the allocated string where to put the result
in	strLen	Size of the input buffer

Returns

Pointer to the resulted buffer

10.6.42 ptoll (uint8_t * pln, uint32_t len, $llAddr_t * <math>pLlAddr$)

Converts a string into an llAddr_t. Presentation to ll function.

Parameters

in	pIn	Pointer to the input buffer
in	len	Size of the input buffer
in	pLlAddr	Pointer to the start of the allocated llAddr_t structure

Returns

TRUE On success FALSE On error

10.6.43 uint32_t NWKU_AsciiToHex (uint8_t * pString, uint32_t strLen)

Converts a string into hex.

Kinetis Thread Stack API Reference Manual

Parameters

in	pString	Pointer to string
in	strLen	String length

Returns

Value in hex

10.6.44 uint32_t NWKU_AsciiToDec (uint8_t * pString, uint32_t strLen)

Converts a string into hex.

Parameters

in	pString	Pointer to string
in	strLen	String length

Returns

Value in decimal

10.6.45 uint8_t NWKU_ByteToDec (uint8_t byte)

Converts a byte from ASCII to decimal.

Parameters

in	byte	Byte value in ASCII	

Returns

Value in decimal

10.6.46 uint8_t NWKU_NibToAscii (int8_t nib, bool_t useUpperCase)

Converts a nib from hex to ASCII.

Kinetis Thread Stack API Reference Manual

Parameters

in	nib	Nib value in hex
in	useUpperCase	Flag to specify if conversion is to ASCII uppercase

Returns

Value in ASCII

10.6.47 void NWKU_HexToAscii (uint8_t * pInputBuff, uint32_t inputBuffLen, uint8 t * pOutputBuffer, uint32 t outputBuffLen, bool t useUpperCase)

Converts a byte to ASCII.

Parameters

in	pInputBuff	Pointer to input buffer
in	inputBuffLen	Length of the input buffer
in	pOutputBuffer	Pointer to output buffer
in	outputBuffLen	Length of the output buffer
in	useUpperCase	Indicate if the output shall be in upper/lower case

10.6.48 uint32_t NWKU_TmrRtcGetElapsedTimeInSeconds (uint32_t timestamp)

Calculates the time passed in seconds from the provided timestamp.

Parameters

in	timestamp	Timestamp in seconds
----	-----------	----------------------

Returns

Number of seconds that have passed since the provided timestamp

10.6.49 bool_t NWKU_IsNUmber (char * pString)

Check if a string is a number.

Parameters

- arameters

Kinetis Thread Stack API Reference Manual

205

in	pString	Pointer to the string
----	---------	-----------------------

Returns

TRUE If the string represents a number FALSE If the string does not represent a number

10.6.50 uint32_t NWKU_GetRandomNoFromInterval (uint32_t *startInterval*, uint32_t *endInterval*)

This function returns a random number from a given interval.

Parameters

in	startInterval	Start value of the interval
in	endInterval	End value of the interval

Returns

Random value

10.6.51 void NWKU_Incrementlp6Addr ($ipAddr_t * plpAddr$)

This function increments a IPv6 type address

Parameters

in	pIpAddr	Pointer to IPv6 address

10.6.52 uint32_t NWKU_RightRotate (uint32_t val, uint8_t amount)

This function rotates a 32bit number to the right with an amount of bits.

Parameters

in	val	Number
in	amount	Number of bits to rotate

Returns

Result of the rotation

NXP Semiconductors

Kinetis Thread Stack API Reference Manual

10.6.53 void NWKU_GetIIDFromLLADDR ($llAddr_t*pLlAddr$, uint16_t panld, uint8 t * pllD)

The function returns the IID from a Link-Layer address.

Parameters

in	pLlAddr	Pointer to the Link-Layer address
in	panId	PAN ID
out	pIID	Pointer to the variable which will hold the IID

10.6.54 void NWKU_GetLLAddrFromIID (uint8_t * pIID, llAddr_t * pLIAddr)

This function returns the Link-Layer address from the IID.

Parameters

in	pIID	Pointer to the IID
out	pLlAddr	Pointer to the variable which will hold the Link-Layer address

10.6.55 void bool t NWKU IsIPAddrBasedOnShort (ipAddr_t * plpAddr)

This function returns true if the IPv6 address is formed with short MAC address.

Parameters

in	pIpAddr	Pointer to the IPv6 address
----	---------	-----------------------------

Returns

TRUE If address is based on short MAC address FALSE Otherwise.

10.6.56 bool t NWKU GetBit (uint32 t bitNr, uint8 t * pArray)

This function returns the value of a bit in an array.

Parameters

in	bitNr	Bit number in the whole array
in	pArray	Pointer to the start of the array

Returns

TRUE If the bit is set FALSE If the bit is not set

Kinetis Thread Stack API Reference Manual NXP Semiconductors 207

10.6.57 void NWKU_SetBit (uint32_t bitNr, uint8_t * pArray)

This function sets a bit in an array.

209

Parameters

in	bitNr	Bit number in the whole array
in	pArray	Pointer to the start of the array

10.6.58 void NWKU ClearBit (uint32 t bitNr, uint8 t * pArray)

This function clears a bit in an array.

Parameters

in	bitNr	Bit number in the whole array
in	pArray	Pointer to the start of the array

10.6.59 uint32_t NWKU_GetFirstBitValueInRange (uint8_t * pArray, uint32_t lowBitNr, uint32_t highBitNr, bool t bitValue)

This function returns the first bit with value=bitValue in a range in the array.

Parameters

in	pArray	Pointer to the start of the array
in	lowBitNr	Starting bit number
in	highBitNr	Ending bit number
in	bitValue	Bit value

Returns

uint32_t Bit number

10.6.60 uint32_t NWKU_GetFirstBitValue (uint8_t * pArray, uint32_t arrayBytes, bool t bitValue)

This function returns the index of the first bit with value=bitValue.

Parameters

in	pArray	Pointer to the start of the array
in	arrayBytes	Number of bytes in the array

in	bitValue	Bit value
----	----------	-----------

Returns

Bit value

10.6.61 uint32_t NWKU_GetNumOfBits (uint8_t * pArray, uint32_t arrayBytes, bool_t bitValue)

This function returns number of bits of value bitValue from an array

Parameters

in	pArray	Pointer to the start of the array
in	arrayBytes	Number of bytes in the array
in	bitValue	Bit value

Returns

Bit value

10.6.62 uint32_t NWKU_ReverseBits (uint32_t num)

Reverse bits

Parameters

in	num	The bits to reverse
----	-----	---------------------

Returns

The reversed bits

10.6.63 uint32_t NWKU_AddTblEntry (uint32_t entry, uint32_t * pTable, uint32_t tableSize)

This function adds a new entry in a table. The table needs to have uint32_t elements.

Kinetis Thread Stack API Reference Manual

Parameters

in	entry	Entry value
in	pTable	Pointer to the start of the table
in	tableSize	The size of the table

Returns

Entry index or -1(0xFFFFFFF) in case of error

10.6.64 uint32_t NWKU_GetTblEntry (uint32_t entry, uint32_t * pTable, uint32_t tableSize)

This function search for an element in a table.

Parameters

in	entry	Entry value
in	pTable	Pointer to the start of the table
in	tableSize	The size of the table

Returns

Entry index or NULL in case of error

10.6.65 void NWKU_SwapArrayBytes (uint8_t * pByte, uint8_t numOfBytes)

This function swaps the bytes in an array and puts the result in the same array.

Parameters

	[in/out]	pByte Pointer to the start of the array
in	numOfBytes	Size of the array

10.6.66 void NWKU_GenRand (uint8_t * pRand, uint8_t randLen)

This function generates a random value in the desired array.

Parameters

Kinetis Thread Stack API Reference Manual

out	pRand	Pointer to the start of the output array
in	randLen	Size of the array

10.6.67 uint32_t NWKU_GetTlvLen (uint8_t type, uint8_t * pStart, uint32_t len)

This function returns the length of the TLV type specified.

Parameters

in	type	Type identifier for the TLV
in	pStart	Pointer to the start if the TLVs
in	len	Size of the TLVs buffer

Returns

Length of the specified TLV type

This function returns the value of a requested TLV in a list of TLVs. The pointer to the value(if found) will be returned and copied in pOut buffer(if pOut is not NULL).

Parameters

in	type	Type identifier for the TLV
in	pStart	Pointer to the start if the TLVs
in	len	Size of the TLVs buffer
in	pOut	Pointer to the output preallocated buffer or NULL

Returns

Pointer to the value of the requested TLV

This function returns the start address of the TLV in the pStart buffer.

213

Parameters

in	type	Type identifier for the TLV
in	pStart	Pointer to the start if the TLVs
in	len	Size of the TLVs buffer
out	pOut	If this buffer is provided, the found TLVs will be copied inside
out	pOutLen	if this variable is provided, the found TLVs length will be copied

Returns

Pointer to the TLV NULL if the requested TLV was not found

10.6.70 bool_t NWKU_Pbkdf2 (pbkdf2Params_t * plnput, uint8_t * pOut, uint32_t outLen)

This function calculates pbkdf2 for an input.

Parameters

in	pInput	Structure containing the input parameters NOTE: - pInput->pSalt
		should include the "salt" plus 4 bytes more at the end
		• pInput->pSalt should specify the "salt" length without the above
		4 bytes
in	pOut	Pointer to the output
in	outLen	Size of the output buffer

Returns

TRUE If the operation has succeeded FALSE If the operation hasn't succeeded

10.6.71 uint64_t NWKU_GetTimestampMs (void)

Get the timestamp in milliseconds.

Returns

Timestamp in milliseconds

10.6.72 int8_t NWKU_isArrayGreater (const uint8_t * a, const uint8_t * b, uint8_t length)

Compare two numbers represented as array.

Parameters

in	а	First array
in	b	Second array
in	length	How many bytes to compare

Returns

0 - are equal

1 - a > b

-1 - b < a

10.7 Variable Documentation

10.7.1 uint16_t uuint16_t::u16

16bit variable

10.7.2 uint8_t uuint16_t::u8[2]

8bit array

10.7.3 uint32_t uuint32_t::u32

32bit variable

10.7.4 uint16_t uuint32_t::u16[2]

16bit array

10.7.5 uint8_t uuint32_t::u8[4]

8bit array

10.7.6 uint64_t uuint64_t::u64

64bit variable

Variable Documentation

10.7.7 uint32 t uuint64 t::u32[2]

32bit array

10.7.8 uint16_t uuint64_t::u16[4]

16bit array

10.7.9 uint8_t uuint64_t::u8[8]

8bit array

10.7.10 uint8_t ipAddr_t::addr8[16]

8bit array

10.7.11 uint16_t ipAddr_t::addr16[8]

16bit array

10.7.12 uint32 t ipAddr t::addr32[4]

32bit array

10.7.13 uint64_t ipAddr_t::addr64[2]

64bit array

10.7.14 struct nwkBuffer tag* nwkBuffer t::next

Pointer to next buffer.

10.7.15 uint8_t* nwkBuffer_t::pData

Pointer to data.

10.7.16 uint32 t nwkBuffer t::size

Size of data.

10.7.17 uint8_t nwkBuffer_t::freeBuffer

Flag used to notify buffer clearance.

10.7.18 uint8_t IIAddr_t::eui[8]

Destination address: short/extended.

10.7.19 llAddrSize_t llAddr_t::addrSize

Destination address type: short/extended.

10.7.20 uint8 t ip6Header t::versionTraficClass

Version Traffic Class.

10.7.21 uint8_t ip6Header_t::trafficClassFlowLabel

Traffic Class Flow label.

10.7.22 uint8_t ip6Header_t::flowLabel[2]

Flow label.

10.7.23 uint8 t ip6Header t::payloadLength[2]

Payload length.

10.7.24 uint8_t ip6Header_t::nextHeader

Next header.

Kinetis Thread Stack API Reference Manual

Variable Documentation

10.7.25 uint8_t ip6Header_t::hopLimit

Hop limit.

10.7.26 uint8_t ip6Header_t::srcAddr[16]

Source Address.

10.7.27 uint8 t ip6Header t::dstAddr[16]

Destination Address.

10.7.28 void* ipPktOptions_t::ifHandle

Pointer to interface handler.

10.7.29 nwkBuffer_t* ipPktOptions_t::ipExtensionHeaderBuffer

Pointer to extended options buffer.

10.7.30 void* ipPktOptions t::ipReassemblyOptions

Pointer to IP reassembly structure.

10.7.31 llAddr_t ipPktOptions_t::srcLlInfo

Source Link Layer information.

10.7.32 uint8 t ipPktOptions t::ipHdrOffset

Offset from beginning of RX data where IP HDR is found.

10.7.33 uint8 t ipPktOptions t::hopLimit

Hop limit.

10.7.34 uint8_t ipPktOptions_t::security

Security option.

10.7.35 uint8_t ipPktOptions_t::lqi

Packet LQI.

10.7.36 uint8_t ipPktOptions_t::qos

Packet Quality of Service.

10.7.37 uint8_t ipPktOptions_t::isRelay

Flag to specify if packet is relay.

10.7.38 uint8_t ipPktOptions_t::macSecKeyIdMode

MacSec Key ID Mode.

10.7.39 uint8_t ipPktOptions_t::channel

Packet Channel.

10.7.40 uint16_t ipPktOptions_t::destPanId

Destination PAN ID.

10.7.41 uint16 t ipPktOptions t::srcPanld

Source PAN ID.

10.7.42 ipIfUniqueId_t recvOptions_t::iplfld

ID of the interface.

Kinetis Thread Stack API Reference Manual

Variable Documentation

10.7.43 uint8_t recvOptions_t::hopLimit

Hop limit.

10.7.44 uint8_t recvOptions_t::security

Security option.

10.7.45 uint8_t recvOptions_t::lqi

Packet LQI.

10.7.46 uint8_t recvOptions_t::isRelay

Flag to specify if packet is relay.

10.7.47 uint8_t recvOptions_t::channel

Packet Channel.

10.7.48 uint8_t recvOptions_t::macSecKeyIdMode

MacSec Key ID Mode.

10.7.49 uint16_t recvOptions_t::macSrcPanId

MAC Source PAN ID.

10.7.50 nwkBuffer_t* ipPktInfo t::pNwkBuff

Pointer to network buffer.

10.7.51 ipAddr_t* ipPktInfo t::plpSrcAddr

Pointer to source IP address.

10.7.52 ipAddr_t* ipPktInfo_t::plpDstAddr

Pointer to destination IP address.

Pointer to the next protocol in pNwkBuff->pData.

Do not free this one!

Source IP address.

10.7.55 ipAddr_t ipPktInfo_t::ipDstAddr

Destination IP address.

Size of the data of next protocol in pNwkBuff->pData.

Protocol type.

Protocol information.

10.7.59 uint16_t ipPktInfo_t::srcPort

Source port.

10.7.60 uint16_t ipPktInfo_t::dstPort

Destination port.

Kinetis Thread Stack API Reference Manual

Variable Documentation

10.7.61 ipPktOptions_t ipPktInfo_t::ipPktOptions

IP packet options.

10.7.62 nwkMsgHandler nwkMsg_t::pFunc

Pointer to packet handler.

10.7.63 void* nwkMsg_t::pPload

Pointer to handler payload.

10.7.64 msgQueue_t taskMsgQueue_t::msgQueue

Pointer to task message queue.

10.7.65 osaTaskId_t taskMsgQueue_t::taskId

Pointer to task ID.

10.7.66 osaEventId_t taskMsgQueue_t::taskEventId

Pointer to task event ID.

Type.

10.7.68 uint8 t lut8 t::idx

Index.

10.7.69 uint8 t nwkStats t::ipktUsed

IP packets used.

10.7.70 uint8_t nwkStats_t::ipktMax

Maximum IP packets.

10.7.71 uint8_t nwkStats_t::nwkBuffUsed

Network buffers used.

10.7.72 uint8_t nwkStats_t::nwkBuffMax

Maximum network buffers.

10.7.73 uint8_t ipPrefix_t::prefixLen

Size of the prefix in bits.

10.7.74 uint8_t ipPrefix_t::aPrefix[]

Pointer to the start of the prefix.

10.7.75 uint8 t* pbkdf2Params t::pPass

Pointer to the password.

10.7.76 uint32_t pbkdf2Params_t::passLen

Length of the password.

10.7.77 uint8_t* pbkdf2Params_t::pSalt

Pointer to the salt.

10.7.78 uint32_t pbkdf2Params_t::saltLen

Length of the salt.

Kinetis Thread Stack API Reference Manual

Variable Documentation

10.7.79 uint32_t pbkdf2Params_t::rounds

Number of rounds.

How to Reach Us:

Home Page:

nxp.com

Web Support:

nxp.com/support

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address:

nxp.com/SalesTermsandConditions.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, I2C BUS, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, AltiVec, C-5, CodeTEST, CodeWarrior, ColdFire, ColdFire+, C-Ware, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorlQ, QorlQ Qonverge, Ready Play, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, SMARTMOS, Tower, TurboLink, and UMEMS are trademarks of NXP B.V. All other product or service names are the property of their respective owners. ARM, AMBA, ARM Powered, Artisan, Cortex, Jazelle, Keil, SecurCore, Thumb, TrustZone, and Vision are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. ARM7, ARM9, ARM11, big.LITTLE, CoreLink, CoreSight, DesignStart, Mali, mbed, NEON, POP, Sensinode, Socrates, ULINK and Versatile are trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© 2016 NXP B.V.

