RELAY SWITCHER

The information on this page is the <u>bare minimum</u> needed to build the project, however you will find more information at http://six4pix.com/relays

I recommend you check the expanded instructions before you start building the board

Here are the component designators used on the PCB:

R1, R11 1K RESISTOR (X2)
R2-R9 100R RESISTOR (X8)
R10, R12 1K5 RESISTOR (X2)
R13 220R RESISTOR

R10 is the unlabelled resistor above R11. R3-R9 are the

unlabelled resistors between R2 and R10.

C1 47UF 50V ELECTROLYTIC CAPACITOR
C2,C3,C4 100nF CERAMIC CAPACITOR (X3)
C5 4U7 10V ELECTROLYTIC CAPACITOR

D2 1N4001 RECTIFIER DIODE D3 1N4148 SIGNAL DIODE

PWR, ACT 3MM LEDS (x2)

 IC1
 PIC16F1825 MICROCONTROLLER (In Socket)

 IC2
 6N138 OPTOCOUPLER (In Socket)

 IC3
 3.3V 0.1A VOLTAGE REGULATOR TO92

MODE 6MM TACTILE SWITCH

5VDC DOUBLE TERMINAL BLOCK 5MM

MIDI IN 5 PIN DIN PCB MOUNT SOCKET

Please carefully check the polarity of C1, C5, D2, D3, IC3

and all LEDs before soldering!

Solder the module to the pin header on the relay board. Attach the 4 nylon stand-offs to the base plate using the screws. Place the relay board on the stand-offs and use the nuts to secure the relay module to the base.

Use the brass stand-offs to support the relay switcher module above the upper part of the base plate.

The default MIDI note to port mapping is

Port	Note	Port	Note
PORT A	C1 (36)	PORT E	E1 (40)
PORT B	C#1 (37)	PORT F	F1 (41)
PORT C	D1 (38)	PORT G	F#1 (42)
PORT D	D#1 (39)	PORT H	G1 (43)

The default receive channel is $\underline{\textbf{MIDI Channel 1}}$ for all ports and outputs will remain trigged for the duration of the MIDI notes.

The configuration can be changed using MIDI sysex files that you can create using the web based configuration form at http://www.six4pix.uk/switcher/patch.asp

- * Power the board from a 5VDC supply being careful to get the polarity correct. Do not power the module from a higher voltage supply this may damage the relay module.
- * The power supply should be able to provide at least 500mA at 5VDC
- * I do not not advise using the module to switch mains electricity unless you are a qualified electrician or otherwise competent to work on mains supplies. If you do so, it is AT YOUR OWN RISK.
- * To electrically isolate the relay coil drivers from the Relay Switcher microprocessor module requires a second DC power supply and removal of the jumper on the relay module. You should consider this step if you are switching mains power with this module. Please check the web site for information.
- * Always check the manual if you have any doubts
- * Have Fun!

Feel free to contact me at $\underline{\text{sixtyfourpixels@qmail.com}}$ with questions, suggestions and feedback.

RELAY SWITCHER

The information on this page is the <u>bare minimum</u> needed to build the project, however you will find more information at http://six4pix.com/relays

I recommend you check the expanded instructions before you start building the

Here are the component designators used on the PCB:

R1, R11 1K RESISTOR (X2)
R2-R9 100R RESISTOR (x8)
R10, R12 1K5 RESISTOR (X2)
R13 220R RESISTOR

R10 is the unlabelled resistor above R11. R3-R9 are the unlabelled resistors between R2 and R10.

C1 47UF 50V ELECTROLYTIC CAPACITOR C2,C3,C4 100nF CERAMIC CAPACITOR (X3)

C5 4U7 10V ELECTROLYTIC CAPACITOR
D2 1N4001 RECTIFIER DIODE

D3 1N4148 SIGNAL DIODE

PWR, ACT 3MM LEDS (x2)

 IC1
 PIC16F1825 MICROCONTROLLER (In Socket)

 IC2
 6N138 OPTOCOUPLER (In Socket)

 IC3
 3.3V 0.1A VOLTAGE REGULATOR TO92

MODE 6MM TACTILE SWITCH

5VDC DOUBLE TERMINAL BLOCK 5MM

MIDI IN 5 PIN DIN PCB MOUNT SOCKET

Please carefully check the polarity of C1, C5, D2, D3, IC3

and all LEDs before soldering!

Solder the module to the pin header on the relay board. Attach the 4 nylon stand-offs to the base plate using the screws. Place the relay board on the stand-offs and use the nuts to secure the relay module to the base.

Use the brass stand-offs to support the relay switcher module above the upper part of the base plate.

The default MIDI note to port mapping is

Port	Note	Port	Note
PORT A	C1 (36)	PORT E	E1 (40)
PORT B	C#1 (37)	PORT F	F1 (41)
PORT C	D1 (38)	PORT G	F#1 (42)
PORT D	D#1 (39)	PORT H	G1 (43)

The default receive channel is $\underline{\textbf{MIDI Channel 1}}$ for all ports and outputs will remain trigged for the duration of the MIDI notes.

- * Power the board from a 5VDC supply being careful to get the polarity correct. Do not power the module from a higher voltage supply this may damage the relay module.
- st The power supply should be able to provide at least 500mA at 5VDC
- * I do not not advise using the module to switch mains electricity unless you are a qualified electrician or otherwise competent to work on mains supplies. If you do so, it is AT YOUR OWN RISK.
- * To electrically isolate the relay coil drivers from the Relay Switcher microprocessor module requires a second DC power supply and removal of the jumper on the relay module. You should consider this step if you are switching mains power with this module. Please check the web site for information.
- * Always check the manual if you have any doubts
- * Have Fun!

Feel free to contact me at $\underline{\textbf{sixtyfourpixels@gmail.com}}$ with questions, suggestions and feedback.