
CSE 321a

Computer Organization (1) تنظيم الحاسبات (1)



3rd year, Computer Engineering Fall 2017

Lecture #6



Dr. Hazem Ibrahim Shehata Dept. of Computer & Systems Engineering

Credits to Dr. Ahmed Abdul-Monem Ahmed for the slides

Administrivia

- Assignment #1:
 - —Solution was posted on Saturday.
- Previous exams/solutions have been posted.
- Assignment #2:
 - —To be released later on this week.

Website: http://hshehata.github.io/courses/zu/cse321a

Office hours: Sunday 1:00pm-2:00pm

Chapter 4. Cache Memory (Cont.)

- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- Addresses
- 6. Size
- 7. Block/line size

2. Replacement Algorithms Direct mapping

- No choice.
- Each block only maps to one line.
- Replace that line.

2. Replacement Algorithms Associative and Set Associative

- Hardware implemented algorithms!
- Most common ones:
 - 1. Least Recently Used (LRU)
 - Replace the block that has not been recently accessed.
 - 2. First In First Out (FIFO)
 - Replace the oldest block.
 - 3. Least Frequently Used
 - Replace the block which has had the fewest hits.
 - 4. Random
 - Replace any block!

- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- Addresses
- 6. Size
- 7. Block/line size

3. Read/Write Policies Read Policy (Hit & Miss)

- Reads dominate processor cache accesses.
 - —All instructions need to be fetched → reads.
 - —Some instructions may read one or more operands.
 - —Most instructions do not write to memory!
- What if CPU wants to read a word from MM?
 - —Read-hit policy: if read hits in cache (i.e., container block is in cache), just read word from cache!
 - —Read-miss policy: if read misses in cache (i.e., container block is in not cache),
 - 1. Read-through: read word from MM, and bring container block to cache.
 - 2. No-read-through: bring container block to cache, and then read word from cache.

3. Read/Write Policies Write Policy (Hit)


- What if CPU wants to write a word to memory?
 - —Write-hit policy: if write hits (i.e., container block is in cache)
 - 1. Write-through: write word to both cache and MM
 - Pros: easier to implement, MM is always consistent with cache, read miss never results in writes to MM.
 - Cons: Every write needs a MM access, slower writes, more MM bandwidth consumption.
 - 2. Write-back: write word to cache only, do not write word to MM until cached version of container block is replaced.
 - + In addition to tag bits, each cache line stores a "dirty bit".
 - Pros: multiple writes within block require only one write to MM, faster writes, less MM bandwidth consumption.
 - Cons: harder to implement, MM is not always consistent with cache, reads may cause writes of dirty blocks to MM.

3. Read/Write Policies Write Policy (Miss)

- ... (Cont.)
 - —Write-miss policy: if write misses (i.e., container block is in not cache)
 - 1. Write-allocate: bring container block to cache, and then act according to write-hit policy.
 - 2. No-write-allocate: write word to container block in MM, and do not bring block to cache.
 - Note: either write-miss policy could be used with write-through or write-back, however:
 - Write-back caches generally use write-allocate
 - Hoping that subsequent writes to block get captured by cache
 - Write-through caches often use no-write-allocate
 - since subsequent writes to block will still have to go to MM

3. Read/Write Policy Cache Coherency ترابط او التحام w/t Multi-CPUs

- Consider a multiple-CPU organization:
 - —Several CPUs share same MM
 - —Each CPU has its own cache.



3. Read/Write Policy Cache Coherency ترابط او التحام w/t Multi-CPUs

- Problem: If data is altered in one cache → this invalidates this word in MM and in other caches.
- This is true even if write-through is used.
- Cache coherency: maintaining data in all caches consistent.
- Some solutions:
 - 1. Bus watching with write-through: Cache controller monitors the bus and invalidates the word in the cache if another master (e.g., CPU) updates it in MM.
 - 2. Hardware transparency: Additional h/w makes sure that if one CPU updates a word in its cache, it is written to MM and updated in other caches.
 - 3. Non-cacheable memory: Only a portion of MM is shared, and that portion is non-cacheable!

- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- Addresses
- 6. Size
- 7. Block/line size

4. Number of Caches Split vs. Unified & Dedicated vs. Shared

- Contemporary multi-core systems use multiple caches organized in a variety of ways:
 - 1. Split cache vs. unified cache
 - Split: one cache for instructions and another for data.
 - + No contention between fetch unit & execute unit.
 - Unified: only one cache for both.
 - Higher hit rate than split since it balances load between instruction and data fetches.

2. Dedicated cache vs. shared cache


- Dedicated: one cache for each CPU
 - No contention between CPUs
- Shared: one cache shared by multiple CPUs
 - Better load balancing

4. Number of Caches Multi-Level Caches


• ... (Cont.)

3. Multi-Level Caches

- Multiple levels of caches located between CPU and MM.
- Level 1 (L1) cache: closest to CPU, fastest, smallest.
- Level 2 (L2) cache: 2nd closest to CPU, 2nd fastest, 2nd smallest.
- Level 3 (L3) cache: ...
- Ex. Operation of two-level cache: CPU looks for the requested word in L1 cache first. If not there, it fetches it from L2 cache. If not there, it is fetched from MM.
- Higher cache levels used to be off-chip, not anymore!!




4. Number of Caches Total Hit Ratio of Two-Level Cache




- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- 5. Addresses
- 6. Size
- 7. Block/line size

5. Cache Addressing Location relative to MMU

- Where does cache sit relative to the memory management unit (MMU)?
 - —Between CPU & MMU (MMU) → Virtual (logical) Cache.



—Between MMU & MM → Physical Cache.



5. Cache Addressing Virtual vs. Physical Cache

Virtual (logical) cache


- —Uses virtual addresses of MM blocks in cache mapping.
- —CPU accesses cache directly (not through MMU).
- No address translation to access cache → Faster access.
- Different applications have similar virtual addresses → Must flush cache on each context switch.

Physical cache


- —Uses physical addresses of MM blocks in cache mapping.
- —CPU accesses cache through MMU.
- Need address translation to access cache → Slower access.
- Different applications have different physical addresses → No need to flush cache on context switch.

- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- Addresses
- 6. Size
- 7. Block/line size

6. Cache Size Cache Size/Associativity vs. Hit ratio



6. Cache Size Cache Size/Associativity vs. Hit Time



Hennessey and Patterson, "Computer Architecture: A Quantitative Approach", 5th Ed.

6. Cache Size Summary

- Trend: Cache size ↑ → Hit ratio ↑ → Hit time ↑.
- Motivations for bigger cache:
 - Better hit ratio → average access time of (cache + MM) is close to cache alone.
- Motivations for smaller cache:
 - —Less gates involved in addressing → faster cache.


—Less cost → average cost per bit of (cache + MM) is

close to MM alone.

- —Fit the chip/board area budget.
- Reality: Cache performance depends on workload → No single "optimum" cache size exists!

- 1. Mapping function
- 2. Replacement algorithm
- 3. Read/Write policies
- 4. Number of caches
- Addresses
- 6. Size
- 7. Block/line size

7. Block/Line Size Block Size vs. Miss Rate



Patterson and Hennessey, "Computer Architecture and Design: the Hardware Software Interface", 5th Ed.

7. Block/Line Size Summary

- Block size increases → hit ratio increases at first (locality of reference).
- Block becomes too big → probability of using the fetched info becomes less than that of reusing info to be replaced → hit ratio begins to decrease.
- Two effects come into play due to larger blocks:
 - Less blocks could be fit into cache → data gets overwritten shortly after being fetched.
 - More words become farther from requested ones → not likely to be referenced.
- Typical block size: 8-64B (PC) & 64-128B (HPC).

Example AMD Bulldozer Cache Organization

- Three-level cache organization: L1, L2, and L3.
 - L1 → split cache
 - L1 Code: 64KB, 2-way, 64B-line, shared (1 per 2 cores).
 - L2 Data: 16KB, 4-way, 64B-line, dedicated (1 per core).
 - Access Latency: 3-4 clock cycles.
 - L2 → unified cache
 - 1-2MB, 16-way, 64B-line, shared (1 per 2 cores).
 - Access Latency: 21 clock cycles.
 - L3 → unified cache
 - 0-8MB, 64-way, 64B-line, shared (1 per all cores).
 - Access Latency: 87 clock cycles.

Reading Material

- Stallings, Chapter 4:
 - —Pages 137 141