CSE 321a

Computer Organization (1) (1) تنظيم الحاسبات



3rd year, Computer Engineering Fall 2016



Lecture #2

Dr. Hazem Ibrahim Shehata Dept. of Computer & Systems Engineering

Credits to Dr. Ahmed Abdul-Monem Ahmed for the slides

Administrivia

- Website:
 - —http://hshehata.github.io/courses/zu/cse321a/
- Lecture Day/Time:
 - —Tuesday 10:15am 12:45am
- Office Hours:
 - —TBA!
- Tutorials:
 - —Starting next week on Sunday at 2:55pm (just once!)
 - —Regular day/time: Thursday 10:00am 11:30am
- Assignment #1:
 - —To be early next week.
 - —Work in groups of two.

Ch. 3: A Top-Level View of Computer Function and Interconnection

Overview

- Computer Structure (Components)
- Computer Function
 - —Instruction Fetch and Execute
 - —Interrupts
- Interconnection Structures
- Bus Interconnection
 - —Bus Structure
 - —Multiple-Bus Hierarchies
 - —Elements of Bus Design

Von Neumann (Princeton) Architecture

- Almost all contemporary computer designs are based on three basic concepts introduced by John von Neumann in 1945:
- 1. Data and instructions are stored in a single read-write memory.
- 2. The contents of this memory are addressable by location, without regard to the type of data contained there.
- 3. Execution occurs in a sequential fashion (unless modified) from one instruction to the next.

Program Concept


 Using a fixed set of logic components, there are two ways to build a system that performs a specific computation on some input data:

1. Special-purpose (customized) hardware:

- Logic components are connected and configured specifically to perform a particular computation.
- Type of computation is specified by way in which components are connected/configured → hardwired programming.
- To change computation, rewire components → inflexible!

2. General-purpose hardware:

- Logic components are connected to form a general-purpose hardware that gets configured using set of input control signals.
- Type of computation (reflected by control signals values) is specified by sequence of input codes → software programming.
- To change computation, change code → flexible!




What is a program?

- A sequence of steps.
- For each step, an arithmetic or logical operation could be done.
- For each operation, a different set of control signals are generated.
 - —Each operation is assigned a unique code.
 - e.g., ADD → 9D, MOVE → E3, ... etc.
 - —A hardware segment accepts the code and issues the control signals.
- That's it. We have a computer!

Computer Components

- Each computer component takes some part in implementing the "s/w programming" approach:
 - —Control unit (CU) acts as instruction interpreter.
 - Arithmetic and logic unit (ALU) implements generalpurpose arithmetic and logic functions.
 - —Both CU and ALU constitute most of central processing unit (CPU).
 - —Data/code get into system, and results get out through input/output (I/O) units.
 - —Data, code, and results are stored temporarily while being processed in main memory (MM) unit.




Overview

- Computer Structure (Components)
- Computer Function
 - —Instruction Fetch and Execute
 - —Interrupts
- Interconnection Structures
- Bus Interconnection
 - —Bus Structure
 - —Multiple-Bus Hierarchies
 - —Elements of Bus Design

Instruction Cycle

- Two steps:
 - —Fetch: CPU reads instructions from memory, one at a time.
 - —Execute: CPU executes instructions.




Fetch Cycle

- Program Counter (PC) holds address of next instruction to fetch.
- Processor fetches instruction from memory location pointed to by PC.
- Increment PC
 - Unless told otherwise
- Instruction loaded into Instruction Register (IR).
- Processor interprets instruction and performs required actions in execute cycle.

Execute Cycle

- Processor-memory
 - Data transfer between CPU and main memory
- Processor-I/O
 - Data transfer between CPU and I/O module
- Data processing
 - —Some arithmetic or logical operation on data
- Control
 - Alteration of sequence of operations
 - e.g., jump
- Combination of the above

Hypothetical Machine






Integer Format

Program Counter (PC) 0001 = Load AC from memory.
Instruction Register (IR) 0010 = Store AC to memory.
Accumulator (AC) 0101 = Add to AC from memory.


CPU Registers

Partial List of Opcodes



Instruction Cycle: State Diagram

CPU-memory or CPU-I/O operations




Overview

- Computer Structure (Components)
- Computer Function
 - —Instruction Fetch and Execute
 - —Interrupts
- Interconnection Structures
- Bus Interconnection
 - —Bus Structure
 - —Multiple-Bus Hierarchies
 - —Elements of Bus Design


Interrupts

- Interrupts are provided to improve processing efficiency.
- Mechanism by which other modules (e.g. I/O) may interrupt normal sequence of processing
- Most common classes of interrupts:
 - —Program
 - e.g. overflow, division by zero
 - —Timer
 - Generated by internal processor timer
 - Used in pre-emptive multi-tasking (i.e., CPU time sharing).
 - -I/O
 - From I/O controller
 - —Hardware failure
 - e.g. memory parity error


Transfer of Control via Interrupts



Program Flow Control



Program Timing




(a) Without interrupts

(a) Without interrupts


Interrupt Cycle

- Added to instruction cycle.
- Processor checks for interrupt
 - Indicated by an interrupt signal
- If no interrupt:
 - —fetch next instruction
- If interrupt pending:
 - —Suspend execution of current program.
 - —Save context (PC & relevant data).
 - —Set PC to start address of interrupt handler routine.
 - —Process interrupt.
 - —Restore context and continue interrupted program.

Instruction Cycle (with interrupts)



Instruction Cycle: State Diagram (with interrupts)



Reading Material

- Stallings, Chapter 3:
 - —Pages 66 80