

www.tachograph.bg


Volvo/Renault Chano

```
Volvo/Renault Chano (
                                      )
    TEA2+ Volvo Renault.
                                TEA2+ (EURO 6). -
TEA2 (
          EURO 5
                         ,
ТЕА2+.
                                                         TEA2+,
```

Volvo/Renault Chano

TCO parameter/TCO

TEA2.






(Volvo/Renault):

Renault T-, K-, C-



CHANO J30CS000054F





J30CS000054F



Volvo - FH FL


CHANO :

: *YV2RTYOA3EA756696*


11- ()

+ 4

Volvo new FH series



Volvo new FM-series




Instruction to program the parameter with the WorkshopTab


To activate the Volvo/Renault Chano Parameter on a universal devices the following steps have to be done.

1. Navigate in the menu *Universal Programming* and select and program the suitable parameter file.

<u>Important:</u> Only a TEA2+ programming (notice in the name of the parameter file) activates the Volvo/Renault Chano Parameter. Below the example of a VOLVO FH/FM Truck (**TEA2+** architecture).



2. Navigate to the menu *TCO parameter*. Now it is possible to edit and write the Volvo/Renault parameter.



3. After the programming the parameter is stored in the DTCO.