


Main Topics



Arithmetic and Logical Instructions



Instruction Sets

- Supports large number of ARM 32 bits instructions
- Supports Thumb instruction set
 - 16 bits and 32 bits
 - Thumb provides better code density at expense of performance
 - Thumb-2 achieves high performance and better code density
 - Most 16-bit instructions can only access eight of the general-purpose registers, R0-R7 (low registers)

ARM and Thumb

ARM

- 32-bit instruction set, called the ARM instructions
- Powerful and good performance
- Larger program memory compared to 8-bit and 16-bit processors
- Larger power consumption

Thumb-1

- 16-bit instruction set, first used in ARM7TDMI processor
- Provides a subset of the ARM instructions
- Better code density compared to 32-bit RISC architecture
- Code size is reduced by ~30%, but performance is also reduced by ~20%

Thumb -2


- Thumb-2
 - Consists of both 32-bit Thumb and 16bit Thumb-1 instruction sets
 - Reduced code size but similar performance
 - Capable of handling all processing requirements in one operation state




5 ECE- 40097

Unified Assembler Language

- UAL is common syntax
 - Canonical form for all ARM and Thumb instructions
 - Code written using UAL can be assembled for ARM or Thumb for any ARM processor
 - For portability of the code
 - Assembler options are: --32, --arm, --thumb, or --Thumbx
- Many operations that would require two or more 16bit instructions
 - Can be more efficiently executed with a single 32-bit instruction
- For GNU GAS, the directive for UAL is
 .syntax unified



Instruction Sets



ARM Cortex-M4 Organization (STM32L4)

CPU Bus

- Bus matrix allows concurrent data streams
 - Connects high speed components such as memory, DMA
- Advanced peripheral bus
 - Low bandwidth communication
 - Used for peripherals
 - Connected to Bus matrix via bridges.
- Advanced high performance Bus
 - High bandwidth communication
 - Used with memory and DMA

Instruction Set Architecture

- Accumulator based ISA
 - Pretty old
 - ALU source operand is implied and is in Accumulator
- Stack based ISA
 - Still old
 - ALU operands are assumed to be on top of stack
- Load Store ISA
 - Used in ARM
 - ALU source operands can be any registers
 - Only Load/Store instructions can access memory


ARM Instruction Format

- label mnemonic operand1, operand2, operand3 ; comments
- Label is a reference to the memory address of this instruction.
- Mnemonic represents the operation to be performed.
- The number of operands varies, depending on each specific instruction. Some instructions have no operands at all.
 - Typically, operand1 is the destination register, and operand2 and operand3 are source operands.
 - operand2 is usually a register.
 - operand3 may be a register, an immediate number, a register shifted to a constant amount of bits, or a register plus an offset (used for memory access).
- Everything after the semicolon ";" is a comment, which is an annotation explicitly declaring programmers' intentions or assumptions.



ARM Instruction Format - Example

label mnemonic operand 1, operand 2, operand 3; comments





Types of instructions supported

- Arithmetic and logic
 - Add, Subtract, Multiply, Divide, Shift, Rotate
- Data movement
 - Load, Store, Move
- Compare and branch
 - Compare, Test, If-then, Branch, compare and branch on zero
- Miscellaneous
 - Breakpoints, wait for events, interrupt enable/disable, data memory barrier, data synchronization barrier

Arithmetic and Logical

- -Shift
 - LSL (logic shift left), LSR (logic shift right), ASR (arithmetic shift right),
 ROR (rotate right), RRX (rotate right with extend)
- Logic
 - AND (bitwise and), ORR (bitwise or), EOR (bitwise exclusive or), ORN (bitwise or not), MVN (move not)
- Bit set/clear
 - BFC (bit field clear), BFI (bit field insert), BIC (bit clear), CLZ (count leading zeroes)
- Bit/byte reordering
 - RBIT (reverse bit order in a word), REV (reverse byte order in a word), REV16 (reverse byte order in each half-word independently), REVSH (reverse byte order in each half-word independently)
- Addition
 - ADD, ADC (add with carry)
- Subtraction
 - SUB, RSB (reverse subtract), SBC (subtract with carry)

More Arithmetic and Logical

- Multiplication
 - MUL (multiply), MLA (multiply-accumulate), MLS (multiply-subtract), SMULL (signed long multiply-accumulate), SMLAL (signed long multiply-accumulate), UMULL (unsigned long multiply-subtract), UMLAL (unsigned long multiply-subtract)
- Division
 - SDIV (signed), UDIV (unsigned)
- Saturation
 - SSAT (signed), USAT (unsigned)
- Sign extension
 - SXTB (signed), SXTH, UXTB, UXTH
- Bit field extract
 - SBFX (signed), UBFX (unsigned)

Operation	Description	Assembler	Cycles
Add	Add	ADD Rd, Rn, <op2></op2>	1
	Add to PC	ADD PC, PC, Rm	1 + P
	Add with carry	ADC Rd, Rn, <op2></op2>	1
	Form address	ADR Rd, <label></label>	1
Subtract	Subtract	SUB Rd, Rn, <op2></op2>	1
	Subtract with borrow	SBC Rd, Rn, <op2></op2>	1
	Reverse	RSB Rd, Rn, <op2></op2>	1
Multiply	Multiply	MUL Rd, Rn, Rm	1
	Multiply accumulate	MLA Rd, Rn, Rm	1
	Multiply subtract	MLS Rd, Rn, Rm	1
	Long signed	SMULL RdLo, RdHi, Rn, Rm	1
	Long unsigned	UMULL RdLo, RdHi, Rn, Rm	1
	Long signed accumulate	SMLAL RdLo, RdHi, Rn, Rm	1
	Long unsigned accumulate	UMLAL RdLo, RdHi, Rn, Rm	1

Examples

Add example

Unified Assembler Language (UAL) Syntax

ADD
$$r1, r2, r3$$
; $r1 = r2 + r3$

Traditional Thumb Syntax


ADD
$$r1, r3$$
; $r1 = r1 + r3$

ADD
$$r1, #15$$
; $r1 = r1 + 15$



Barrel Shifter

- The second operand of ALU has a special hardware called Barrel shifter
- Barrel Shifter is a functional unit that is used to perform the Shift and Rotate Operations.
- Use Barrel shifter to speed up the application
- Example:
 - ADD r1, r0, r0, LSL #3 ; r1 = r0 + r0 << 3 = 9 × r0</p>



18 ECE- 40097

BFC and BFI

- Bit Field Clear (BFC) and Bit Field Insert (BFI).
- SyntaxBFC Rd, #Isb, #widthBFI Rd, Rn, #Isb, #width

Examples:

BFC R4, #8, #12

; Clear bit 8 to bit 19 (12 bits) of R4 to 0

BFI R9, R2, #8, #12

; Replace bit 8 to bit 19 (12 bits) of R9 with bit 0 to bit 11 from R2.

Reverse Order

RBIT Rd, Rn	Reverse bit order in a word. for (i = 0; i < 32; i++) $Rd[i] \leftarrow RN[31-i]$	
REV Rd, Rn	Reverse byte order in a word. Rd[31:24] ← Rn[7:0], Rd[23:16] ← Rn[15:8], Rd[15:8] ← Rn[23:16], Rd[7:0] ← Rn[31:24]	
REV16 Rd, Rn	Reverse byte order in each half-word. $Rd[15:8] \leftarrow Rn[7:0], Rd[7:0] \leftarrow Rn[15:8],$ $Rd[31:24] \leftarrow Rn[23:16], Rd[23:16] \leftarrow Rn[31:24]$	
REVSH Rd, Rn	Reverse byte order in bottom half-word and sign extend. Rd[15:8] ← Rn[7:0], Rd[7:0] ← Rn[15:8], Rd[31:16] ← Rn[7] & 0xFFFF	

```
LDR r0, =0x12345678; r0 = 0x12345678

RBIT r1, r0 ; Reverse bits, r1 = 0x1E6A2C48

REV16 R2, R0 ; R2 = 0x34127856
```

Examples

Suppose r0 = 0x56789ABC, find the result of the following operation.

RBIT r1, r0 REV r1, r0 REV16 r1, r0 REVSH r1, r0

$R0 = 0 \times 0101 \ 0110 \ 0111 \ 1000 \ 1001 \ 1010 \ 1011 \ 1100$

RBIT r1, r0 ; 0011 1101 0101 1001 0001 1110 01010 1010 R1 = 0x3D591E6A

$R0 = 0 \times 0101 \ 0110 \ 0111 \ 1000 \ 1001 \ 1010 \ 1011 \ 1100$

REV r1, r0 ; 1011 1100 1001 1010 0111 1000 0101 0110 R1 = 0xBC9A7856

$R0 = 0 \times 0101 \ 0110 \ 0111 \ 1000 \ 1001 \ 1010 \ 1011 \ 1100$

REV16 r1, r0 ; 0111 1000 0101 0110 1011 1100 1001 1010 R1 = 0x7856BC9A

$R0 = 0 \times 0101 \ 0110 \ 0111 \ 1000 \ 1001 \ 1010 \ 1011 \ 1100$

REVSH r1, r0 ; 0xffff 1011 1100 1001 1010 R1 = 0xFFFFBC9A

Move Between Registers

MOV	Rd ← operand2	
MVN	Rd ← NOT operand2	
MRS Rd, spec_reg	Move from special register to general register	
MSR spec_reg, Rm	Move from general register to special register	

```
MOV r4, r5 ; Copy r5 to r4

MVN r4, r5 ; r4 = bitwise logical NOT of r5

MOV r1, r2, LSL #3 ; r1 = r2 << 3

MOV r0, PC ; Copy PC (r15) to r0

MOV r1, SP ; Copy SP (r14) to r1
```

Multiply examples

```
x = x * y + z - x;
```

```
Solution:

; r0 = x, r1 = y, r2 = z

MLA r2, r0, r1, r2 ; r2 = r2 + r0 * r1, z = x*y + z

SUB r0, r2, r0 ; x = z - x
```

//Alternatively we could first multiply x and Y, subtract z and x and then add together

```
; r0 = x, r1 = y, r2 = z

MUL r1, r0, r1 ; r1 = r0*r1; y = x *y

SUB r0, r2, r0 ; x = z - x

Add r0, r0, r1 ; r0 = r0 + r1; x+y
```

Division examples

```
x = x \% y; x and y are unsigned numbers
Solution:
; r0 = x, r1 = y
UDIV r2, r0, r1 ; r2 = floor(r0/r1)
MLS r0, r1, r2, r0 ; r0 = r0 - r1*r2
```

Logical Operation examples

```
Lets assume, r0 = 0x0F0F0F0F, and r1 = 0xFEDCBA98
```

```
EOR r3, r1, r0 ; Exclusive OR R3 = 0xF1D3B597
```

ORR r3, r1, r0 ; Simple OR R3 = 0xFFDFBF9F

AND r3, r1, r0; Simple AND

R3 = 0x0E0C0A08

BIC r3, r1, r0; Bit clear, Logical AND NOT R3 = 0xF0D0B090

AREA	.section	Make a new block of data or code
ENTRY		Declare an entry point where the program execution starts and command line for GNU
ALIGN	.ba lign	Align data or code to a particular memory boundary
DCB	.byte	Allocate one or more bytes (8 bits) of data
DCW	.hword	Allocate one or more half-words (16 bits) of data
DCD	.word	Allocate one or more words (32 bits) of data
SPACE	.org	Allocate a zeroed block of memory with a particular size
FILL	.fill	Allocate a block of memory and fill with a given value.
EQU	.equ	Give a symbol name to a numeric constant
RN	.req	Give a symbol name to a register
EXPORT	.global	Declare a symbol and make it referable by other source files
IMPORT	.global	Provide a symbol defined outside the current source file
INCLUDE/GET	include	Include a separate source file within the current source file
PROC	function	Declare the start of a procedure
ENDP	.endp	Designate the end of a procedure
END	.end	Designate the end of a source file

Assembler Directive for ARM and GNU

ARM example

```
; Simple ARM syntax example
; Iterate round a loop 10 times, adding 1 to a register each time.
    AREA | |.text | |, CODE, READONLY, ALIGN=2
main PROC
    MOV r0, #0x64; r0 = 100
    MOV  r1,#0  ; r1 = 0
         test_loop ; branch to test_loop
loop
           r0,r0,#1 ; Add 1 to r0
    ADD
    ADD
           r1,r1,#1 ; Add 1 to r1
test_loop
           r1,#0xa; if r1 < 10, branch back to loop
    CMP
    BLT
          loop
    ENDP
    END
```

GNU example

```
// Simple GNU syntax example
// Iterate round a loop 10 times, adding 1 to a register each time.
     .section .text,"x"
     .balign 4
main:
    MOV r0,#0x64 // r0 = 100
MOV r1,#0 // r1 = 0
           test_loop // branch to test_loop
loop:
             r0,r0,#1 // Add 1 to r0 r1,r1,,#1 // Add 1 to r1
     ADD
     ADD
test_loop:
             wr14,#0xa // if r1 < 10, branch back to loop
     CMP
     BLT
            loop
     .end
```

Bit-Band Operation

- Bit-band operation allows a single load/store operation to access a single bit in the memory
- For example, to change a single bit of one 32-bit data
 - Normal operation without bit-band (readmodify-write)
 - Read the value of 32-bit data
 - Modify a single bit of the 32-bit value (keep other bits unchanged)
 - Write the value back to the address
- Bit-band operation
 - Directly write a single bit (0 or 1) to the "bitband alias address" of the data

Example

```
;Read-Modify-Write Operation
```

```
LDR R1, =0x20000000 ;Setup address
```

LDR RO, [R1] ;Read

ORR.W R0, #0x8 ;Modify bit STR R0, [R1] ;Write back

;Bit-band Operation

LDR R1, =0x2200000C ;Setup address

MOV RO, #1 ;Load data

STR RO, [R1] ;Write

Cortex-M4 summary

Architecture	Armv7E-M
Bus Interface	3x AMBA AHB-Lite interface (Harvard bus architecture) AMBA ATB interface for CoreSight debug components
ISA Support	Thumb/Thumb-2
Pipeline	3-stage + branch speculation
DSP Extension	Single cycle 16/32-bit MAC Single cycle dual 16-bit MAC 8/16-bit SIMD arithmetic Hardware Divide (2-12 Cycles)
Floating-Point Unit	Optional single precision floating point unit IEEE 754 compliant
Memory Protection	Optional 8 region MPU with sub regions and background region
Bit Manipulation	Integrated Bit Field Processing Instructions & Bus Level Bit Banding
Interrupts	Non-maskable Interrupt (NMI) + 1 to 240 physical interrupts
Interrupt Priority Levels	8 to 256 priority levels
Wake-up Interrupt Controller	Optional
Sleep Modes	Integrated WFI and WFE Instructions and Sleep On Exit capability Sleep & Deep Sleep Signals Optional Retention Mode with Arm Power Management Kit

Further reading

- Cortex-M4 Technical Reference Manual:
 http://infocenter.arm.com/help/topic/com.arm.do
 c.ddi0439d/DDI0439D cortex m4 processor r0p1 tr
 m.pdf
- Cortex-M4 Devices Generic User Guide:
 http://infocenter.arm.com/help/topic/com.arm.do
 cortex m4 dgug.pdf
- About the processor

https://developer.arm.com/ip-products/processors/cortex-m/cortex-

m4#:~:text=The%20Arm%20Cortex%2DM4%20processor,control%20and%20signal%20processing%20capabilities.

Next Lesson Topic

- Big and Little Endian
- Load and Store
- Flow Control
- Code examples
- C and Assembly