MPEZ44 Fall 2023

August 21 (Monday)

Organizational Meeting.

1. The Greenshot" is posted on Note: Bring your Laptop Computer to the class.

https://github.com/hualili/CMPE244

Course and Contact Information

Instructor: Harry Li, Ph.D. Professor, Computer Engineering De-

State University

Office Location: Engineering Building 267A

(408) 924-4060 (650) doo-1126 Telephone:

Email: hua.li@sjsu.edu

Class Days/Time: Mondays and Wednesdays, 4:30 pm – 5:45 pm, Aug

Office Hours: Mondays and Wednesdays, 3:00 pm – 4:00 pm

Classroom: Engineering Building Room 295

Prerequisites: CMPE 180A and CMPE 180D, classified standing, c

Artificial Intelligence or Computer Engineering or S-

majors only.

2. Emphasis on Posix O.S. LINUX Open Source O.S. & Device Privers
Trugramming and Development. Scalability of Ventical Solution.

Course Description

Experiments dealing with advanced embedded software programming concepts, interfacing techniques, hardware organization, and software development using embedded systems. Individual projects.

3. (west tornat: In-Person.

Hands-ON Class. Prototype System

NUDA JOSON NAND. (JPU (128)

4 GB Version Tetrack

Option Z. BroadCom Pie3B+, Pie4.

mption3. RIX-V FPGA Dev. Board. Mas Limitted

LFC17tg, PCTOS. NXP DOV. FORUM. May Not Meet the Need for Dur Project

Selection Decision in I week

4. Text Book & References

Set I: Datasheet(5), CPU Datasheet, Developer Guide, Set I: NUDA Daveloper Forum, Set II: PPTS, Sample Gode, Handouts in the Class githoub.

Course Materials

Instructor's teaching materials and online resources.

- 1. Professor's git: https://github.com/hualili/CMPE244
- 2. Jetson NANO Jetpack download https://developer.nvidia.com/embedded/downloads

Other Equipment / Material

- Hardware Equipment: You may choose any one of the following options. For detailed selection information, I will cover it in the introduction session of the class. Option 1. Nvidia Jetson NANO Board with minimum 2 GB RAM; or Option 2. Pie 3B+, or Pie 4; Option 3: Nvidia Jetson Tx2 developer kit; or Option 4: LPC1769 CPU Module:
 https://www.mouser.com/NXP-Semiconductors/Embedded-Solutions/Engineering-Tools/Embedded-Processor-Development-Kits/Development-Boards-Kits-ARM/_/N-cxd2t?
 P=1z0jm4m&Keyword=LPC1769&FS=True&gclid=Cj0KCQjwqKuKBhCxARIsACf4XuHyN8WfqtQ24WGgtoMdKd6n-kl7c-YNz-r1hTcPt0ErdZN62jrMQmgaAtXZEALw_wcB_ or Option 5: Samsung ARM11 developer platform.
- 2. Linux Host Machine (Ubuntu 18.04) .

2021F-114-handout-gpi... Add files via upload


2021F-114b-pwm-nano... Add files via upload


1. Somester ID


A & B

Whe: Tegarding the Selection of A & C

A Target Platform:








Note: The CPU Block Diagram for LPC1769 is a Sample for the Rest of the target platforms, e.g. Pie34; Sam's ARMII; NUTA JOSSON NANO

Notez:





MPEZYY F2023 Example: Connection to (Embedded) Software Architecture OpenCU IP Stack HAL "Char Hardware Devices! as tiles. GPP Abstraction Layer Embedded Sytware; Kernel V.S. Fig.1. Device Aniver - ARPS for - Phone Note: Data Size for 1080P Android Phone Image 012 7207 ZO CANVASISMP. Honesty Pledge August 28 (Monday) 30 Target platform - Mine upgrade Note: 10 Brief Description DN to Enable RTC By Adding ON-Board Battery the Scape of Semester-Long

Project.

F2023

Example: Continuation of the Introduction/ Subedded Software Architecture.





		•		7	
	August 30 (Wed)	trefix +	Root		
	Note: 1° CANVAS is MP.	Trefix 1 3 Letters	3 betters.		
	Honesty Pledge to Be Signed	GPX			
		P.C. F	The state of the s		
	By this Friday 11:59 pm.	(renx	12 7		
-	Z° Please Bring the target	Frefix Forthe multiple we have GPB	L GPPS,		
	platform to the Class. Next	Wehave			
	Midnesday.	<u> </u>	CON GPI GON	, etc.	
	30 (10) oblar Regularments In Zwe	ek Suppose We	. Want 47 us	ie GPV Fin	
٦	Wednesday. 30 (Written Requirements) in Zwe	5 as an 0	whent to th	an owloff	
_	Bringupyour turget platform	LED.		•	
	By Down Loading Kernel 0.5.	Design 2nd St	17 17		
-	Image to A milro-SD Card,				
	then boot the System.	CIPA	DAT		
-	then Screen Capture with your			יאי	nd
1	personal identifier, Submit it		Root	vo -	<u> </u>
	ON CANVAS.	r3		V3 1	
	40 Create A Chatlapt	Tá I		111	
	Account, Python interfine				
	/ .	GPOOT			
	to Chat GPT (3.5) API.	0×2009_C004		Pin5	
- */	imple: Continued.	7 (40 "\"	@15 to 000	tent bonical	_
, •	Naming Convention of the	, , , , , , , , , , , , , , , , , , ,) .	VVII 33 ()	
	Control & Configuration Register.		itigh.		
	By John Henessy Golden Rules			• • •	
	(1, 2, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1, 1,	`	JW.		
	Uniformity, 1, 3+3	#define	GPOCIN GPO DAT	<u>ښ</u>	
	1 segment of		GP9 DOTT	\sim	
	Lorthogonality Naming Conv	CN-1 MA			

galget - ARM - Corret

Porting .

Septb (Wed).

Note: 1º Target Board

Inspection:

Purpose: J4/ Connector

Ref: ON the github.

2021F-114~

Harry Li, Ph.D. NVIDIA Jetson Nano J41 Header Pinout https://www.jetsonhacks.com/nvidia-jetson-nano-j41-header-pinout/


Note: I2C and UART pins are connected to hardware and should not be reassigned. By default, all other pins (except power) are assigned as GPIO. Pins labeled with other functions are recommended functions if using a different device tree.


1. take Pin 1 Vcc (3.3V) and Pin 39 GND to test out LED, make sure you can light up a LED with 220 Ohm resistor in series.



2 (I2C_2_SDA 5.0 VDC GND I2C 2 SCL UART 2 TX AUDIO MCLK GND UART_2_RX UART_2_RTS I2S_4_SCLK gpio79 SPI_2_SCK LCD_TE SPI_2_CS1 3.3 VDC SPI_2_CS0 SPI_1_MOS SPI 2 MISO SPI_1_MISO SPI_1_SCK SPI_1_CS0 gpio19 SPI_1_CS1

Note: 1 Power Pins NoteZ GPIO CTU Functionality JAI PINS 1 GNO: 6/9/25/30 apioza チャート Vont 373 VOC 5VDC Pin / PinZy J41-40 9P1078 Vin: Jzs (5Aorhigher @5Ubc)





GPI	0		, Note	<u>-</u>		USer Some	Code
7 1PC	71 nS	CPU Functionality			Code	User Some	VV0G
J41	-12	api079	Out	two		Kemel som	re bode
J41-	40	97°078	In	nt		_	
					Takeas	reference Desi	4
					from Ar	zmV.Savisviv	G CTV.
	JL.	Target	7 Platfor	cm	Pal. So	imple code Tas b	ven
	/ \	NA NA	ino Pie		-	sted on the girt	hwb.
		AH ~	Stee	eper Moto	r (loo		
<				~\$5	harryghan	rry-laptop:/opt/Frie	endlvARM/min
	X	LV-I	P	0	2022s-104	4d-userSpace-gpio.c rry-laptop:/opt/Frie	<pre>led led.c</pre>
_	J41	Olp		NEMP			
				1	10.		
Note: Fo	rm Z-7e	vson team for	С	MPE242-Eml	bedded-Systems- /	2022S / 2022S-104d-us	erSpace-gpio.c
		r Long Project.		🍓 hualili A	dd files via upload		
	_	are longer		Code Blan	me 37 lines (30 lo	oc) · 642 Bytes 👸 Co	de 55% faster with Git
J. 00 (2 #i	nclude <stdio.h> nclude <stdlib.h> nclude <unistd.h></unistd.h></stdlib.h></stdio.h>		
	1 / 3,	vsors/Actualins) Secuation		4 #1 5 #1	nclude <sys ioctl.h=""> nclude <sys types.h=""></sys></sys>		
	Device	Driver Kernels	RMC	0 #1 7 #i	nclude <sys stat.h=""></sys>		
	•	TWESS	<u> </u>	<	Sept.11 (mo	ndey\	
	4	Troless	thong				
	,	servar				work, Due in 1-	
	1				To Be Poste	d on Line today	, ;
	\bigvee	14			a. Bring w	pthe farget, S With Revsonn	Screen
	2mmst 1	-hune AFPs.			Capture	With Personal	Identitier.
	Chutch	PT3.5 API+PV	thon Int	éfene	b. GPIN TO	esting (Rythan t	Hardwave
					Circuit).	1 Input Tes	ting CKT.
(-	example:	Sample Code for Driver	GPP D	આં(૧		ng CKT. (2) Coo	
		Alvinai		•	Rython.	7	
	I .						

Note Z: B.o.M. [Bill of Material) C. Smartphone sithane
for the class (Project
a. Motor (Stepper Motor. NEMA.



Nema17 Stepper Motor \$8.99 Amazon.com

2 BLDC
Brushless DC
motor

Platform. Ubuntu Linux.

18.04 NVDA JodPack (0.5.)




350W Brushed Electric Motor



10 Inch Hub Motor 1000w, ...



48V 500W Wheel Motor ...



NOAJEKONINAND Brend Board

b. Motor Dive Unit.



EASON Stepper Motor \$9.69

Amazon.com



SparkFun Electronics ...

\$12.09 DigiKey



WWZMDiB A4988 Stepper

\$7.99 Amazon.com



Pololu Corporation

\$8.49 DigiKey



Board.

STEPPERONLINE
CNC Stepper Motor
Driver 1.0-4.2A
20-50VDC 1/128

```
Example: Continuentlaw on Linux D.D.
                           amsung). Note: userspace Keunelspace code
Code Samples,
       harry@harry-laptop:/opt/FriendlyAPM/mini6410$ cd linux/
       harry@harry-laptop:/opt/Friendly/RM/mini6410/linuxs ls
                            examples
       arm-qte-4.7.0
                                                u-boot-mini6410
       arm-qt-extended-4.4.3 linux-2.6.
                                                x86-qte-4.6.1
       arm-qtopia
                            rootfs_qtopia_qt4
                                                x86-qt-extended-4.4.3
       busybox-1.17.2
                            rootfs_qtopia_qt4-s x86-qtopia
       harry@harry-laptop:/opt/FriendlyARM/mini6410/linux$
       Cet: Sample Code ON github.
       harry@harry-laptop:/opt/FriendlyARM/mini6410/linux/examples/leds$ ls
       2022s-104d-userSpace-gpio.c led led.c led.c~ Makefile Makefile~
      harry@harry-laptop:/opt/FriendlyARM/mini6410/linux/examples/leds$
                                               Note 1: Char Device. Open the Device
                                                         just like a file.
                     fd = open("/dev/leds0", 0);
if (fd < 0) {
           23
           24
                      if (fd < 0) {
           25
                             fd = open("/dev
           26
                      if (fd < 0) {
           27
                                                                     Kornel (0.5. Image)
Path to the Dovice.
           28
                             perror("open device leds");
           29
                             exit(1);
           30
           31
                                                                       the Device Oniver Cambe
                     ioctl(fd, on, led_no);
                   close(fd);
                                                                       either integrated as the
                    for passing control parameter(s)
to the Device for Control Action.
                                                                       Whole Kernel Image OR
                                                                       module (Installed (Templed)
Notes. Close it, when Done !
```

Build Kerneltmage using Android. Menuconfig DVDA, Broadcom Smunt phones

```
🛿 🖨 📵 harry@harry-laptop: /opt/FriendlyARM/mini6410/linux/linux-2.6.38
                                        Linux/arm 2.6.38 Kernel Configura
    Arrow keys navigate the menu. <Enter> selects submenus --->. Highlighted letters are hotkeys. Pressing
    <Y> includes, <N> excludes, <M> modularizes features. Press <Esc> to exit, <?> for Help, </> for
    Search. Legend: [*] built-in [ ] excluded <M> module < > module capable
                      General setup --->
[*] Enable loadable module support --->
                       -*- Enable the block layer -
                           System Type --->
                          Bus support --->
                          Kernel Features --->
                           Boot options --->
                          CPU Power Management --->
                          Floating point emulation ---> Userspace binary formats --->
                           Power management options --->
                       [*] Networking support --
                           Device Drivers --->
                          File systems --->
                           Kernel hacking --->
                           Security options --->
                       -*- Cryptographic API --->
                          Library routines --->
                          Load an Alternate Configuration File
                           Save an Alternate Configuration File
                                           <Select>
                                                       < Exit >
```

config - Linux/arm 2.6.38 Kernel Configuration Device Drivers Arrow keys navigate the menu. <Enter> selects submenus --->. H <Y> includes, <N> excludes, <M> modularizes features. Press <Es Search. Legend: [*] built-in [] excluded <M> module < > mod SCSI device support ---> < > Serial ATA and Parallel ATA drivers ---> [] Multiple devices driver support (RAID and < > Generic Target Core Mod (TCM) and ConfigFS [*] Network device support [] ISDN support. < > Telephony support Input device support -Character devices ---> <*> I2C support ---> [] SPI support ---> PPS support --->

-*- GPIO Support --->

< > Dallas's 1-wire support ---> < > Power supply class support ---> <*> Hardware Monitoring support --->

```
Note 4. Menuconfix controls how the Kernel Image is Birlt.
Here, the "Char" Device Drive Can be scheded Deselected.
b. Use "Space Bar" to toggle between 3 options.
              Arrow keys navigate the mend.
                                              <tnter> selects submenus --->. Hig
              <Y> includes, <N> excludes, <M> modularizes features. Press <Esc>
              Search. Legend: [*] built-in [ ] excluded <M> module < > modul
                                      Virtual terminal
                                  Support for binding and unbinding console
                                     dev/kmem virtual device support
                                   MS LED Support for Mini6410 GPIO LEDs
                                  <N>> Harry 2021-2-3: I2C sensor module
                                  <M>> Harry: 2016-Feb-22, CMPE 242 Mini6410 module
                                  <M>> Harry: Mini6410 Test module
                                  <M>> Harry: Mini6410 PWM2 module
                                  < > Buttons driver for FriendlyARM Mini6410 deve
                                  < > Buzzer driver for FriendlyARM Mini6410 devel
                                  < > ADC driver for FriendlyARM Mini6410 developm
                                  [ ] Non-standard serial port support
                                  < > GSM MUX line discipline support (EXPERIMENTA)
                                      Serial drivers --->
                                  -*- Unix98 PTY support
                                       Support multiple instances of devpts
```

[*] Legacy (BSD) PTY support

[] ARM JTAG DCC console


(16) Maximum number of legacy PTY in use

TPMT top-level message handle

Note 5 Folder for the "Char" D.D., The apio (leds) Device Priver 2025-104e Tharry@harry-laptop:/opt/FriendlyARM/mini6410/linux/linux-2.6.38/drivers\$ cd char CMPEZ4Z) harry@harry-laptop:/opt/FriendlyARM/mini6410/linux/linux-2.6.8/drivers/char\$ 20-2021S-9-mini6410_pwmHarry.c ip2 misc.c 2q misc.o SCC. agp isicom.c mmtimer.c scx20 amiserial.c istallion.c modules.built ser i apm-emulation.c Kconfia modules.order ser a applicom.c lp.c ser a applicom.h Makefile moxa.h ser i bfin_jtag_comm.c Makefile-backup mspec.c seri bfin-otp.c mbcs.c mwave snsc briq_panel.c mbcs.h mxser.c bsr.c mem.c mxser.h snsc built-in.o mem.o _gpio.c cd1865.h mini6410_adc.c spec cyclades.c mini6410_adc.mod.c nvram.c spec. digi1.h mini6410_adc.o nwbutton.c stal digiFep1.h nwbutton.h mini6410_buttons.c sxbo digiPCI.h mini6410_buttons.o nwflash.c SX.C mini6410_hello_module.c ds1302.c pc8736x_gpio.c sx.h mini6410_hello_module.ko ds1620.c pcmcia sxwii mini6410_hello_module.mod.c dsp56k.c ppdev.c SVNC mini6410_hello_module.mod.o mini6410_hello_module.o dtlk.c ps3flash.c sync efirtc.c ramoops.c sync epca.c mini6410_leds.c random.c tb02 epcaconfig.h random.o tlcl

mini6410 leds.ko

F2023



0011 = I2S CDCLK[1]

0101 = Reserved

0111 = Reserved

0100 = AC97 RESETn

0110 = Reserved

Notes. From the D.D. Code, GPE1 is utilized for the

I/O function

GPE CON[7:4] = 0001

	0. 000		DU.	Description	
	GPE0	[3:0]	0000 = Input 0010 = PCM SCLK[1] 0100 = AC97 BITCLK 0110 = Reserved	0001 = Output 0011 = I2S CLK[1] 0101 = Reserved 0111 = Reserved	
5	GPE1	[7:4]	0000 = Input 0010 = PCM EXTCLK[1] 0100 = AC97 RESETn 0110 = Reserved	0001 = Output 0011 = I2S CDCLK[1] 0101 = Reserved 0111 = Reserved	
GPIO)	GPE2	[11:8]	0000 = Input 0010 = PCM FSYNC[1] 0100 = AC97 SYNC 0110 = Reserved	0001 = Output 0011 = I2S LRCLK[1] 0101 = Reserved 0111 = Reserved	
	GPE3	[15:12]	0000 = Input 0010 = PCM SIN[1] 0100 = AC97 SDI 0110 = Reserved	0001 = Output 0011 = I2S D[1] 0101 = Reserved 0111 = Reserved	
	GPE4	[19:16]	0000 = Input 0010 = PCM SOUT[1] 0100 = AC97 SDO 0110 = Reserved	0001 = Output 0011 = I2S DO[1] 0101 = Reserved 0111 = Reserved	
	HOW	W			

Question: Make GPEI as an output pin, But Keep the Rest unchanged?

Sept. 18 (Monday)

Note: 1 Homework Posted DN the

CANVAS.

20 Homework, Due Sept. 27

(Wed), TWM Testing.

O Enable FWM Device Driver Via Driver Mapping utility By NOA

(2) Test PWM Owhert By Changing from ZKHZ to 50 Hz; By Changing

Duty Cycle from 5% to 90%.

Then, Observe it's onlynt

Note: Owkard with ZZZZ upn Transistor

to drive a LED. (see the

details in the Class PPT ON

github). (U.S.)

Note: Prepare the Source Distribution

Download to build Kernel

Image from the distribution.

(1~12 week)

Note: Ref. Ou Smartphone Apps.

And void ATPs Development.

191 Note: Device Oniver Sample Code ZUZ3F-104-gpio-command-line-202... Add files via upioad 2023F-105a-2022s-104d-userSpace... Add files via upload 2023F-105b-mini6410_leds.mod.c Add files via upload 2023F-106a-CMPE244-#190h-1d-A... Add files via upload Note: Install Android Studio ON Your Lastop. 2023F-106a-CMPE244-#190h-1d-Android-Test-Environment-v2-YY 2023-9-18.pdf Install Android Studio on Ubuntu 18.04 (9/15-8/3/2023) nnn-n-Android-Development-HelloWorld-Calculator-v2-XW-2023-7-7.odt 1.Check Java version 3. Once installed, double click the icon to start the enjdk 11.0.19 2023-04-18 penJDK Runtime Environment (build 11.0.19+7-post-Ubuntu-Oubuntu118.04.1) penJDK 64-Bit Server VM (build 11.0.19+7-post-Ubuntu-Oubuntu118.04.1, mixed mod sharing) cole@nicole-GS65:-S 2. Install Android Studio using snap \$ snap find "android-studio" \$ sudo snap install android-studio -- classic ricole@nicole-GS65:-\$ snap find "android-studio" Hame Version Publisher ndroid-studio 2022.2.1.19 ndroid-studio-canary 2022.1.1.7 nicole-GS65:~\$ sudo snap install android-studio --classic base) harry@harrys-gpu-laptop:~\$ sudo snap install android-studio --classic [sudo] password for harry: android-studio 2022.3.1.18 from Snapcrafters tinstalled Note: Team Troject (1) Formation of The Team; (2) Selection of Sment; home for the ATP 3 Stepper motor GPIO Command Line https://jetsonhacks.com/2019/06/07/jetson-nano-qpio/ Drive Board and Stepper motor. # Map GPIO Pin # gpio79 is pin 12 on the Jetson Nano \$ echo 79 > /sys/class/gpio/export Example: GPIO & PWM. # Set Direction \$ echo out > /sys/class/gpio/gpio79/direction # Bit Bangin'! \$ echo 1 > /sys/class/gpio/gpio79/value 2073F-104 . \$ echo 0 > /sys/class/gpio/gpio79/value # Unmap GPIO Pin

\$ echo 79 > /sys/class/gpio/unexport

\$ cat /sys/kernel/debug/gpio

Query Status

```
DWM
     Z02/F-1146-~
                                  Middem Exam, and Find Exam are
                                   Basedon Analyzing & Executing your
   Note: Establish Remote
    Access to your target,
                                  Implementation code on the target that form;
   e.g. Laptop to Access
                                   & Bring goin Homenark with the
  Your target Board.
                                    target Brand to the Classon
 A Next Monday, Show + Tell
                                   Wednesday for Rnick Inspection,
    in class
                                    Strow Ftell; (Sopt. 27, Wednesday)
 Sept 25 (monday)
                                   Note: HOMI Monitoris optional,
  (Vote: 10 Nydoted git hub
                                      To Be Able to Boot Your System's
   Sample code.
                                      the requirement.
  (1) Z0Z3F-107.
                                Consider the github Sample code.
   Booting Jotson WAND
   Without HDMI
                                   12ef: -105a, User Sport Program.
                                           for GPID. OFEN()
Lichse()
    Connection.
  (2) -2023× 405a 40
     2023F-105f.
                                       -(v5b &c)
                                                          Device NAME
   User Some S g Pro
Sample code Spwm
                                                              r. User spart
Program.
   Kernel Spore , gpio
   Danice Priver LAMM.
                                                                 (make
                                                              mennunting
Forthe Kennel
                                         unsigned tmp; case \theta:
Target Brave Connection
                                                              Driver
Coofigniation.
Requirements.
  a. The Demofshow of Tell in
Class is veguined, Also
```

```
Koonf
```

R Kernel configmation for make menn compig.

```
🔊 🗇 📵 harry@harry-laptop: /opt/FriendlyARM/mini6410/linux/linux-2.6.38/drivers
  81 source "drivers/hid/Kconfig"
                                                   Kernel folder/driver folder
  83 source "drivers/usb/Kconfig"
  85 source "drivers/uwb/Kconfig"
  87 source "drivers/mmc/Kconfig"
  89 source "drivers/memstick/Kconfig"
  91 source "drivers/leds/Kconfig"
  93 source "drivers/nfc/Ksonfig"
  95 source "drivers/accessibility/Kconfig"
      if (argc != 3 || sscanf(a/gv[1], "%d", &led_no)
                         on < 0 \mid / on > 1 \mid \mid led no < 0
                fprintf(stderr,/"Usage: leds led_no 0|1"
                exit(1);
      }
       fd = open("\dev/leds0", 0);
       if (fd < 0) }
                fd = open("/dev/leds", 0);
       if (fd < 0) {
                perror ("open device leds"); to SPZ Naming Convention Addr. e.g.
 Note: 10
35 static long sbc2440_leds_ioctl(struct file *filp, unsigned
37
          switch(cmd) {
38
                 unsigned tmp;
          case 0:
39
40
          case 1:
                  if (arg > 4) {
                         return - INVAL;
42
                                                 S Bitwise Operations.
43
                  tmp = readl(SC64XX\_GPKDAT);
45
                  tmp |= ((!cmd)) < (4 < arg)
46
47
                  writel(tmp.
                             S3C64XX GPKDAT)
                 //printk (DEVICE_NAME": %d %d\n", arg, cmd);
48
                 return Θ;
          default:
50
51
                 return -EINVAL;
52
53 }
```

CMPEZ44

TP FZ0Z3.

I TOWARDS

GPEDAT[4:0]

GPEDAT[0] OUT.

× Grel

Initial State

(O/P)

Gredat [1] IN

GPEDAT	Bit	Description
GPE[4:0]	. ,	When the port is configured as input port, the corresponding bit is the pin state. When the port is configured as output port, the pin state is the same as the corresponding bit. When the port is configured as functional pin, the undefined value will be read.

Note: Such bit (pin) can be set as an input or ordered

By GRECON.

PO 320.

. 44	JW.				
GPDCON Bit		Des	cri ption		
Ε0	[3:0]	0000 = Input	0001 = Output		

GPE0	[3:0]	0000 = Input 0010 = PCM SCLK[1] 0100 = AC97 BITCLK 0110 = Reserved	0001 = Output 0011 = I2S CLK[1] 0101 = Reserved 0111 = Reserved	0000
GPE1	[7:4]	0000 = Input 0010 = PCM EXTCLK[1] 0100 = AC97 RESETN 0110 = Reserved	0001 = Output 0011 = I2S CDCLK[1] 0101 = Reserved 0111 = Reserved	0000
GPE2	[11:8]	0000 = Input 0010 = PCM FSYNO[1] 0100 = AC97 SYNC 0110 = Reserved	0001 = Output 0011 = I2S LRCLK[1] 0101 = Reserved 0111 = Reserved	0000
GPE3	[15:12]	0000 = Input 0010 = PCM SIN[1] 0100 = AC97 SDI 0110 = Reserved	0001 = Output 0011 = I2S DI[1] 0101 = Reserved 0111 = Reserved	0000
GPE4	[19:16]	0000 = Input 0010 = PCM SOUT[1] 0100 = AC97 SDO 0110 = Reserved	0001 = Output 0011 = I2S DO[1] 0101 = Reserved 0111 = Reserved	0000

Find the Binary Tattern to Set these Zpins.

GPELON [3:1] = 000 (0/2)

GRECONT: 4] = 0000 (T/P)

for init & Config.

Define Bitwise Operation mark

20P ==

Maskto Be Designed

GPECON

Designthe Binary Pattern.