

#### CSSE2010/CSSE7201 Lecture 20

## **Assembly**

School of Information Technology and Electrical Engineering
The University of Queensland



#### **Admin**


- Quiz 9 is due on Friday of this week
- Assignment 2 will be released Tuesday
  - CSSE7201 students will have an additional theoretical questions part which will be released separately and need to be submitted separately

			1/		p	( 10111) = 1 000/	
Semester Break							
10	Mon-Tue	04-05 Oct	18 Serial I/O - Pre-recored due to public holiday on 4 Oct	15	AVR Interrupts	Quiz 8	
	Wed-Fri	06-08 Oct	19 More on Input-Output on AVR (6 Oct)	16	Serial I/O and ADC	(4pm, 8 Oct)	
11	Mon-Tue	11-12 Oct	20 Assembly Process (11 Oct)	17	SPI/Communication, Assignment 2 released	Quiz 9	
	Wed-Fri	13-15 Oct	21 Compilation and Linking Process (13 Oct)			(4pm, 15 Oct)	
12	Mon-Tue	18-19 Oct	22 Memory and Disks (18 Oct)			Quiz 10	
	Wed-Fri	20-22 Oct	23 File System and Busses (20 Oct)		Assignment 2	(4pm, 22 Oct)	
13	Mon-Tue	25-26 Oct	24 Floating Point Numbers (25 Oct)			Assignment 2	
13	Wed-Fri	27-29 Oct	25 Final Exam Review (27 Oct)			(4pm, 1 Nov)	
Revision week - a 2-hour exam review session might be held							
Final Exam during the examination period, 2 hour invigilated exam, IN: paper-based on campus exam, EX: Proctor U online exam							



#### From Lecture 1

#### **Structured Computer Organisation**





#### Previously ... Today...

- Previously
  - Many assembly language and instruction examples
  - The binary equivalent of the instruction machine code.
- Today
  - Assembly language more than instructions
  - Assembly How does an assembly language program get turned into machine code?



### **Assembly Language Format**

formula: Idi r20, i ; register r20 = i

- Statements have 4 parts (called fields):
  - a field for label
  - a field for operation (opcode)
  - a field for operand(s)
  - a field for comments
- Labels needed so statements can be jumped to, and so that data can be referenced
- A label usually starts in column 1
- Some assemblers require a semicolon to indicate end of a statement, others don't



#### **Assembly Language Format**

- Opcode has symbolic abbreviation for an instruction opcode
  - e.g. LDS for Load Direct from Data Space
- Operand field specifies addresses and registers used as operands of the instruction
- Register names vary from machine to machine
  - Pentium has eax, ebx, esi, edi, etc
  - Sparc has o0 .. o7, i0..i7, l0..l7, g0..g7
  - AVR has simple r0-r31
- Comments field is space for programmer to put helpful explanations
  - Only for human consumption
  - Vital for assembly language programs



#### **Assembly Language Format**

- What else do we need?
  - We need to provide other information to the assembler, e.g.
    - Where in memory the program should be put, etc.
    - Nicer names to use for registers (e.g. temp, SPH)
- A command (directive) to the assembler itself!
  - **Example:** .byte
- Precede with "."
- Called "Pseudo-instruction" or "directive"



#### **Memory Segments**

- Different types of memory are known as segments to the assembler
- Assembler directives enable code/data to be placed into different segments
- AVR has
  - Data segment (RAM)
    - Can't place values here, just reserve space (for variables)
  - Code segment (Flash)
    - Can place program code or constant data here
  - EEPROM Segment
    - Can place constants here



#### Pseudoinstructions (Directives)

- From Atmel Studio Help
  - There are more..
- These are for the Microchip Studio Assembler (AVRASM2)

Directive	Description	
BYTE	Reserve byte(s) to a variable.  Code Segment	
CSEG		
CSEGSIZE	Program memory size	
DB	Define constant byte(s)	
DEF	Define a symbolic name on a register	
DSEG	Data Segment	
DW	Define Constant word(s)	
 ENDM, ENDMACRO	EndMacro	
EQU	Set a symbol equal to an expression	
ESEG	EEPROM Segment	

Exit from file

Begin Macro

Read source from another file

Turn Macro expansion in list file on

Turn listfile generation on

Turn listfile generation off

Set a symbol to an expression

Set program origin

Conditional assembly

Conditional accombly

**EXIT** 

LIST

**INCLUDE** 

LISTMAC **MACRO** 

NOLIST

ELSE, ELIF ENIDIE

ORG

SET



#### **Pseudo-instructions**

- .byte: Reserve space; only allowed in dseg
- Segment directives .cseg and .dseg allow the text and data segments to be built up in pieces:

```
.dseg
amount: .byte 2
.cseg
formula: ...
.dseg
count: .byte 2
.db: Initialise constant in code or EEPROM segment
.dw: As above but defines a 16-bit word
```



#### **Pseudo-instructions (cont.)**

.def: Make a definition (for registers only)

```
.def ZH=r31
.def ZL=r30
```

 device: Specify the exact processor that this program is designed for

```
.device ATmega324A
```

Prohibits use of non-implemented instructions

- .include: Include a file
- .exit: Stop processing this file



#### Pseudo-instructions (cont.)

- .equ: Equate (not changeable)
   .set: Equate (but changeable)
   .equ sreg = 0x3f ; Status register
   .set io\_offset = 0x23 ; For now
   .org: Set location counter i.e. address (in any segment)
- The above all apply to the assembler built into the Atmel Studio tool.
- Other assemblers (even targeting the AVR) use different syntax



#### **Assembly Process**

- Assembly language program consists of one line statements
  - We can not always just read each statement and generate machine code
  - For example, first statement is jmp RESET
  - We don't know the address of the RESET label, so we can't generate the instruction
    - We know the opcode but not the operand
- This is called forward reference problem



#### **Two Pass Assembly Process**

- We need to process the file twice
- Pass One
  - Define all the symbols (labels etc)
- Pass Two
  - Values of symbols known
  - Can assemble each instruction
    - i.e. produce the actual machine code



varl:

var2:

mesq:

#### Two Pass Assembly Example

```
RAMEND = $08FF
         .equ
                 SPH = $3E
         .equ
                 SPL = $3D
         .equ
         .def ZH = r31
         .def ZL = r30
        jmp
                 RESET
         .dseq
         .byte
         .byte
         .cseq
         .def
                temp = r16
         .db
                 72,101,108,108,111
table:.dw
                 var1, var2
RESET:ldi
                 temp, low(RAMEND)
        out
                 SPL, temp
        ldi
                 temp, high (RAMEND)
        out
                 SPH, temp
        ldi
                 ZH, high(mesg*2)
        ldi
                 ZL, low(mesg*2)
                    ;R0 \ll M[Z]
        lpm
```



# At what program address will the instruction at label RESET be placed?

```
jmp RESET
20%4. 9
                                           jmp ISR1
                                          jmp ISR2
20% 12
                                  .dseq
                                  var1: .BYTE 1
20%C, 15
                                  var2: .BYTE 3
                                  var3: .BYTE 2
20% 18
                                  .cseq
                                  .def temp=r20
                                  message1: .DB 72,101,111,111,0
20% None of the above
                                  message2: .DB 0,65,66,68,0
```



RESET:

ldi temp, low(RAMEND)
out SPL, temp
ldi temp, high(RAMEND)
out SPH, temp