Gaze Toolset v3.2.0

Generated by Doxygen 1.8.17

| 1 v3.2.0  | 1  |
|---|----|
| 2 Toolset to Control Tobii Eye Tracker                      | 5  |
| 3 Namespace Index   | 9  |
| 3.1 Namespace List  | 9  |
| 4 Hierarchical Index  | 11 |
| 4.1 Class Hierarchy   | 11 |
| 5 Class Index   | 13 |
| 5.1 Class List  | 13 |
| 6 Namespace Documentation                                   | 17 |
| 6.1 CustomCalibrationLibrary Namespace Reference            | 17 |
| 6.2 CustomCalibrationLibrary.Commands Namespace Reference   | 17 |
| 6.3 CustomCalibrationLibrary.Converters Namespace Reference | 17 |
| 6.4 CustomCalibrationLibrary.Models Namespace Reference     | 17 |
| 6.4.1 Enumeration Type Documentation                        | 18 |
| 6.4.1.1 CalibrationEventType                                | 18 |
| 6.4.1.2 CalibrationStatus                                   | 18 |
| 6.5 CustomCalibrationLibrary.ViewModels Namespace Reference | 18 |
| 6.6 CustomCalibrationLibrary.Views Namespace Reference      | 19 |
| 6.7 GazeControl Namespace Reference                         | 19 |
| 6.8 GazeToMouse Namespace Reference                         | 19 |
| 6.9 GazeUtilityLibrary Namespace Reference                  | 19 |
| 6.9.1 Detailed Description                                  | 20 |
| 6.9.2 Enumeration Type Documentation                        | 20 |
| 6.9.2.1 ECalibrationDataError                               | 21 |
| 6.9.2.2 EGazeConfigError                                    | 21 |
| 6.9.2.3 EGazeDataError                                      | 21 |
| 6.10 GazeUtilityLibrary.DataStructs Namespace Reference     | 21 |
| 6.10.1 Enumeration Type Documentation                       | 22 |
| 6.10.1.1 CalibrationOutputValue                             | 22 |
| 6.10.1.2 GazeOutputValue                                    | 22 |
| 6.11 GazeUtilityLibrary.Tracker Namespace Reference         | 22 |
| 6.12 ShowMouse Namespace Reference                          | 23 |
| 6.13 Tobii Namespace Reference                              | 23 |
| 6.14 Tobii.Research Namespace Reference                     | 23 |
| 6.15 Tobii.Research.Addons Namespace Reference              | 23 |
| 6.16 Tobii.Research.Addons.Utility Namespace Reference      | 23 |
| 6.17 TobiiCalibrate Namespace Reference                     | 23 |
| 7 Class Documentation                                       | 25 |

| 7.1 GazeControl.App Class Reference                        | 25 |
|--|----|
| 7.1.1 Detailed Description                                 | 26 |
| 7.2 GazeToMouse.App Class Reference                        | 26 |
| 7.2.1 Detailed Description                                 | 27 |
| 7.2.2 Constructor & Destructor Documentation               | 27 |
| 7.2.2.1 App()  | 27 |
| 7.2.3 Member Function Documentation                        | 27 |
| 7.2.3.1 CompensateDrift()                                  | 28 |
| 7.2.3.2 CustomCalibrate()                                  | 28 |
| 7.2.3.3 GazeRecordingDisable()                             | 28 |
| 7.2.3.4 GazeRecordingEnable()                              | 28 |
| 7.2.3.5 MouseTrackingDisable()                             | 28 |
| 7.2.3.6 MouseTrackingEnable()                              | 29 |
| 7.2.3.7 ResetDriftCompensation()                           | 29 |
| 7.3 ShowMouse.App Class Reference                          | 29 |
| 7.3.1 Detailed Description                                 | 30 |
| 7.4 TobiiCalibrate.App Class Reference                     | 30 |
| 7.4.1 Detailed Description                                 | 30 |
| 7.5 GazeUtilityLibrary.Tracker.BaseTracker Class Reference | 31 |
| 7.5.1 Detailed Description                                 | 34 |
| 7.5.2 Constructor & Destructor Documentation               | 34 |
| 7.5.2.1 BaseTracker()                                      | 34 |
| 7.5.3 Member Function Documentation                        | 34 |
| 7.5.3.1 ApplyCalibration()                                 | 34 |
| 7.5.3.2 CollectCalibrationData()                           | 34 |
| 7.5.3.3 Dispose() [1/2]                                    | 35 |
| 7.5.3.4 Dispose() [2/2]                                    | 35 |
| 7.5.3.5 DriftCompensationEventHandler()                    | 35 |
| 7.5.3.6 FinishCalibration()                                | 36 |
| 7.5.3.7 GazeDataHandler()                                  | 36 |
| 7.5.3.8 GetFixationFrameCount()                            | 36 |
| 7.5.3.9 GetUnitDirection()                                 | 37 |
| 7.5.3.10 InitCalibration()                                 | 37 |
| 7.5.3.11 InitDriftCompensation()                           | 37 |
| 7.5.3.12 IsInitialised()                                   | 37 |
| 7.5.3.13 IsReady()   | 38 |
| 7.5.3.14 OnGazeDataReceived()                              | 38 |
| 7.5.3.15 OnPropertyChanged()                               | 38 |
| 7.5.3.16 OnTrackerDisabled()                               | 38 |
| 7.5.3.17 OnTrackerDisabledTimeout()                        | 39 |
| 7.5.3.18 OnTrackerEnabled()                                | 39 |
| 7.5.3.19 OnUserPositionDataReceived()                      | 39 |

| 7.5.3.20 PatternReplace()  | 39 |
|--|----|
| 7.5.3.21 ResetDriftCompensation()  | 40 |
| 7.5.3.22 StartDriftCompensation()  | 40 |
| 7.5.3.23 UserPositionDataHandler()                                       | 40 |
| 7.5.4 Member Data Documentation  | 40 |
| 7.5.4.1 config   | 40 |
| 7.5.4.2 DeviceName   | 41 |
| 7.5.4.3 dialogBoxTimer   | 41 |
| 7.5.4.4 driftCompensation  | 41 |
| 7.5.4.5 logger   | 41 |
| 7.5.4.6 screenArea   | 41 |
| 7.5.4.7 trackerMessageBox  | 41 |
| 7.5.5 Property Documentation   | 42 |
| 7.5.5.1 State  | 42 |
| 7.5.6 Event Documentation  | 42 |
| 7.5.6.1 DriftCompensationComputed  | 42 |
| 7.5.6.2 GazeDataReceived   | 42 |
| 7.5.6.3 PropertyChanged  | 42 |
| 7.5.6.4 TrackerDisabled  | 42 |
| 7.5.6.5 TrackerEnabled   | 43 |
| 7.5.6.6 UserPositionDataReceived   | 43 |
| 7.6 CustomCalibrationLibrary.Views.Calibration Class Reference           | 43 |
| 7.6.1 Detailed Description   | 44 |
| 7.7 CustomCalibrationLibrary.Commands.CalibrationCommand Class Reference | 44 |
| 7.7.1 Detailed Description   | 45 |
| 7.8 GazeUtilityLibrary.CalibrationDataError Class Reference              | 45 |
| 7.8.1 Member Function Documentation                                      | 46 |
| 7.8.1.1 GetCalibrationDataErrorString()                                  | 46 |
| 7.9 CustomCalibrationLibrary.Views.CalibrationFailed Class Reference     | 46 |
| 7.9.1 Detailed Description   | 47 |
| 7.9.2 Constructor & Destructor Documentation                             | 47 |
| 7.9.2.1 CalibrationFailed()  | 47 |
| 7.9.3 Property Documentation   | 48 |
| 7.9.3.1 CalibrationAbortCommand  | 48 |
| 7.9.3.2 CalibrationRestartCommand  | 48 |
| 7.9.3.3 Error  | 48 |
| 7.9.4 Event Documentation  | 48 |
| 7.9.4.1 PropertyChanged  | 48 |
| 7.10 CustomCalibrationLibrary.Views.CalibrationFrame Class Reference     | 49 |
| 7.10.1 Detailed Description  | 49 |
| 7.11 CustomCalibrationLibrary.Models.CalibrationModel Class Reference    | 50 |
| 7.11.1 Detailed Description  | 51 |

| 7.11.2 Member Function Documentation  | 51 |
|---|----|
| 7.11.2.1 GazeDataCollected()  | 51 |
| 7.11.2.2 InitCalibration()  | 51 |
| 7.11.2.3 NextCalibrationPoint()   | 52 |
| 7.11.2.4 RedoCalibrationPoint()   | 52 |
| 7.11.2.5 SetCalibrationResult()   | 52 |
| 7.11.2.6 UpdateGazePoint()  | 52 |
| 7.11.3 Property Documentation   | 52 |
| 7.11.3.1 CalibrationPoints  | 53 |
| 7.11.3.2 Error  | 53 |
| 7.11.3.3 GazePoint  | 53 |
| 7.11.3.4 Index  | 53 |
| 7.11.3.5 LastStatus   | 53 |
| 7.11.3.6 Points   | 53 |
| 7.11.3.7 Status   | 54 |
| 7.11.3.8 UserPositionGuide  | 54 |
| 7.11.4 Event Documentation  | 54 |
| 7.11.4.1 CalibrationEvent   | 54 |
| 7.12 GazeUtilityLibrary.DataStructs.CalibrationPoint Class Reference                | 54 |
| 7.12.1 Detailed Description   | 55 |
| 7.12.2 Property Documentation   | 55 |
| 7.12.2.1 GazePositionAverage  | 56 |
| 7.12.2.2 GazePositionLeft   | 56 |
| 7.12.2.3 GazePositionRight  | 56 |
| 7.12.2.4 HasData  | 56 |
| 7.12.2.5 Index  | 56 |
| 7.12.2.6 Position   | 56 |
| 7.13 CustomCalibrationLibrary.Views.CalibrationPoint Class Reference                | 57 |
| 7.13.1 Detailed Description   | 57 |
| 7.14 CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel Class Reference  | 58 |
| 7.14.1 Detailed Description   | 59 |
| 7.15 CustomCalibrationLibrary.Views.CalibrationResult Class Reference               | 59 |
| 7.15.1 Detailed Description   | 60 |
| 7.16 CustomCalibrationLibrary.Views.CalibrationResultPoint Class Reference          | 60 |
| 7.16.1 Detailed Description   | 61 |
| 7.17 CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel Class Reference | 61 |
| 7.17.1 Detailed Description   | 62 |
| 7.17.2 Constructor & Destructor Documentation                                       | 63 |
| 7.17.2.1 CalibrationResultViewModel()   | 63 |
| 7.17.3 Member Function Documentation  | 63 |
| 7.17.3.1 OnGazeToggle()   | 63 |
| 7.17.4 Property Documentation   | 63 |

| 7.17.4.1 CalibrationAcceptCommand   | 63 |
|---|----|
| 7.17.4.2 CalibrationRestartCommand  | 63 |
| 7.17.4.3 GazePoint  | 64 |
| 7.17.4.4 GazeVisibilityCommand  | 64 |
| 7.18 Tobii.Research.Addons.CalibrationValidationPoint Class Reference         | 64 |
| 7.18.1 Detailed Description   | 65 |
| 7.18.2 Property Documentation   | 65 |
| 7.18.2.1 AccuracyLeftEye  | 65 |
| 7.18.2.2 AccuracyRightEye   | 65 |
| 7.18.2.3 Coordinates  | 65 |
| 7.18.2.4 GazeData   | 65 |
| 7.18.2.5 PrecisionLeftEye   | 65 |
| 7.18.2.6 PrecisionRightEye  | 66 |
| 7.18.2.7 PrecisionRMSLeftEye  | 66 |
| 7.18.2.8 PrecisionRMSRightEye   | 66 |
| 7.18.2.9 TimedOut   | 66 |
| 7.19 Tobii.Research.Addons.CalibrationValidationResult Class Reference        | 66 |
| 7.19.1 Detailed Description   | 67 |
| 7.19.2 Property Documentation   | 67 |
| 7.19.2.1 AverageAccuracyLeftEye   | 67 |
| 7.19.2.2 AverageAccuracyRightEye  | 67 |
| 7.19.2.3 AveragePrecisionLeftEye  | 67 |
| 7.19.2.4 AveragePrecisionRightEye   | 68 |
| 7.19.2.5 AveragePrecisionRMSLeftEye   | 68 |
| 7.19.2.6 AveragePrecisionRMSRightEye  | 68 |
| 7.19.2.7 Points   | 68 |
| 7.20 CustomCalibrationLibrary.ViewModels.CalibrationViewModel Class Reference | 69 |
| 7.20.1 Detailed Description   | 70 |
| 7.20.2 Constructor & Destructor Documentation                                 | 70 |
| 7.20.2.1 CalibrationViewModel()   | 70 |
| 7.20.3 Property Documentation   | 70 |
| 7.20.3.1 CalibrationPoints  | 70 |
| 7.21 CustomCalibrationLibrary.Views.CalibrationWindow Class Reference         | 71 |
| 7.21.1 Detailed Description   | 71 |
| 7.22 CustomCalibrationLibrary.Views.Computing Class Reference                 | 72 |
| 7.22.1 Detailed Description   | 72 |
| 7.23 GazeUtilityLibrary.ConfigItem Class Reference                            | 72 |
| 7.23.1 Detailed Description   | 73 |
| 7.24 CustomCalibrationLibrary.Views.Disconnect Class Reference                | 73 |
| 7.24.1 Detailed Description   | 74 |
| 7.24.2 Property Documentation   | 74 |
| 7.24.2.1 CalibrationAbortCommand  | 75 |

| 7.25 GazeUtilityLibrary.DriftCompensation Class Reference                           | 75 |
|---|----|
| 7.25.1 Detailed Description   | 75 |
| 7.25.2 Member Function Documentation  | 75 |
| 7.25.2.1 Reset()  | 75 |
| 7.25.2.2 Start()  | 76 |
| 7.25.2.3 Update()   | 76 |
| 7.25.3 Property Documentation   | 76 |
| 7.25.3.1 Q  | 76 |
| 7.26 GazeUtilityLibrary.DataStructs.DriftCompensationData Class Reference           | 76 |
| 7.26.1 Detailed Description   | 77 |
| 7.26.2 Constructor & Destructor Documentation                                       | 77 |
| 7.26.2.1 DriftCompensationData()  | 77 |
| 7.26.3 Property Documentation   | 77 |
| 7.26.3.1 Compensation   | 77 |
| 7.26.3.2 GazePosition2d   | 78 |
| 7.26.3.3 GazePosition3d   | 78 |
| 7.27 CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel Class Reference | 78 |
| 7.27.1 Detailed Description   | 78 |
| 7.27.2 Constructor & Destructor Documentation                                       | 78 |
| 7.27.2.1 DriftCompensationViewModel()   | 79 |
| 7.27.3 Property Documentation   | 79 |
| 7.27.3.1 FixationPoint  | 79 |
| 7.28 CustomCalibrationLibrary.Views.DriftCompensationWindow Class Reference         | 79 |
| 7.28.1 Detailed Description   | 80 |
| 7.29 GazeUtilityLibrary.DataStructs.EyeData Class Reference                         | 80 |
| 7.29.1 Detailed Description   | 80 |
| 7.29.2 Constructor & Destructor Documentation                                       | 81 |
| 7.29.2.1 EyeData()  | 81 |
| 7.29.3 Property Documentation   | 81 |
| 7.29.3.1 IsPupilDiameterValid   | 81 |
| 7.29.3.2 PupilDiameter  | 81 |
| 7.30 GazeUtilityLibrary.Tracker.EyeTrackerPro Class Reference                       | 82 |
| 7.30.1 Detailed Description   | 83 |
| 7.30.2 Constructor & Destructor Documentation                                       | 83 |
| 7.30.2.1 EyeTrackerPro()  | 83 |
| 7.30.3 Member Function Documentation  | 84 |
| 7.30.3.1 ApplyCalibration()   | 84 |
| 7.30.3.2 CollectCalibrationData()   | 84 |
| 7.30.3.3 FinishCalibration()  | 84 |
| 7.30.3.4 GetFixationFrameCount()  | 85 |
| 7.30.3.5 GetUnitDirection()   | 85 |
| 7.30.3.6 InitCalibration()  | 85 |

| 7.30.3.7 InitDriftCompensation()  | . 85 |
|---|------|
| 7.30.3.8 IsInitialised()  | . 86 |
| 7.30.3.9 lsLicenseOk()  | . 86 |
| 7.30.3.10 PatternReplace()  | . 86 |
| 7.31 CustomCalibrationLibrary.Views.FixationPoint Class Reference       | . 87 |
| 7.31.1 Detailed Description   | . 87 |
| 7.32 GazeUtilityLibrary.DataStructs.GazeCalibrationData Class Reference | . 87 |
| 7.32.1 Detailed Description   | . 88 |
| 7.32.2 Constructor & Destructor Documentation                           | . 88 |
| 7.32.2.1 GazeCalibrationData()  | . 88 |
| 7.32.3 Member Function Documentation                                    | . 89 |
| 7.32.3.1 Prepare()  | . 89 |
| 7.33 GazeUtilityLibrary.GazeConfigError Class Reference                 | . 89 |
| 7.33.1 Member Function Documentation                                    | . 90 |
| 7.33.1.1 GetGazeConfigErrorString()                                     | . 90 |
| 7.34 GazeUtilityLibrary.GazeConfiguration Class Reference               | . 91 |
| 7.34.1 Member Function Documentation                                    | . 91 |
| 7.34.1.1 CleanupCalibrationOutputFile()                                 | . 91 |
| 7.34.1.2 CleanupGazeOutputFile()  | . 92 |
| 7.34.1.3 DumpCurrentConfigurationFile()                                 | . 92 |
| 7.34.1.4 InitConfig()   | . 92 |
| 7.34.1.5 PrepareCalibrationOutputFile()                                 | . 92 |
| 7.34.1.6 PrepareGazeOutputFile()  | . 93 |
| 7.34.1.7 WriteToCalibrationOutput()                                     | . 93 |
| 7.34.1.8 WriteToGazeOutput()  | . 93 |
| 7.35 GazeUtilityLibrary.DataStructs.GazeData Class Reference            | . 94 |
| 7.35.1 Detailed Description   | . 94 |
| 7.35.2 Constructor & Destructor Documentation                           | . 94 |
| 7.35.2.1 GazeData() [1/3]   | . 94 |
| 7.35.2.2 GazeData() [2/3]   | . 95 |
| 7.35.2.3 GazeData() [3/3]   | . 95 |
| 7.35.3 Member Function Documentation                                    | . 96 |
| 7.35.3.1 Prepare()  | . 96 |
| 7.36 GazeUtilityLibrary.DataStructs.GazeData2d Class Reference          | . 97 |
| 7.36.1 Detailed Description   | . 97 |
| 7.36.2 Constructor & Destructor Documentation                           | . 97 |
| 7.36.2.1 GazeData2d()   | . 97 |
| 7.37 GazeUtilityLibrary.DataStructs.GazeData3d Class Reference          | . 97 |
| 7.37.1 Detailed Description   | . 98 |
| 7.37.2 Constructor & Destructor Documentation                           | . 98 |
| 7.37.2.1 GazeData3d()   | . 98 |
| 7.38 GazeUtilityLibrary.DataStructs.GazeDataCollection Class Reference  | . 98 |

| 7.38.1 Detailed Description   |
|---|
| 7.38.2 Constructor & Destructor Documentation   |
| 7.38.2.1 GazeDataCollection() [1/2]   |
| 7.38.2.2 GazeDataCollection() [2/2]   |
| 7.39 GazeUtilityLibrary.GazeDataError Class Reference                                 |
| 7.39.1 Member Function Documentation  |
| 7.39.1.1 GetGazeDataErrorString()   |
| 7.40 GazeUtilityLibrary.GazeError Class Reference                                     |
| 7.40.1 Member Function Documentation  |
| 7.40.1.1 ConvertToBinString()   |
| 7.41 CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter Class Reference |
| 7.41.1 Detailed Description   |
| 7.42 GazeUtilityLibrary.JsonConfigParser Class Reference                              |
| 7.42.1 Detailed Description   |
| 7.42.2 Constructor & Destructor Documentation   |
| 7.42.2.1 JsonConfigParser()   |
| 7.42.3 Member Function Documentation  |
| 7.42.3.1 GetDefaultConfig()   |
| 7.42.3.2 ParseJsonConfig()  |
| 7.42.3.3 SerializeJsonConfig()  |
| 7.43 GazeUtilityLibrary.DataStructs.LiveGazePoint Class Reference                     |
| 7.44 GazeUtilityLibrary.MouseHider Class Reference                                    |
| 7.44.1 Detailed Description   |
| 7.44.2 Constructor & Destructor Documentation   |
| 7.44.2.1 MouseHider()   |
| 7.44.3 Member Function Documentation  |
| 7.44.3.1 HideCursor()   |
| 7.44.3.2 ShowCursor()   |
| 7.45 GazeUtilityLibrary.Tracker.MouseTracker Class Reference                          |
| 7.45.1 Detailed Description   |
| 7.45.2 Constructor & Destructor Documentation   |
| 7.45.2.1 MouseTracker()   |
| 7.45.3 Member Function Documentation  |
| 7.45.3.1 ApplyCalibration()   |
| 7.45.3.2 CollectCalibrationData()   |
| 7.45.3.3 Dispose()  |
| 7.45.3.4 FinishCalibration()  |
| 7.45.3.5 GetFixationFrameCount()  |
| 7.45.3.6 GetUnitDirection()   |
| 7.45.3.7 InitCalibration()  |
| 7.45.3.8 InitDriftCompensation()  |
| 7.45.3.9 Start()  |

| 7.45.3.10 Stop()   | 13 |
|--|----|
| 7.46 GazeUtilityLibrary.DataStructs.PipeCommand Class Reference                  | 13 |
| 7.47 CustomCalibrationLibrary.Converters.PositionConverter Class Reference       | 13 |
| 7.47.1 Detailed Description  | 14 |
| 7.47.2 Member Data Documentation   | 14 |
| 7.47.2.1 OffsetProperty  | 14 |
| 7.48 CustomCalibrationLibrary.Converters.ProximityColorConverter Class Reference | 15 |
| 7.48.1 Detailed Description  | 15 |
| 7.49 GazeUtilityLibrary.ScreenArea Class Reference                               | 16 |
| 7.49.1 Detailed Description  | 16 |
| 7.49.2 Constructor & Destructor Documentation                                    | 16 |
| 7.49.2.1 ScreenArea()  | 16 |
| 7.49.3 Member Function Documentation   | 17 |
| 7.49.3.1 GetIntersectionPoint()  | 17 |
| 7.49.3.2 GetPoint2d()  | 17 |
| 7.49.3.3 GetPoint2dNormalized()  | 18 |
| 7.50 Tobii.Research.Addons.ScreenBasedCalibrationValidation Class Reference      | 18 |
| 7.50.1 Detailed Description  | 20 |
| 7.50.2 Member Enumeration Documentation  | 20 |
| 7.50.2.1 ValidationState   | 20 |
| 7.50.3 Constructor & Destructor Documentation                                    | 20 |
| 7.50.3.1 ScreenBasedCalibrationValidation()                                      | 20 |
| 7.50.4 Member Function Documentation   | 21 |
| 7.50.4.1 Compute()   | 21 |
| 7.50.4.2 DiscardData()   | 21 |
| 7.50.4.3 Dispose()   | 21 |
| 7.50.4.4 EnterValidationMode()   | 21 |
| 7.50.4.5 LeaveValidationMode()   | 22 |
| 7.50.4.6 StartCollectingData()   | 22 |
| 7.50.5 Property Documentation  | 22 |
| 7.50.5.1 Result  | 22 |
| 7.50.5.2 State   | 22 |
| 7.51 GazeUtilityLibrary.ScreenTriangle Class Reference                           | 23 |
| 7.51.1 Detailed Description  | 23 |
| 7.51.2 Member Function Documentation   | 23 |
| 7.51.2.1 GetIntersectionPoint()  | 23 |
| 7.52 GazeUtilityLibrary.TrackerLogger Class Reference                            | 24 |
| 7.52.1 Detailed Description  | 24 |
| 7.52.2 Constructor & Destructor Documentation                                    | 24 |
| 7.52.2.1 TrackerLogger()   | 24 |
| 7.52.3 Member Function Documentation   | 24 |
| 7.52.3.1 Debug()   | 24 |

| 127 |
|-----|
| 127 |
| 128 |
| 129 |
| 129 |
| 129 |
| 129 |
| 129 |
| 130 |
| 130 |
| 130 |
| 130 |
| 131 |
|     |

## v3.2.0

#### **New Features**

- · Add relative timestamp to output data.
- · Add annotation tag to ouput data.
- Add pipe command SET\_TAG to allow annotate data samples.
- Add pipe command RESET\_START\_TIMER to reste the relative timestamp.
- · Add a log entry of the version of the gaze application.
- Add helper scripts to generate shortcuts to GazeControl.exe.

## v3.1.0

## **New Features**

- · Add a custom drift compensation process
- · Allow to pass the argument outputPath to the application for dynamic output path assignement.

## **Improvements**

- Integrate calibration into Gaze.exe
- · Remove Tobii research dependencies from everywhere except the eye tracker device class
- · Cleanup and rearrangement of code to improve readability

## v3.0.0

#### **New Features**

- A custom calibration application is added to the portfolio. This allows to calibrate a device without the need for a 3rd party application.
- Proper shutdown handling of GazeToMouse through named pipes.
- · Allow to enable/disable gaze recording through named pipes.
- Allow to enable/disable mouse tracking through named pipes.
- Allow to pass argument subject to the application.

2 v3.2.0

## **Improvements**

- Update all projects to .NET version 6.0.
- · Cleanup code base, split functions into seperate libraries.
- Apply MVVM architectural pattern where sensible.

#### Changes

- · Remove Tobii Interaction Library
- Remove all configuration options for Tobii Core (only Tobii Pro SDK is supported)
- Remove Tobii Core application wrapper (TobiiTest, TobiiGuestCalibrate)
- Use the Tobii pro eye tracker manager for device calibration instead of the Tobii Core software.
- Rename GazeToMouse to Gaze and GazeToMouseClose to GazeClose.

## v2.3.0

#### **New Features**

• A mouse tracker device can now be used instead of an eyetracker device. The mouse tracker logs the timestamp and the x and y coordinates of the mouse pointer whenever the mouse-move event is fired. The mouse tracker is used when the configuration filed 'TrackerDevice' is set to the value 2.

### **Improvements**

· Rename the configuration field 'TobiiSDK' to 'TrackerDevice'.

## v2.2.0

#### **New Features**

- · Configuration file
  - Dump the configurations used for an experiment to a file at the "DataLogPath"
  - Allow to configure an experiment name which is used as a postfix of the dumped configuration file name
  - Consider the config file as invalid if not all required configuration parameters are defined
  - Consider the config file as invalid if unknown parameters are defined
  - Allow to configure whether to log data sets where all data is invalid (eyes closed, no subject in front of the screen, etc)
- · Error Handling
  - Attach an error string to the output file, indicating errors that occurred during the run
  - Attach an error string to the dumped configuration file, indicating errors of the configuration

## Improvements

• Fall back to Core SDK if the license file cannot be applied to the device

## v2.1.0

#### **New Features**

- · Log eye origin coordinates
  - x, y, z coordinates of the left and the right eye
  - compute distance of the left and right eye to the eyetracker
  - compute the average distance of the two eyes

## Improvements

· Check the three format values and the column order individually to produce more specific log entries

## v2.0.1

## **Bug Fix**

- · with SDK Pro, use system timestamp to cope with disconnected device
- fix the path in the z-tree sample file

## v2.0.0

## **New Features**

- Support for Tobii Pro SDK
  - apply license to eyetracker device at stratup
  - logging of pupil diameter
  - logging of individual eye data
- · Allow to configure column headers of output file

## Improvements

· Improved configuration options for the output file

## v1.0.0

## **New Features**

- · Notify user with popup if eyetracker is not ready
- · Allow to configure time interval for the software to wait for the eyetracker to become ready

4 v3.2.0

## Improvements

• Rename default output file for data from cprefix>\_data.txt to <prefix>\_gaze.txt

## v0.3.2

### **Improvements**

- · add header to the data log file.
- · change the default value of allowed gaze data files.
- · check and wait for ready state of the eye tracker before performing operations with it.

#### **Bug Fix**

• create a log file per machine to prevent concurrency conflicts.

## v0.3.1

#### **Improvements**

• ignore the option "HideMouse" when "ControlMouse" is disabled.

#### **Bug Fix**

· remove double log entry of mouse hiding and restoring event.

## v0.3.0

## **New Features**

- · allow to configure whether the gaze data is logged.
- allow to configure the maximum allowed amount of gaze data files in the output folder. Oldest files are deleted first.

#### Improvements

• limit the logfile size to 1MB. If the size is exceeded a new file is created. At any time only two log files are allowed, The older file is overwritten once both files exceed 1MB.

## v0.2.0

## **New Features**

- · allow to configure whether the mouse is controlled by the gaze of the subject or not.
- allow to configure the output format of the gaze data.

## v0.1.0

First release of the GazeToMouse toolset.

The toolset was tested on Windows 7 in conjunction with ztree v3.6.7 and Tobii Eye Tracking Core v2.11.1.6952.

## **Toolset to Control Tobii Eye Tracker**

This repository contains the source code for multiple simple tools that allow to control a Tobii eye tracker from a 3rd party application. Specifically, this project aims at providing a set of executables that can be called from within ztree to allow eye tracker support for economic experiments.

For more details please refer to the documentation.

## Installation

The complete toolset package can be downloaded from the release folder. The package contains the following executables:

- \*\*Gaze.exe\*\* This program uses the Tobii Pro SDK to extract the gaze position on the screen where the subject is looking at. The extracted data is recorded and stored to a file. Optionally, the mouse cursor position is updated to this position such that the mouse cursor is controlled by the gaze of the subject. Instead of using an eye tracker device it is also possible to simply log the mouse coordinates. \*\*Gaze. exe\*\* runs infinitely until it is terminated by an external command. This should **not** be done with a forced kill (e.g. by executing the command taskkill /F /IM Gaze.exe or by killing the task with the task manager) because it prevents the program from terminating gracefully. This as several consequences:
  - open files are not closed properly and the data stream is cut off. This can lead to corrupt files.
  - if the feature of hiding the mouse pointer is used, the mouse will remain hidden.
  - memory is not freed properly. Instead the program \*\*GazeControls.exe /command TERMI← NATE\*\* should be used.
- \*\*GazeControl.exe\*\* This program allows to interact with \*\*Gaze.exe\*\* by passing the arguments /command <COMMAND>, /value <VALUE>, and /reset to the application. Passing an argument to an application can be done in command line or by crating a shortcut to the program. Corresponding shortcuts for all available <COMMAND>s are provided in the release package. The following <COMMAND>s are available (use argument /value <VALUE> whenever a command accepts a value):
  - CUSTOM\_CALIBRATE uses the Tobii Pro SDK and launches a custom calibration process which allows to calibrate the eye tracker without having to rely on the calibration software provided by Tobii.
  - DRIFT\_COMPENSATION launches a custom drift compensation process to compensate gaze drifts that may occur during experimentation.
  - GAZE\_RECORDING\_DISABLE requests \*\*Gaze.exe\*\* to stop recording gaze data. Gaze.exe will
    continue to run (and update the mouse pointer if configured accordingly) but no longer store gaze data
    to the disk.

- GAZE\_RECORDING\_ENABLE requests \*\*Gaze.exe\*\* to start recording gaze data.
- MOUSE\_TRACKING\_DISABLE requests \*\*Gaze.exe\*\* to stop updating the mouse pointer by the gaze position.
- MOUSE\_TRACKING\_ENABLE requests \*\*Gaze.exe\*\* to start updating the mouse pointer by the gaze position.
- RESET\_DRIFT\_COMPENSATION resets the drift compensation computed with the command DRI← FT\_COMPENSATION.
- TERMINATE requests \*\*Gaze.exe\*\* to close gracefully and logs these events to the log file.
- SET\_TAG <TAG> sets a custom tag <TAG> which will be added to each data sample in the output file (use argument /value to define the <TAG>).
- RESET\_START\_TIME allows to reset the relative timestamp. The relative timestamp can also be reset by passing the argument /reset to the application with any of the above commands.
- \*\*ShowMouse.exe\*\* This program allows to restore the standard mouse pointer. It might be useful if the program \texttt{Gaze.exe} crashes or is closed forcefully such that the mouse pointer is not restored after terminating. The subject might end up with a hidden mouse pointer. A good solution for such a case is to install a shortcut to \texttt{ShowMouse.exe} on the desktop in order to execute it with the keyboard.

In order to run the executables the following files need to be placed in the same directory as the executables:

```
• tobii_pro.dll
```

- tobii\_firmware\_upgrade.dll
- assets/blank.cur
- config.json

Further, the Tobii engine must be running and the eye tracker must be enabled.

## **Tobii** Eye Tracker 4c

To install the driver for the Tobii Eye Tracker 4c install Tobii Experience Driver.

This will start the following services:

- Tobii Runtime Service
- Tobii Service

and the following processs:

• Tobii Interaction Engine

### **Tobii Pro Spark**

To install the driver for the Tobii Pro Spark use the Tobii Pro Eye Tracker Manager:

- 1. Install Tobii Pro Eye Tracker Manager (ETM)
- 2. Connect the Tobii Pro SPark device to the computer
- 3. Install the driver with the ETM

This starts the service Tobii Pro Spark Runtime.

## **Scripts**

The folder scripts contains two files <code>CreateShortcut.ps1</code> and <code>CreateShortcuts.bat</code> which allow to create shortcuts to the application <code>GazeControl.exe</code> with predefined command arguments. In order to generate the shortcut files perform the following steps:

- 1. copy the two script files into the installation folder
- 1. execute the script CreateShortcuts.bat

Nothe that the generated shortcuts are tied to the installation folder. Copying the installation folder to another location will break the links.

## **3rd Party Applications**

This section provides some infromation on how to run the here provided executables from within 3rd party applications.

#### ztree

For quick starters, a simple ztree sample program is available.

## **Opensesame**

To start a process from within opensesame use a python script. The following example starts the custom calibartion program with the subject number passed as argument:

```
import subprocess
subprocess.run(["CustomCalibrate.exe", "/subject", var.get(u'subject_nr')])
```

## **Release Notes**

Information about the releases can be found in the CHANGELOG

# Namespace Index

## 3.1 Namespace List

Here is a list of all documented namespaces with brief descriptions:

| CustomCalibrationLibrary                        | 17 |
|---|----|
| CustomCalibrationLibrary.Commands               | 17 |
| CustomCalibrationLibrary.Converters             | 17 |
| CustomCalibrationLibrary.Models                 | 17 |
| CustomCalibrationLibrary.ViewModels             | 18 |
| CustomCalibrationLibrary.Views                  | 19 |
| GazeControl                                     | 19 |
| GazeToMouse                                     | 19 |
| GazeUtilityLibrary                              |    |
| helper class to show and hide the system curser | 19 |
| GazeUtilityLibrary.DataStructs                  | 21 |
| GazeUtilityLibrary.Tracker                      | 22 |
| ShowMouse                                       | 23 |
| Г <mark>оbіі</mark>                             | 23 |
| Tobii.Research                                  | 23 |
| Tobii.Research.Addons                           | 23 |
| Tobii.Research.Addons.Utility                   | 23 |
| lobiiCalibrate                                  | 23 |

10 Namespace Index

# **Hierarchical Index**

## 4.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

| Application   |
|---|
| GazeControl.App   |
| GazeToMouse.App   |
| ShowMouse.App   |
| TobiiCalibrate.App  |
| Tobii.Research.Addons.CalibrationValidationPoint                  |
| Tobii.Research.Addons.CalibrationValidationResult                 |
| CustomCalibrationLibrary.ViewModels.CalibrationViewModel          |
| CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel 61 |
| GazeUtilityLibrary.ConfigItem                                     |
| DependencyObject  |
| CustomCalibrationLibrary.Converters.PositionConverter             |
| GazeUtilityLibrary.DriftCompensation                              |
| GazeUtilityLibrary.DataStructs.DriftCompensationData              |
| CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel    |
| GazeUtilityLibrary.DataStructs.EyeData                            |
| Frame   |
| CustomCalibrationLibrary.Views.CalibrationFrame                   |
| GazeUtilityLibrary.DataStructs.GazeCalibrationData                |
| GazeUtilityLibrary.GazeConfiguration                              |
| GazeUtilityLibrary.DataStructs.GazeData                           |
| GazeUtilityLibrary.DataStructs.GazeData2d                         |
| GazeUtilityLibrary.DataStructs.GazeData3d                         |
| GazeUtilityLibrary.DataStructs.GazeDataCollection                 |
| GazeUtilityLibrary.GazeError                                      |
| GazeUtilityLibrary.CalibrationDataError                           |
| GazeUtilityLibrary.GazeConfigError                                |
| GazeUtilityLibrary.GazeDataError                                  |
| ICommand  |
| CustomCalibrationLibrary.Commands.CalibrationCommand              |
| IDisposable   |
| GazeUtilityLibrary.Tracker.BaseTracker                            |
| GazeUtilityLibrary.Tracker.EyeTrackerPro                          |
| GazeUtilityLibrary.Tracker.MouseTracker                           |
| Tobii.Research.Addons.ScreenBasedCalibrationValidation            |

12 Hierarchical Index

| INotifyPropertyChanged   |
|--|
| CustomCalibrationLibrary.Models.CalibrationModel                 |
| CustomCalibrationLibrary.Views.CalibrationFailed                 |
| GazeUtilityLibrary.DataStructs.CalibrationPoint                  |
| CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel    |
| GazeUtilityLibrary.DataStructs.LiveGazePoint                     |
| GazeUtilityLibrary.DataStructs.UserPositionData                  |
| GazeUtilityLibrary.Tracker.BaseTracker                           |
| IValueConverter  |
| CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter |
| CustomCalibrationLibrary.Converters.PositionConverter            |
| CustomCalibrationLibrary.Converters.ProximityColorConverter      |
| GazeUtilityLibrary.JsonConfigParser                              |
| GazeUtilityLibrary.MouseHider                                    |
| Page   |
| CustomCalibrationLibrary.Views.Calibration                       |
| CustomCalibrationLibrary.Views.CalibrationFailed                 |
| CustomCalibrationLibrary.Views.CalibrationResult                 |
| CustomCalibrationLibrary.Views.UserPositionGuide                 |
| Page   |
| CustomCalibrationLibrary.Views.Computing                         |
| CustomCalibrationLibrary.Views.Disconnect                        |
| GazeUtilityLibrary.DataStructs.PipeCommand                       |
| GazeUtilityLibrary.ScreenArea                                    |
| GazeUtilityLibrary.ScreenTriangle                                |
| GazeUtilityLibrary.TrackerLogger                                 |
| UserControl  |
| CustomCalibrationLibrary.Views.CalibrationPoint                  |
| CustomCalibrationLibrary.Views.CalibrationResultPoint            |
| CustomCalibrationLibrary.Views.FixationPoint                     |
| CustomCalibrationLibrary.ViewModels.UserPositionGuideViewModel   |
| Window   |
| CustomCalibrationLibrary.Views.CalibrationWindow                 |
| CustomCalibrationLibrary.Views.DriftCompensationWindow           |
| GazeUtilityLibrary.TrackerMessageBox                             |

# **Class Index**

## 5.1 Class List

Here are the classes, structs, unions and interfaces with brief descriptions:

| GazeControl.App   |    |
|---|----|
| Interaction logic for App.xaml  | 25 |
| GazeToMouse.App   |    |
| Interaction logic for App.xaml  | 26 |
| ShowMouse.App   |    |
| Interaction logic for App.xaml  | 29 |
| TobiiCalibrate.App  |    |
| Interaction logic for App.xaml  | 30 |
| GazeUtilityLibrary.Tracker.BaseTracker  |    |
| The common interface for the Tobii eyetracker Engines Core and Pro                                    | 31 |
| CustomCalibrationLibrary.Views.Calibration  |    |
| Interaction logic for Calibration.xaml  | 43 |
| CustomCalibrationLibrary.Commands.CalibrationCommand  |    |
| Comand class to trigger calibration events  | 44 |
| GazeUtilityLibrary.CalibrationDataError   | 45 |
| CustomCalibrationLibrary.Views.CalibrationFailed  |    |
| Interaction logic for CalibrationFailed.xaml  | 46 |
| CustomCalibrationLibrary.Views.CalibrationFrame   |    |
| Interaction logic for CalibrationCollection.xaml  | 49 |
| CustomCalibrationLibrary.Models.CalibrationModel  |    |
| The model for the calibration process   | 50 |
| GazeUtilityLibrary.DataStructs.CalibrationPoint   |    |
| A calibration point class holding several metrics connected to a calibration point                    | 54 |
| CustomCalibrationLibrary.Views.CalibrationPoint   |    |
| Interaction logic for CalibrationPoint.xaml   | 57 |
| CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel   |    |
| The view model for a calibration point  | 58 |
| CustomCalibrationLibrary.Views.CalibrationResult  |    |
| Interaction logic for CalibrationResult.xaml  | 59 |
| CustomCalibrationLibrary.Views.CalibrationResultPoint   |    |
| Interaction logic for CalibrationResultPoint.xaml   | 60 |
| CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel  |    |
| View model class of the gaze calibration result   | 61 |
| Tobii.Research.Addons.CalibrationValidationPoint  |    |
| Represents a collected point that goes into the calibration validation. It contains calculated values |    |
| for accuracy and precision as well as the original gaze samples collected for the point               | 64 |

14 Class Index

| Tobii.Research.Addons.CalibrationValidationResult  |     |
|--|-----|
| Contains the result of the calibration validation  | 66  |
| CustomCalibrationLibrary.ViewModels.CalibrationViewModel   |     |
| The view model class of the calibration view   | 69  |
| CustomCalibrationLibrary.Views.CalibrationWindow   |     |
| Interaction logic for MainWindow.xaml  | 71  |
| CustomCalibrationLibrary. Views. Computing   |     |
| Interaction logic for Computing.xaml   | 72  |
| GazeUtilityLibrary.ConfigItem  |     |
| configuration file class   | 72  |
| CustomCalibrationLibrary.Views.Disconnect  |     |
| Interaction logic for Disconnect.xaml  | 73  |
| GazeUtilityLibrary.DriftCompensation   |     |
| The class to handle drift compensation   | 75  |
| GazeUtilityLibrary.DataStructs.DriftCompensationData   |     |
| The drift compensation data structure  | 76  |
| CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel   |     |
| The view model class of the drift compensation view  | 78  |
| CustomCalibrationLibrary.Views.DriftCompensationWindow   |     |
| Interaction logic for DriftCompensation.xaml   | 79  |
| GazeUtilityLibrary.DataStructs.EyeData   |     |
| The eye data set, including pupil information  | 80  |
| GazeUtilityLibrary.Tracker.EyeTrackerPro   |     |
| Interface to the Tobii SDK Pro engine  | 82  |
| CustomCalibrationLibrary. Views. FixationPoint   |     |
| Interaction logic for FixationPoint.xaml   | 87  |
| GazeUtilityLibrary.DataStructs.GazeCalibrationData   | •   |
| The event argument class for Tobii eyetracker data   | 87  |
| GazeUtilityLibrary.GazeConfigError   | 89  |
| GazeUtilityLibrary.GazeConfiguration   | 91  |
| GazeUtilityLibrary.DataStructs.GazeData  | •   |
| The class definition of a gaze data set  | 94  |
| GazeUtilityLibrary.DataStructs.GazeData2d  | 54  |
| The 2d gaze data set   | 97  |
| GazeUtilityLibrary.DataStructs.GazeData3d  | 0,  |
| The 3d gaze data set   | 97  |
| GazeUtilityLibrary.DataStructs.GazeDataCollection  | 0,  |
| The gaze data set, including 2d and (optionally) 3d gaze data as well as optional eye data   | 98  |
| GazeUtilityLibrary.GazeDataError   | 100 |
| GazeUtilityLibrary.GazeError   | 102 |
| CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter   | 102 |
| Converts True to Hidden and False to Visible   | 103 |
| GazeUtilityLibrary.JsonConfigParser  | 100 |
| The config file "config.json" is parsed and its values are attributed to the Configltem class  | 104 |
| GazeUtilityLibrary.DataStructs.LiveGazePoint   | 104 |
| GazeUtilityLibrary.MouseHider  | 100 |
| hide standard mouse pointer and resore it  | 107 |
| GazeUtilityLibrary.Tracker.MouseTracker  | 107 |
| This class is used to hook into the system mouse events and track the position   | 108 |
| GazeUtilityLibrary.DataStructs.PipeCommand   | 113 |
| CustomCalibrationLibrary.Converters.PositionConverter  | 113 |
| Converter class to convert a normalized coordinate to a pixel coordinate   | 110 |
| ·  | 113 |
| CustomCalibrationLibrary.Converters.ProximityColorConverter  Converter class to convert the proximito of a normailezed coordinate to the center point (0.5) into |     |
| colors   | 115 |
| GazeUtilityLibrary.ScreenArea  | 113 |
| The class describing the Screen area in 3d and 2d space  | 116 |
| The diass describing the doleen area in ou and zu space  | 110 |

5.1 Class List

| Tobii.Research.Addons.ScreenBasedCalibrationValidation  |     |
|---|-----|
| Provides methods and properties for managing calibration validation for screen based eye track-   |     |
| ers   | 118 |
| GazeUtilityLibrary.ScreenTriangle   |     |
| A class to describe a triangle. This was supposed to be used to construct the ScreenArea but it turned out that it is simpler to work with the screen plane and use the normalised intersection |     |
| points to check wheter the gaze point is outside the screen area  | 123 |
| GazeUtilityLibrary.TrackerLogger  |     |
| Simple logger class   | 124 |
| GazeUtilityLibrary.TrackerMessageBox  |     |
| Interaction logic for TrackerMessageBox.xaml  | 126 |
| GazeUtilityLibrary.DataStructs.UserPositionData   | 127 |
| CustomCalibrationLibrary.Views.UserPositionGuide  |     |
| Interaction logic for UserPositionGuide.xaml  | 128 |
| CustomCalibrationLibrary.ViewModels.UserPositionGuideViewModel  |     |
| The view model class for the user position guide view   | 129 |

16 Class Index

# **Namespace Documentation**

## 6.1 CustomCalibrationLibrary Namespace Reference

## 6.2 CustomCalibrationLibrary.Commands Namespace Reference

#### **Classes**

· class CalibrationCommand

Comand class to trigger calibration events.

class GazeVisibilityCommand

Command class to change the gaze visibility

## 6.3 CustomCalibrationLibrary.Converters Namespace Reference

#### **Classes**

class HasDataToVisibilityConverter

Converts True to Hidden and False to Visible

· class PositionConverter

Converter class to convert a normalized coordinate to a pixel coordinate.

· class ProximityColorConverter

Converter class to convert the proximito of a normaliezed coordinate to the center point (0.5) into colors.

## 6.4 CustomCalibrationLibrary.Models Namespace Reference

## **Classes**

· class CalibrationModel

The model for the calibration process.

## **Enumerations**

enum CalibrationEventType { Start, Accept, Restart, Abort }

Events to trigger changes in the calibration process.

• enum CalibrationStatus {

HeadPosition, DataCollection, Computing, DataResult, Error, Disconnect }

The status of the calibarion process.

## 6.4.1 Enumeration Type Documentation

#### 6.4.1.1 CalibrationEventType

```
enum CustomCalibrationLibrary.Models.CalibrationEventType [strong]
```

Events to trigger changes in the calibration process.

### 6.4.1.2 CalibrationStatus

```
enum CustomCalibrationLibrary.Models.CalibrationStatus [strong]
```

The status of the calibarion process.

## 6.5 CustomCalibrationLibrary.ViewModels Namespace Reference

## Classes

· class CalibrationPointViewModel

The view model for a calibration point.

• class CalibrationResultViewModel

View model class of the gaze calibration result.

· class CalibrationViewModel

The view model class of the calibration view

class DriftCompensationViewModel

The view model class of the drift compensation view.

• class UserPositionGuideViewModel

The view model class for the user position guide view.

## 6.6 CustomCalibrationLibrary.Views Namespace Reference

#### **Classes**

class Calibration

Interaction logic for Calibration.xaml

· class CalibrationFailed

Interaction logic for CalibrationFailed.xaml

· class CalibrationFrame

Interaction logic for CalibrationCollection.xaml

· class CalibrationPoint

Interaction logic for CalibrationPoint.xaml

class CalibrationResult

Interaction logic for CalibrationResult.xaml

· class CalibrationResultPoint

Interaction logic for CalibrationResultPoint.xaml

· class CalibrationWindow

Interaction logic for MainWindow.xaml

· class Computing

Interaction logic for Computing.xaml

class Disconnect

Interaction logic for Disconnect.xaml

· class DriftCompensationWindow

Interaction logic for DriftCompensation.xaml

class FixationPoint

Interaction logic for FixationPoint.xaml

· class UserPositionGuide

Interaction logic for UserPositionGuide.xaml

## 6.7 GazeControl Namespace Reference

## **Classes**

class App

Interaction logic for App.xaml

· class NamedPipeClient

## 6.8 GazeToMouse Namespace Reference

## **Classes**

class App

Interaction logic for App.xaml

## 6.9 GazeUtilityLibrary Namespace Reference

helper class to show and hide the system curser

#### **Classes**

- · class CalibrationDataError
- · class ConfigChecker
- class ConfigItem

configuration file class

· class DriftCompensation

The class to handle drift compensation.

- class GazeConfigError
- class GazeConfiguration
- · class GazeDataError
- class GazeError
- · class JsonConfigParser

The config file "config.json" is parsed and its values are attributed to the Configltem class.

class MouseHider

hide standard mouse pointer and resore it

class ScreenArea

The class describing the Screen area in 3d and 2d space.

class ScreenTriangle

A class to describe a triangle. This was supposed to be used to construct the ScreenArea but it turned out that it is simpler to work with the screen plane and use the normalised intersection points to check wheter the gaze point is outside the screen area.

· class TrackerLogger

Simple logger class.

class TrackerMessageBox

Interaction logic for TrackerMessageBox.xaml

## **Enumerations**

- enum EOutputType { gaze, calibration }
- enum EGazeConfigError {

FallbackToDefaultConfigName = 0x001, FallbackToCurrentOutputDir = 0x002, FallbackToDefault $\leftarrow$  Config = 0x004, FallbackToDefaultDiameterFormat = 0x008,

FallbackToDefaultOriginFormat = 0x010, FallbackToDefaultTimestampFormat = 0x020, OmitColumn $\leftarrow$  Titles = 0x040, FallbackToDefualtColumnOrder = 0x080,

**FallbackToDefaultNormalizedFormat** = 0x100 }

Error values of the configuration

• enum EGazeDataError { FallbackToMouse = 0x01, DeviceInterrupt = 0x02 }

Error values of the gaze output data

• enum ECalibrationDataError { DeviceNotSupported = 0x01, DeviceInterrupt = 0x02 }

Error values of the gaze output data

## 6.9.1 Detailed Description

helper class to show and hide the system curser

## 6.9.2 Enumeration Type Documentation

#### 6.9.2.1 ECalibrationDataError

enum GazeUtilityLibrary.ECalibrationDataError [strong]

Error values of the gaze output data

## 6.9.2.2 EGazeConfigError

enum GazeUtilityLibrary.EGazeConfigError [strong]

Error values of the configuration

#### 6.9.2.3 EGazeDataError

enum GazeUtilityLibrary.EGazeDataError [strong]

Error values of the gaze output data

## 6.10 GazeUtilityLibrary.DataStructs Namespace Reference

### **Classes**

class CalibrationPoint

A calibration point class holding several metrics connected to a calibration point.

class DriftCompensationData

The drift compensation data structure

class EyeData

The eye data set, including pupil information.

· class GazeCalibrationData

The event argument class for Tobii eyetracker data

class GazeData

The class definition of a gaze data set

class GazeData2d

The 2d gaze data set.

· class GazeData3d

The 3d gaze data set.

· class GazeDataCollection

The gaze data set, including 2d and (optionally) 3d gaze data as well as optional eye data.

- class GazeDataConverter
- class LiveGazePoint
- class PipeCommand
- class UserPositionData

#### **Enumerations**

enum GazeOutputValue {

 $\label{eq:decomposition} \textbf{DataTimeStampRelative}, \ \textbf{Tag}, \ \textbf{CombinedGazePoint2dCompensatedX}, \ \textbf{CombinedGazePoint2dCompensatedY}, \ \textbf{CombinedGazePoint2dX}, \ \textbf{CombinedGazePoint2dY}, \ \textbf{CombinedGazeP$ 

 $\label{lem:combinedGazePoint3dCompensatedY} CombinedGazePoint3dCompensatedY, \quad CombinedGazePoint3dCompensatedY, \quad CombinedGazePoint3dX,$ 

 $\textbf{CombinedGazePoint3dY}, \ \textbf{CombinedGazePoint3dZ}, \ \textbf{CombinedGazePoint3dIsValid}, \ \textbf{CombinedGazePoint3dX}, \\ \textbf{Origin3dX}, \\ \textbf{Origin3d$ 

 $\textbf{CombinedGazeOrigin3dY}, \ \ \textbf{CombinedGazeOrigin3dZ}, \ \ \textbf{CombinedGazeOrigin3dIsValid}, \ \ \textbf{Co$ 

CombinedPupilDiameter, CombinedPupilDiameterIsValid, LeftGazePoint2dX, LeftGazePoint2dY,

LeftGazePoint2dlsValid, LeftGazePoint3dX, LeftGazePoint3dY, LeftGazePoint3dZ,

LeftGazePoint3dlsValid, LeftGazeOrigin3dX, LeftGazeOrigin3dY, LeftGazeOrigin3dZ,

LeftGazeOrigin3dlsValid, LeftGazeDistance, LeftPupilDiameter, LeftPupilDiameterlsValid,

 $Right Gaze Point 2 dX, \ Right Gaze Point 2 dY, \ Right Gaze Point 2 dIs Valid, \ Right Gaze Point 3 dX, \ Right Gaze Point 2 dIs Valid, \ Right Gaze Point 3 dX, \ Right Gaze Point 2 dIs Valid, \ Right Gaze Point 3 dX, \ Right Gaze Point 2 dIs Valid, \ Right Gaze Point 3 dX, \ Right Gaze Point$ 

RightGazePoint3dY, RightGazePoint3dZ, RightGazePoint3dlsValid, RightGazeOrigin3dX, RightGazeOrigin3dY, RightGazeOrigin3dZ, RightGazeOrigin3dlsValid, RightGazeDistance,

PinktDurilDirector Director Di

RightPupilDiameter, RightPupilDiameterIsValid }

enummerates output values produced by the eyetracker

enum CalibrationOutputValue {

XCoord, YCoord, XCoordLeft, YCoordLeft,

ValidCoordLeft, XCoordRight, YCoordRight, ValidCoordRight }

enummerates output values produced by the eyetracker

## 6.10.1 Enumeration Type Documentation

## 6.10.1.1 CalibrationOutputValue

```
enum GazeUtilityLibrary.DataStructs.CalibrationOutputValue [strong]
enummerates output values produced by the eyetracker
```

## 6.10.1.2 GazeOutputValue

```
enum GazeUtilityLibrary.DataStructs.GazeOutputValue [strong]
```

enummerates output values produced by the eyetracker

## 6.11 GazeUtilityLibrary.Tracker Namespace Reference

## **Classes**

· class BaseTracker

The common interface for the Tobii eyetracker Engines Core and Pro

class EyeTrackerPro

Interface to the Tobii SDK Pro engine

· class MouseTracker

This class is used to hook into the system mouse events and track the position

## 6.12 ShowMouse Namespace Reference

#### **Classes**

class App

Interaction logic for App.xaml

## 6.13 Tobii Namespace Reference

## 6.14 Tobii.Research Namespace Reference

## 6.15 Tobii.Research.Addons Namespace Reference

## **Classes**

· class CalibrationValidationPoint

Represents a collected point that goes into the calibration validation. It contains calculated values for accuracy and precision as well as the original gaze samples collected for the point.

· class CalibrationValidationResult

Contains the result of the calibration validation.

class ScreenBasedCalibrationValidation

Provides methods and properties for managing calibration validation for screen based eye trackers.

## 6.16 Tobii.Research.Addons.Utility Namespace Reference

#### **Classes**

· class Extensions

Extensions with some operations on Point3D and NormalizedPoint2D among other things.

class TimeKeeper

## 6.17 TobiiCalibrate Namespace Reference

## **Classes**

class App

Interaction logic for App.xaml


# **Chapter 7**

# **Class Documentation**


# 7.1 GazeControl.App Class Reference

Interaction logic for App.xaml

Inheritance diagram for GazeControl.App:



Collaboration diagram for GazeControl.App:



# 7.1.1 Detailed Description

Interaction logic for App.xaml


The documentation for this class was generated from the following file:

• source/GazeControl/App.xaml.cs


# 7.2 GazeToMouse.App Class Reference

Interaction logic for App.xaml

Inheritance diagram for GazeToMouse.App:



Collaboration diagram for GazeToMouse.App:



#### **Public Member Functions**

• void GazeRecordingEnable ()

Enable gaze recordings to disk.

• void GazeRecordingDisable ()

Disable gaze recordings.

• void MouseTrackingEnable ()

Enable mouse tracking which updates the mouse position to the current gaze point.

void MouseTrackingDisable ()

Disable mouse tracking.

• void ResetDriftCompensation ()

Reset the current drift compensation offset to zero.

async Task< bool > CompensateDrift ()

Start the drift compensation process

async Task< bool > CustomCalibrate ()

Start the gaze calibration process

• App ()

Constructor: initialised logger, gaze configuration, pipe server, and calibration model

# **Properties**

```
• TimeSpan StartTime [get, set]
```

• string Tag [get, set]

# 7.2.1 Detailed Description

Interaction logic for App.xaml

# 7.2.2 Constructor & Destructor Documentation

#### 7.2.2.1 App()

```
GazeToMouse.App.App ( ) [inline]
```

Constructor: initialised logger, gaze configuration, pipe server, and calibration model

#### 7.2.3 Member Function Documentation

#### 7.2.3.1 CompensateDrift()

```
async Task<bool> GazeToMouse.App.CompensateDrift ( ) [inline]
```

Start the drift compensation process

Returns

True on success, false on failure

# 7.2.3.2 CustomCalibrate()

```
async Task<bool> GazeToMouse.App.CustomCalibrate ( ) [inline]
```

Start the gaze calibration process

Returns

True on success, false on failure

# 7.2.3.3 GazeRecordingDisable()

```
void GazeToMouse.App.GazeRecordingDisable ( ) [inline]
```

Disable gaze recordings.

#### 7.2.3.4 GazeRecordingEnable()

```
void GazeToMouse.App.GazeRecordingEnable ( ) [inline]
```

Enable gaze recordings to disk.

# 7.2.3.5 MouseTrackingDisable()

```
void GazeToMouse.App.MouseTrackingDisable ( ) [inline]
```

Disable mouse tracking.

# 7.2.3.6 MouseTrackingEnable()

```
void GazeToMouse.App.MouseTrackingEnable ( ) [inline]
```

Enable mouse tracking which updates the mouse position to the current gaze point.

### 7.2.3.7 ResetDriftCompensation()

```
void GazeToMouse.App.ResetDriftCompensation ( ) [inline]
```

Reset the current drift compensation offset to zero.


The documentation for this class was generated from the following file:

• source/GazeToMouse/App.xaml.cs


# 7.3 ShowMouse.App Class Reference

Interaction logic for App.xaml

Inheritance diagram for ShowMouse.App:



Collaboration diagram for ShowMouse.App:



# 7.3.1 Detailed Description

Interaction logic for App.xaml


The documentation for this class was generated from the following file:

• source/ShowMouse/App.xaml.cs


# 7.4 TobiiCalibrate.App Class Reference

Interaction logic for App.xaml

Inheritance diagram for TobiiCalibrate.App:



Collaboration diagram for TobiiCalibrate.App:



# 7.4.1 Detailed Description

Interaction logic for App.xaml


The documentation for this class was generated from the following file:

source/TobiiCalibrate/App.xaml.cs


# 7.5 GazeUtilityLibrary.Tracker.BaseTracker Class Reference

The common interface for the Tobii eyetracker Engines Core and Pro

Inheritance diagram for GazeUtilityLibrary.Tracker.BaseTracker:



 $Collaboration\ diagram\ for\ Gaze Utility Library. Tracker. Base Tracker:$ 



# **Public Types**

enum DeviceStatus {
 Configuring, Initializing, InvalidConfiguration, DeviceNotConnected,
 Tracking }

#### **Public Member Functions**

delegate void GazeDataHandler (object sender, GazeData gazeData)

Event handler for gaze data events of the eyetracker

delegate void DriftCompensationEventHandler (object sender, Quaternion driftCompensation)

Event handler for drift compensation events

• delegate void UserPositionDataHandler (object sender, UserPositionData e)

Event handler for user position data events of the eyetracker

BaseTracker (TrackerLogger logger, ConfigItem config, string deviceName)

Initializes a new instance of the EyeTrackerHandler class.

• void Dispose ()

Performs application-defined tasks associated with freeing, releasing, or resetting unmanaged resources.

virtual string PatternReplace (string pattern)

Replaces a patten string with information from the eye tracker. This is device specific and may be overwritten by the device class.

• abstract Task InitCalibration ()

Initialise the calibartion process. This is device specific and must be overwritten by the device class.

· abstract Task FinishCalibration ()

Finish the calibartion process. This is device specific and must be overwritten by the device class.

abstract Task< List< GazeCalibrationData > > ApplyCalibration ()

Apply the calibration data. This is device specific and must be overwritten by the device class.

abstract Task< bool > CollectCalibrationData (Point point)

Collect calibration data on a calibration point. This is device specific and must be overwritten by the device class.

void StartDriftCompensation ()

Start the drift compensation process.

void ResetDriftCompensation ()

Reset the drift compensation value

virtual bool IsInitialised ()

Checks wheter the device is connected and initialised. This is device specific and may be overwritten. Otherwise true is always returned.

#### **Public Attributes**

readonly string DeviceName

The name of the tracker device

#### **Protected Member Functions**

abstract void InitDriftCompensation ()

Initialise the drift compensation. This is device specific and must be overwritten by the device class.

abstract int GetFixationFrameCount ()

Get the number of required gaze samples to compute a fixation. This is device specific and must be overwritten by the device because the duration of fixation point detection depends on the frame rate of the device.

• abstract Vector3 GetUnitDirection ()

Get the unit vector pointing in the direction of the gaze vector. This is device specific as the gaze data are represented in a coordinate system as defined by the device.

virtual void Dispose (bool disposing)

Releases unmanaged and - optionally - managed resources.

• bool IsReady ()

Determines whether this eye tracker is ready.

virtual void OnGazeDataReceived (GazeData gazeData)

Called when [gaze data received].

virtual void OnUserPositionDataReceived (UserPositionData e)

Called when [user position data received].

virtual void OnPropertyChanged (string property\_name)

Called when when the state property of EyeTracker is changing.

virtual void OnTrackerDisabled (EventArgs e)

Raises the E:TrackerDisabled event.

• void OnTrackerDisabledTimeout (object? source, ElapsedEventArgs e)

Called after a specified amount of time of the eyetracker not being ready.

virtual void OnTrackerEnabled (EventArgs e)

Raises the E:TrackerEnabled event.

#### **Protected Attributes**

Timer? dialogBoxTimer

Timer to control the apperance of the dialog box

TrackerLogger logger

The logger

• TrackerMessageBox? trackerMessageBox

The dialog box that is controlled by the dialogBoxTimer

• DriftCompensation? driftCompensation

drift compensation handler

• ScreenArea? screenArea = null

The scrren area structure holding the metrics of the screen in 3d space.

· ConfigItem config

The gaze configuration item

# **Properties**

• DeviceStatus State [get, set]

Gets or sets the state of the eyetracker device.

#### **Events**

· EventHandler? TrackerEnabled

Occurs when [tracker enabled].

• EventHandler? TrackerDisabled

Occurs when [tracker disabled].

• PropertyChangedEventHandler? PropertyChanged

Occurs when a property value changes.

GazeDataHandler? GazeDataReceived

Occurs when [gaze data received].

• DriftCompensationEventHandler? DriftCompensationComputed

Occurs when drift compensation was computed.

• UserPositionDataHandler? UserPositionDataReceived

Occurs when [user position data received].

# 7.5.1 Detailed Description

The common interface for the Tobii eyetracker Engines Core and Pro

See also

INotifyPropertyChanged, IDisposable

#### 7.5.2 Constructor & Destructor Documentation

#### 7.5.2.1 BaseTracker()

Initializes a new instance of the EyeTrackerHandler class.

#### **Parameters**

| logger      | The logger.         |
|-------------|---------------------|
| ready_timer | The ready timer.    |
| device_name | Name of the device. |

#### 7.5.3 Member Function Documentation

#### 7.5.3.1 ApplyCalibration()

```
abstract\ Task < List < Gaze Calibration Data > Saze Utility Library. Tracker. Base Tracker. Apply \leftarrow Calibration ( ) [pure virtual]
```

Apply the calibration data. This is device specific and must be overwritten by the device class.

#### Returns

The calibration data result wrapped by an async handler.

Implemented in GazeUtilityLibrary.Tracker.EyeTrackerPro, and GazeUtilityLibrary.Tracker.MouseTracker.

#### 7.5.3.2 CollectCalibrationData()

Collect calibration data on a calibration point. This is device specific and must be overwritten by the device class.

#### **Parameters**

| point | The calibration point for which to collect data |
|-------|---|
|-------|---|

#### Returns

True on success, false on failure, wrapped by an async handler.

Implemented in GazeUtilityLibrary.Tracker.EyeTrackerPro, and GazeUtilityLibrary.Tracker.MouseTracker.

# 7.5.3.3 Dispose() [1/2]

```
void GazeUtilityLibrary.Tracker.BaseTracker.Dispose ( ) [inline]
```

Performs application-defined tasks associated with freeing, releasing, or resetting unmanaged resources.

#### 7.5.3.4 Dispose() [2/2]

Releases unmanaged and - optionally - managed resources.

#### **Parameters**

| disposing | true to release both managed and unmanaged resources; false to release only unmanaged |
|-----------|---|
|           | resources.  |

Reimplemented in GazeUtilityLibrary.Tracker.MouseTracker.

# 7.5.3.5 DriftCompensationEventHandler()

Event handler for drift compensation events

#### **Parameters**

| sender            | The sender.                       |
|-------------------|-----------------------------------|
| driftCompensation | The drift compensation quaternion |

#### 7.5.3.6 FinishCalibration()

```
abstract Task GazeUtilityLibrary.Tracker.BaseTracker.FinishCalibration ( ) [pure virtual]
```

Finish the calibartion process. This is device specific and must be overwritten by the device class.

#### Returns

An async handler

Implemented in GazeUtilityLibrary.Tracker.EyeTrackerPro, and GazeUtilityLibrary.Tracker.MouseTracker.

#### 7.5.3.7 GazeDataHandler()

Event handler for gaze data events of the eyetracker

#### **Parameters**

| sender   | The sender. |
|----------|-------------|
| gazeData | The e.      |

### 7.5.3.8 GetFixationFrameCount()

```
abstract int GazeUtilityLibrary.Tracker.BaseTracker.GetFixationFrameCount () [protected], [pure virtual]
```

Get the number of required gaze samples to compute a fixation. This is device specific and must be overwritten by the device because the duration of fixation point detection depends on the frame rate of the device.

#### Returns

The number of gaze samples to require for fixation detection.

Implemented in GazeUtilityLibrary.Tracker.EyeTrackerPro, and GazeUtilityLibrary.Tracker.MouseTracker.

#### 7.5.3.9 GetUnitDirection()

```
abstract Vector3 GazeUtilityLibrary.Tracker.BaseTracker.GetUnitDirection ( ) [protected],
[pure virtual]
```

Get the unit vector pointing in the direction of the gaze vector. This is device specific as the gaze data are represented in a coordinate system as defined by the device.

Returns

The unit vector

Implemented in GazeUtilityLibrary.Tracker.EyeTrackerPro, and GazeUtilityLibrary.Tracker.MouseTracker.

#### 7.5.3.10 InitCalibration()

```
abstract Task GazeUtilityLibrary.Tracker.BaseTracker.InitCalibration ( ) [pure virtual]
```

Initialise the calibartion process. This is device specific and must be overwritten by the device class.

Returns

An async handler

Implemented in GazeUtilityLibrary.Tracker.MouseTracker, and GazeUtilityLibrary.Tracker.EyeTrackerPro.

#### 7.5.3.11 InitDriftCompensation()

```
abstract void GazeUtilityLibrary.Tracker.BaseTracker.InitDriftCompensation ( ) [protected], [pure virtual]
```

Initialise the drift compensation. This is device specific and must be overwritten by the device class.

Implemented in GazeUtilityLibrary.Tracker.MouseTracker, and GazeUtilityLibrary.Tracker.EyeTrackerPro.

#### 7.5.3.12 IsInitialised()

```
virtual bool GazeUtilityLibrary.Tracker.BaseTracker.IsInitialised ( ) [inline], [virtual]
```

Checks wheter the device is connected and initialised. This is device specific and may be overwritten. Otherwise true is always returned.

Returns

True

Reimplemented in GazeUtilityLibrary.Tracker.EyeTrackerPro.

#### 7.5.3.13 IsReady()

```
bool GazeUtilityLibrary.Tracker.BaseTracker.IsReady ( ) [inline], [protected]
```

Determines whether this eye tracker is ready.

#### Returns

true if this instance is ready; otherwise, false.

#### 7.5.3.14 OnGazeDataReceived()

Called when [gaze data received].

#### **Parameters**

data The gaze data event data.

#### 7.5.3.15 OnPropertyChanged()

Called when when the state property of EyeTracker is changing.

### **Parameters**

```
property name Name of the property in WPF.
```

#### 7.5.3.16 OnTrackerDisabled()

Raises the E:TrackerDisabled event.

#### **Parameters**

*e* The EventArgs instance containing the event data.

#### 7.5.3.17 OnTrackerDisabledTimeout()

Called after a specified amount of time of the eyetracker not being ready.

#### **Parameters**

| source | The source.  |
|--------|--|
| е      | The ElapsedEventArgs instance containing the event data. |

#### 7.5.3.18 OnTrackerEnabled()

Raises the E:TrackerEnabled event.

#### **Parameters**

```
e The EventArgs instance containing the event data.
```

#### 7.5.3.19 OnUserPositionDataReceived()

Called when [user position data received].

#### **Parameters**

```
e The gaze data event data.
```

#### 7.5.3.20 PatternReplace()

Replaces a patten string with information from the eye tracker. This is device specific and may be overwritten by the device class.

#### Returns

The string where patterns were replaced.

Reimplemented in GazeUtilityLibrary.Tracker.EyeTrackerPro.

#### 7.5.3.21 ResetDriftCompensation()

```
void GazeUtilityLibrary.Tracker.BaseTracker.ResetDriftCompensation ( ) [inline]
```

Reset the drift compensation value

#### 7.5.3.22 StartDriftCompensation()

```
\verb|void GazeUtilityLibrary.Tracker.BaseTracker.StartDriftCompensation () [inline]|\\
```

Start the drift compensation process.

#### 7.5.3.23 UserPositionDataHandler()

Event handler for user position data events of the eyetracker

#### **Parameters**

| sender | The sender. |
|--------|-------------|
| е      | The e.      |

# 7.5.4 Member Data Documentation

# 7.5.4.1 config

 ${\tt ConfigItem\ GazeUtilityLibrary.Tracker.BaseTracker.config\ [protected]}$ 

The gaze configuration item

#### 7.5.4.2 DeviceName

readonly string GazeUtilityLibrary.Tracker.BaseTracker.DeviceName

The name of the tracker device

#### 7.5.4.3 dialogBoxTimer

 ${\tt Timer?} \quad {\tt GazeUtilityLibrary.Tracker.BaseTracker.dialogBoxTimer} \quad [protected]$ 

Timer to control the apperance of the dialog box

### 7.5.4.4 driftCompensation

DriftCompensation? GazeUtilityLibrary.Tracker.BaseTracker.driftCompensation [protected] drift compensation handler

#### 7.5.4.5 logger

TrackerLogger GazeUtilityLibrary.Tracker.BaseTracker.logger [protected]

The logger

#### 7.5.4.6 screenArea

```
ScreenArea? GazeUtilityLibrary.Tracker.BaseTracker.screenArea = null [protected]
```

The scrren area structure holding the metrics of the screen in 3d space.

#### 7.5.4.7 trackerMessageBox

TrackerMessageBox? GazeUtilityLibrary.Tracker.BaseTracker.trackerMessageBox [protected]

The dialog box that is controlled by the dialogBoxTimer

# 7.5.5 Property Documentation

#### 7.5.5.1 State

DeviceStatus GazeUtilityLibrary.Tracker.BaseTracker.State [get], [set]

Gets or sets the state of the eyetracker device.

The state.

# 7.5.6 Event Documentation

# 7.5.6.1 DriftCompensationComputed

Occurs when drift compensation was computed.

#### 7.5.6.2 GazeDataReceived

GazeDataHandler? GazeUtilityLibrary.Tracker.BaseTracker.GazeDataReceived

Occurs when [gaze data received].

#### 7.5.6.3 PropertyChanged

 ${\tt PropertyChangedEventHandler?} \quad {\tt GazeUtilityLibrary.Tracker.BaseTracker.PropertyChangedEventHandler?} \\$ 

Occurs when a property value changes.

#### 7.5.6.4 TrackerDisabled

 ${\tt EventHandler?} \quad {\tt GazeUtilityLibrary.Tracker.BaseTracker.TrackerDisabled}$ 

Occurs when [tracker disabled].

#### 7.5.6.5 TrackerEnabled

EventHandler? GazeUtilityLibrary.Tracker.BaseTracker.TrackerEnabled

Occurs when [tracker enabled].

#### 7.5.6.6 UserPositionDataReceived

UserPositionDataHandler? GazeUtilityLibrary.Tracker.BaseTracker.UserPositionDataReceived

Occurs when [user position data received].


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/Tracker/BaseTracker.cs


# 7.6 CustomCalibrationLibrary.Views.Calibration Class Reference

Interaction logic for Calibration.xaml

Inheritance diagram for CustomCalibrationLibrary.Views.Calibration:



Collaboration diagram for CustomCalibrationLibrary. Views. Calibration:



# **Public Member Functions**

• Calibration (CalibrationModel model)

# 7.6.1 Detailed Description

Interaction logic for Calibration.xaml


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/Calibration.xaml.cs


# 7.7 CustomCalibrationLibrary.Commands.CalibrationCommand Class Reference

Comand class to trigger calibration events.

Inheritance diagram for CustomCalibrationLibrary.Commands.CalibrationCommand:



 $Collaboration\ diagram\ for\ Custom Calibration Library. Commands. Calibration Command:$ 



# **Public Member Functions**

- CalibrationCommand (CalibrationModel model, CalibrationEventType eventType)
- bool CanExecute (object? parameter)
- · void Execute (object? parameter)

#### **Events**

• EventHandler? CanExecuteChanged

# 7.7.1 Detailed Description


Comand class to trigger calibration events.

The documentation for this class was generated from the following file:


• source/CustomCalibrationLibrary/Commands/CalibrationCommand.cs

# 7.8 GazeUtilityLibrary.CalibrationDataError Class Reference

Inheritance diagram for GazeUtilityLibrary.CalibrationDataError:



 $Collaboration\ diagram\ for\ Gaze Utility Library. Calibration Data Error:$ 



#### **Public Member Functions**

string GetCalibrationDataErrorString ()
 Gets the gaze error string.

# **Properties**

• ECalibrationDataError Error [set]

#### **Additional Inherited Members**

#### 7.8.1 Member Function Documentation

#### 7.8.1.1 GetCalibrationDataErrorString()

string GazeUtilityLibrary.CalibrationDataError.GetCalibrationDataErrorString ( ) [inline]

Gets the gaze error string.

#### Returns

the error string with binary error values if errors ocurred, the empty srting otherwise


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/GazeError.cs


# 7.9 CustomCalibrationLibrary.Views.CalibrationFailed Class Reference

Interaction logic for CalibrationFailed.xaml

 $Inheritance\ diagram\ for\ Custom Calibration Library. Views. Calibration Failed:$ 



Collaboration diagram for CustomCalibrationLibrary. Views. CalibrationFailed:



#### **Public Member Functions**

CalibrationFailed (CalibrationModel model)
 Constructor

# **Properties**

- ICommand CalibrationRestartCommand [get]

  Command to restart the calibration
- ICommand CalibrationAbortCommand [get]

Command to abort the calibration

• string Error [get, set]

The error message to be updated on the view.

#### **Events**

PropertyChangedEventHandler? PropertyChanged
 The property change event to update the view.

# 7.9.1 Detailed Description

Interaction logic for CalibrationFailed.xaml

# 7.9.2 Constructor & Destructor Documentation

# 7.9.2.1 CalibrationFailed()

Constructor

#### **Parameters**

| model The clai | bration model |
|----------------|---------------|
|----------------|---------------|

# 7.9.3 Property Documentation

#### 7.9.3.1 CalibrationAbortCommand

 ${\tt ICommand~CustomCalibrationLibrary. Views. CalibrationFailed. CalibrationAbortCommand~[get]}$ 

Command to abort the calibration

#### 7.9.3.2 CalibrationRestartCommand

 ${\tt ICommand\ CustomCalibrationLibrary. Views. CalibrationFailed. CalibrationRestart Command\ [get]}$ 

Command to restart the calibration

# 7.9.3.3 Error

string CustomCalibrationLibrary.Views.CalibrationFailed.Error [get], [set]

The error message to be updated on the view.

#### 7.9.4 Event Documentation

#### 7.9.4.1 PropertyChanged

PropertyChangedEventHandler? CustomCalibrationLibrary.Views.CalibrationFailed.PropertyChanged

The property change event to update the view.


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/CalibrationFailed.xaml.cs


# 7.10 CustomCalibrationLibrary.Views.CalibrationFrame Class Reference

Interaction logic for CalibrationCollection.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. CalibrationFrame:



Collaboration diagram for CustomCalibrationLibrary. Views. CalibrationFrame:



# **Public Member Functions**

• CalibrationFrame (CalibrationModel model)

# 7.10.1 Detailed Description

Interaction logic for CalibrationCollection.xaml


The documentation for this class was generated from the following file:

 $\bullet \ \ source/Custom Calibration Library/Views/Calibration Frame.xaml.cs$ 


# 7.11 CustomCalibrationLibrary.Models.CalibrationModel Class Reference

The model for the calibration process.

Inheritance diagram for CustomCalibrationLibrary.Models.CalibrationModel:



Collaboration diagram for CustomCalibrationLibrary.Models.CalibrationModel:



# **Public Member Functions**

- void OnCalibrationEvent (CalibrationEventType type)
- CalibrationModel (TrackerLogger logger, double[][] points)
- void UpdateGazePoint (double x, double y)

Update the normalized gaze point on the screen.

• void InitCalibration ()

Initialise the calibration.

void NextCalibrationPoint ()

Trigger the next calibration point.

void RedoCalibrationPoint ()

Remove and re-add the current calibration point

void GazeDataCollected ()

Trigger the data collected events.

void SetCalibrationResult (List< GazeCalibrationData > points)

Updates the calibration results on the screen.

# **Properties**

• string Error [get, set]

The error message of the calibration process.

• CalibrationStatus Status [get, set]

The status of the calibarion process.

CalibrationStatus LastStatus [get]

The calibration status before an error occured.

• Point[] Points [get]

All calibration points.

• ObservableCollection < CalibrationPoint > CalibrationPoints [get]

The calibration points to be added during the calibration process.

• Point GazePoint [get]

The gaze point position.

• UserPositionData UserPositionGuide [get, set]

The user position giude values.

• int Index [get]

The index of the current calibration point

#### **Events**

EventHandler < CalibrationEventType >? CalibrationEvent

Events to trigger changes in the calibration process.

- · PropertyChangedEventHandler? PropertyChanged
- EventHandler< Point >? GazePointChanged
- EventHandler< UserPositionData >? UserPositionGuideChanged

#### 7.11.1 Detailed Description

The model for the calibration process.

#### 7.11.2 Member Function Documentation

# 7.11.2.1 GazeDataCollected()

```
\verb|void CustomCalibrationLibrary.Models.CalibrationModel.GazeDataCollected () | [inline]| \\
```

Trigger the data collected events.

#### 7.11.2.2 InitCalibration()

```
\verb|void CustomCalibrationLibrary.Models.CalibrationModel.InitCalibration () | [inline]| \\
```

Initialise the calibration.

#### 7.11.2.3 NextCalibrationPoint()

```
\verb|void CustomCalibrationLibrary.Models.CalibrationModel.NextCalibrationPoint () | [inline]| \\
```

Trigger the next calibration point.

#### 7.11.2.4 RedoCalibrationPoint()

```
\verb|void CustomCalibrationLibrary.Models.CalibrationModel.RedoCalibrationPoint () | [inline]| \\
```

Remove and re-add the current calibration point

# 7.11.2.5 SetCalibrationResult()

```
\label{limit} \mbox{\sc Void CustomCalibrationLibrary.Models.CalibrationModel.SetCalibrationResult (} \\ \mbox{\sc List} < \mbox{\sc GazeCalibrationData} > points \mbox{\sc )} \mbox{\sc [inline]}
```

Updates the calibration results on the screen.

#### **Parameters**

points

# 7.11.2.6 UpdateGazePoint()

```
void CustomCalibrationLibrary.Models.CalibrationModel.UpdateGazePoint ( double x, double y) [inline]
```

Update the normalized gaze point on the screen.

#### **Parameters**

| Х | The x coordinate |
|---|------------------|
| У | The y coordinate |

# 7.11.3 Property Documentation

#### 7.11.3.1 CalibrationPoints

 $\label{localibrationPoint} Observable Collection < CalibrationPoint > Custom Calibration Library. Models. Calibration Model. \leftarrow Calibration Points \ [get]$ 

The calibration points to be added during the calibration process.

#### 7.11.3.2 Error

string CustomCalibrationLibrary.Models.CalibrationModel.Error [get], [set]

The error message of the calibration process.

#### 7.11.3.3 GazePoint

Point CustomCalibrationLibrary.Models.CalibrationModel.GazePoint [get]

The gaze point position.

#### 7.11.3.4 Index

int CustomCalibrationLibrary.Models.CalibrationModel.Index [get]

The index of the current calibration point

#### 7.11.3.5 LastStatus

CalibrationStatus CustomCalibrationLibrary.Models.CalibrationModel.LastStatus [get]

The calibration status before an error occured.

#### 7.11.3.6 Points

Point [] CustomCalibrationLibrary.Models.CalibrationModel.Points [get]

All calibration points.

#### 7.11.3.7 Status

CalibrationStatus CustomCalibrationLibrary.Models.CalibrationModel.Status [get], [set]

The status of the calibarion process.

#### 7.11.3.8 UserPositionGuide

UserPositionData CustomCalibrationLibrary.Models.CalibrationModel.UserPositionGuide [get],
[set]

The user position giude values.

#### 7.11.4 Event Documentation

#### 7.11.4.1 CalibrationEvent

 $\label{limit} \textbf{EventHandler} < \textbf{CalibrationEventType} > ? \quad \textbf{CustomCalibrationLibrary.Models.CalibrationModel.Calibration} \leftarrow \textbf{Event}$ 

Events to trigger changes in the calibration process.


The documentation for this class was generated from the following file:

 $\bullet \ source/Custom Calibration Library/Models/Calibration Model. cs$ 


# 7.12 GazeUtilityLibrary.DataStructs.CalibrationPoint Class Reference

A calibration point class holding several metrics connected to a calibration point.

 $Inheritance\ diagram\ for\ Gaze Utility Library. Data Structs. Calibration Point:$ 



Collaboration diagram for GazeUtilityLibrary.DataStructs.CalibrationPoint:



#### **Public Member Functions**

• CalibrationPoint (Point position, int index)

# **Properties**

```
• int Index [get]
```

The index of the calibration point.

• bool HasData [get, set]

Flag to indicate whether data has been collected for this calibration point.

• Point Position [get, set]

The position of the calibration point.

• Point GazePositionAverage [get, set]

The average between the left and the right gaze point.

• Point GazePositionLeft [get, set]

The left gaze point.

• Point GazePositionRight [get, set]

The right gaze point.

# **Events**

• PropertyChangedEventHandler? PropertyChanged

# 7.12.1 Detailed Description

A calibration point class holding several metrics connected to a calibration point.

# 7.12.2 Property Documentation

#### 7.12.2.1 GazePositionAverage

Point GazeUtilityLibrary.DataStructs.CalibrationPoint.GazePositionAverage [get], [set]

The average between the left and the right gaze point.

#### 7.12.2.2 GazePositionLeft

Point GazeUtilityLibrary.DataStructs.CalibrationPoint.GazePositionLeft [get], [set]

The left gaze point.

#### 7.12.2.3 GazePositionRight

Point GazeUtilityLibrary.DataStructs.CalibrationPoint.GazePositionRight [get], [set]

The right gaze point.

#### 7.12.2.4 HasData

bool GazeUtilityLibrary.DataStructs.CalibrationPoint.HasData [get], [set]

Flag to indicate whether data has been collected for this calibration point.

# 7.12.2.5 Index

int GazeUtilityLibrary.DataStructs.CalibrationPoint.Index [get]

The index of the calibration point.

#### 7.12.2.6 Position

Point GazeUtilityLibrary.DataStructs.CalibrationPoint.Position [get], [set]

The position of the calibration point.


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/CalibrationPoint.cs


# 7.13 CustomCalibrationLibrary.Views.CalibrationPoint Class Reference

Interaction logic for CalibrationPoint.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. CalibrationPoint:



Collaboration diagram for CustomCalibrationLibrary. Views. CalibrationPoint:



# 7.13.1 Detailed Description

Interaction logic for CalibrationPoint.xaml


The documentation for this class was generated from the following file:

 $\bullet \ \ source/Custom Calibration Library/Views/Calibration Point.xam I.cs$ 


# 7.14 CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel Class Reference

The view model for a calibration point.

Inheritance diagram for CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel:



Collaboration diagram for CustomCalibrationLibrary.ViewModels.CalibrationPointViewModel:



### **Public Member Functions**

- CalibrationPointViewModel (Point point, int index)
- CalibrationPointViewModel (CalibrationPoint model)

# **Additional Inherited Members**

# 7.14.1 Detailed Description

The view model for a calibration point.


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/ViewModels/CalibrationPointViewModel.cs


# 7.15 CustomCalibrationLibrary.Views.CalibrationResult Class Reference

Interaction logic for CalibrationResult.xaml

Inheritance diagram for CustomCalibrationLibrary.Views.CalibrationResult:



Collaboration diagram for CustomCalibrationLibrary. Views. CalibrationResult:



# **Public Member Functions**

• CalibrationResult (CalibrationModel model)

# 7.15.1 Detailed Description

Interaction logic for CalibrationResult.xaml


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/CalibrationResult.xaml.cs


# 7.16 CustomCalibrationLibrary.Views.CalibrationResultPoint Class Reference

Interaction logic for CalibrationResultPoint.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. CalibrationResultPoint:



 $Collaboration\ diagram\ for\ Custom Calibration Library. Views. Calibration Result Point:$ 



# 7.16.1 Detailed Description

Interaction logic for CalibrationResultPoint.xaml


The documentation for this class was generated from the following file:

 $\bullet \ source/Custom Calibration Library/Views/Calibration Result Point.x aml. cs$ 


# 7.17 CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel Class Reference

View model class of the gaze calibration result.

 $Inheritance\ diagram\ for\ Custom Calibration Library. View Models. Calibration Result View Model:$ 



Collaboration diagram for CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel:



# **Public Member Functions**

- CalibrationResultViewModel (CalibrationModel model)
   Constructor
- void OnGazeToggle ()

Toggle the visibility of the live gaze point.

# **Properties**

- ICommand CalibrationRestartCommand [get]
  - Command to restart the calibration
- ICommand CalibrationAcceptCommand [get]

Command to accept the calibration

• ICommand GazeVisibilityCommand [get]

Command to toggle the visibility of the live gaze point

• LiveGazePoint GazePoint [get]

The position of the live gaze point

#### **Additional Inherited Members**

# 7.17.1 Detailed Description

View model class of the gaze calibration result.

# 7.17.2 Constructor & Destructor Documentation

## 7.17.2.1 CalibrationResultViewModel()

Constructor

**Parameters** 

model The claibration model

#### 7.17.3 Member Function Documentation

# 7.17.3.1 OnGazeToggle()

 $\verb|void CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel.OnGazeToggle () | [inline]| \\$ 

Toggle the visibility of the live gaze point.

# 7.17.4 Property Documentation

# 7.17.4.1 CalibrationAcceptCommand

 $\label{localibrationLibrary.ViewModels.CalibrationResultViewModel.CalibrationAccept} $$\operatorname{Command}$ [get]$ 

Command to accept the calibration

#### 7.17.4.2 CalibrationRestartCommand

 $\label{thm:command} I Command \ Custom Calibration Library. View Models. Calibration Result View Model. Calibration Restart \leftarrow Command \ [get]$ 

Command to restart the calibration

#### 7.17.4.3 GazePoint

LiveGazePoint CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel.GazePoint [get]

The position of the live gaze point

#### 7.17.4.4 GazeVisibilityCommand

ICommand CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel.GazeVisibilityCommand [qet]

Command to toggle the visibility of the live gaze point

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/ViewModels/CalibrationResultViewModel.cs

# 7.18 Tobii.Research.Addons.CalibrationValidationPoint Class Reference

Represents a collected point that goes into the calibration validation. It contains calculated values for accuracy and precision as well as the original gaze samples collected for the point.

#### **Public Member Functions**

• override string ToString ()

# **Properties**

NormalizedPoint2D Coordinates [get]

The 2D coordinates of this point (in Active Display Coordinate System).

• float AccuracyLeftEye [get]

The accuracy in degrees for the left eye.

• float PrecisionLeftEye [get]

The precision (standard deviation) in degrees for the left eye.

• float PrecisionRMSLeftEye [get]

The precision (root mean square of sample-to-sample error) in degrees for the left eye.

• float AccuracyRightEye [get]

The accuracy in degrees for the right eye.

float PrecisionRightEye [get]

The precision (standard deviation) in degrees for the right eye.

• float PrecisionRMSRightEye [get]

The precision (root mean square of sample-to-sample error) in degrees for the right eye.

bool TimedOut [get]

A boolean indicating if there was a timeout while collecting data for this point.

GazeDataEventArgs[] GazeData [get]

The gaze data samples collected for this point. These samples are the base for the calculated accuracy and precision.

# 7.18.1 Detailed Description

Represents a collected point that goes into the calibration validation. It contains calculated values for accuracy and precision as well as the original gaze samples collected for the point.

# 7.18.2 Property Documentation

#### 7.18.2.1 AccuracyLeftEye

float Tobii.Research.Addons.CalibrationValidationPoint.AccuracyLeftEye [get]

The accuracy in degrees for the left eye.

#### 7.18.2.2 AccuracyRightEye

float Tobii.Research.Addons.CalibrationValidationPoint.AccuracyRightEye [get]

The accuracy in degrees for the right eye.

### 7.18.2.3 Coordinates

NormalizedPoint2D Tobii.Research.Addons.CalibrationValidationPoint.Coordinates [get]

The 2D coordinates of this point (in Active Display Coordinate System).

#### 7.18.2.4 GazeData

GazeDataEventArgs [] Tobii.Research.Addons.CalibrationValidationPoint.GazeData [get]

The gaze data samples collected for this point. These samples are the base for the calculated accuracy and precision.

# 7.18.2.5 PrecisionLeftEye

float Tobii.Research.Addons.CalibrationValidationPoint.PrecisionLeftEye [get]

The precision (standard deviation) in degrees for the left eye.

#### 7.18.2.6 PrecisionRightEye

float Tobii.Research.Addons.CalibrationValidationPoint.PrecisionRightEye [get]

The precision (standard deviation) in degrees for the right eye.

#### 7.18.2.7 PrecisionRMSLeftEye

float Tobii.Research.Addons.CalibrationValidationPoint.PrecisionRMSLeftEye [get]

The precision (root mean square of sample-to-sample error) in degrees for the left eye.

#### 7.18.2.8 PrecisionRMSRightEye

float Tobii.Research.Addons.CalibrationValidationPoint.PrecisionRMSRightEye [get]

The precision (root mean square of sample-to-sample error) in degrees for the right eye.

#### 7.18.2.9 TimedOut

bool Tobii.Research.Addons.CalibrationValidationPoint.TimedOut [get]

A boolean indicating if there was a timeout while collecting data for this point.

The documentation for this class was generated from the following file:

• source/TobiiProSdkAddons/ScreenBasedCalibrationValidation.cs

# 7.19 Tobii.Research.Addons.CalibrationValidationResult Class Reference

Contains the result of the calibration validation.

#### **Public Member Functions**

override string ToString ()

# **Properties**

List < CalibrationValidationPoint > Points [get]

The results of the calibration validation per point (same points as were collected).

• float AverageAccuracyLeftEye [get]

The accuracy in degrees averaged over all collected points for the left eye.

• float AveragePrecisionLeftEye [get]

The precision (standard deviation) in degrees averaged over all collected points for the left eye.

float AveragePrecisionRMSLeftEye [get]

The precision (root mean square of sample-to-sample error) in degrees averaged over all collected points for the left eye.

• float AverageAccuracyRightEye [get]

The accuracy in degrees averaged over all collected points for the right eye.

• float AveragePrecisionRightEye [get]

The precision (standard deviation) in degrees averaged over all collected points for the right eye.

float AveragePrecisionRMSRightEye [get]

The precision (root mean square of sample-to-sample error) in degrees averaged over all collected points for the right eye.

# 7.19.1 Detailed Description

Contains the result of the calibration validation.

### 7.19.2 Property Documentation

#### 7.19.2.1 AverageAccuracyLeftEye

float Tobii.Research.Addons.CalibrationValidationResult.AverageAccuracyLeftEye [get]

The accuracy in degrees averaged over all collected points for the left eye.

# 7.19.2.2 AverageAccuracyRightEye

 ${\tt float\ Tobii.Research.Addons.CalibrationValidationResult.AverageAccuracyRightEye\ [get]}$ 

The accuracy in degrees averaged over all collected points for the right eye.

#### 7.19.2.3 AveragePrecisionLeftEye

float Tobii.Research.Addons.CalibrationValidationResult.AveragePrecisionLeftEye [get]

The precision (standard deviation) in degrees averaged over all collected points for the left eye.

#### 7.19.2.4 AveragePrecisionRightEye

float Tobii.Research.Addons.CalibrationValidationResult.AveragePrecisionRightEye [get]

The precision (standard deviation) in degrees averaged over all collected points for the right eye.

#### 7.19.2.5 AveragePrecisionRMSLeftEye

float Tobii.Research.Addons.CalibrationValidationResult.AveragePrecisionRMSLeftEye [get]

The precision (root mean square of sample-to-sample error) in degrees averaged over all collected points for the left eye.

#### 7.19.2.6 AveragePrecisionRMSRightEye

float Tobii.Research.Addons.CalibrationValidationResult.AveragePrecisionRMSRightEye [get]

The precision (root mean square of sample-to-sample error) in degrees averaged over all collected points for the right eye.

#### 7.19.2.7 Points

List < Calibration Validation Point > Tobii. Research. Addons. Calibration Validation Result. Points [get]

The results of the calibration validation per point (same points as were collected).


The documentation for this class was generated from the following file:

• source/TobiiProSdkAddons/ScreenBasedCalibrationValidation.cs


# 7.20 CustomCalibrationLibrary.ViewModels.CalibrationViewModel Class Reference

The view model class of the calibration view

Inheritance diagram for CustomCalibrationLibrary.ViewModels.CalibrationViewModel:



Collaboration diagram for CustomCalibrationLibrary.ViewModels.CalibrationViewModel:



#### **Public Member Functions**

CalibrationViewModel (CalibrationModel model)

Constructor

# **Protected Attributes**

• CalibrationModel \_model

# **Properties**

• ObservableCollection< CalibrationPointViewModel > CalibrationPoints [get]

The collection of calibration points to be shown on the view

# 7.20.1 Detailed Description

The view model class of the calibration view

#### 7.20.2 Constructor & Destructor Documentation

#### 7.20.2.1 CalibrationViewModel()

Constructor

#### **Parameters**

| model The cali | bration model |
|----------------|---------------|
|----------------|---------------|

# 7.20.3 Property Documentation

#### 7.20.3.1 CalibrationPoints

 $\label{localibrationPointViewModel} Observable Collibration Library. View Models. Calibration \\ \leftarrow View Model. Calibration Points \ [get]$ 

The collection of calibration points to be shown on the view


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/ViewModels/CalibrationViewModel.cs


# 7.21 CustomCalibrationLibrary.Views.CalibrationWindow Class Reference

Interaction logic for MainWindow.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. CalibrationWindow:



 $Collaboration\ diagram\ for\ Custom Calibration Library. Views. Calibration Window:$ 



# 7.21.1 Detailed Description

Interaction logic for MainWindow.xaml


The documentation for this class was generated from the following file:

 $\bullet \ \ source/CustomCalibrationLibrary/Views/CalibrationWindow.xaml.cs$ 


# 7.22 CustomCalibrationLibrary.Views.Computing Class Reference

Interaction logic for Computing.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. Computing:



Collaboration diagram for CustomCalibrationLibrary. Views. Computing:



# 7.22.1 Detailed Description

Interaction logic for Computing.xaml

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/Computing.xaml.cs

# 7.23 GazeUtilityLibrary.Configltem Class Reference

configuration file class

# **Properties**

```
• string? ConfigName [get, set]
• string DataLogColumnOrder [get, set]
• string[] DataLogColumnTitle [get, set]

    string CalibrationLogColumnOrder [get, set]

    string[] CalibrationLogColumnTitle [get, set]

    int DataLogCount [get, set]

    string DataLogFormatDiameter [get, set]

• string DataLogFormatOrigin [get, set]

    string DataLogFormatNormalizedPoint [get, set]

• string DataLogFormatTimeStamp [get, set]

    string DataLogFormatTimeStampRelative [get, set]

    string DataLogPath [get, set]

    bool DataLogWriteOutput [get, set]

    bool CalibrationLogWriteOutput [get, set]

    double[][] CalibrationPoints [get, set]

    bool DataLogDisabledOnStartup [get, set]

    double DispersionThreshold [get, set]

• double DriftCompensationTimer [get, set]
• string? LicensePath [get, set]

    bool MouseControl [get, set]

    bool MouseControlHide [get, set]

    bool MouseCalibrationHide [get, set]

    string MouseStandardIconPath [get, set]

• int ReadyTimer [get, set]
• int TrackerDevice [get, set]
• string TobiiApplicationPath [get, set]
• string TobiiCalibrate [get, set]

    string TobiiCalibrateArguments [get, set]
```

#### 7.23.1 Detailed Description

configuration file class


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/GazeConfiguration.cs


# 7.24 CustomCalibrationLibrary.Views.Disconnect Class Reference

Interaction logic for Disconnect.xaml

Inheritance diagram for CustomCalibrationLibrary. Views. Disconnect:



Collaboration diagram for CustomCalibrationLibrary. Views. Disconnect:



# **Public Member Functions**

• Disconnect (CalibrationModel model)

# **Properties**

• ICommand CalibrationAbortCommand [get]

Command to abort the calibration

# 7.24.1 Detailed Description

Interaction logic for Disconnect.xaml

# 7.24.2 Property Documentation

#### 7.24.2.1 CalibrationAbortCommand

ICommand CustomCalibrationLibrary.Views.Disconnect.CalibrationAbortCommand [get]

Command to abort the calibration

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/Disconnect.xaml.cs

# 7.25 GazeUtilityLibrary.DriftCompensation Class Reference

The class to handle drift compensation.

#### **Public Member Functions**

- · DriftCompensation (Vector3 fixationPoint, int fixationFrameCount, double dispersionThreashold)
- · void Reset ()

Reset the drift compensation quaternion to the identity.

• void Start ()

Start the drift compensation.

bool Update (GazeData gazeData)

Collect gaze data samples of a fixation and once enough samples are collected, compute the drift compensation quaternion.

# **Properties**

• Quaternion Q [get]

The drift compensation quatrenion.

# 7.25.1 Detailed Description

The class to handle drift compensation.

# 7.25.2 Member Function Documentation

# 7.25.2.1 Reset()

void GazeUtilityLibrary.DriftCompensation.Reset ( ) [inline]

Reset the drift compensation quaternion to the identity.

#### 7.25.2.2 Start()

```
void GazeUtilityLibrary.DriftCompensation.Start ( ) [inline]
```

Start the drift compensation.

#### 7.25.2.3 Update()

Collect gaze data samples of a fixation and once enough samples are collected, compute the drift compensation quaternion.

#### **Parameters**

| gazeData | The gaze data sample to collect if it belongs to a fixation. |
|----------|--|
|          |  |

#### Returns

True if new drift compensation is computed, false if the process is ongoning.

# 7.25.3 Property Documentation

# 7.25.3.1 Q

```
Quaternion GazeUtilityLibrary.DriftCompensation.Q [get]
```

The drift compensation quatrenion.

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DriftCompensation.cs

# 7.26 GazeUtilityLibrary.DataStructs.DriftCompensationData Class Reference

The drift compensation data structure

#### **Public Member Functions**

DriftCompensationData (ScreenArea screen, Quaternion driftCompensation, GazeData3d gazeData)
 Constructor

# **Properties**

```
• Vector2 GazePosition2d [get]
```

The drift compensated 2d gaze position

• Vector3 GazePosition3d [get]

The drift compensated 3d gaze position

• Quaternion Compensation [get]

The drift compensation quaternion

# 7.26.1 Detailed Description

The drift compensation data structure

# 7.26.2 Constructor & Destructor Documentation

#### 7.26.2.1 DriftCompensationData()

# Constructor

#### **Parameters**

| screen            | The screen area                   |
|-------------------|-----------------------------------|
| driftCompensation | The drift compensation quaternion |
| gazeData          | The 3d gaze data structure        |

# 7.26.3 Property Documentation

# 7.26.3.1 Compensation

Quaternion GazeUtilityLibrary.DataStructs.DriftCompensationData.Compensation [get]

The drift compensation quaternion

#### 7.26.3.2 GazePosition2d

Vector2 GazeUtilityLibrary.DataStructs.DriftCompensationData.GazePosition2d [get]

The drift compensated 2d gaze position

#### 7.26.3.3 GazePosition3d

Vector3 GazeUtilityLibrary.DataStructs.DriftCompensationData.GazePosition3d [get]

The drift compensated 3d gaze position

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/DriftCompensationData.cs

# 7.27 CustomCalibrationLibrary.ViewModels.DriftCompensationView Model Class Reference

The view model class of the drift compensation view.

#### **Public Member Functions**

• DriftCompensationViewModel ()

Constructor

# **Properties**

• CalibrationPoint FixationPoint [get, set]

The point on the screen which the participant is supposed to fixate.

# 7.27.1 Detailed Description

The view model class of the drift compensation view.

# 7.27.2 Constructor & Destructor Documentation

#### 7.27.2.1 DriftCompensationViewModel()

 ${\tt CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel.DriftCompensationViewModel} \ (\ ) \\ [inline]$ 

Constructor

# 7.27.3 Property Documentation

#### 7.27.3.1 FixationPoint

CalibrationPoint CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel.FixationPoint
[get], [set]

The point on the screen which the participant is supposed to fixate.


The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/ViewModels/DriftCompensationViewModel.cs


# 7.28 CustomCalibrationLibrary.Views.DriftCompensationWindow Class Reference

Interaction logic for DriftCompensation.xaml

Inheritance diagram for CustomCalibrationLibrary.Views.DriftCompensationWindow:



Collaboration diagram for CustomCalibrationLibrary. Views. DriftCompensationWindow:



# 7.28.1 Detailed Description

Interaction logic for DriftCompensation.xaml

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/DriftCompensationWindow.xaml.cs

# 7.29 GazeUtilityLibrary.DataStructs.EyeData Class Reference

The eye data set, including pupil information.

# **Public Member Functions**

• EyeData (float pupilDiameter, bool isPupilDiameterValid)

Initializes a new instance of the EyeData class.

# **Properties**

• float PupilDiameter [get]

The diameter of the pupil

• bool IsPupilDiameterValid [get]

The validity flag of th epupil diameter

# 7.29.1 Detailed Description

The eye data set, including pupil information.

# 7.29.2 Constructor & Destructor Documentation

# 7.29.2.1 EyeData()

Initializes a new instance of the EyeData class.

#### **Parameters**

| pupilDiameter        | The pupil diameter.                 |
|----------------------|-------------------------------------|
| isPupilDiameterValid | The validity of the pupil diameter. |

# 7.29.3 Property Documentation

#### 7.29.3.1 IsPupilDiameterValid

```
bool GazeUtilityLibrary.DataStructs.EyeData.IsPupilDiameterValid [get]
```

The validity flag of th epupil diameter

# 7.29.3.2 PupilDiameter

```
float GazeUtilityLibrary.DataStructs.EyeData.PupilDiameter [get]
```

The diameter of the pupil


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/EyeData.cs


# 7.30 GazeUtilityLibrary.Tracker.EyeTrackerPro Class Reference

Interface to the Tobii SDK Pro engine

Inheritance diagram for GazeUtilityLibrary.Tracker.EyeTrackerPro:



Collaboration diagram for GazeUtilityLibrary.Tracker.EyeTrackerPro:



# **Public Member Functions**

- EyeTrackerPro (TrackerLogger logger, ConfigItem config)
  - Initializes a new instance of the EyeTrackerPro class.
- override async Task InitCalibration ()
  - Initialise the screen based calibration.
- override async Task< bool > CollectCalibrationData (Point point)
  - Collects gaze data of a calibration point.
- override async Task FinishCalibration ()

Finish the screen based calibration process.

override async Task< List< GazeCalibrationData > > ApplyCalibration ()

Compute and apply the calibration data. Transform the Tobi calibration result into the GazeCalibrationData structure.

• bool IsLicenseOk ()

Determines whether the license is applied to the eyetracker device

• override bool IsInitialised ()

Checks if the tracker device exists.

override string PatternReplace (string pattern)

Replaces a patten string with information from the eye tracker. Supported patterns are S for the serial number and A for the address.

#### **Protected Member Functions**

• override void InitDriftCompensation ()

Initialise the drift compensation.

· override int GetFixationFrameCount ()

Get the number of required gaze samples to compute a fixation.

• override Vector3 GetUnitDirection ()

Get the unit vector pointing in the direction of the gaze vector.

#### **Additional Inherited Members**

# 7.30.1 Detailed Description

Interface to the Tobii SDK Pro engine

See also

GazeHelper.TrackerHandler

#### 7.30.2 Constructor & Destructor Documentation

# 7.30.2.1 EyeTrackerPro()

Initializes a new instance of the EyeTrackerPro class.

#### **Parameters**

| logger       | The logger.       |
|--------------|-------------------|
| ready_timer  | The ready timer.  |
| license path | The license path. |

#### 7.30.3 Member Function Documentation

# 7.30.3.1 ApplyCalibration()

```
override async Task<List<GazeCalibrationData> > GazeUtilityLibrary.Tracker.EyeTrackerPro.↔
ApplyCalibration ( ) [inline], [virtual]
```

Compute and apply the calibration data. Transform the Tobi calibration result into the GazeCalibrationData structure.

#### Returns

The calibration data result wrapped by an async handler.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.30.3.2 CollectCalibrationData()

Collects gaze data of a calibration point.

# **Parameters**

point

#### Returns

True on success, false on failure, wrapped by an async handler.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.30.3.3 FinishCalibration()

override async Task GazeUtilityLibrary.Tracker.EyeTrackerPro.FinishCalibration ( ) [inline],

Finish the screen based calibration process.

# Returns

An async handler

 $Implements\ Gaze Utility Library. Tracker. Base Tracker.$ 

#### 7.30.3.4 GetFixationFrameCount()

```
override int GazeUtilityLibrary.Tracker.EyeTrackerPro.GetFixationFrameCount ( ) [inline],
[protected], [virtual]
```

Get the number of required gaze samples to compute a fixation.

Returns

60

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.30.3.5 GetUnitDirection()

```
override Vector3 GazeUtilityLibrary.Tracker.EyeTrackerPro.GetUnitDirection ( ) [inline],
[protected], [virtual]
```

Get the unit vector pointing in the direction of the gaze vector.

Returns

The unit vector pointing in the negative z direction.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.30.3.6 InitCalibration()

```
override async Task GazeUtilityLibrary.Tracker.EyeTrackerPro.InitCalibration ( ) [inline],
[virtual]
```

Initialise the screen based calibration.

Returns

An async handler

 $Implements\ Gaze Utility Library. Tracker. Base Tracker.$ 

#### 7.30.3.7 InitDriftCompensation()

```
override void GazeUtilityLibrary.Tracker.EyeTrackerPro.InitDriftCompensation ( ) [inline],
[protected], [virtual]
```

Initialise the drift compensation.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.30.3.8 IsInitialised()

```
override bool GazeUtilityLibrary.Tracker.EyeTrackerPro.IsInitialised ( ) [inline], [virtual]
```

Checks if the tracker device exists.

#### Returns

True if the tracker device exists, false otherwise.

Reimplemented from GazeUtilityLibrary.Tracker.BaseTracker.

# 7.30.3.9 IsLicenseOk()

```
bool GazeUtilityLibrary.Tracker.EyeTrackerPro.IsLicenseOk ( ) [inline]
```

Determines whether the license is applied to the eyetracker device

#### Returns

true if [is license ok]; otherwise, false.

# 7.30.3.10 PatternReplace()

Replaces a patten string with information from the eye tracker. Supported patterns are S for the serial number and A for the address.

#### Returns

The string where patterns were replaced.

 $Reimplemented\ from\ Gaze Utility Library. Tracker. Base Tracker.$ 


The documentation for this class was generated from the following file:

source/GazeUtilityLibrary/Tracker/EyeTrackerPro.cs


# 7.31 CustomCalibrationLibrary.Views.FixationPoint Class Reference

Interaction logic for FixationPoint.xaml

Inheritance diagram for CustomCalibrationLibrary.Views.FixationPoint:



Collaboration diagram for CustomCalibrationLibrary. Views. FixationPoint:



# 7.31.1 Detailed Description

Interaction logic for FixationPoint.xaml

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/FixationPoint.xaml.cs

# 7.32 GazeUtilityLibrary.DataStructs.GazeCalibrationData Class Reference

The event argument class for Tobii eyetracker data

#### **Public Member Functions**

GazeCalibrationData (double xCoord, double yCoord, double xCoordLeft, double yCoordLeft, bool validity
 —
 Left, double xCoordRight, double yCoordRight, bool validityRight)

Initializes a new instance of the GazeDataArgs class.

string[] Prepare (ConfigItem config)

Prepare a list of formatted calibration data values

# **Properties**

```
double XCoord [get]
double YCoord [get]
double XCoordLeft [get]
double YCoordLeft [get]
bool ValidityLeft [get]
double XCoordRight [get]
double YCoordRight [get]
bool ValidityRight [get]
```

# 7.32.1 Detailed Description

The event argument class for Tobii eyetracker data

# 7.32.2 Constructor & Destructor Documentation

#### 7.32.2.1 GazeCalibrationData()

Initializes a new instance of the GazeDataArgs class.

#### **Parameters**

| xCoord        | The x coord of the calibration point.                   |
|---------------|---|
| yCoord        | The y coord of the calibration point.                   |
| xCoordLeft    | The x coord of the gaze point of the left eye.          |
| yCoordLeft    | The y coord of the gaze point of the left eye.          |
| validityLeft  | the validity of gaze point coordinate of the left eye.  |
| xCoordRight   | The x coord of the gaze point of the right eye.         |
| yCoordRight   | The y coord of the gaze point of the right eye.         |
| validityRight | the validity of gaze point coordinate of the right eye. |

# 7.32.3 Member Function Documentation

# 7.32.3.1 Prepare()

Prepare a list of formatted calibration data values

#### **Parameters**

| config The gaze configuration structure | ation structure |
|---|-----------------|
|---|-----------------|

#### Returns


A list of formatted values. Each index corresponds to a specific value. This allows to reorder the list according to a format string.

The documentation for this class was generated from the following file:


• source/GazeUtilityLibrary/DataStructs/GazeCalibrationData.cs

# 7.33 GazeUtilityLibrary.GazeConfigError Class Reference

 $Inheritance\ diagram\ for\ Gaze Utility Library. Gaze Config Error:$ 



Collaboration diagram for GazeUtilityLibrary.GazeConfigError:



# **Public Member Functions**

• string GetGazeConfigErrorString ()

Gets the gaze error string.

# **Properties**

• EGazeConfigError Error [set]

# **Additional Inherited Members**

# 7.33.1 Member Function Documentation

## 7.33.1.1 GetGazeConfigErrorString()

 $string \ \ Gaze Utility Library. Gaze Config Error. Get Gaze Config Error String \ (\ ) \quad [in line]$ 

Gets the gaze error string.

#### Returns

the error string with binary error values if errors ocurred, the empty srting otherwise

The documentation for this class was generated from the following file:

 $\bullet \ source/GazeUtilityLibrary/GazeError.cs\\$ 

# 7.34 GazeUtilityLibrary.GazeConfiguration Class Reference

# **Public Member Functions**

- GazeConfiguration (TrackerLogger logger)
- bool InitConfig ()

Initialise the gaze configuration by parsing and checking the configuration file.

bool CleanupGazeOutputFile (string error)

Close the gaze outputfile and rename it by appending error codes.

bool CleanupCalibrationOutputFile (string error)

Close the calibration outputfile and rename it by appending error codes.

• bool DumpCurrentConfigurationFile ()

Dump current configuration to the disk.

• bool PrepareGazeOutputFile (string? subjectCode, string? outputPath)

Prepare the gaze output file based on the configuration.

• bool PrepareCalibrationOutputFile (string? subjectCode)

Prepare the calibration output file based on the configuration.

• void WriteToGazeOutput (string[] formatted\_values)

Write to the gaze output file

void WriteToCalibrationOutput (string[] formatted\_values)

Write to the calibration output file

# **Properties**

ConfigItem?? Config [get]

#### 7.34.1 Member Function Documentation

# 7.34.1.1 CleanupCalibrationOutputFile()

```
bool GazeUtilityLibrary. GazeConfiguration. CleanupCalibrationOutputFile ( string\ error\ ) \quad [inline]
```

Close the calibration outputfile and rename it by appending error codes.

#### **Parameters**

error

#### Returns

True on success, False on failure.

#### 7.34.1.2 CleanupGazeOutputFile()

```
bool GazeUtilityLibrary.GazeConfiguration.CleanupGazeOutputFile ( string\ error\ )\ \ [inline]
```

Close the gaze outputfile and rename it by appending error codes.

**Parameters** 

error

#### Returns

True on success, False on failure.

#### 7.34.1.3 DumpCurrentConfigurationFile()

```
bool GazeUtilityLibrary.GazeConfiguration.DumpCurrentConfigurationFile ( ) [inline]
```

Dump current configuration to the disk.

#### Returns

True on success, False on failure.

## 7.34.1.4 InitConfig()

```
bool GazeUtilityLibrary.GazeConfiguration.InitConfig ( ) [inline]
```

Initialise the gaze configuration by parsing and checking the configuration file.

#### Returns

True on success, False on failure.

# 7.34.1.5 PrepareCalibrationOutputFile()

Prepare the calibration output file based on the configuration.

#### **Parameters**

| subjectCode | An optional subject code to be appended to the file name if set. |  |
|-------------|--|--|
|-------------|--|--|

#### Returns

True on success, False on failure.

#### 7.34.1.6 PrepareGazeOutputFile()

Prepare the gaze output file based on the configuration.

#### **Parameters**

| subjectCode | An optional subject code to be appended to the file name if set. |
|-------------|--|
| outputPath  | An optional output path where the file will be stored.           |

#### Returns

True on success, False on failure.

#### 7.34.1.7 WriteToCalibrationOutput()

```
\begin{tabular}{ll} void $\tt GazeUtilityLibrary.GazeConfiguration.WriteToCalibrationOutput ( & string[] $\it formatted\_values ) $$ [inline] $$ \end{tabular}
```

Write to the calibration output file

#### **Parameters**

| formatted_values | The list of formatted values to be written to the file. |
|------------------|---|
|------------------|---|

# 7.34.1.8 WriteToGazeOutput()

Write to the gaze output file

#### **Parameters**

| formatted_values   The list of formatted values to be written to the file. | rmatted_values The li | at of formatted values to be written to the file. |
|--|-----------------------|---|
|--|-----------------------|---|

The documentation for this class was generated from the following file:

· source/GazeUtilityLibrary/GazeConfiguration.cs

# 7.35 GazeUtilityLibrary.DataStructs.GazeData Class Reference

The class definition of a gaze data set

#### **Public Member Functions**

• GazeData (TimeSpan timestamp, Vector2 gazePoint2d, bool isGazePoint2dValid)

Initializes a new instance of the GazeDataArgs class.

GazeData (TimeSpan timestamp, Vector2 gazePoint2dLeft, bool isGazePoint2dValidLeft, Vector2 gaze
 — Point2dRight, bool isGazePoint2dValidRight)

Initializes a new instance of the GazeDataArgs class.

GazeData (TimeSpan timestamp, Vector2 gazePoint2dLeft, bool isGazePoint2dValidLeft, Vector2 gaze
 — Point2dRight, bool isGazePoint2dValidRight, Vector3 gazePoint3dLeft, bool isGazePoint3dValidLeft, Vector3
 gazePoint3dRight, bool isGazePoint3dValidRight, Vector3 gazeOrigin3dLeft, bool isGazeOrigin3dValidLeft,
 Vector3 gazeOrigin3dRight, bool isGazeOrigin3dValidRight, float pupilDiameterLeft, bool isPupilDiameter
 — ValidLeft, float pupilDiameterRight, bool isPupilDiameterValidRight)

Initializes a new instance of the GazeDataArgs class.

• string[] Prepare (ConfigItem config, string tag, TimeSpan startTime)

Prepare a list of formatted gaze data values

#### **Properties**

- TimeSpan Timestamp [get, set]
- GazeDataCollection? Left [get]
- GazeDataCollection? Right [get]
- GazeDataCollection Combined [get]
- DriftCompensationData? DriftCompensation [get, set]

#### 7.35.1 Detailed Description

The class definition of a gaze data set

#### 7.35.2 Constructor & Destructor Documentation

# 7.35.2.1 GazeData() [1/3]

Initializes a new instance of the GazeDataArgs class.

#### **Parameters**

| timestamp          | The timestamp.                                 |
|--------------------|--|
| gazePoint2d        | The 2d coordinates of the combined gaze point. |
| isGazePoint2dValid | The validity of the combined 2d gaze point.    |

# 7.35.2.2 GazeData() [2/3]

Initializes a new instance of the GazeDataArgs class.

#### **Parameters**

| timestamp               | The timestamp.                              |
|-------------------------|---|
| gazePoint2dLeft         | The 2d coordinates of the left gaze point.  |
| isGazePoint2dValidLeft  | The validity of the left 2d gaze point.     |
| gazePoint2dRight        | The 2d coordinates of the right gaze point. |
| isGazePoint2dValidRight | The validity of the right 2d gaze point.    |

## 7.35.2.3 GazeData() [3/3]

```
GazeUtilityLibrary.DataStructs.GazeData.GazeData (
              TimeSpan timestamp,
              Vector2 gazePoint2dLeft,
              bool is Gaze Point 2dValid Left,
              Vector2 gazePoint2dRight,
              bool is Gaze Point 2d Valid Right,
              Vector3 gazePoint3dLeft,
              bool is Gaze Point 3dValid Left,
              Vector3 gazePoint3dRight,
              bool is Gaze Point 3dValid Right,
              Vector3 gazeOrigin3dLeft,
              bool is GazeOrigin 3dValidLeft,
              Vector3 gazeOrigin3dRight,
              bool is GazeOrigin 3dValidRight,
              float pupilDiameterLeft,
              bool isPupilDiameterValidLeft,
              float pupilDiameterRight,
              \verb|bool| is \textit{PupilDiameterValidRight}|) | [in line]
```

Initializes a new instance of the GazeDataArgs class.

#### **Parameters**

| timestamp                 | The timestamp.                               |
|---------------------------|--|
| gazePoint2dLeft           | The 2d coordinates of the left gaze point.   |
| isGazePoint2dValidLeft    | The validity of the left 2d gaze point.      |
| gazePoint2dRight          | The 2d coordinates of the right gaze point.  |
| isGazePoint2dValidRight   | The validity of the right 2d gaze point.     |
| gazePoint3dLeft           | The 3d coordinates of the left gaze point.   |
| isGazePoint3dValidLeft    | The validity of the left 3d gaze point.      |
| gazePoint3dRight          | The 3d coordinates of the right gaze point.  |
| isGazePoint3dValidRight   | The validity of the right 3d gaze point.     |
| gazeOrigin3dLeft          | The 3d coordinates of the left gaze origin.  |
| isGazeOrigin3dValidLeft   | The validity of the left 3d gaze origin.     |
| gazeOrigin3dRight         | The 3d coordinates of the right gaze origin. |
| isGazeOrigin3dValidRight  | The validity of the right 3d gaze origin.    |
| pupilDiameterLeft         | The pupil diameter the left eye.             |
| isPupilDiameterValidLeft  | The validity of the left pupil diameter.     |
| pupilDiameterRight        | The pupil diameter the left eye.             |
| isPupilDiameterValidRight | The validity of the left pupil diameter.     |

# 7.35.3 Member Function Documentation

# 7.35.3.1 Prepare()

Prepare a list of formatted gaze data values

# Parameters

| config    | The gaze configuration structure                          |
|-----------|---|
| tag       | An arbitrary tag to associate with the data sample.       |
| startTime | The system time to use toi compute the relative timestamp |

# Returns

A list of formatted values. Each index corresponds to a specific value. This allows to reorder the list according to a format string.

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/GazeData.cs

## 7.36 GazeUtilityLibrary.DataStructs.GazeData2d Class Reference

The 2d gaze data set.

## **Public Member Functions**

GazeData2d (Vector2 gazePoint, bool isGazePointValid)
 Initializes a new instance of the GazeData2d class.

## **Properties**

- Vector2 GazePoint [get]
- bool IsGazePointValid [get]

## 7.36.1 Detailed Description

The 2d gaze data set.

## 7.36.2 Constructor & Destructor Documentation

## 7.36.2.1 GazeData2d()

Initializes a new instance of the GazeData2d class.

## **Parameters**

| gazePoint        | The 2d coordinates of the gaze point. |
|------------------|---------------------------------------|
| isGazePointValid | The validity of the 2d gaze point.    |

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/GazeData2d.cs

## 7.37 GazeUtilityLibrary.DataStructs.GazeData3d Class Reference

The 3d gaze data set.

## **Public Member Functions**

GazeData3d (Vector3 gazePoint, bool isGazePointValid, Vector3 gazeOrigin, bool isGazeOriginValid)
 Initializes a new instance of the GazeData3d class.

## **Properties**

- Vector3 GazePoint [get]
- bool IsGazePointValid [get]
- Vector3 GazeOrigin [get]
- Vector3 GazeDirection [get]
- float GazeDistance [get]
- bool IsGazeOriginValid [get]

## 7.37.1 Detailed Description

The 3d gaze data set.

## 7.37.2 Constructor & Destructor Documentation

## 7.37.2.1 GazeData3d()

Initializes a new instance of the GazeData3d class.

## **Parameters**

| gazePoint         | The 3d coordinates of the gaze point.  |
|-------------------|--|
| isGazePointValid  | The validity of the 3d gaze point.     |
| gazeOrigin        | The 3d coordinates of the gaze origin. |
| isGazeOriginValid | The validity of the 3d gaze origin.    |

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/GazeData3d.cs

## 7.38 GazeUtilityLibrary.DataStructs.GazeDataCollection Class Reference

The gaze data set, including 2d and (optionally) 3d gaze data as well as optional eye data.

## **Public Member Functions**

GazeDataCollection (Vector2 gazePoint2d, bool isGazePoint2dValid)

Initializes a new instance of the GazeDataItem class.

GazeDataCollection (Vector2 gazePoint2d, bool isGazePoint2dValid, Vector3 gazePoint3d, bool isGaze
 — Point3dValid, Vector3 gazeOrigin3d, bool isGazeOrigin3dValid, float pupilDiameter, bool isPupilDiameter
 — Valid)

Initializes a new instance of the GazeDataItem class.

## **Properties**

- GazeData2d GazeData2d [get]
- GazeData3d? GazeData3d [get]
- EyeData? EyeData [get]

## 7.38.1 Detailed Description

The gaze data set, including 2d and (optionally) 3d gaze data as well as optional eye data.

## 7.38.2 Constructor & Destructor Documentation

## 7.38.2.1 GazeDataCollection() [1/2]

```
\label{lem:GazeDataCollection.GazeDataCollection} GazeDataCollection \mbox{ (} \\ Vector2 \mbox{ } gazePoint2d, \\ bool \mbox{ } isGazePoint2dValid \mbox{ ) } \mbox{ [inline]}
```

Initializes a new instance of the GazeDataItem class.

## Parameters

| gazePoint2d        | The 2d coordinates of the gaze point. |
|--------------------|---------------------------------------|
| isGazePoint2dValid | The validity of the 2d gaze point.    |

## 7.38.2.2 GazeDataCollection() [2/2]

bool isGazeOrigin3dValid,
float pupilDiameter,
bool isPupilDiameterValid ) [inline]

Initializes a new instance of the GazeDataItem class.

## **Parameters**


| gazePoint2d          | The 2d coordinates of the gaze point.  |
|----------------------|--|
| isGazePoint2dValid   | The validity of the 2d gaze point.     |
| gazePoint3d          | The 3d coordinates of the gaze point.  |
| isGazePoint3dValid   | The validity of the 3d gaze point.     |
| gazeOrigin3d         | The 3d coordinates of the gaze origin. |
| isGazeOrigin3dValid  | The validity of the 3d gaze origin.    |
| pupilDiameter        | The pupil diameter.                    |
| isPupilDiameterValid | The validity of the pupil diameter.    |

The documentation for this class was generated from the following file:


• source/GazeUtilityLibrary/DataStructs/GazeDataCollection.cs

## 7.39 GazeUtilityLibrary.GazeDataError Class Reference

 $Inheritance\ diagram\ for\ Gaze Utility Library. Gaze Data Error:$ 



 $Collaboration\ diagram\ for\ Gaze Utility Library. Gaze Data Error:$ 



## **Public Member Functions**

• string GetGazeDataErrorString ()

Gets the gaze error string.

## **Properties**

• EGazeDataError Error [set]

## **Additional Inherited Members**

## 7.39.1 Member Function Documentation

## 7.39.1.1 GetGazeDataErrorString()

string GazeUtilityLibrary.GazeDataError.GetGazeDataErrorString ( ) [inline]

Gets the gaze error string.

## Returns


the error string with binary error values if errors ocurred, the empty srting otherwise

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/GazeError.cs

## 7.40 GazeUtilityLibrary.GazeError Class Reference

Inheritance diagram for GazeUtilityLibrary.GazeError:



## **Protected Member Functions**

string ConvertToBinString (int val, int len)
 Converts a integer value to a binary string.

## 7.40.1 Member Function Documentation

## 7.40.1.1 ConvertToBinString()

Converts a integer value to a binary string.

#### **Parameters**

| val | The value.                       |
|-----|----------------------------------|
| len | The length of the binary string. |

## Returns

a binary string of specified length, left-padded with '0'


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/GazeError.cs


## 7.41 CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter Class Reference

Converts True to Hidden and False to Visible

Inheritance diagram for CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter:



Collaboration diagram for CustomCalibrationLibrary.Converters.HasDataToVisibilityConverter:



## **Public Member Functions**

- object Convert (object value, Type targetType, object parameter, System.Globalization.CultureInfo culture)
- object ConvertBack (object value, Type targetType, object parameter, System.Globalization.CultureInfo culture)

## 7.41.1 Detailed Description

Converts True to Hidden and False to Visible

The documentation for this class was generated from the following file:

 $\bullet \ source/Custom Calibration Library/Converters/HasData To Visibility Converter.cs$ 

## 7.42 GazeUtilityLibrary.JsonConfigParser Class Reference

The config file "config.json" is parsed and its values are attributed to the Configltem class.

## **Public Member Functions**

• JsonConfigParser (TrackerLogger logger)

Initializes a new instance of the JsonConfigParser class.

· ConfigItem? ParseJsonConfig (ref GazeConfigError error)

Parses the json configuration.

· void SerializeJsonConfig (ConfigItem item, string path)

Serializes the json configuration object to a string and writes it to a file.

· ConfigItem GetDefaultConfig ()

Gets the default configuration values.

## 7.42.1 Detailed Description

The config file "config.json" is parsed and its values are attributed to the Configltem class.

## 7.42.2 Constructor & Destructor Documentation

## 7.42.2.1 JsonConfigParser()

```
\label{limit} {\tt GazeUtilityLibrary.JsonConfigParser.JsonConfigParser \ (} \\ {\tt TrackerLogger} \ logger \ ) \ [inline]
```

Initializes a new instance of the JsonConfigParser class.

**Parameters** 

```
logger The logger.
```

## 7.42.3 Member Function Documentation

## 7.42.3.1 GetDefaultConfig()

```
ConfigItem GazeUtilityLibrary.JsonConfigParser.GetDefaultConfig ( ) [inline]
```

Gets the default configuration values.

## Returns

the default configuration values.

## 7.42.3.2 ParseJsonConfig()

Parses the json configuration.

## Returns

the updated Configltem class.

## 7.42.3.3 SerializeJsonConfig()

Serializes the json configuration object to a string and writes it to a file.

## **Parameters**


| item | The json configuration item.             |
|------|--|
| path | The path where the file will be written. |

The documentation for this class was generated from the following file:


source/GazeUtilityLibrary/GazeConfiguration.cs

## 7.43 GazeUtilityLibrary.DataStructs.LiveGazePoint Class Reference

Inheritance diagram for GazeUtilityLibrary.DataStructs.LiveGazePoint:



Collaboration diagram for GazeUtilityLibrary.DataStructs.LiveGazePoint:



## **Properties**

- double X [get, set]
- double Y [get, set]
- bool **Visibility** [get, set]

## **Events**

· PropertyChangedEventHandler? PropertyChanged

The documentation for this class was generated from the following file:

 $\bullet \ source/GazeUtilityLibrary/DataStructs/LiveGazePoint.cs\\$ 

## 7.44 GazeUtilityLibrary.MouseHider Class Reference

hide standard mouse pointer and resore it

## **Public Member Functions**

• MouseHider (TrackerLogger logger)

Initializes a new instance of the MouseHider class.

• void HideCursor ()

Hides the cursor.

void ShowCursor (string? pathToCur)

Shows the cursor.

## 7.44.1 Detailed Description

hide standard mouse pointer and resore it

## 7.44.2 Constructor & Destructor Documentation

## 7.44.2.1 MouseHider()

Initializes a new instance of the MouseHider class.

**Parameters** 

logger The logger.

## 7.44.3 Member Function Documentation

## 7.44.3.1 HideCursor()

```
\label{thm:cond} \mbox{\sc NouseHider.HideCursor ( ) } \mbox{\sc [inline]}
```

Hides the cursor.

Hides the standard mouse pointer by replacing the current icon with a transparent icon.

## 7.44.3.2 ShowCursor()

Shows the cursor.

the standard mouse pointer by replacing the current icon with the standard mouse pointer icon

## **Parameters**

| pathToCur | The path to the standard mouse pointer icon. |
|-----------|--|
|-----------|--|


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/MouseHider.cs


## 7.45 GazeUtilityLibrary.Tracker.MouseTracker Class Reference

This class is used to hook into the system mouse events and track the position

 $Inheritance\ diagram\ for\ Gaze Utility Library. Tracker. Mouse Tracker:$ 



Collaboration diagram for GazeUtilityLibrary.Tracker.MouseTracker:



## **Public Member Functions**

MouseTracker (TrackerLogger logger, ConfigItem config)

Initializes a new instance of the MouseTracker class.

override Task< List< GazeCalibrationData > > ApplyCalibration ()

Apply the calibration data. This is device specific and must be overwritten by the device class.

override Task< bool > CollectCalibrationData (Point point)

Collect calibration data on a calibration point. This is device specific and must be overwritten by the device class.

• override Task FinishCalibration ()

Finish the calibartion process. This is device specific and must be overwritten by the device class.

override Task InitCalibration ()

Initialise the calibartion process. This is device specific and must be overwritten by the device class.

• void Start ()

Hooks the callback function HookCallback(int, IntPtr, IntPtr) to mouse events.

• void Stop ()

Removes to mouse event hook.

## **Protected Member Functions**

• override void Dispose (bool disposing)

Releases unmanaged and - optionally - managed resources.

override int GetFixationFrameCount ()

Get the number of required gaze samples to compute a fixation. This is device specific and must be overwritten by the device because the duration of fixation point detection depends on the frame rate of the device.

override Vector3 GetUnitDirection ()

Get the unit vector pointing in the direction of the gaze vector. This is device specific as the gaze data are represented in a coordinate system as defined by the device.

override void InitDriftCompensation ()

Initialise the drift compensation. This is device specific and must be overwritten by the device class.

## **Additional Inherited Members**

## 7.45.1 Detailed Description

This class is used to hook into the system mouse events and track the position

See also

GazeHelper.TrackerHandler

## 7.45.2 Constructor & Destructor Documentation

## 7.45.2.1 MouseTracker()

Initializes a new instance of the MouseTracker class.

## **Parameters**

| logger      | The logger.      |
|-------------|------------------|
| ready_timer | The ready timer. |

## 7.45.3 Member Function Documentation

## 7.45.3.1 ApplyCalibration()

```
\label{limit} override \ Task < List < Gaze Calibration Data > Gaze Utility Library. Tracker. Mouse Tracker. Apply \leftarrow Calibration ( ) [inline], [virtual]
```

Apply the calibration data. This is device specific and must be overwritten by the device class.

Returns

The calibration data result wrapped by an async handler.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

## 7.45.3.2 CollectCalibrationData()

Collect calibration data on a calibration point. This is device specific and must be overwritten by the device class.

#### **Parameters**

| point | The calibration point for which to collect data |
|-------|---|
|-------|---|

## Returns

True on success, false on failure, wrapped by an async handler.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

## 7.45.3.3 Dispose()

Releases unmanaged and - optionally - managed resources.

#### **Parameters**

| disposing | true to release both managed and unmanaged resources; false to release only unmanaged |
|-----------|---|
|           | resources.  |

 $Reimplemented\ from\ Gaze Utility Library. Tracker. Base Tracker.$ 

## 7.45.3.4 FinishCalibration()

```
override Task GazeUtilityLibrary.Tracker.MouseTracker.FinishCalibration ( ) [inline], [virtual]
```

Finish the calibartion process. This is device specific and must be overwritten by the device class.

#### Returns

An async handler

Implements GazeUtilityLibrary.Tracker.BaseTracker.

## 7.45.3.5 GetFixationFrameCount()

```
override int GazeUtilityLibrary.Tracker.MouseTracker.GetFixationFrameCount ( ) [inline], [protected], [virtual]
```

Get the number of required gaze samples to compute a fixation. This is device specific and must be overwritten by the device because the duration of fixation point detection depends on the frame rate of the device.

## Returns

The number of gaze samples to require for fixation detection.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

## 7.45.3.6 GetUnitDirection()

override Vector3 GazeUtilityLibrary.Tracker.MouseTracker.GetUnitDirection ( ) [inline], [protected],
[virtual]

Get the unit vector pointing in the direction of the gaze vector. This is device specific as the gaze data are represented in a coordinate system as defined by the device.

Returns

The unit vector

 $Implements\ Gaze Utility Library. Tracker. Base Tracker.$ 

## 7.45.3.7 InitCalibration()

```
override Task GazeUtilityLibrary.Tracker.MouseTracker.InitCalibration ( ) [inline], [virtual]
```

Initialise the calibartion process. This is device specific and must be overwritten by the device class.

Returns

An async handler

Implements GazeUtilityLibrary.Tracker.BaseTracker.

## 7.45.3.8 InitDriftCompensation()

```
override void GazeUtilityLibrary.Tracker.MouseTracker.InitDriftCompensation ( ) [inline],
[protected], [virtual]
```

Initialise the drift compensation. This is device specific and must be overwritten by the device class.

Implements GazeUtilityLibrary.Tracker.BaseTracker.

#### 7.45.3.9 Start()

```
void GazeUtilityLibrary.Tracker.MouseTracker.Start ( ) [inline]
```

Hooks the callback function HookCallback(int, IntPtr, IntPtr) to mouse events.

## 7.45.3.10 Stop()

void GazeUtilityLibrary.Tracker.MouseTracker.Stop ( ) [inline]

Removes to mouse event hook.

The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/Tracker/MouseTracker.cs

## 7.46 GazeUtilityLibrary.DataStructs.PipeCommand Class Reference

## **Public Member Functions**

• PipeCommand (string command, bool reset, string? value)

## **Properties**

- string Command [get, set]
- string? Value [get, set]
- bool? ResetStartTime [get, set]


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/PipeCommand.cs


## 7.47 CustomCalibrationLibrary.Converters.PositionConverter Class Reference

Converter class to convert a normalized coordinate to a pixel coordinate.

Inheritance diagram for CustomCalibrationLibrary.Converters.PositionConverter:



Collaboration diagram for CustomCalibrationLibrary.Converters.PositionConverter:



## **Public Member Functions**

- object Convert (object value, Type targetType, object parameter, CultureInfo culture)
- object ConvertBack (object value, Type targetType, object parameter, CultureInfo culture)

## **Static Public Attributes**

• static readonly DependencyProperty OffsetProperty

## **Properties**

• string?? Offset [get, set]

## 7.47.1 Detailed Description

Converter class to convert a normalized coordinate to a pixel coordinate.

## 7.47.2 Member Data Documentation

## 7.47.2.1 OffsetProperty

readonly DependencyProperty CustomCalibrationLibrary.Converters.PositionConverter.Offset  $\leftarrow$  Property [static]

## Initial value:

DependencyProperty.Register("Offset", typeof(string), typeof(PositionConverter), new PropertyMetadata(null))


The documentation for this class was generated from the following file:

source/CustomCalibrationLibrary/Converters/PositionConverter.cs


## 7.48 CustomCalibrationLibrary.Converters.ProximityColorConverter Class Reference

Converter class to convert the proximito of a normaliezed coordinate to the center point (0.5) into colors.

Inheritance diagram for CustomCalibrationLibrary.Converters.ProximityColorConverter:



Collaboration diagram for CustomCalibrationLibrary.Converters.ProximityColorConverter:



## **Public Member Functions**

- object Convert (object value, Type targetType, object parameter, CultureInfo culture)
- object ConvertBack (object value, Type targetType, object parameter, CultureInfo culture)

## 7.48.1 Detailed Description

Converter class to convert the proximito of a normaliezed coordinate to the center point (0.5) into colors.

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Converters/ProximityColorConverter.cs

## 7.49 GazeUtilityLibrary.ScreenArea Class Reference

The class describing the Screen area in 3d and 2d space.

## **Public Member Functions**

 ScreenArea (Vector3 bottomLeft, Vector3 bottomRight, Vector3 topLeft, Vector3 topRight, float width, float height)

Constructor. Assigns parameters ann computes the transformation matrix to transform a 3d point into a 2d point.

Vector3? GetIntersectionPoint (Vector3 gazeOrigin, Vector3 gazeDirection)

Compute the intersection point with the screen plane given a gaze origin and a gaze direction. Note that this does not compute the intersection with the screen area but with the infinite plane which is co-aligned with the screen. Pass the here computed intersection point to the method GetPoint2dNormalized to get the normalized intersection point on the sreen area.

Vector2 GetPoint2d (Vector3 point)

Get the 2d point on the sreen given given a 3d point on the screen plane.

Vector2 GetPoint2dNormalized (Vector3 point3d)

Get the normalized 2d point on the sreen given a 3d point on the screen plane. Note that values outside of the interval [0, 1] indicate an intersection point outsate of the screen area.

## **Properties**

```
float Width [get]
float Height [get]
Vector3 BottomLeft [get]
Vector3 TopLeft [get]
Vector3 TopRight [get]
```

## 7.49.1 Detailed Description

Vector3 Center [get]

The class describing the Screen area in 3d and 2d space.

## 7.49.2 Constructor & Destructor Documentation

## 7.49.2.1 ScreenArea()

Constructor. Assigns parameters ann computes the transformation matrix to transform a 3d point into a 2d point.

#### **Parameters**

| bottomLeft  | The bottom left 3d coordinate of the screen.  |
|-------------|---|
| bottomRight | The bottom right 3d coordinate of the screen. |
| topLeft     | The top left 3d coordinate of the screen.     |
| topRight    | The top right 3d coordinate of the screen     |
| width       | The width of the screen                       |
| height      | The heigth of the screen                      |

## 7.49.3 Member Function Documentation

## 7.49.3.1 GetIntersectionPoint()

Compute the intersection point with the screen plane given a gaze origin and a gaze direction. Note that this does not compute the intersection with the screen area but with the infinite plane which is co-aligned with the screen. Pass the here computed intersection point to the method GetPoint2dNormalized to get the normalized intersection point on the sreen area.

## **Parameters**

| gazeOrigin    | The origin of the gaze.    |
|---------------|----------------------------|
| gazeDirection | The direction of the gaze. |

## Returns

The intersection point with the screen or null if no intersection point exists.

## 7.49.3.2 GetPoint2d()

Get the 2d point on the sreen given a 3d point on the screen plane.

## **Parameters**

| point | The 3d point on the screen plane to convert. |
|-------|--|

#### Returns

The 2d point on the screen plane

## 7.49.3.3 GetPoint2dNormalized()

```
\label{thm:condition} \mbox{Vector2 GazeUtilityLibrary.ScreenArea.GetPoint2dNormalized (} \\ \mbox{Vector3 point3d} \mbox{) [inline]}
```

Get the normalized 2d point on the sreen given given a 3d point on the screen plane. Note that values outside of the interval [0, 1] indicate an intersection point outsate of the screen area.

#### **Parameters**

| oint The 3d point on the screen plane | e to convert. |
|---------------------------------------|---------------|
|---------------------------------------|---------------|

## Returns

The normalized 2d point on the screen plane


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/ScreenArea.cs


## 7.50 Tobii.Research.Addons.ScreenBasedCalibrationValidation Class Reference

Provides methods and properties for managing calibration validation for screen based eye trackers.

 $Inheritance\ diagram\ for\ Tobii. Research. Add on s. Screen Based Calibration Validation:$ 



Collaboration diagram for Tobii.Research.Addons.ScreenBasedCalibrationValidation:



## **Public Types**

enum ValidationState { NotInValidationMode, NotCollectingData, CollectingData }

ValidationState.NotInValidationMode - EnterValidationMode must be called starting to collect data. ValidationState.← NotCollectingData - Ready to start collecting data or computing result. ValidationState.CollectingData - Currently collecting data. Will finish after the sample count is reached or a timeout.

## **Public Member Functions**

• ScreenBasedCalibrationValidation (IEyeTracker eyeTracker, int sampleCount=30, int timeoutMS=1000)

Create a calibration validation object for screen based eye trackers.

void StartCollectingData (NormalizedPoint2D calibrationPointCoordinates)

Starts collecting data for a calibration validation point. The argument used is the point the user is assumed to be looking at and is given in the active display area coordinate system. Please check State property to know when data collection is completed (or timed out).

void DiscardData (NormalizedPoint2D calibrationPointCoordinates)

Removes the collected data for a specific calibration validation point.

void EnterValidationMode ()

Enter the calibration validation mode and starts subscribing to gaze data from the eye tracker.

• void LeaveValidationMode ()

Leaves the calibration validation mode, clears all collected data, and unsubscribes from the eye tracker.

CalibrationValidationResult Compute ()

Uses the collected data and tries to compute accuracy and precision values for all points. If the calculation is successful, the result is returned, and stored in the Result property of the CalibrationValidation object. If there is insufficient data to compute the results for a certain point that CalibrationValidationPoint will contain invalid data (NaN) for the results. Gaze data will still be untouched. If there is no valid data for any point, the average results of CalibrationValidationResult will be invalid (NaN) as well.

• void Dispose ()

Dispose will unsubscribe to gaze data and exit validation mode, if the object is not already in ValidationState.NotIn⊷ ValidationMode

• override string ToString ()

## **Properties**

• ValidationState State [get]

Get the current state of the validation object.

• CalibrationValidationResult Result [get]

Get the current CalibrationValidationResult with the computed accuracy and precision. Compute must have been called for this to contain valid data.

## 7.50.1 Detailed Description

Provides methods and properties for managing calibration validation for screen based eye trackers.

## 7.50.2 Member Enumeration Documentation

## 7.50.2.1 ValidationState

```
enum Tobii.Research.Addons.ScreenBasedCalibrationValidation.ValidationState [strong]
```

ValidationState.NotInValidationMode - EnterValidationMode must be called starting to collect data. Validation← State.NotCollectingData - Ready to start collecting data or computing result. ValidationState.CollectingData - Currently collecting data. Will finish after the sample count is reached or a timeout.

## 7.50.3 Constructor & Destructor Documentation

## 7.50.3.1 ScreenBasedCalibrationValidation()

Create a calibration validation object for screen based eye trackers.

## **Parameters**

| eyeTracker  | An IEyeTracker instance.  |
|-------------|---|
| sampleCount | The number of samples to collect. Default 30, minimum 10, maximum 3000. |
| timeoutMS   | Timeout in milliseconds. Default 1000, minimum 100, maximum 3000.       |

## 7.50.4 Member Function Documentation

## 7.50.4.1 Compute()

CalibrationValidationResult Tobii.Research.Addons.ScreenBasedCalibrationValidation.Compute ( )
[inline]

Uses the collected data and tries to compute accuracy and precision values for all points. If the calculation is successful, the result is returned, and stored in the Result property of the CalibrationValidation object. If there is insufficient data to compute the results for a certain point that CalibrationValidationPoint will contain invalid data (NaN) for the results. Gaze data will still be untouched. If there is no valid data for any point, the average results of CalibrationValidationResult will be invalid (NaN) as well.

#### Returns

The CalibrationValidationResult

## 7.50.4.2 DiscardData()

Removes the collected data for a specific calibration validation point.

## **Parameters**

| ı | calibrationPointCoordinates  | The calibration point to remove. | 1 |
|---|------------------------------|----------------------------------|---|
|   | candialionFolinecoolulitales | The calibration point to remove. |   |

## 7.50.4.3 Dispose()

```
void Tobii.Research.Addons.ScreenBasedCalibrationValidation.Dispose ( ) [inline]
```

Dispose will unsubscribe to gaze data and exit validation mode, if the object is not already in ValidationState.Not 

InValidationMode

## 7.50.4.4 EnterValidationMode()

```
void Tobii.Research.Addons.ScreenBasedCalibrationValidation.EnterValidationMode ( ) [inline]
```

Enter the calibration validation mode and starts subscribing to gaze data from the eye tracker.

## 7.50.4.5 LeaveValidationMode()

```
void Tobii.Research.Addons.ScreenBasedCalibrationValidation.LeaveValidationMode ( ) [inline]
```

Leaves the calibration validation mode, clears all collected data, and unsubscribes from the eye tracker.

## 7.50.4.6 StartCollectingData()

```
\label{thm:condition} void \ \ Tobii.Research.Addons.ScreenBasedCalibrationValidation.StartCollectingData \ ( \\ NormalizedPoint2D \ calibrationPointCoordinates \ ) \ \ [inline]
```

Starts collecting data for a calibration validation point. The argument used is the point the user is assumed to be looking at and is given in the active display area coordinate system. Please check State property to know when data collection is completed (or timed out).

#### **Parameters**

| calibrationPointCoordinates  The normalized 2D point on the display area |
|--|
|--|

## 7.50.5 Property Documentation

## 7.50.5.1 Result

CalibrationValidationResult Tobii.Research.Addons.ScreenBasedCalibrationValidation.Result [get]

Get the current CalibrationValidationResult with the computed accuracy and precision. Compute must have been called for this to contain valid data.

## 7.50.5.2 State

ValidationState Tobii.Research.Addons.ScreenBasedCalibrationValidation.State [get]

Get the current state of the validation object.

The documentation for this class was generated from the following file:

• source/TobiiProSdkAddons/ScreenBasedCalibrationValidation.cs

## 7.51 GazeUtilityLibrary.ScreenTriangle Class Reference

A class to describe a triangle. This was supposed to be used to construct the ScreenArea but it turned out that it is simpler to work with the screen plane and use the normalised intersection points to check wheter the gaze point is outside the screen area.

## **Public Member Functions**

- ScreenTriangle (Vector3 v1, Vector3 v2, Vector3 v3)
- Vector3? GetIntersectionPoint (Vector3 origin, Vector3 direction)

Compute the intersection point with the triangle with the Moller-Trumbore algorithm.

## **Properties**

- Vector3 V1 [get]
- Vector3 V2 [get]
- Vector3 V3 [get]
- Vector3 E1 [get]
- Vector3 E2 [get]

## 7.51.1 Detailed Description

A class to describe a triangle. This was supposed to be used to construct the ScreenArea but it turned out that it is simpler to work with the screen plane and use the normalised intersection points to check wheter the gaze point is outside the screen area.

## 7.51.2 Member Function Documentation

## 7.51.2.1 GetIntersectionPoint()

Compute the intersection point with the triangle with the Moller-Trumbore algorithm.

## **Parameters**

| origin    | The origin of the gaze point    |
|-----------|---------------------------------|
| direction | The direction of the gaze point |

## Returns

The intersection point or null if no intersection point could be computed.

The documentation for this class was generated from the following file:

· source/GazeUtilityLibrary/ScreenTriangle.cs

## 7.52 GazeUtilityLibrary.TrackerLogger Class Reference

Simple logger class.

## **Public Member Functions**

- TrackerLogger (string? logPath, EOutputType type=EOutputType.gaze)

  Initializes a new instance of the TrackerLogger class.
- void DumpFatal (Exception e)

Dumps exception to a new file if it is not possible to write to the main log file.

- void Debug (string message)
  - wrapper function for debug level logging.
- void Info (string message)

wrapper function for info level logging

- void Warning (string message)
  - wrapper function for warning level logging
- void Error (string message)

wrapper function for error level logging

## 7.52.1 Detailed Description

Simple logger class.

## 7.52.2 Constructor & Destructor Documentation

## 7.52.2.1 TrackerLogger()

Initializes a new instance of the TrackerLogger class.

## 7.52.3 Member Function Documentation

## 7.52.3.1 Debug()

wrapper function for debug level logging.

## **Parameters**

| message | The message. |
|---------|--------------|
|---------|--------------|

## 7.52.3.2 DumpFatal()

Dumps exception to a new file if it is not possible to write to the main log file.

#### **Parameters**

```
e The exception.
```

## 7.52.3.3 Error()

wrapper function for error level logging

## **Parameters**

```
message The message.
```

## 7.52.3.4 Info()

wrapper function for info level logging

## **Parameters**

message The message.

## 7.52.3.5 Warning()

wrapper function for warning level logging

**Parameters** 

| message | The message. |
|---------|--------------|
|---------|--------------|


The documentation for this class was generated from the following file:

· source/GazeUtilityLibrary/Logger.cs


## 7.53 GazeUtilityLibrary.TrackerMessageBox Class Reference

Interaction logic for TrackerMessageBox.xaml

Inheritance diagram for GazeUtilityLibrary.TrackerMessageBox:



 $Collaboration\ diagram\ for\ Gaze Utility Library. Tracker Message Box:$ 



## 7.53.1 Detailed Description


Interaction logic for TrackerMessageBox.xaml

The documentation for this class was generated from the following file:


• source/GazeUtilityLibrary/TrackerMessageBox.xaml.cs

## 7.54 GazeUtilityLibrary.DataStructs.UserPositionData Class Reference

Inheritance diagram for GazeUtilityLibrary.DataStructs.UserPositionData:



 $Collaboration\ diagram\ for\ Gaze Utility Library. Data Structs. User Position Data:$ 



## **Public Member Functions**

• **UserPositionData** (double xCoordLeft, double yCoordLeft, double zCoordLeft, double xCoordRight, double yCoordRight, double zCoordRight)

## **Properties**

```
double XCoordLeft
double YCoordLeft
double ZCoordLeft
double XCoordRight
double YCoordRight
double ZCoordRight
double ZCoordRight
[get, set]
double ZCoordRight
[get, set]
```

## **Events**

· PropertyChangedEventHandler? PropertyChanged


The documentation for this class was generated from the following file:

• source/GazeUtilityLibrary/DataStructs/UserPositionData.cs


## 7.55 CustomCalibrationLibrary.Views.UserPositionGuide Class Reference

Interaction logic for UserPositionGuide.xaml

Inheritance diagram for CustomCalibrationLibrary.Views.UserPositionGuide:



Collaboration diagram for CustomCalibrationLibrary.Views.UserPositionGuide:



## **Public Member Functions**

• UserPositionGuide (CalibrationModel model)

## 7.55.1 Detailed Description

Interaction logic for UserPositionGuide.xaml

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/Views/UserPositionGuide.xaml.cs

# 7.56 CustomCalibrationLibrary.ViewModels.UserPositionGuideView Model Class Reference

The view model class for the user position guide view.

## **Public Member Functions**

UserPositionGuideViewModel (CalibrationModel model)
 Constructor

## **Properties**

• UserPositionData UserPosition [get]

The user position to be represented on the view

- ICommand CalibrationStartCommand [get]
- Command to start the calibration
   ICommand CalibrationAbortCommand [get]

Command to abort the calibration

## 7.56.1 Detailed Description

The view model class for the user position guide view.

## 7.56.2 Constructor & Destructor Documentation

## 7.56.2.1 UserPositionGuideViewModel()

Constructor

## **Parameters**

## 7.56.3 Property Documentation

## 7.56.3.1 CalibrationAbortCommand

 $\label{thm:command} I Command Custom Calibration Library. View Models. User Position Guide View Model. Calibration Abort \hookleftarrow Command [get]$ 

Command to abort the calibration

## 7.56.3.2 CalibrationStartCommand

 $\label{thm:command} I Command \ Custom Calibration Library. View Models. User Position Guide View Model. Calibration Start \\ \leftarrow Command \ [get]$ 

Command to start the calibration

## 7.56.3.3 UserPosition

UserPositionData CustomCalibrationLibrary.ViewModels.UserPositionGuideViewModel.UserPosition
[get]

The user position to be represented on the view

The documentation for this class was generated from the following file:

• source/CustomCalibrationLibrary/ViewModels/UserPositionGuideViewModel.cs

## Index

| AccuracyLeftEye  | CustomCalibrationLibrary.Views.CalibrationFailed,  |
|--|--|
| Tobii.Research.Addons.CalibrationValidationPoint,  | 47   |
| 65   | CalibrationOutputValue   |
| AccuracyRightEye   | GazeUtilityLibrary.DataStructs, 22   |
| Tobii.Research.Addons.CalibrationValidationPoint,  | CalibrationPoints  |
| 65   | CustomCalibrationLibrary.Models.CalibrationModel,  |
| Арр  | 52   |
| GazeToMouse.App, 27  | Custom Calibration Library. View Models. Calibration View Model,   |
| ApplyCalibration   | 70   |
| GazeUtilityLibrary.Tracker.BaseTracker, 34   | CalibrationRestartCommand  |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 84   | Custom Calibration Library. View Models. Calibration Result View Model,  |
| GazeUtilityLibrary.Tracker.MouseTracker, 110   | 63   |
| AverageAccuracyLeftEye   | Custom Calibration Library. Views. Calibration Failed,   |
| Tobii. Research. Addons. Calibration Validation Result,  | 48   |
| 67   | CalibrationResultViewModel   |
| AverageAccuracyRightEye  | Custom Calibration Library. View Models. Calibration Result View Model,  |
| Tobii.Research.Addons.CalibrationValidationResult,   | 63   |
| 67   | CalibrationStartCommand  |
| AveragePrecisionLeftEye  | Custom Calibration Library. View Models. User Position Guide View Model Substitution and the property of the |
| Tobii.Research.Addons.CalibrationValidationResult,   | 130  |
| 67   | CalibrationStatus  |
| AveragePrecisionRightEye   | CustomCalibrationLibrary.Models, 18  |
| Tobii.Research.Addons.CalibrationValidationResult,   | CalibrationViewModel   |
| 67   | Custom Calibration Library. View Models. Calibration View Model,   |
| AveragePrecisionRMSLeftEye   | 70   |
| Tobii.Research.Addons.CalibrationValidationResult,   | CleanupCalibrationOutputFile   |
| 68   | GazeUtilityLibrary.GazeConfiguration, 91   |
| AveragePrecisionRMSRightEye  | CleanupGazeOutputFile  |
| Tobii.Research.Addons.CalibrationValidationResult,   | GazeUtilityLibrary.GazeConfiguration, 91   |
| 68   | CollectCalibrationData   |
|  | GazeUtilityLibrary.Tracker.BaseTracker, 34   |
| BaseTracker  | GazeUtilityLibrary.Tracker.EyeTrackerPro, 84   |
| GazeUtilityLibrary.Tracker.BaseTracker, 34   | GazeUtilityLibrary.Tracker.MouseTracker, 110   |
|  | CompensateDrift  |
| CalibrationAbortCommand  | GazeToMouse.App, 27  |
| CustomCalibrationLibrary.ViewModels.UserPositionC  | G <b>ûde\pensabid</b> el,  |
| 130  | GazeUtilityLibrary.DataStructs.DriftCompensationData,  |
| Custom Calibration Library. Views. Calibration Failed,   | 77   |
| 48   | Compute  |
| CustomCalibrationLibrary.Views.Disconnect, 74  | To bii. Research. Addons. Screen Based Calibration Validation,   |
| CalibrationAcceptCommand   | 121  |
| Custom Calibration Library. View Models. Calibration Research Research Calibration Research |  |
| 63   | GazeUtilityLibrary.Tracker.BaseTracker, 40   |
| CalibrationEvent   | ConvertToBinString   |
| Custom Calibration Library. Models. Calibration Model,   | GazeUtilityLibrary.GazeError, 102  |
| 54   | Coordinates  |
| CalibrationEventType   | Tobii.Research.Addons.CalibrationValidationPoint,  |
| CustomCalibrationLibrary.Models, 18  | 65   |
| CalibrationFailed  | CustomCalibrate  |

| GazeToMouse.App, 28   | CustomCalibrationLibrary.Views.Calibration, 43  |
|---|---|
| CustomCalibrationLibrary, 17  | CustomCalibrationLibrary.Views.CalibrationFailed, 46  |
| CustomCalibrationLibrary.Commands, 17                               | CalibrationAbortCommand, 48   |
| Custom Calibration Library. Commands. Calibration Commands.         |   |
| 44  | CalibrationRestartCommand, 48   |
| CustomCalibrationLibrary.Converters, 17                             | Error, 48   |
| CustomCalibrationLibrary.Converters.HasDataToVisibility             |   |
| 103   | CustomCalibrationLibrary.Views.CalibrationFrame, 49   |
| Custom Calibration Library. Converters. Position Converter,         | CustomCalibrationLibrary.Views.CalibrationPoint, 57   |
| 113   | CustomCalibrationLibrary.Views.CalibrationResult, 59  |
| OffsetProperty, 114   | CustomCalibrationLibrary.Views.CalibrationResultPoint,  |
| Custom Calibration Library. Converters. Proximity Color Converters. |   |
| 115   | CustomCalibrationLibrary.Views.CalibrationWindow, 71  |
| CustomCalibrationLibrary.Models, 17                                 | CustomCalibrationLibrary.Views.Computing, 72  |
| CalibrationEventType, 18  | CustomCalibrationLibrary.Views.Disconnect, 73   |
| CalibrationStatus, 18   | CalibrationAbortCommand, 74   |
| CustomCalibrationLibrary.Models.CalibrationModel, 50                | CustomCalibrationLibrary.Views.DriftCompensationWindow,   |
| CalibrationEvent, 54  | 79  |
| CalibrationPoints, 52   | CustomCalibrationLibrary.Views.FixationPoint, 87  |
| Error, 53   | CustomCalibrationLibrary.Views.UserPositionGuide,   |
| GazeDataCollected, 51   | 128   |
| GazePoint, 53   | Dahua   |
| Index, 53   | Debug   |
| InitCalibration, 51   | GazeUtilityLibrary.TrackerLogger, 124   |
| LastStatus, 53  | DeviceName  |
| NextCalibrationPoint, 51  | GazeUtilityLibrary.Tracker.BaseTracker, 41  |
| Points, 53  | dialogBoxTimer  |
| RedoCalibrationPoint, 52  | GazeUtilityLibrary.Tracker.BaseTracker, 41  |
| SetCalibrationResult, 52  | DiscardData   |
| Status, 53  | Tobii.Research.Addons.ScreenBasedCalibrationValidation,   |
| UpdateGazePoint, 52   | 121   |
| UserPositionGuide, 54   | Dispose   |
| Custom Calibration Library Viau Madala 10                           | GazeUtilityLibrary.Tracker.BaseTracker, 35  |
| CustomCalibrationLibrary.ViewModels.CalibrationPointVie             | GazeUtilityLibrary.Tracker.MouseTracker, 111 ewModel, Tobii.Research.Addons.ScreenBasedCalibrationValidation, |
| 58  | 101   |
| CustomCalibrationLibrary.ViewModels.CalibrationResultV              | 121<br>'iewModel  |
| 61  |   |
| CalibrationAcceptCommand, 63  | GazeUtilityLibrary.Tracker.BaseTracker, 41  |
| CalibrationRestartCommand, 63                                       | DriftCompensationComputed   |
| CalibrationResultViewModel, 63                                      | GazeUtilityLibrary.Tracker.BaseTracker, 42  |
| GazePoint, 63   | DriftCompensationData   |
| GazeVisibilityCommand, 64   | GazeUtilityLibrary.DataStructs.DriftCompensationData,   |
| OnGazeToggle, 63  | 77  |
| CustomCalibrationLibrary.ViewModels.CalibrationViewMo               | DriftCompensationEventHandler   |
| 69  | dazeotinty Library. Hacker, base Hacker, 55   |
| CalibrationPoints, 70   | DriftCompensationViewModel  |
| CalibrationViewModel, 70  | CustomCalibrationLibrary.ViewModels.DriftCompensationViewModel  |
| CustomCalibrationLibrary.ViewModels.DriftCompensation               | 78<br>WiewModel   |
| 78  |   |
| DriftCompensationViewModel, 78                                      | GazeUtilityLibrary.GazeConfiguration, 92  |
| FixationPoint, 79   | DumpFatal   |
| CustomCalibrationLibrary.ViewModels.UserPositionGuide               | GazeUtilityLibrary.TrackerLogger, 125   |
| 129   | ECalibrationDataError   |
| CalibrationAbortCommand, 130  |   |
|   | GazeUtilityLibrary, 20  |
| CalibrationStartCommand, 130  | EGazeConfigError  |
| UserPosition, 130   | GazeUtilityLibrary, 21  |
| UserPositionGuideViewModel, 129                                     | EGazeDataError  |
| CustomCalibrationLibrary.Views, 19                                  | GazeUtilityLibrary, 21  |

| EnterValidationMode                                    | GazeUtilityLibrary.DataStructs.CalibrationPoint, 55    |
|--|--|
| Tobii.Research.Addons.ScreenBasedCalibrationValid      | dataze, Position Left                                  |
| 121  | GazeUtilityLibrary.DataStructs.CalibrationPoint, 56    |
| Error  | GazePositionRight                                      |
| CustomCalibrationLibrary.Models.CalibrationModel,      | GazeUtilityLibrary.DataStructs.CalibrationPoint, 56    |
| 53   | GazeRecordingDisable                                   |
| Custom Calibration Library. Views. Calibration Failed, | GazeToMouse.App, 28                                    |
| 48   | GazeRecordingEnable                                    |
| GazeUtilityLibrary.TrackerLogger, 125                  | GazeToMouse.App, 28                                    |
| EyeData  | GazeToMouse, 19  |
| GazeUtilityLibrary.DataStructs.EyeData, 81             | GazeToMouse.App, 26                                    |
| EyeTrackerPro  | App, 27  |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 83           | CompensateDrift, 27                                    |
|  | CustomCalibrate, 28                                    |
| FinishCalibration                                      | GazeRecordingDisable, 28                               |
| GazeUtilityLibrary.Tracker.BaseTracker, 36             | GazeRecordingEnable, 28                                |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 84           | MouseTrackingDisable, 28                               |
| GazeUtilityLibrary.Tracker.MouseTracker, 111           | MouseTrackingEnable, 28                                |
| FixationPoint  | ResetDriftCompensation, 29                             |
| CustomCalibrationLibrary.ViewModels.DriftCompens       | ationViewModel<br>GazeUtilityLibrary, 19               |
| 79   | ECalibrationDataError, 20                              |
| 0 0 111 11 15 1  | EGazeConfigError, 21                                   |
| GazeCalibrationData                                    | EGazeDataError, 21                                     |
| GazeUtilityLibrary.DataStructs.GazeCalibrationData,    | GazeUtilityLibrary.CalibrationDataError, 45            |
| 88   | GetCalibrationDataErrorString, 46                      |
| GazeControl, 19  | GazeUtilityLibrary.ConfigItem, 72                      |
| GazeControl.App, 25                                    | GazeUtilityLibrary.DataStructs, 21                     |
| GazeData   | CalibrationOutputValue, 22                             |
| GazeUtilityLibrary.DataStructs.GazeData, 94, 95        | GazeOutputValue, 22                                    |
| Tobii.Research.Addons.CalibrationValidationPoint,      | GazeUtilityLibrary.DataStructs.CalibrationPoint, 54    |
| 65   |  |
| GazeData2d   | GazePositionAverage, 55                                |
| GazeUtilityLibrary.DataStructs.GazeData2d, 97          | GazePositionLeft, 56                                   |
| GazeData3d   | GazePositionRight, 56                                  |
| GazeUtilityLibrary.DataStructs.GazeData3d, 98          | HasData, 56  |
| GazeDataCollected                                      | Index, 56  |
| Custom Calibration Library. Models. Calibration Model, | Position, 56   |
| 51   | GazeUtilityLibrary.DataStructs.DriftCompensationData,  |
| GazeDataCollection                                     | 76   |
| GazeUtilityLibrary.DataStructs.GazeDataCollection,     | Compensation, 77                                       |
| 99   | DriftCompensationData, 77                              |
| GazeDataHandler  | GazePosition2d, 77                                     |
| GazeUtilityLibrary.Tracker.BaseTracker, 36             | GazePosition3d, 78                                     |
| GazeDataReceived                                       | GazeUtilityLibrary.DataStructs.EyeData, 80             |
| GazeUtilityLibrary.Tracker.BaseTracker, 42             | EyeData, 81  |
| GazeOutputValue  | IsPupilDiameterValid, 81                               |
| GazeUtilityLibrary.DataStructs, 22                     | PupilDiameter, 81                                      |
| GazePoint  | GazeUtilityLibrary.DataStructs.GazeCalibrationData, 87 |
| CustomCalibrationLibrary.Models.CalibrationModel,      | GazeCalibrationData, 88                                |
| 53   | Prepare, 89  |
| CustomCalibrationLibrary.ViewModels.CalibrationRes     | s Gaze Wility վայի rary. Data Structs. Gaze Data, 94   |
| 63   | GazeData, 94, 95                                       |
| GazePosition2d   | Prepare, 96  |
| GazeUtilityLibrary.DataStructs.DriftCompensationDat    | •  |
| 77   | GazeData2d, 97   |
| GazePosition3d   | GazeUtilityLibrary.DataStructs.GazeData3d, 97          |
| GazeUtilityLibrary.DataStructs.DriftCompensationDat    |  |
| 78   | GazeUtilityLibrary.DataStructs.GazeDataCollection, 98  |
| GazePositionAverage                                    | GazeDataCollection, 99                                 |
|  | 3.420 = 4.40 0.10 0.10 11, VV                          |

| GazeUtilityLibrary.DataStructs.LiveGazePoint, 106    | IsInitialised, 37   |
|--|---|
| GazeUtilityLibrary.DataStructs.PipeCommand, 113      | IsReady, 37   |
| GazeUtilityLibrary.DataStructs.UserPositionData, 127 | logger, 41  |
| GazeUtilityLibrary.DriftCompensation, 75             | OnGazeDataReceived, 38  |
| Q, 76  | OnPropertyChanged, 38   |
| Reset, 75  | OnTrackerDisabled, 38   |
| Start, 75  | OnTrackerDisabled, 39   |
| Update, 76   | OnTrackerEnabled, 39  |
| GazeUtilityLibrary.GazeConfigError, 89               | OnUserPositionDataReceived, 39  |
| GetGazeConfigErrorString, 90                         | PatternReplace, 39  |
| GazeUtilityLibrary.GazeConfiguration, 91             | PropertyChanged, 42   |
| CleanupCalibrationOutputFile, 91                     | ResetDriftCompensation, 40  |
| CleanupGazeOutputFile, 91                            | screenArea, 41  |
| DumpCurrentConfigurationFile, 92                     | StartDriftCompensation, 40  |
| InitConfig, 92                                       | State, 42   |
| PrepareCalibrationOutputFile, 92                     | TrackerDisabled, 42   |
| PrepareGazeOutputFile, 93                            | TrackerEnabled, 42  |
| WriteToCalibrationOutput, 93                         | trackerMessageBox, 41   |
| WriteToGazeOutput, 93                                | UserPositionDataHandler, 40   |
|  |   |
| GazeUtilityLibrary.GazeDataError, 100                | UserPositionDataReceived, 43  |
| GetGazeDataErrorString, 101                          | GazeUtilityLibrary.Tracker.EyeTrackerPro, 82                            |
| GazeUtilityLibrary.GazeError, 102                    | ApplyCalibration, 84  |
| ConvertToBinString, 102                              | CollectCalibrationData, 84  |
| GazeUtilityLibrary.JsonConfigParser, 104             | EyeTrackerPro, 83   |
| GetDefaultConfig, 104                                | FinishCalibration, 84   |
| JsonConfigParser, 104                                | GetFixationFrameCount, 84   |
| ParseJsonConfig, 105                                 | GetUnitDirection, 85  |
| SerializeJsonConfig, 105                             | InitCalibration, 85   |
| GazeUtilityLibrary.MouseHider, 107                   | InitDriftCompensation, 85   |
| HideCursor, 107                                      | IsInitialised, 85   |
| MouseHider, 107                                      | IsLicenseOk, 86   |
| ShowCursor, 107                                      | PatternReplace, 86  |
| GazeUtilityLibrary.ScreenArea, 116                   | GazeUtilityLibrary.Tracker.MouseTracker, 108                            |
| GetIntersectionPoint, 117                            | ApplyCalibration, 110   |
| GetPoint2d, 117                                      | CollectCalibrationData, 110   |
| GetPoint2dNormalized, 118                            | Dispose, 111  |
| ScreenArea, 116                                      | FinishCalibration, 111  |
| GazeUtilityLibrary.ScreenTriangle, 123               | GetFixationFrameCount, 111  |
| GetIntersectionPoint, 123                            | GetUnitDirection, 111   |
| GazeUtilityLibrary.Tracker, 22                       | InitCalibration, 112  |
| GazeUtilityLibrary.Tracker.BaseTracker, 31           | InitDriftCompensation, 112  |
| ApplyCalibration, 34                                 | MouseTracker, 110   |
| BaseTracker, 34                                      | Start, 112  |
| CollectCalibrationData, 34                           | Stop, 112   |
| config, 40   | GazeUtilityLibrary.TrackerLogger, 124                                   |
| DeviceName, 41                                       | Debug, 124  |
| dialogBoxTimer, 41                                   | DumpFatal, 125  |
| Dispose, 35  | Error, 125  |
| driftCompensation, 41                                | Info, 125   |
| DriftCompensationComputed, 42                        | TrackerLogger, 124  |
| DriftCompensationEventHandler, 35                    | Warning, 125  |
| FinishCalibration, 36                                | GazeUtilityLibrary.TrackerMessageBox, 126                               |
| GazeDataHandler, 36                                  | GazeVisibilityCommand   |
| GazeDataReceived, 42                                 | Custom Calibration Library. View Models. Calibration Result View Model, |
| GetFixationFrameCount, 36                            | 64  |
| GetUnitDirection, 36                                 | GetCalibrationDataErrorString   |
| InitCalibration, 37                                  | GazeUtilityLibrary.CalibrationDataError, 46                             |
| InitDriftCompensation, 37                            | GetDefaultConfig  |

| GazeUtilityLibrary.JsonConfigParser, 104 GetFixationFrameCount | CustomCalibrationLibrary.Models.CalibrationModel, 53            |
|--|---|
| GazeUtilityLibrary.Tracker.BaseTracker, 36                     | LeaveValidationMode   |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 84                   | Tobii.Research.Addons.ScreenBasedCalibrationValidation,         |
| GazeUtilityLibrary.Tracker.MouseTracker, 111                   | 121   |
| GetGazeConfigErrorString                                       | logger  |
| GazeUtilityLibrary.GazeConfigError, 90                         | GazeUtilityLibrary.Tracker.BaseTracker, 41                      |
| GetGazeDataErrorString   |   |
| GazeUtilityLibrary.GazeDataError, 101                          | MouseHider  |
| GetIntersectionPoint   | GazeUtilityLibrary.MouseHider, 107                              |
| GazeUtilityLibrary.ScreenArea, 117                             | MouseTracker  |
| GazeUtilityLibrary.ScreenTriangle, 123                         | GazeUtilityLibrary.Tracker.MouseTracker, 110                    |
| GetPoint2d   | MouseTrackingDisable  |
| GazeUtilityLibrary.ScreenArea, 117                             | GazeToMouse.App, 28   |
| GetPoint2dNormalized   | MouseTrackingEnable   |
| GazeUtilityLibrary.ScreenArea, 118                             | GazeToMouse.App, 28   |
| GetUnitDirection   | NextCalibrationPoint  |
| GazeUtilityLibrary.Tracker.BaseTracker, 36                     | CustomCalibrationLibrary.Models.CalibrationModel,               |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 85                   | 51  |
| GazeUtilityLibrary.Tracker.MouseTracker, 111                   | 31  |
|  | OffsetProperty  |
| HasData  | CustomCalibrationLibrary.Converters.PositionConverter,          |
| GazeUtilityLibrary.DataStructs.CalibrationPoint, 56            | 114   |
| HideCursor   | OnGazeDataReceived  |
| GazeUtilityLibrary.MouseHider, 107                             | GazeUtilityLibrary.Tracker.BaseTracker, 38                      |
|  | OnGazeToggle  |
| Index  | CustomCalibrationLibrary.ViewModels.CalibrationResultViewModel, |
| Custom Calibration Library. Models. Calibration Model,         | 63  |
| 53   | OnPropertyChanged   |
| GazeUtilityLibrary.DataStructs.CalibrationPoint, 56            | GazeUtilityLibrary.Tracker.BaseTracker, 38                      |
| Info   | OnTrackerDisabled   |
| GazeUtilityLibrary.TrackerLogger, 125                          | GazeUtilityLibrary.Tracker.BaseTracker, 38                      |
| InitCalibration  | OnTrackerDisabledTimeout  |
| CustomCalibrationLibrary.Models.CalibrationModel,              | GazeUtilityLibrary.Tracker.BaseTracker, 39                      |
| 51   | OnTrackerEnabled  |
| GazeUtilityLibrary.Tracker.BaseTracker, 37                     | GazeUtilityLibrary.Tracker.BaseTracker, 39                      |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 85                   | OnUserPositionDataReceived                                      |
| GazeUtilityLibrary.Tracker.MouseTracker, 112                   | GazeUtilityLibrary.Tracker.BaseTracker, 39                      |
| InitConfig   |   |
| GazeUtilityLibrary.GazeConfiguration, 92                       | ParseJsonConfig   |
| InitDriftCompensation  | GazeUtilityLibrary.JsonConfigParser, 105                        |
| GazeUtilityLibrary.Tracker.BaseTracker, 37                     | PatternReplace  |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 85                   | GazeUtilityLibrary.Tracker.BaseTracker, 39                      |
| GazeUtilityLibrary.Tracker.MouseTracker, 112                   | GazeUtilityLibrary.Tracker.EyeTrackerPro, 86                    |
| IsInitialised  | Points  |
| GazeUtilityLibrary.Tracker.BaseTracker, 37                     | CustomCalibrationLibrary.Models.CalibrationModel,               |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 85                   | 53  |
| IsLicenseOk  | Tobii.Research.Addons.CalibrationValidationResult,              |
| GazeUtilityLibrary.Tracker.EyeTrackerPro, 86                   | 68  |
| IsPupilDiameterValid   | Position  |
| GazeUtilityLibrary.DataStructs.EyeData, 81                     | GazeUtilityLibrary.DataStructs.CalibrationPoint, 56             |
| IsReady  Gazal Hilital ibrary Tracker RecoTracker, 27          | PrecisionLeftEye  |
| GazeUtilityLibrary.Tracker.BaseTracker, 37                     | Tobii.Research.Addons.CalibrationValidationPoint,               |
| loonConfigPorpor   | 65<br>Procision Dight Eve                                       |
| JsonConfigParser GazeUtilityLibrary.JsonConfigParser, 104      | PrecisionRightEye   |
| Gazeoliiliyeibiaiy.55011001111gPaisei, 104                     | Tobii.Research.Addons.CalibrationValidationPoint, 65            |
| LastStatus   | PrecisionRMSLeftEye   |
|  | . rosioioni aviolottejo   |

| Tobii.Research.Addons.CalibrationValidationPoint, 66                        | State GazeUtilityLibrary.Tracker.BaseTracker, 42            |
|---|---|
| PrecisionRMSRightEye Tobii.Research.Addons.CalibrationValidationPoint,      | Tobii.Research.Addons.ScreenBasedCalibrationValidation, 122 |
| 66  | Status  |
| Prepare   | CustomCalibrationLibrary.Models.CalibrationModel,           |
| GazeUtilityLibrary.DataStructs.GazeCalibrationData,                         |   |
| 89  | Stop  |
| GazeUtilityLibrary.DataStructs.GazeData, 96                                 | GazeUtilityLibrary.Tracker.MouseTracker, 112                |
| PrepareCalibrationOutputFile  | •   |
| GazeUtilityLibrary.GazeConfiguration, 92                                    | TimedOut  |
| PrepareGazeOutputFile   | Tobii.Research.Addons.CalibrationValidationPoint,           |
| GazeUtilityLibrary.GazeConfiguration, 93                                    | 66  |
| PropertyChanged   | Tobii, 23   |
| CustomCalibrationLibrary.Views.CalibrationFailed,                           | Tobii.Research, 23  |
| 48  | Tobii.Research.Addons, 23                                   |
| GazeUtilityLibrary.Tracker.BaseTracker, 42                                  | Tobii.Research.Addons.CalibrationValidationPoint, 64        |
| PupilDiameter   | AccuracyLeftEye, 65   |
| GazeUtilityLibrary.DataStructs.EyeData, 81                                  | AccuracyRightEye, 65 Coordinates, 65                        |
| Q   | GazeData, 65  |
| GazeUtilityLibrary.DriftCompensation, 76                                    | PrecisionLeftEye, 65  |
| dazeotilityLibrary.DriftCompensation, 70                                    | PrecisionRightEye, 65                                       |
| RedoCalibrationPoint  | PrecisionRMSLeftEye, 66                                     |
| CustomCalibrationLibrary.Models.CalibrationModel,                           | PrecisionRMSRightEye, 66                                    |
| 52  | TimedOut, 66  |
| Reset   | Tobii.Research.Addons.CalibrationValidationResult, 66       |
| GazeUtilityLibrary.DriftCompensation, 75                                    | AverageAccuracyLeftEye, 67                                  |
| ResetDriftCompensation  | AverageAccuracyRightEye, 67                                 |
| GazeToMouse.App, 29   | AveragePrecisionLeftEye, 67                                 |
| GazeUtilityLibrary.Tracker.BaseTracker, 40                                  | AveragePrecisionRightEye, 67                                |
| Result  | AveragePrecisionRMSLeftEye, 68                              |
| Tobii.Research.Addons.ScreenBasedCalibrationValid                           | dation,AveragePrecisionRMSRightEye, 68                      |
| 122   | Points, 68  |
| 0 4   | Tobii.Research.Addons.ScreenBasedCalibrationValidation,     |
| ScreenArea  | 118   |
| GazeUtilityLibrary.ScreenArea, 116  | Compute, 121  |
| screenArea  | DiscardData, 121  |
| GazeUtilityLibrary.Tracker.BaseTracker, 41 ScreenBasedCalibrationValidation | Dispose, 121  |
| Tobii.Research.Addons.ScreenBasedCalibrationValid                           | EnterValidationMode, 121                                    |
| 120   | Result, 122   |
| SerializeJsonConfig   | ScreenBasedCalibrationValidation, 120                       |
| GazeUtilityLibrary.JsonConfigParser, 105                                    | StartCollectingData, 122                                    |
| SetCalibrationResult  | State, 122  |
| CustomCalibrationLibrary.Models.CalibrationModel,                           | ValidationState, 120  |
| 52  | Tobii.Research.Addons.Utility, 23                           |
| ShowCursor  | TobiiCalibrate, 23  |
| GazeUtilityLibrary.MouseHider, 107  | TobiiCalibrate.App, 30                                      |
| ShowMouse, 23   | TrackerDisabled   |
| ShowMouse.App, 29   | GazeUtilityLibrary.Tracker.BaseTracker, 42                  |
| Start   | TrackerEnabled  |
| GazeUtilityLibrary.DriftCompensation, 75                                    | GazeUtilityLibrary.Tracker.BaseTracker, 42                  |
| GazeUtilityLibrary.Tracker.MouseTracker, 112                                | TrackerLogger   |
| StartCollectingData   | GazeUtilityLibrary.TrackerLogger, 124                       |
| Tobii.Research.Addons.ScreenBasedCalibrationValid                           | datiatikerMessageBox  |
| 122   | GazeUtilityLibrary.Tracker.BaseTracker, 41                  |
| StartDriftCompensation  |   |
| GazeUtilityLibrary.Tracker.BaseTracker, 40                                  | Update  |

```
GazeUtilityLibrary.DriftCompensation, 76
UpdateGazePoint
     CustomCalibrationLibrary.Models.CalibrationModel,
UserPosition
     CustomCalibrationLibrary.ViewModels.UserPositionGuideViewModel,
          130
UserPositionDataHandler
     GazeUtilityLibrary.Tracker.BaseTracker, 40
UserPositionDataReceived
     GazeUtilityLibrary.Tracker.BaseTracker, 43
UserPositionGuide
     CustomCalibrationLibrary.Models.CalibrationModel,
UserPositionGuideViewModel
    Custom Calibration Library. View Models. User Position Guide View Model,\\
          129
ValidationState
     Tobii.Research.Addons.ScreenBasedCalibrationValidation,
          120
Warning
     GazeUtilityLibrary.TrackerLogger, 125
Write To Calibration Output\\
     GazeUtilityLibrary.GazeConfiguration, 93
WriteToGazeOutput
     GazeUtilityLibrary.GazeConfiguration, 93
```