U19EC046 | TLEM | LAB 4

AIM

Design $\lambda/2$ dipole antenna for the operating frequency of 575 MHz in AN-SOF Software and Plot:

- a. Current Distribution 2D and 3D Plot.
- b. 2D Plot of Directivity of θ = 90 degree and ϕ = 90 degree and find out the front to back ratio, HPBW and FNBW.
- c. Observe the 3D Polar Plot of Directivity.

THEORY

An Antenna is a transducer which converts electrical power into electromagnetic waves and vice versa. It is a coupling device that radiates/receives EM waves. It is tuned and is mostly passive. The energy radiated by an antenna is represented by the Radiation pattern of the antenna. Radiation Patterns are diagrammatic representations of the distribution of radiated energy into space, as a function of direction.

FEW COMMON TYPES OF ANTENNA RADIATION ARE AS FOLLOWS:

1. ISOTROPIC RADIATOR

- This is an impractical antenna, it is capable of radiating uniformly in all directions.
- It is used for reference purpose Ex: Point Source.
- Also called Non- Directional Radiator.

2. DIRECTIONAL RADIATOR

All Practical Antennas are Directional Radiators, they are capable of radiating or receiving EM waves through some particular direction.

3. OMNI DIRECTIONAL RADIATOR

It is a special kind of Directional radiator capable of radiating uniformly in (θ = 90 degree) azimuthal plane and having non-uniform radiation in elevation plane (ϕ = constant) Ex: Dipole Antenna.

BEAM WIDTH

Beam width is the aperture angle from where most of the power is radiated. The two main considerations of this beam width are Half Power Beam Width (HPBW) and First Null Beam Width (FNBW).

HALF-POWER BEAM WIDTH

The angular separation, in which the magnitude of the radiation pattern decreases by 50% (or -3dB) from the peak of the main beam, is the Half Power Beam Width. In other words, Beam width is the area where most of the power is radiated, which is the peak power. Half power beam width is the angle in which relative power is more than 50% of the peak power, in the effective radiated field of the antenna.

FIRST NULL BEAM WIDTH

The angular span between the first pattern nulls adjacent to the main lobe, is called the First Null Beam Width. Simply, FNBW is the angular separation, quoted away from the main beam, which is drawn between the null points of the radiation pattern, on its major lobe.


Procedure:

- Configure the frequency of the antenna and make sure all the parameters are in mm.
- Construct an antenna from the draw tab and set the coordinates based on the wavelength we calculated for the given frequency.
- Select the number of segments as 11, and set the cross-section as 0.25mm.
- Add the source to the centre and simulate, using the Run All command.
- Observe the current plots and the Directive plots to draw the conclusions.


CALCULATIONS:

For f = 475 MHz, λ = c/f = (3*10^8)/(575*10^6) = 63.16 cm λ /2 = 31.58 cm


OBSERVATIONS




AN-SOF DESIGN




COORDINATES




3D CURRENT DISTRIBUTION




2D CURRENT DISTRIBUTION



3D DIRECTIVITY PLOT



2-D Radiation Plot for $\theta = 0$ degree



2-D Radiation Plot for $\phi = 90$ degree

CALCULATIONS

From these graphs:

- 1. Front to Back Ratio= 1
- 2. HPBW 80 degree for
- 3. FNBW = 2.25*80 degree = 180 degree for

CONCLUSION

Through this Practical we planned 1/2 dipole antenna for 475MHz and plot current distribution, 2D plot and 3D plot of different antenna lengths utilizing AN-SOF Simulation Software and we likewise determined front to back proportion, HPBW and FNBW.