putty.exe, it cannot register any key stroke that I type in



2

I am using the correct baud rate, correct COM, and right USB-to-serial driver and when I reboot the device I am able to see the text, but PuTTY is not recognizing any of my keyboard strokes. It was working perfect until now.



Can anyone help?



keyboard serial-port putty

2





- 1 "putty is not recognizing any of my keyboard strokes' -- Do you mean you're not seeing the characters echoed (on the terminal display)? Have you set up for local echo, or is the device (on the other end of the serial link) supposed to echo your input? sawdust Dec 24 '14 at 6:47
 - @sawdust Nope my keyboard stroke were not identified. I resolved it by changing the settings. –
 talktomevintron Jan 7 '15 at 2:02

2 Answers



Have you looked at the flow control? Try using XON/XOFF or maybe none and see if that doesn't get it working for you.





answered Dec 23 '14 at 20:30



Thank you Martin :) – talktomevintron Jan 7 '15 at 2:01



One of the main release for not being able to have keystroke is if the Serial to USB is broken. If not all ports are working the we landup in this issue.



and Yes XON/XOFF will help.






If Using Windows Keyboard use the configuration below. It resolved my problem.



Σ3



My issue is solved.



Connecting to Linux embedded device: Using exactly the same settings but doesn't work for me. I see the characters in the terminal window but can't access the console. But I am able to access the shell via LAN. But on a Linux desktop using minicom it works ... so the board itself doesn't seem to be the issue ... Seems to be a Windows/PuTTY issue. – hfrmobile Mar 23 '17 at 10:31