# 02\_02 Performing PAA Gel Electrophoresis

FREITAG, 14.5.2021

### **Goal-Setting**

• Performing PAA gel electrophoresis

#### **Terms / abbreviations**

- EDTA = Ethylenediaminetetraacetatic acid
- PAA = Polyacrylamide
- TBE = Tris-borate-EDTA

#### **Risk areas**



## Required materials and / or information

- 1x TBE-Buffer (approx. 1.5 L)
- GeneRuler Ultra Low Range DNA Ladder, ThermoFisher
- PAA Gel
- Samples

#### Templates, devices, software

- BioRad MINI PROTEAN II Apparatus
- BioRad PROTEAN Tetra Cell
- Gel electrophoresis Power Supply, Consort

#### **Preliminary work**


- 00\_02 10x TBE Buffer Recipe
- 02\_01 PAA Gel Preparation (Native)
- 02 01 PAA Gel Preparation (Denaturating)
- 01\_02 Sample Preparation for Gel Electrophoresis

## **Operation**

- 1. Take the gel out of the fridge and set it up in the BioRad MINI PROTEAN II Apparatus (two gel brackets à two gels fit into one apparatus)
  - a. Place the small glass slides inwards
  - b. Use a bracket with connective plugs!
- 2. Fill first the bracket, then the whole chamber up to the line with 1x TBE buffer
  - a. It is important to use the same batch of electrophoresis buffer in both of the reservoirs and in the gel
  - b. Small differences in ionic strength or pH produce buffer fronts that can greatly distort the migration of DNA
  - c. If the bracket is filled first, leaks can be seen
  - d. If leaks should be avoided completely, fill up the whole chamber up to the level of the inner bracket

- e. Make sure to create two different "rooms". The water level should not be equal!
- 3. Pipette 5 µL of the ladder and desired amount of prepared samples into a distinct well
  - a. Be careful not to disrupt the gel; make sure the sample sinks into the well
- 4. Place the lid properly onto the gel electrophoresis chamber, the electrodes have to correctly connect with the BioRad MINI PROTEAN II Apparatus (see image)






- 1. Attach the electrode cables to the Consort gel electrophoresis Power Supply, turn it on and set the right conditions
  - a. Set device to desired voltage
  - b. Set Watt and Ampere to max
  - c. Set time
  - d. Start
- 2. Perform gel electrophoresis at 100 V for 1 h
- 3. When finished, take out the BioRad MINI PROTEAN II and pour the used TBE buffer back into a schottflask (mark the number of uses of the buffer on the schottflask)
- 4. When finished, clean all used parts under water and place in the rack to dry

#### **Disposal**

• TBE buffer can be discarded in sink with a lot of water

#### **Troubleshooting**

- It is important to use the same batch of electrophoresis buffer in both of the reservoirs and in the gel (Step 2!)
- For any problems use google to search for 'gel electrophoresis troubleshooting'
- Blurry bands? Too much DNA or excess salt will create smeared bands and/or streaking in the gel. Loading the correct amount of DNA (usually a maximum of 100-250 ng/mm well width) and desalting samples with a spin column prior to loading will prevent this
- Loading buffer floats away? Rinsing wells with running buffer just before loading is essential; failure to do so may prevent the loading mixture from sinking to the bottom of the well, resulting in an uneven band and delayed migration



## Follow-up work

- 02\_04 SYBR Gold Staining
- 02\_03 Silver Staining DNA in PAA Gels