PID CONTROLLER FOR DRONES



Contents

1	Controller For Drones																						
	1.1	Abstr	act																				2
	1.2	Why	con	Coor	rdina	tes																	2
	1.3	Types	s of	Con	trolle	ers							 										3
		1.3.1	P	Con	troll	er .							 										4
		1.3.2	P	D C	ontro	oller																	6
		1.3.3	P	ID (contr	olle	r						 										8
		1.3.4	T	o sui	${ m n}$ it	up																	10
	1.4	Refer	enc	es .																			11
	1.5	Softw	are	Setu	ıp.																		11

Controller For Drones

1.1 Abstract

Systems can broadly be divided into two types; **open loop systems** and **closed loop systems**. An open loop system is also called an *uncontrolled system*. The output of such a system is not controlled as the system has no feedback. a closed loop system is also called a *controlled system*. The output of such a system is controlled as it receives feedback. PID is an example of a close loop system. Proportional-integral-derivative (PID) controllers are widely used in industrial systems despite the significant developments of recent years in control theory and technology. They perform well for a wide class of processes. Also, they give robust performance for a wide range of operating conditions and, they are easy to implement using analogue or digital hardware.

1.2 Whycon Coordinates



Figure 1.1: Whycon Coordinates



The figure shows the output from the vision sensor with whycon coordinates as output. The direction for positive x-axis and positive y-axis are as shown in the figure above for the whycon coordinate system. The positive direction for the z-axis is away from the vision sensor.

1.3 Types of Controllers

• Proportional Controller (P Controller)

P controller is mostly used in first order processes with single energy storage to stabilize the unstable process. The main usage of the P controller is to decrease the steady state error of the system. As the proportional gain factor K increases, the steady state error of the system decreases. However, despite the reduction, P control can never manage to eliminate the steady state error of the system. As we increase the proportional gain, it provides smaller amplitude and phase margin, faster dynamics satisfying wider frequency band and larger sensitivity to the noise. We can use this controller only when our system is tolerable to a constant steady state error. In addition, it can be easily concluded that applying P controller decreases the rise time and after a certain value of reduction on the steady state error, increasing K only leads to overshoot of the system response. P control also causes oscillation if sufficiently aggressive in the presence of lags and/or dead time. The more lags (higher order), the more problem it leads. Plus, it directly amplifies process noise.

• Proportional Derivative Controller (PD Controller)

The aim of using P-D controller is to increase the stability of the system by improving control since it has an ability to predict the future error of the system response. In order to avoid effects of the sudden change in the value of the error signal, the derivative is taken from the output response of the system variable instead of the error signal. Therefore, D mode is designed to be proportional to the change of the output variable to prevent the sudden changes occurring in the control output resulting from sudden changes in the error signal. In addition D directly amplifies process noise therefore D-only control is not used.

• Proportional Integral Derivative (PID Controller)

P-I-D controller has the optimum control dynamics including zero steady state error, fast response (short rise time), no oscillations and higher stability. The necessity of using a derivative gain component in addition




to the PI controller is to eliminate the overshoot and the oscillations occurring in the output response of the system.

1.3.1 P Controller

A P controller consists of only a linear gain Kp. The output of such controller can be simply given as

$$output = Kp * error$$

Block diagram



The whycon input consists of x, y and z coordinates which gives the current location of the drone.

Suppose the destination is say, (x1, y1, z1), then the difference of coordinates i.e (x1-x), (y1-y), (z1-z) will be fed as an input to the P-controller. The resultant product i.e Kp * error will be added or subtracted to the offset pwm as the need be to give the final output.


Observations

It was observed that the drone never settled at its destination. Instead it oscillated about its destination. The higher the value of Kp the more the amplitude of the oscillation and the drone would be out of the flying zone.

Below is a plot between error in x, y, and z coordinates and time. Clearly it is visible that the drone was not able to stabilise itself at the destination.



1.3. TYPES OF CONTROLLERS




Hence, it was concluded that a P-controller by itself wasn't able to stabilise the drone at a required point.



1.3.2 PD Controller

In the previous section we saw how the P-Controller wasn't successful in stabilising the drone at a given point. It was observed that there were oscillations instead. These oscillations can be damped by using a differential gain along with the P-Controller. The system as a whole is said to be a PD Controller

Block diagram



The differential gain Kd is multiplied with the difference of error and previous error. Previous error is a variable that holds the last error generated by the controller output.

The controller output in this case is given as

Note that Kd is calculated keeping the sampling time in consideration. This output will be further added or subtracted to the offset pwm as the need be to give the final output.


Observations

The results of this controller was no match to the P-controller.

The oscillations were damped with change in time. Here is a plot of error and time for a PD controller implemented on the Pluto drone.



1.3. TYPES OF CONTROLLERS



But, there was a hitch!

On having a closer look it was observed that though the drone could hover with respectable stability, it did not do so over the correct point, i.e the drone did not reach its destination instead it would hover at a point near to the destination.

This slight error is known as the steady state error.

Hence, it was concluded that a PD controller also by itself wasn't able to stabilise the drone at the correct destination.




1.3.3 PID Controller

In the previous section we saw how a PD controller was not quite enough. In order to minimise the steady state error we introduce another gain called Ki ,the integral gain.

Such a system is said to be a PID Controller

Block diagram



Here in we keep track of the error over time i.e. sum up the errors over a specified sampling time.

$$Iterm = (Iterm + error) * Ki$$

Further explanation regarding implementation of this Iterm is given in the code.

Note that Ki is calculated keeping the sampling time in consideration.

This output will be further added or subtracted to the offset pwm as the need be to give the final output.

$$output = Kp*error + Iterm + Kd*(error - previous error)$$


Observations

The PID controller was successful in hovering the drone above the destination point with minimal error .




1.3. TYPES OF CONTROLLERS

It overcome the steady state error which was noticeable in previous controllers. Here is a plot of error and time for a PID controller implemented on the Pluto drone.





1.3.4 To sum it up





1.4 References

Please refer to the following video tutorials for a more detailed explanation:

- 1. PID Control Tutorial 1.1 Introduction to PID (Part 1) In this video you will learn about:
 - (a) V-REP Simulator
 - (b) Motions of a Drone
 - (c) Controlling the eDrone Model in V-REP using ROS
 - (d) Arming, Disarming and Flight
 - (e) Localizing the Drone using Whycon
- 2. PID Control Tutorial 1.2 Introduction to PID (Part 2)
 In this video you will learn about the effect of PID parameters on characteristics of a closed loop system.
- 3. PID Control Tutorial 2 Tuning of PID Parameters
 In this video we will learn how to tune the PID parameters for the
 eDrone model in V-REP starting with throttle followed by yaw and
 finally pitch and roll

1.5 Software Setup

To clone the packages used in the video tutorial type the following commands in the terminal:

```
>> cd ~/catkin_ws/src
>> git clone https://github.com/fayyazpocker/pid_tune.git
>> sudo apt-get install ros-kinetic-plotjuggler
>> cd .. && catkin_make
>> source devel/setup.bash
```