

Autonomous Vehicle Simulation (AVS) Laboratory, University of Colorado

Basilisk Technical Memorandum

Document ID: Basilisk-mrpRotation

MRP ROTATION ATTITUDE GUIDANCE MODULE

Prepared by	H. Schaub
-------------	-----------

Status: First Release

Scope/Contents

This attitude guidance module creates a dynamic reference frame attitude state message where the initial orientation relative to the input reference frame is specified through an MRP set, and the angular velocity vector is held fixed as seen by the resulting reference frame. Besides setting the desired MRP and angular velocity values directly within the module, they can also be read in from an optional input message. The reset process will re-read these desired attitude states from this input message. If a reset is called without an input attitude state message, then the last stored attitude states are used to continue the rotation. Optionally, the compute attitude states relative to the input frame can be fed to an output message as well.

Rev	Change Description	Ву	Date
1.0	Initial Release	H. Schaub	May 22, 2018

Contents

1	Model Description	1
2	Module Functions	2
3	Module Assumptions and Limitations	2
4	Test Description and Success Criteria	3
5	Test Parameters	3
6	Test Results	3
7	User Guide7.1Specifying Desired Rotation	




Fig. 1: Illustration of the mrpRotation() input and output messages. Required messages are shown with a solid line, while optional message have a dashed line.

1 Model Description

The purpose of this mrpRotation module is to add a constant rotation relative to the input frame \mathcal{R}_0 . The output reference frame is called \mathcal{R} . The initial orientation is specified through an MRP¹ set $\sigma_{R/R0}$, while the \mathcal{R} -frame angular velocity vector ${}^{\mathcal{R}}\omega_{R/R0}$ is held constant in this module.

Assume that the input reference frame \mathcal{R}_0 is given through an attitude state input message containing $\sigma_{R_0/N}$, $^{\mathcal{N}}\omega_{R_0/N}$ and $^{\mathcal{N}}\dot{\omega}_{R_0/N}$ as illustrated in Figure 1. The MRP set is mapped into the corresponding Direction Cosine Matrix or DCM¹ using

$$[R_0 N] = [R_0 N(\sigma_{R_0/N})] \tag{1}$$

The goal of the motion is to compute the attitude of $\mathcal R$ relative to input frame $\mathcal R_0$ such that

$$\dot{\boldsymbol{\sigma}}_{R/R_0} = \frac{1}{4} [B(\boldsymbol{\sigma}_{R/R_0})]^{\mathcal{R}} \boldsymbol{\omega}_{R/R_0}$$
 (2)

$$\frac{{}^{\mathcal{R}}\mathrm{d}\boldsymbol{\omega}_{R/R_0}}{\mathrm{d}t} = \mathbf{0} \tag{3}$$

Assume the initial $\sigma_{R/R_0}(t_0)$ set and the \mathcal{R} -frame relative invariant ${}^{\mathcal{R}}\omega_{R/R_0}$ vector are provided to the module. The current $\sigma_{R/R_0}(t_0)$ value is then obtained by Eq. (2). The current DCM of the \mathcal{R} -frame is thus

$$[RN] = [RR_0(\boldsymbol{\sigma}_{R/R_0}(t))][R_0N] \tag{4}$$

Next, the angular velocity vector is transformed to inertial frame \mathcal{N} -frame components using

$${}^{\mathcal{N}}\boldsymbol{\omega}_{R/R_0} = [RN]^T \, {}^{\mathcal{R}}\boldsymbol{\omega}_{R/R_0} \tag{5}$$

to find the inertial angular velocity of the output reference frame:

$$^{\mathcal{N}}\boldsymbol{\omega}_{R/N} = ^{\mathcal{N}}\boldsymbol{\omega}_{R/R_0} + ^{\mathcal{N}}\boldsymbol{\omega}_{R_0/N} \tag{6}$$

Finally, the inertial angular acceleration of the output reference frame is found using the transport theorem:

$$\dot{\omega}_{R/N} = \frac{\mathcal{R}_{d\omega_{R/R_0}}}{dt} + \omega_{R/N} \times \omega_{R/R_0} + \dot{\omega}_{R_0/N} = \omega_{R_0/N} \times \omega_{R/R_0} + \dot{\omega}_{R_0/N}$$
(7)

where $\omega_{R/N} \times \omega_{R/R_0} = (\omega_{R/R_0} + \omega_{R_0/N}) \times \omega_{R/R_0} = \omega_{R_0/N} \times \omega_{R/R_0}$ is used. Expressed in $\mathcal N$ frame components, this vector equation is numerically evaluated using:

$${}^{\mathcal{N}}\dot{\boldsymbol{\omega}}_{R/N} = {}^{\mathcal{N}}\boldsymbol{\omega}_{R_0/N} \times {}^{\mathcal{N}}\boldsymbol{\omega}_{R/R_0} + {}^{\mathcal{N}}\dot{\boldsymbol{\omega}}_{R_0/N} \tag{8}$$

2 Module Functions

The mrpRotation module has the following design goals

- **Constant Spin**: The angular velocity vector between the input and output frame is constant as see by output reference frame
- MPR attitude representation: The initial and output attitude is described through an MRP coordinate set
- **Flexible Setup**: The desired rotation state can be described through an initial MRP and angular velocity vector specified in module internal variables, or read in through a Basilisk AttStateFswMsg message.

3 Module Assumptions and Limitations

- On reset the the next time step doesn't yield an integration as the integration time evaluation requires at least a second time step.
- If the desired rotation states are read in with an input message, on reset these values are re-read in again.
- If the desired rotation is specified with module internal states, then on reset the prior internal states are re-used unless they are over-written after the reset call.

4 Test Description and Success Criteria

The module is run on its own with specified inputs to ensure the outputs are correct. The outputs are evaluated dynamically using a support python script, and then compared to the Basilisk evaluated results. A nominal simulation length of 1 second is used with a time step of 0.5 seconds, yielding 3 return values.

If the rotation states are set directly in the module by specifying mrpSet and omega_RRO_R, then the values $\sigma_{R/R_0}(t_0)=$ [0.3 0.5 0.] and $^{\mathcal{R}}\omega_{R/R_0}=$ [0.1 0. 0.]deg/sec are used. The simulation flag cmdStateFlag determines if the rotation states are specified through an input message. If yes, then the values $\sigma_{R/R_0}(t_0)=$ [0.1 0. -0.2] and $^{\mathcal{R}}\omega_{R/R_0}=$ [0.1 1. 0.5]deg/sec are used instead.

If the simulation flag stateOutputFlag is true then the optional attitude states of \mathcal{R} relative to \mathcal{R}_0 are provided in an output message.

If the simulation flag testReset is true then the simulation will run an addition 1 second, but after a reset function is called.

Check	cmdStateFlag	stateOutputFlag	testReset	
1	False	False	False	
2	True	False	False	
3	False	True	False	
4	False	False	True	
5	True	False	True	

Table 2: Test Scenarios.

5 Test Parameters

The output variables being tested are listed in Table 3, including the test tolerance value.

Output Value Tested Tolerated Error

attRefOutMsgName.sigma_RN 1e-12
attRefOutMsgName.omega_RN_N 1e-12
attRefOutMsgName.domega_RN_N 1e-12
attitudeOutMsgName.state 1e-12
attitudeOutMsgName.rate 1e-12

Table 3: Error tolerance for each test.

6 Test Results

The results of the unit test are listed in Table 4. All of the tests passed:

Table 4: Test results

Check	Pass/Fail		
1	PASSED		
2	PASSED		
3	PASSED		
4	PASSED		
5	PASSED		

7 User Guide

7.1 Specifying Desired Rotation

If the mrpRotation module is set directly with the desired rotation states, then the modules variables mrpSet and omega_RRO_R must be set.

If instead the desired rotation states are to be read in, then then input message name desiredAttInMsgName must be specified, and a corresponding message of type AttStateFswMsg created.

7.2 Required Input and Output Messages

The \mathcal{R}_0 input reference frame state message is specified through tt attRefInMsgName. The output message name is specified through the attRefOutMsgName.

7.3 Optional Output Message

If desired, the σ_{R/R_0} and ${}^{\mathcal{R}}\omega_{R/R_0}$ states can be written to the message attitudeOutMsgName. If this message name is not set, then this output message is not created.

REFERENCES

[1] Hanspeter Schaub and John L. Junkins. *Analytical Mechanics of Space Systems*. AIAA Education Series, Reston, VA, 4th edition, 2018.