

Detailed Certificate of Calibration

Equipment Calibrated

Description: Six-Axis Force/Torque Sensor

Manufacturer: ATI Industrial Automation

Serial Number: FT16737 Model: Mini45 Calibration: SI-290-10 Electronics: DAQ Output Range: $\pm 5V$

Gain Multiplier: 100%

Customer Information

Mr. William Zhang

Shanghai Forever Young Imp. & Exp. Co., Ltd. Rm.105,107 of South Dianxin Building, Tongji University, No.500, Zhennan Road

Shanghai, 200331

CHINA

william@f-young.com

Equipment Condition and Notes: Factory new.

Calibration Results: Passed

Offset: Normal Gain: Normal

Calibrated Ranges (±):

Fx	Fy	Fz	Tx	Ту	Tz
290 N	290 N	580 N	10 N-m	10 N-m	10 N-m

Measurement Uncertainty (95% confidence level, percent of full-scale load):

Fx	Fy	Fz	Tx	Ту	Tz
1.00%	0.75%	0.75%	1.00%	1.25%	1.25%

The above Measurement Uncertainty values are the maximum amount of error for each axis expressed as a percentage of its full-scale load.

Calibration Temperature: 22.2°±1.1° C (72°±2° F)

Temperature Compensation: hardware

Calibration Method: WI-FTP-026, DAQ Calibration Instructions

Date of Calibration: 01 Apr 2015

Certificate Date: 02 Apr 2015

Calibrated by: Melvin Wells, Calibration Technician

> Page 1 of 6 Certificate Number: FT16737-20150401

Jel E. Well



This calibration is traceable to the National Institute of Standards and Technology (NIST). Calibration standards (not all of the listed standards are used for this calibration):

Calibration Equipment							
Description	Identification						
Calibration Tool	FTT-1920						
DAQ, 200KS/S, 16-BIT, 16 AN	CNTLR-2002-1						
DAQ, 200KS/S, 16-BIT, 16 AN	CNTLR-2015-3						
DAQ, 200KS/S, 16-BIT, 16 AN	CNTLR-2025-2						
3X STND-ALN CONTROLLER	CNTLR-2040						
3X STND-ALN CONTROLLER	CNTLR-2042						
3X STND-ALN CONTROLLER	CNTLR-2050						
PCI-6034E	CNTLR-2060-4						
30K LOAD CELL	FTT-1990						
9105-NETB BOX #2	FTT-1999						
SS Hook Weights	WHT-1706,1708,1709,1718						
Weights Type II	WHT-1700-1705,1707						
SS Set of 13 Weights	WHT-1721						
Brass Set of 13 Weights	WHT-1719						

ATI Industrial Automation (ATI) certifies that the above product was calibrated in accordance with applicable ATI procedures. These procedures are compliant with the ISO 9001 standard to ensure that the above product is within ATI specifications. To meet this level of accuracy any loads must be correctly aligned to the transducer origin and the transducer must be mounted to a sufficiently strong surface.

To ensure the transducer measurement uncertainties listed on page 1 are met, more-conservative limits are used as calibration targets during the calibration process. If any of the calibration targets are exceeded the calibration will not pass. It is possible for a transducer to exceed these calibration targets while meeting the page 1 measurement uncertainties. The following calibration targets were used for this transducer: Fx=0.75%, Fy=0.50%, Fz=0.50%, Tx=0.75%, Ty=1.00%, and Tz=1.00%.

Note: If this is a recalibration of a legacy transducer that does not have precision locating features (such as dowel holes), there could be additional error in Tx and Ty due to inexact mounting location. Precision locating features are highly recommended for best accuracy and can be added by ATI.

This certificate shall not be reproduced except in full without written approval from ATI. This certificate only applies to the items listed and does not include unlisted ancillary items such as data acquisition equipment.

For questions or comments, please contact your ATI representative.



Calibration Accuracy Section Sensor System FT16737, Mini45/SI-290-10 Force units: N; Torque units: N-m

Calibrated Ranges (±)							
Fx Fy Fz Tx Ty Tz							
290	290	580	10	10	10		

	Applied Loads							
	Fx	Fy	Fz	Tx	Ту	Tz		
1	0.000	80.068	0.000	-8.133	0.000	0.000		
2	-80.068	0.000	0.000	0.000	-8.133	0.000		
3	0.000	-80.068	0.000	8.133	0.000	0.000		
4	80.068	0.000	0.000	0.000	8.133	0.000		
5	0.000	222.411	0.000	-6.756	0.000	0.000		
6	-222.411	0.000	0.000	0.000	-6.756	0.000		
7	0.000	-222.411	0.000	6.756	0.000	0.000		
8	222.411	0.000	0.000	0.000	6.756	0.000		
9	0.000	75.620	0.000	-0.576	0.000	-8.649		
10	0.000	75.620	0.000	-0.576	0.000	8.645		
11	-75.620	0.000	0.000	0.000	-0.576	-8.652		
12	-75.620	0.000	0.000	0.000	-0.576	8.640		
13	0.000	-75.620	0.000	0.576	0.000	-8.645		
14	0.000	-75.620	0.000	0.576	0.000	8.649		
15	75.620	0.000	0.000	0.000	0.576	-8.640		
16	75.620	0.000	0.000	0.000	0.576	8.652		
17	0.000	0.000	115.654	-8.840	0.000	0.000		
18	0.000	0.000	115.654	0.000	-8.833	0.000		
19	0.000	0.000	115.654	8.816	0.000	0.000		
20	0.000	0.000	115.654	0.000	8.814	0.000		
21	0.000	0.000	489.304	0.000	0.000	0.000		
22	0.000	0.000	-489.304	0.000	0.000	0.000		
23	0.000	0.000	-115.654	8.840	0.000	0.000		
24	0.000	0.000	-115.654	0.000	8.833	0.000		
25	0.000	0.000	-115.654	-8.816	0.000	0.000		
26	0.000	0.000	-115.654	0.000	-8.814	0.000		

Refer to page 6 for important information on regarding this report.



	Full-Scale Error							
	Fx	Fy	Fz	Tx	Ту	Tz		
1	-0.21%	0.00%	-0.02%	-0.18%	0.22%	0.05%		
2	0.20%	-0.07%	0.06%	-0.01%	-0.20%	0.02%		
3	-0.24%	-0.01%	-0.03%	-0.06%	0.36%	0.02%		
4	0.18%	-0.05%	0.02%	-0.13%	-0.29%	0.09%		
5	-0.35%	0.01%	-0.02%	0.03%	0.25%	0.38%		
6	0.13%	-0.01%	0.11%	-0.11%	-0.20%	0.20%		
7	-0.34%	-0.05%	-0.01%	-0.05%	0.29%	0.39%		
8	0.21%	0.00%	0.10%	-0.06%	-0.34%	0.24%		
9	-0.02%	-0.01%	0.02%	0.01%	0.20%	0.03%		
10	-0.05%	0.00%	0.00%	0.01%	0.15%	0.07%		
11	0.08%	0.12%	0.00%	-0.06%	-0.12%	0.19%		
12	0.06%	0.01%	0.00%	0.11%	-0.13%	-0.01%		
13	-0.06%	0.05%	0.01%	0.05%	-0.02%	0.01%		
14	-0.03%	0.11%	0.01%	0.07%	0.09%	0.10%		
15	-0.07%	0.01%	0.03%	0.13%	0.16%	-0.03%		
16	-0.05%	0.06%	0.04%	-0.07%	0.11%	0.02%		
17	-0.21%	0.02%	-0.11%	0.25%	0.43%	0.03%		
18	0.15%	-0.01%	-0.04%	-0.24%	-0.28%	0.04%		
19	-0.18%	-0.01%	-0.12%	0.09%	0.26%	0.02%		
20	0.08%	0.00%	0.00%	-0.19%	-0.30%	-0.10%		
21	0.01%	0.02%	0.16%	0.17%	-0.03%	0.00%		
22	-0.12%	0.09%	0.11%	0.36%	-0.10%	0.01%		
23	-0.19%	-0.08%	-0.10%	-0.23%	0.31%	0.02%		
24	0.41%	-0.05%	0.08%	-0.15%	-0.02%	-0.01%		
25	-0.18%	-0.15%	-0.10%	-0.34%	0.28%	-0.01%		
26	0.36%	-0.03%	0.07%	-0.17%	-0.18%	-0.06%		

Refer to page 6 for important information on regarding this report.

	Offset Report						
	Fx	Fy	Fz	Tx	Ту	Tz	
F/T Offset	2.8298	4.1051	-1.3607	0.0474	0.0086	-0.0006	
	SG0	SG1	SG2	SG3	SG4	SG5	
SG Offset	0.0022	0.0256	0.0094	0.0274	0.0030	0.0023	
±SG Limit	0.2442	0.2442	0.2442	0.2442	0.2442	0.2442	

Offsets are measured in a unique configuration not available to the user. Refer to page 6 for important information on regarding this report.



	Gain-Check Report					
	SG0	SG1	SG2	SG3	SG4	SG5
Lower Limit	0.7500	0.7500	0.7500	0.7500	0.7500	0.7500
Lower Output	0.8756	0.8695	0.8812	0.8515	0.8602	0.8655
Upper Output	0.8791	0.8716	0.8863	0.8537	0.8791	0.8709
Upper Limit	1.0000	1.0000	1.0000	1.0000	1.0000	1.0000

Gain readings are measured in a unique loading configuration. Refer to page 6 for important information on regarding this report.



As part of our commitment to quality, each ATI force/torque transducer undergoes rigorous accuracy testing. This process, which involves applying and verifying a rich set of loading cases designed to cover the transducer's entire six-axis calibrated range, is designed to ensure that your transducer meets the measurement uncertainties listed in this Certificate of Calibration.

Our transducers often exceed our quality standards for accuracy. Often, transducers perform exceptionally well in certain loading situations. This report summarizes the performance of your ATI F/T transducer in our factory tests. It can be thought of as a 'best-case scenario' snapshot of your transducer's performance under laboratory conditions, in a variety of loading situations. You can expect the accuracy of your transducer measurements to fall somewhere between its performance during testing and the measurement uncertainties listed on its calibration certificate.

The Calibration Accuracy Section contains several tables of data. The Calibrated Ranges (±) table lists the transducer's rated range for each axis. The Applied Loads table lists the loads applied during calibration and testing. The Full-Scale Error table shows the sensor system's measurement error as a percentage of full scale for each axis in each loading case. The Offset Report table shows transducer readings during offset adjustment and associated control limits. And the Gain-Check Report table shows verification of the transducer's sensitivity and associated control limits. If included, the Before and After Report table shows a loading case relating the transducer's performance as received to its performance after recalibration.

For best accuracy, be sure to use your transducer's precision location features, and mount your transducer to a stiff surface. If an ongoing guarantee of sensor accuracy is important to you, we recommend that your sensor be tested annually. Contact your ATI Industrial Automation distributor to schedule recalibrations.