
## ATE305 Control Guide Part 3

Daniel 2017/4/21 Initial Version

New PEB Board 進行 digital pattern 測試時我們稱為 Normal Mode,另外每一個 pin 我們都能夠設定為 PMU mode,進行 PMU 相關參數量測。

以一個基本的 ATE305 + Channel FPGA + PMU ADC + Relay 的接線如下圖:



### Pin Mode API:

Pin Mode (channel, OFF/PMU/VTT/LOAD/NORMAL)

每個 Channel 可以個別指定 Pin Mode:

OFF: 關閉 Pin Drive、PMU 所有功能

PMU: 設定為 PMU 使用(此時可以 FV/FI/MV/MI)

VTT: Terminate on VTT (此時可以 MV)
LOAD: 加掛 Active Load (此時可以 MV)
Normal: 關閉 Active Load (此時可以 MV)

#### PMU APIs:

- FV (channel, Value, I\_range, clamp\_H, clamp\_L, delay) // default delay = 0ms
- FI (channel, Value, I\_range, clamp\_H, clamp\_L, delay) // default delay = 0ms
- MV (channel, count) // default count(1)
- MI (channel, count) // default count(1)

Pin\_Mode API 底層撰寫指導:

- Pin Mode (channel, OFF/PMU/VTT/LOAD/NORMAL)

Channel 對應哪個 Slot 由上層軟體決定,底層 API 我們只需決定 1~64Channel 是哪一個 Channel FPGA 的哪一個 Channel 即可:

(channel / 16) = CH\_FPGA\_SEL, (channel % 16) = CH\_SEL

W 0xFF 0x0002 << CH\_FPGA\_SEL // Channel FPGA Select

基本上 Pin\_Mode API 主要控制 ATE305 的 Register 0x0C、0x0D 位置

針對 OFF Mode,我們使用 ATE305 spec Table29 的第一行"High-Z without clamps",並且同時關閉 PMU 的功能:

Table 29. Driver and Load Truth Table<sup>1</sup>

Registers				Signals			
PE Disable DATA[0] ADDR[4:0] = 0x0C	Force VT DATA[1] ADDR[4:0] = 0x0C	Load Enable DATA[1] ADDR[4:0] = 0x0D	Driver High-Z/VT DATA[0] ADDR[4:0] = 0x0D	DATAx	RCVx	Driver State	Load State
1	X	X	X	X	X	High-Z without clamps	Power-down
0	1	X	X	Х	Х	VT	Power-down
0	0	0	0	0	0	VL	Power-down
0	0	0	0	0	1	High-Z with clamps	Power-down
0	0	0	0	1	0	VH	Power-down
0	0	0	0	1	1	High-Z with clamps	Power-down
0	0	0	1	0	0	VL	Power-down
0	0	0	1	0	1	VT	Power-down
0	0	0	1	1	0	VH	Power-down
0	0	0	1	1	1	VT	Power-down
0	0	1	0	0	0	VL	Active off
0	0	1	0	0	1	High-Z with clamps	Active on
0	0	1	0	1	0	VH	Active off
0	0	1	0	1	1	High-Z with clamps	Active on
0	0	1	1	0	0	VL	Active on
0	0	1	1	0	1	High-Z with clamps	Active on
0	0	1	1	1	0	VH	Active on
0	0	1	1	1	1	High-Z with clamps	Active on

ATE305 0x0C DATA[0] = 1, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x1 = 1 // DATA[2:0] = 3'b001 for 0x0C

 $ATE305_SEL = (0x01 << (CH_SEL / 2))$ 

ATE305\_CH\_SEL = CH\_SEL % 2

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0C} // Set 0x0C Register

針對 PMU Mode 我們需將指定的 Channel 開啟為 PMU,並因為要使用 Clamp 功能,使用的 Table 如下:

Table 29. Driver and Load Truth Table<sup>1</sup>

Registers			Signals				
PE Disable DATA[0] ADDR[4:0] = 0x0C	Force VT DATA[1] ADDR[4:0] = 0x0C	Load Enable DATA[1] ADDR[4:0] = 0x0D	Driver High-Z/VT DATA[0] ADDR[4:0] = 0x0D	DATAx	RCVx	Driver State	Load State
1	X	X	X	Х	Х	High-Z without clamps	Power-down
0	1	X	X	X	X	VT	Power-down
0	0	0	0	0	0	VL	Power-down
0	0	0	0	0	1	High-Z with clamps	Power-down
0	0	0	0	1	0	VH	Power-down
0	0	0	0	1	1	High-Z with clamps	Power-down
0	0	0	1	0	0	VL	Power-down
0	0	0	1	0	1	VT	Power-down
0	0	0	1	1	0	VH	Power-down
0	0	0	1	1	1	VT	Power-down
0	0	1	0	0	0	VL	Active off
0	0	1	0	0	1	High-Z with clamps	Active on
0	0	1	0	1	0	VH	Active off
0	0	1	0	1	1	High-Z with clamps	Active on
0	0	1	1	0	0	VL	Active on
0	0	1	1	0	1	High-Z with clamps	Active on
0	0	1	1	1	0	VH	Active on
0	0	1	1	1	1	High-Z with clamps	Active on

當使用 PMU 的時候,其他 Driver 應該為 High-Z 才不會影響 PMU Driver 的輸出或量測 PMU\_MODE = PMU\_MODE || (0x0001 << CH\_SEL)

```
W 0x3E PMU_MODE // Make RCV = 1, DATA don't care
```

ATE305 0x0C DATA[0] = 0, DATA[1] = 0, DATA[2] = 1

```
W = 0x38 = 0x4 = // DATA[2:0] = 3'b100 for 0x0C
```

ATE305 0x0D DATA[0] = 0, DATA[1] = 0, DATA[2] = 0

```
W = 0x38 = 0x0  // DATA[2:0] = 3'b000 for 0x0D
```

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0D} // Set 0x0D Register

針對 VTT Mode,跑 Pattern 時若 RCV= 1 則原本的 High-Z 要改為 terminate 至 VTT,我們使用 ATE305 spec Table29 如下:

Table 29. Driver and Load Truth Table 1

Registers				Signals			
PE Disable DATA[0] ADDR[4:0] = 0x0C	Force VT DATA[1] ADDR[4:0] = 0x0C	Load Enable DATA[1] ADDR[4:0] = 0x0D	Driver High-Z/VT DATA[0] ADDR[4:0] = 0x0D	DATAx	RCVx	Driver State	Load State
1	X	X	X	X	Х	High-Z without clamps	Power-down
0	1	X	X	X	X	VT	Power-down
0	0	0	0	0	0	VL	Power-down
0	0	0	0	0	1	High-Z with clamps	Power-down
0	0	0	0	1	0	VH	Power-down
0	0	0	0	1	1	High-Z with clamps	Power-dowr
0	0	0	1	0	0	VL	Power-down
0	0	0	1	0	1	VT	Power-dowr
0	0	0	1	1	0	VH	Power-dowr
0	0	0	1	1	1	VT	Power-dowr
0	0	1	0	0	0	VL	Active off
0	0	1	0	0	1	High-Z with clamps	Active on
0	0	1	0	1	0	VH	Active off
0	0	1	0	1	1	High-Z with clamps	Active on
0	0	1	1	0	0	VL	Active on
0	0	1	1	0	1	High-Z with clamps	Active on
0	0	1	1	1	0	VH	Active on
0	0	1	1	1	1	High-Z with clamps	Active on

首先確定 Channel FPGA PMU 模式為關閉

PMU\_MODE = PMU\_MODE && (~(0x0001 << CH\_SEL))

W 0x3C PMU\_MODE // Disable PMU Mode

ATE305 0x0C DATA[0] = 0, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x0 // DATA[2:0] = 3'b000 for 0x0C

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0C} // Set 0x0C Register

ATE305 0x0D DATA[0] = 1, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x1 = // DATA[2:0] = 3'b001 for 0x0D

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0D} // Set 0x0D Register

# 針對 LOAD Mode 跑 Pattern 時若 RCV=0 則要開啟 Active Load,使用 Table 如下:

Table 29. Driver and Load Truth Table<sup>1</sup>

Registers				Signals			
PE Disable DATA[0] ADDR[4:0] = 0x0C	Force VT DATA[1] ADDR[4:0] = 0x0C	Load Enable DATA[1] ADDR[4:0] = 0x0D	Driver High-Z/VT DATA[0] ADDR[4:0] = 0x0D	DATAx	RCVx	Driver State	Load State
1	X	Х	Х	Х	Х	High-Z without clamps	Power-down
0	1	X	X	X	X	VT	Power-down
0	0	0	0	0	0	VL	Power-down
0	0	0	0	0	1	High-Z with clamps	Power-down
0	0	0	0	1	0	VH	Power-down
0	0	0	0	1	1	High-Z with clamps	Power-down
0	0	0	1	0	0	VL	Power-dowr
0	0	0	1	0	1	VT	Power-down
0	0	0	1	1	0	VH	Power-down
0	0	0	1	1	1	VT	Power-down
0	0	1	0	0	0	VL	Active off
0	0	1	0	0	1	High-Z with clamps	Active on
0	0	1	0	1	0	VH	Active off
0	0	1	0	1	1	High-Z with clamps	Active on
0	0	1	1	0	0	VL	Active on
0	0	1	1	0	1	High-Z with clamps	Active on
0	0	1	1	1	0	VH	Active on
0	0	1	1	1	1	High-Z with clamps	Active on

首先確定 Channel FPGA PMU 模式為關閉

PMU\_MODE = PMU\_MODE && (~(0x0001 << CH\_SEL))

W 0x3C PMU\_MODE // Disable PMU Mode

ATE305 0x0C DATA[0] = 0, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x0 // DATA[2:0] = 3'b000 for 0x0C

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0C} // Set 0x0C Register

ATE305 0x0D DATA[0] = 0, DATA[1] = 1, DATA[2] = 0

W = 0x38 = 0x2 = 1 / DATA[2:0] = 3'b010 for 0x0D

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0D} // Set 0x0D Register

# 針對 Normal Mode 跑 Pattern 時,沒有 load 也不會 terminate 至 VTT,使用 Table 如下:

Table 29. Driver and Load Truth Table<sup>1</sup>

Registers			Signals				
PE Disable DATA[0] ADDR[4:0] = 0x0C	Force VT DATA[1] ADDR[4:0] = 0x0C	Load Enable DATA[1] ADDR[4:0] = 0x0D	Driver High-Z/VT DATA[0] ADDR[4:0] = 0x0D	DATAx	RCVx	Driver State	Load State
1	X	X	X	Х	Х	High-Z without clamps	Power-down
0	1	X	X	X	X	VT	Power-down
0	0	0	0	0	0	VL	Power-down
0	0	0	0	0	1	High-Z with clamps	Power-down
0	0	0	0	1	0	VH	Power-down
0	0	0	0	1	1	High-Z with clamps	Power-down
0	0	0	1	0	0	VL	Power-down
0	0	0	1	0	1	VT	Power-down
0	0	0	1	1	0	VH	Power-down
0	0	0	1	1	1	VT	Power-down
0	0	1	0	0	0	VL	Active off
0	0	1	0	0	1	High-Z with clamps	Active on
0	0	1	0	1	0	VH	Active off
0	0	1	0	1	1	High-Z with clamps	Active on
0	0	1	1	0	0	VL	Active on
0	0	1	1	0	1	High-Z with clamps	Active on
0	0	1	1	1	0	VH	Active on
0	0	1	1	1	1	High-Z with clamps	Active on

首先確定 Channel FPGA PMU 模式為關閉

PMU\_MODE = PMU\_MODE && (~(0x0001 << CH\_SEL))

W 0x3C PMU\_MODE // Disable PMU Mode

ATE305 0x0C DATA[0] = 0, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x0 // DATA[2:0] = 3'b000 for 0x0C

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0C} // Set 0x0C Register

ATE305 0x0D DATA[0] = 0, DATA[1] = 0, DATA[2] = 0

W = 0x38 = 0x0 // DATA[2:0] = 3'b000 for 0x0D

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0D} // Set 0x0D Register

上面的 Pin Mode API 若將某一 Channel 的 Pin Mode 設定為"PMU",則可以使用下面 API:

- FV (channel, Value, I range, clamp H, clamp L, delay) // default delay = 0ms
- FI (channel, Value, I\_range, clamp\_H, clamp\_L, delay) // default delay = 0ms
- MI (channel, count) // default count(1)

上面的 Pin\_Mode API 除"OFF"模式之外,都可以使用 MV:

MV (channel, count) // default count(1)

### FV API 底層撰寫指導:

FV (channel, Value, I\_range, clamp\_H, clamp\_L, delay)

由於 FV 只能在 PMU 模式下使用,所以首先要設定為 PMU 模式:

Pin Mode(PMU)

將 ClampH/L 的值先設定於 ATE305

W 0x38 ClampH

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h06} // Set 0x06 Register

W 0x38 ClampL

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h07} // Set 0x07 Register

Force Voltage 的來源為 PMUDAC,以輸入參數"Value"代入並運算公式得 FV VALUE

W 0x38 FV\_VALUE

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0B} // Set 0x0B Register

ATE305 0x0E DATA[2:0] = I\_range, DATA[3] = 0, DATA[4] = 1, DATA[5] = 1, DATA[7] = 0, DATA[9:8] = 2'b11

W 0x38 DATA

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0E} // Set 0x0E Register

#### FI API 底層撰寫指導:

FI (channel, Value, I\_range, clamp\_H, clamp\_L, delay)

由於 FI 只能在 PMU 模式下使用,所以首先要設定為 PMU 模式:

Pin Mode(PMU)

將 ClampH/L 的值先設定於 ATE305

W 0x38 ClampH

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h06} // Set 0x06 Register

W 0x38 ClampL

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h07} // Set 0x07 Register

Force Current 的來源為 PMUDAC,以輸入參數"Value、I\_range"代入並運算公式得 FI\_VALUE

W 0x38 FI VALUE

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0B} // Set 0x0B Register

ATE305 0x0E DATA[2:0] = I range, DATA[3] = 1, DATA[4] = 0, DATA[5] = 1, DATA[7] = 0, DATA[9:8] = 2'b11

W 0x38 DATA

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0E} // Set 0x0E Register

MI API 底層撰寫指導:

MI (channel, count)

由於 MI 只能在 PMU 模式下使用,所以首先要設定為 PMU 模式:

Pin Mode(PMU)

在 MI 之前不知道是 FV 或 FI,故先回讀 ATE305 0x0E 當下資料

W 0x37 {ATE305\_SEL, 1'b0, (0x1 << ATE305\_CH\_SEL), 5'h0E} // Read 0x0E Register

R 0x38 READ DATA

將回讀回來的 0x0E 狀態改為 measure current mode

DATA = *READ\_DATA* | | 9'b0000010000

處理過後寫回 0x0E

W 0x38 DATA

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0E} // Set 0x0E Register

開啟量測通道

W 0x38 {1'b0, ATE305 CH SEL, 1'b1}

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0F} // Set 0x0F Register

固定 delay 一段時間

Delay();

發出 PMU ADC 量測命令

W 0x39 count

確認量測完成

R = 0x39 WORKING = 0

讀取結果

R 0x3A ADC\_MSB

R 0x3B ADC LSB

依照一開始讀回的 READ DATA[2:0]決定 range 選擇公式,並回傳結果

關閉量測通道,避免通道衝突

W 0x38 0x0

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0F} // Set 0x0F Register

### MV API 底層撰寫指導:

MV (channel, count)

MV 除了 OFF 模式之外都能使用,但在 MV 之前不知道是否有 FV 或 FI ,故先回讀 ATE305 0x0E 當下資料

W 0x37 {ATE305\_SEL, 1'b0, (0x1 << ATE305\_CH\_SEL), 5'h0E} // Read 0x0E Register

R 0x38 READ\_DATA

將回讀回來的 0x0E 狀態改為 measure voltage mode

DATA = READ DATA && 9'b1111101111

處理過後寫回 0x0E

W 0x38 DATA

W 0x37 {ATE305\_SEL, 1'b1, (0x1 << ATE305\_CH\_SEL), 5'h0E} // Set 0x0E Register

開啟量測通道

W 0x38 {1'b0, ATE305\_CH\_SEL, 1'b1}

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0F} // Set 0x0F Register

固定 delay 一段時間

Delay();

發出 PMU ADC 量測命令

W 0x39 count

確認量測完成

R = 0x39 WORKING = 0

讀取結果

R 0x3A ADC MSB

R 0x3B ADC LSB

MV 只有一個公式,運算後回傳結果

關閉量測通道,避免通道衝突

W 0x38 0x0

W 0x37 {ATE305 SEL, 1'b1, (0x1 << ATE305 CH SEL), 5'h0F} // Set 0x0F Register