## OpenMDAO Optimization Report for Problem RunOAS

# OpenMDAO Optimization Report for Problem RunOAS (All values are in unscaled, physical units)

Problem: RunOAS Script: RunOAS.py

Optimizer: ScipyOptimize\_SLSQP

Number of driver iterations: 18 Number of model evals: 18 Number of deriv evals: 9

Execution start time: 2025-06-04 12:58:40

Wall clock run time: 00 hours 00 minutes 00 seconds 461.9 milliseconds

Exit status: FAIL

#### **Objectives**

name	val	$\operatorname{ref}$	ref0	adder	scaler	units
flight_condition_0.wing_perf.CD	[11.83626929]	0.01			100.0	

#### Design Variables

name	alias	size	$\min$	max	mean	lower	upper	equals	$\operatorname{ref}$	ref0	units	visual	
												0.0	10.0
												***************************************	
alpha		1	10	(10)	10	0	10		1	0	$\deg$		10
•				( )							Ö	0.2	1.0
													***************************************
wing.taper		1	(0.2)	0.2	0.2	0.2	1		1	0		0.2	
0 1			( )									10 -	
in-m-tint on		2	1101	( 10 )	110	-10	10		1	0	مامس	0	1
wing.twist_cp		2	10	( 10 )	10	-10	10		1	U	$\deg$	10.0	30.0
													***************************************
wing.sweep		1	14.5	14.5	14.5	10	30		1	0	$\deg$	14.5	

### Constraints

name	alias	size	min	max	mean	lower	upper	equals	ref	ref0	units	visual
flight_condition_0.wing_perf.CL		1	0.796	0.796	0.796			2	1	0		Both lower and upper bounds are None.

## Optimizer settings

Setting	Val	Description
debug_print		List of what type of Driver variables to print at each iteration.
invalid_desvar_behavior	warn	Behavior of driver if the initial value of a design variable exceeds its bounds. The default value may be using the 'OPENMDAO_INVALID_DESVA
optimizer	SLSQP	Name of optimizer to use
tol	1e-06	Tolerance for termination. For detailed control, use solver-specific options.
maxiter	200	Maximum number of iterations.
disp	True	Set to False to prevent printing of Scipy convergence messages
singular_jac_behavior	warn	Defines behavior of a zero row/col check after first call tocompute_totals:error - raise an error.warn - raise a warning.ignore - don't perform check.
singular_jac_tol	1e-16	Tolerance for zero row/column check.