OpenMDAO Optimization Report for Problem RunOAS

OpenMDAO Optimization Report for Problem RunOAS (All values are in unscaled, physical units)

Problem: RunOAS Script: RunOAS.py

Optimizer: ScipyOptimize_SLSQP

Number of driver iterations: 11 Number of model evals: 11 Number of deriv evals: 9

Execution start time: 2025-05-24 15:00:49

Wall clock run time: 00 hours 00 minutes 00 seconds 218.2 milliseconds

Exit status: SUCCESS

Objectives

name	val	ref	ref0	adder	scaler	units
$\overline{ {\rm flight_condition_0.wing_perf.CD} }$	[1.09694736]	0.01			100.0	

Design Variables

name	alias	size	\min	max	mean	lower	upper	equals	ref	ref0	units	visual	
												0.0	10.0
												***************************************	***************************************
alpha		1	3.95	3.95	3.95	0	10		1	0	\deg	3.95	
											0	0.2	1.0
												***************************************	***************************************
wing.taper		1	(0.2)	0.2	0.2	0.2	1		1	0		0.2	
0 1			,									10 -	/VVVVVVVVVVVV
												-10 -	
wing.twist_cp		2	1.46	2.47	1.96	-10	10		1	0	\deg	0	1
wing.twist_cp		_	[1.10]	2.11	1.50	10	10		-	O	acs	0.0	30.0
												2000000000000	
wing.sweep		1	28.5	28.5	28.5	0	30		1	0	\deg		28.5

Constraints

name	alias	size	min	max	mean	lower	upper	equals	ref	ref0	units	visual
flight_condition_0.wing_perf.CL		1	0.5	0.5	0.5			0.5	1	0		Both lower and upper bounds are None.

Optimizer settings

Setting	Val	Description
debug_print		List of what type of Driver variables to print at each iteration.
invalid_desvar_behavior	warn	Behavior of driver if the initial value of a design variable exceeds its bounds. The default value may be using the 'OPENMDAO_INVALID_DESVA
optimizer	SLSQP	Name of optimizer to use
tol	1e-06	Tolerance for termination. For detailed control, use solver-specific options.
maxiter	200	Maximum number of iterations.
disp	True	Set to False to prevent printing of Scipy convergence messages
singular_jac_behavior	warn	Defines behavior of a zero row/col check after first call tocompute_totals:error - raise an error.warn - raise a warning.ignore - don't perform check.
singular_jac_tol	1e-16	Tolerance for zero row/column check.