
## Практическая работа 16

Создал, айпи настроил:



```
Switch>en
 Switch#conf t
 Enter configuration commands, one per line. End with CNTL/Z.
 Switch(config) #hostname lsw
 lsw(config) #int vlan 1
 lsw(config-if) #no sh
 lsw(config-if)#
 %LINK-5-CHANGED: Interface Vlan1, changed state to up
 %LINEPROTO-5-UPDOWN: Line protocol on Interface Vlanl, changed state to up
 lsw(config-if)#ip address 192.168.0.2 255.255.255.0
 lsw(config-if)#exit
Switch>en
Switch#conf t
Enter configuration commands, one per line. End with CNTL/Z.
Switch(config) #hostname sw2
sw2(config)#int vlan 1
sw2(config-if)#no
% Incomplete command.
sw2(config-if)#no sh
sw2(config-if)#
%LINK-5-CHANGED: Interface Vlan1, changed state to up
%LINEPROTO-5-UPDOWN: Line protocol on Interface Vlanl, changed state to up
sw2(config-if)#ip address 192.168.0.3 255.255.255.0
sw2(config-if)#exit
Настроил telnet:
lsw(config)#line vty 0 4
lsw(config-line) #pass 111
lsw(config-line) #en secret 123
% Ambiguous command: "en secret 123"
lsw(config) #enable secret 123
```

```
sw2(config) #line vty 0 4
sw2(config-line) #pass 111
sw2(config-line) #enable secret 123
```

## Работает:

```
Cisco Packet Tracer PC Command Line 1.0
C:\>telnet 192.168.0.3
Trying 192.168.0.3 ...Open

User Access Verification

Password:
Password:
sw2>en
Password:
sw2‡
```

И через первый свич подключился ко второму:

```
C:\>telnet 192.168.0.2
Trying 192.168.0.2 ...Open

User Access Verification

Password:
1sw>telnet 192.168.0.3
Trying 192.168.0.3 ...Open

User Access Verification

Password:
sw2>
```